

MASTER PARTS CATALOG

OF

CHASSIS AND BODY PARTS

FOR

PONTIAC

WAREHOUSES LOCATED AT THE FOLLOWING POINTS

*Atlanta, Georgia
 *Baltimore, Md.
 Birmingham, Ala.
 *Bloomfield, N. J.
 Boston, Mass.
 Buffalo, N. Y.
 Charlotte, N. C.
 *Chicago, Ill.
 Cleveland, Ohio
 Denver, Colo.
 Des Moines, Ia.
 *Detroit, Mich.
 El Paso, Texas
 Fargo, N. D.

*Fort Worth, Texas
 Great Falls, Mont.
 Houston, Texas
 Indianapolis, Ind.
 Jacksonville, Fla.
 *Kansas City, Mo.
 Long Island City, N. Y.
 *Los Angeles, Cal.
 Louisville, Ky.
 Memphis, Tenn.
 Milwaukee, Wis.
 *Minneapolis, Minn.
 New Orleans, La.
 Norwood, Ohio

*Oakland, Cal.
 Oklahoma City, Okla.
 Omaha, Nebr.
 Philadelphia, Pa.
 Pittsburgh, Pa.
 *Portland, Oregon
 Richmond, Virginia
 Salt Lake City, Utah
 San Antonio, Texas
 Scranton, Pa.
 St. Louis, Mo.
 Seattle, Wash.
 Shreveport, La.
 Wichita, Kansas

*Master Warehouse

**ALL PARTS SHOULD BE ORDERED FROM THE NEAREST
 GENERAL MOTORS PARTS DIVISION WAREHOUSE**

Prices subject to change without notice

EFFECTIVE DECEMBER 18, 1953

This Index Feature for Your Convenience

A heavy black spot is placed on the first page of each section of this parts book. By bending the book backward these spots are exposed opposite the individual section headings. If the thumb of the right hand is placed on the black spot opposite the section desired, the book may be opened to the corresponding section.

PONTIAC MOTOR DIVISION
 General Motors Corporation
 PONTIAC, MICHIGAN

FORM No. P 54-08

PRINTED IN U. S. A.

**ALPHABETICAL
 INDEX**

**ACCESSORY
 SECTION**

**0.000 to 0.999
 ENGINE-CLUTCH**

**1.000 to 1.999
 COOLING AND
 OILING**

**2.000 to 2.999
 ELECTRICAL**

**3.000 to 3.999
 FUEL
 CARBURETION
 MANIFOLDS**

**4.000 to 4.999
 TRANSMISSION
 AND BRAKES**

**5.000 to 5.999
 REAR AXLE AND
 BRAKES**

**6.000 to 6.999
 FRONT AXLE AND
 STEERING GEAR**

**7.000 to 7.999
 FRAME
 SPRINGS-BUMPERS**

**8.000 to 8.890
 HOOD-FENDERS-
 APRONS-HEATER**

**8.899 to 8.991
 STANDARD
 PARTS**

**9.000 to 9.999
 RADIO - ANTENNA
 CLOCK-DEFROSTER**

**BODY
 SECTION**

**PARTS
 HISTORY INDEX**

INTRODUCTION

The **MASTER PARTS CATALOG** has been carefully compiled to include all **PONTIAC REPLACEMENT PARTS** available to date and to simplify the ordering of Parts, it has been arranged as follows:

Introduction	Chassis Illustration Index
GM Telegraphic Code	Accessory Section
Chassis Abbreviations	Chassis Parts Section
Engine Specifications	Body Alphabetical Index
Model Information	Body Illustration Index
Assembly Plant Serial Numbers	Body Parts Section
Chassis Alphabetical Index	Parts History Index

THE GROUP SYSTEM

All **PONTIAC REPLACEMENTS PARTS** are listed in this Catalog under the **PONTIAC GROUP SYSTEM** which is the same system used by Buick, Chevrolet, and Oldsmobile. This System lists all parts of an assembly together so that they can be easily located. Main assemblies of **PONTIAC AUTOMOBILES** are identified by the numeral preceding the decimal. For example:

Engine	0.	Electrical	2.
Cooling and Oiling	1.	Fuel System	3.

Each part is assigned a group number. The first numeral identifies the main assembly; the numerals following the decimal give the exact location of the sub-group under which all parts of the same name or function are located. For example:

0.603 Connecting Rod

The "0." indicates it is an engine part and ".603" is the location within the "0." group where all connecting rods available for service may be found.

LOCATING PARTS

If the name of the desired part is known, refer to the **ALPHABETICAL INDEX** for the Group Number. If the Part Number is known, refer to the **DEALER PARTS PRICE SCHEDULE** compiled in Part Number numerical sequence to find the Group Number.

If the Part Name or Part Number is not known, but for example, it is part of a Synchro-Mesh Transmission (Reverse Idler Gear), find the Transmission Illustration and locate the part under Group 4.430.

Illustrations are now located on the first pages of each Major Group to simplify the locating of the desired part or parts.

GENERAL INFORMATION

The **GENERAL MOTORS TELEGRAPHIC CODE** should be familiar to all **PARTS PERSONNEL**, and if properly used, will be both convenient and economical in transmitting telegraphic messages.

A complete **CHASSIS ALPHABETICAL INDEX** is shown preceding the Chassis Section, and the **BODY ALPHABETICAL INDEX** is shown at the front of the Body Section.

The **ACCESSORY SECTION** has been revised for 1954 and includes only **COMPLETE ACCESSORIES** for the **CURRENT MODEL**. All **PARTS** of **ACCESSORIES** now appear in their regular groups throughout the Catalog.

All Chassis Parts listed that are peculiar to the Six Cylinder Engine only are designated in the Model Column as P/6, and parts peculiar to the Eight Cylinder Engine only are designated in the Model Column as P/8. Parts peculiar to a particular model series are identified in the Model Column as 25 All, 26 All, 28 All, etc. All body styles (with the exception of Station Wagon (Sta. Wag.) through the Year 1948) are referred to in the Catalog by Body Style Number which appears on the **BODY IDENTIFICATION PLATE** located under the hood on the Cowl.

Examples and the interpretations of style numbers used in this Catalog are as follows:

2507	Standard Models
2507 "D"	Deluxe Models
2507 All	Standard and Deluxe Models
2562	Standard 3 Seat Station Wagon
2562 "F"	Standard 2 Seat Station Wagon with folding seat
2562 "DF"	Deluxe 2 Seat Station Wagon with folding seat
2562 All	Standard and Deluxe Station Wagon

For your convenience, various parts having multiple usage are listed in all the Groups where they are used. However, since a part can have but one Group Number for ordering and proper Bin Location, it is placed in a "Principal or Prime Group". When a part is listed in a group other than the prime group, reference is made to the "Prime Group" by placing the Group Number in parentheses just to the right of the Part Number. For example, under Group 0.659 Part Number 495152 is listed as Key, balancer to crankshaft and to the right of Number 495152 is shown (0.729) which is the "Prime" Group of the part.

STANDARD PARTS

Beginning at Group Number 8.899 is a **CLASSIFIED LIST of STANDARD PARTS**, which simplifies the identification of these parts by their description.

PARTS HISTORY INDEX

A complete **PARTS HISTORY INDEX** follows the **BODY SECTION**. All parts removed, replaced, or transferred after December 31, 1950, are included.

How To Keep Your Master Parts Catalog Up To Date

If you have subscribed to the Replacement Page Plan for 1954, Pontiac Motor Division will keep your Master Parts Catalog and Dealer Parts Price Schedule up to date. Revised pages will be issued Monthly for changes, including New Parts, Replacements, Transfers, Discontinuations and Price Changes.

If you did not choose to subscribe to the Replacement Page Plan, the following procedure is suggested when you receive the Parts Release and Change Notice each month:

- FIRST:** Enter all Transfers and Replacements as quite a few of these will be New Parts and will, therefore, eliminate duplication when entering New Parts. These changes should be made by crossing out the old Part Number and inserting the new one in the space provided for changes and transferring all model information from the old part to the replacing number.
- SECOND:** Enter the remaining New Parts released that have not been previously entered from Transfers or Replacements. Where more than one item is being entered in a group, an extra page should be inserted for listing this additional information.
- THIRD:** Remove all Discontinuations, make Corrections and Price Changes to the Dealer Parts Price Schedule as outlined in the introductory pages of that schedule.

G. M. TELEGRAPHIC CODE

Revised telegraph regulations now make it possible to specify actual part number digits at code word cost when ordering parts by telegram. Therefore it will not be necessary to use the G. M. Numerical Code for sending part numbers in telegrams.

The Numerical Code should be used in decoding phrases which are always prefixed XL.

G	M	P	R	O	D	U	C	T	S
1	2	3	4	5	6	7	8	9	0

COMMONLY USED PHRASES—CODING TABULATION

101 Refer order.....	XLGSG	302 Shipped by freight.....	XLPSM
102 Refer to our wire (of).....	XLGSM	303 Shipped by truck.....	XLPSD
103 Refer to our letter (of).....	XLGSP	306 Shipped by air mail.....	XLPSU
105 Wire answer to our wire (of).....	XLGSO	307 Shipped by air express.....	XLPSU
109 Refer to your wire (of).....	XLGST	308 Shipped by parcel post.....	XLPSU
110 Refer to your letter (of).....	XLGGS	325 Shipped by parcel post special delivery.....	XLPMO
111 Refer our phone conversation.....	XLGGG	337 Cannot locate your order number..... date.....	XLPPU
115 Wire answer.....	XLGGO	338 Do not understand your telegram.....	XLPPC
116 Wire advise.....	XLGGD	346 Canceled as per your request.....	XLPRD
132 Wire if unable to ship today.....	XLGPM	351 Material shipped; cannot cancel as requested.....	XLPOG
134 Ship today.....	XLGPR	368 Advise Body Style, paint combination numbers for parts your order number.....	XLPOG
135 Urgent. Car tied up.....	XLGPO	371 Wire Part Number.....	XLPOG
141 Check and advise by wire.....	XLGRG	372 Advise car and engine number for parts your order number.....	XLPOG
151 Ship by express.....	XLGOG	385 No record part number.....	XLPCO
152 Ship by freight.....	XLGOM	399 Part number and description do not agree.....	XLPTT
154 Ship by truck.....	XLGOR	409 Part not released for service; use.....	XLST
157 Ship by air mail.....	XLGOV	462 Refer to parts release and change notice number.....	XLST
158 Ship by air express.....	XLGOC	463 Refer to dealer service department bulletin.....	XLST
159 Ship by parcel post.....	XLGOT	513 Change our order..... to read as follows.....	XLST
160 Ship by parcel post spec. del.....	XLGDS	514 Change shipping instructions on our order to read.....	XLST
170 Cancel our order of.....	XLGUS	517 Incorrect parts received on our order.....	XLST
174 Cancel following items our order.....	XLGUR	519 Advise which is correct.....	XLST
181 Add to our order.....	XLGCG	542 Shipped by parcel post spec. del.....	XLST
190 Wire shipping date our order.....	XLGTS	554 Hold up until advised.....	XLST
191 Wire full forwarding information.....	XLGTG	557 Material urgently required.....	XLST
253 How and when did you ship?.....	XLMOG	609 Urgent—car inoperative.....	XLST
290 Shipped today.....	XLMTS		
296 Expect to ship your order.....	XLMTD		
301 Shipped by express.....	XLPSG		

CODE PHRASES CLASSIFIED

REFERENCE

See Code Nos. 101, 102, 103, 109, 110, 111, 462 and 463

SPECIFICATIONS AND INSTRUCTIONS

See Code Nos. 368, 372, 385, 399 and 519

CANCELLATION

See Code Nos. 170, 174, 346 and 351

ADDITIONS, CHANGES, SUBSTITUTIONS AND ERRORS

See Code Nos. 181, 513, 514 and 517

SHIP OR SEND

See Code Nos. 132, 134, 151, 152, 154, 157, 158, 159 and 160

SHIPPED OR SENT

See Code Nos. 301, 302, 303, 306, 307, 308, 325, 351 and 542

SHIPPING

See Code Nos. 290 and 296

INQUIRIES ON SHIPMENTS

See Code Nos. 190, 191, 253, 337, 338 and 371

REPLY

See Code Nos. 105, 115, 116, 141, 190, 191 and 371

URGENCY

See Code Nos. 135, 554, 557 and 609

Avoid Delay

To Assure Prompt Shipment of Parts Always Give Car Serial and Engine Numbers for Chassis Parts.

Specify Style—Body—Trim and Paint Numbers for Body Parts.

ABBREVIATIONS

Abs. Absorber
 Accel. Accelerator
 Adj. { Adjustable
 Adjuster
 Adjusting
 Amp. Ampere
 AR As Required
 Assy. Assembly
 Aux. Auxiliary

Batt. Battery
 Bind. Binding
 Bpr. Bumper
 Brg. Bearing
 Brk. Brake
 Brkt. Bracket
 Bshg. Bushing
 Bus. Business

Cad. Cadmium
 Carb. Carburetor
 Carr. Carriage
 C to C Center to Center
 Ch. Chassis
 Chan. Channel
 Chr. Chrome
 Cl. Clutch
 Cm/S. Camshaft
 Col. Column
 Comb. Combination
 Comp. Compression
 Compt. Compartment
 Conn. Connector—ing
 Cont. Control
 Conv. Convertible
 CP. Candlepower
 Cpe. Coupe
 Cplg. Coupling
 Cr. Cross
 Crk/S. Crankshaft
 C/Sunk. Countersunk
 Ctr. Center
 Ctr/S. Countershaft
 Cush. Cushion
 Cyl. Cylinder

"D" Deluxe
 Dbl. Double
 D.C. Double Contact
 Def. Defroster
 Defl. Deflector
 "DF" Deluxe Folding

Dia. Diameter
 Diaph. Diaphragm
 Diff. Differential
 Dir. Direction—al
 Dist. Distributor
 Div. Division
 Dlx. Deluxe
 Dr. Door

Emerg. Emergency
 Eng. Engine
 Equip. Equipment
 Esc. Escutcheon
 Exc. Except
 Exch. Exchange
 Exh. Exhaust
 Expan. Expansion
 Ext. { External
 Extension

"F" Folding
 Fdr. Fender
 Fill. Filler
 Fldg. Folding
 Flex. Flexible
 Flt. Flat
 Frt. Front
 Ft. Foot

Gal. Gallon
 Garn. Garnish
 Gen. Generator
 Gov. Governor
 Gr. Group
 G/Shift. Gearshift
 Gskt. Gasket

Hd. Head
 Hdl. Handle
 Hdng. Headlining
 Hdlp. Headlamp
 Hex. Hexagon
 Hsg. Housing
 H.T. Hydramatic Transmission
 Htr. Heater
 Hyd. Hydraulic

I.D. Inside Diameter
 Ident. Identification
 Ign. Ignition
 Imit. Imitation
 Incl. Includes
 Ind. Indicator
 Ins. Insulator
 Inst. Instrument
 Int. { Intake
 Internal
 Inter. Intermediate

Lea. Leather
 L.H. Left Hand
 L.H.D. Left Hand Drive
 Lwr. Lower

Mach. Machine
 Matl. Material
 Max. Maximum
 Mbr. Member
 Mech. Mechanical
 Med. Medium
 Mfld. Manifold
 Min. Minimum
 Mldg. Molding
 M/M. Millimeter
 Mstr. Master
 Mtg. Mounting
 Mtr. Motor
 Mtrg. Metering

N.D. New Departure
 Nic. Nickel
 No. Number
 N.S. Not Serviced

O.D. Outside Diameter
 Orn. Ornament
 O.S. Oversize
 Ov. Oval

Pass. Passenger
 P.B. Power Brake
 Perc. Percolator
 P.G. Power Glide
 Pit. Pitman
 Pkg. Package
 Pkzd. Parkerized
 Pl. Plain
 Prop. Propeller
 P.S. Power Steering
 Pt. Point

Qt. Quart
 Qtr. Quarter

Rad. Radiator
 Rd. Round
 Reg. Regulator
 Reinf. Reinforcement
 Ret. Retainer
 R.H. Right Hand
 R.H.D. Right Hand Drive
 Rkr. Rocker
 Rr. Rear

S.C. Single Contact
 "SD" Super Deluxe
 Sdl. Sedan Delivery
 Sed. Sedan
 Ser. Serial
 Shk. Shock
 Sig. Signal
 Sl't'd. Slotted
 Spec. Special
 Speedo. Speedometer
 Sprg. Spring
 Sq. Square
 S.S. Standard Steering
 S.T. Syncromesh Transmission
 Sta. Station
 Stab. Stabilizer
 Stat. Stationary
 Std. Standard
 Strg. Steering
 Supt. Support
 Swgn. Station Wagon
 Synchro. Synchronizer—ing

Temp. Temperature
 Term. Terminal
 Thd. Thread
 Therm. Thermogauge
 Trans. Transmission

U/J. Universal Joint
 Up. Upper
 U.S. Under Size
 U/S. Under Seat

Vac. Vacuum
 Vent. Ventilator

W/ With
 Wag. Wagon
 W/cord. Weathercord
 W/House. Wheelhouse
 Wind. Window
 W/O. Without
 W/P. Water Pump
 W/S. Windshield
 Wshr. Washer
 W/Strip. Weatherstrip

ENGINE SPECIFICATIONS and CAR WHEELBASE

Year	Model	No. Cyl.	Bore	Stroke	Horsepower S.A.E.	Cu. In. P.D.	Wheel Base
1936	Master Six	6	3 $\frac{3}{8}$ "	3 $\frac{1}{8}$ "	27.4	208.0	112"
1936	DeLuxe Six	6	3 $\frac{3}{8}$ "	3 $\frac{1}{8}$ "	27.4	208.0	112"
1936	Eight	8	3 $\frac{1}{4}$ "	3 $\frac{1}{2}$ "	33.8	232.3	116 $\frac{3}{8}$ "
1937	Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	117"
1937	Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1938	Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	117"
1938	Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1939	25 DeLuxe 115 Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	115"
1939	26 DeLuxe 120 Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	120"
1939	28 DeLuxe Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	120"
1940	25 Special Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	117"
1940	26 DeLuxe Six	6	3 $\frac{1}{16}$ "	4"	28.3	222.7	120"
1940	28 DeLuxe Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	120"
1940	29 Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1941	25 DeLuxe Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	119"
1941	26 Streamliner Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1941	24 Custom Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1941	27 DeLuxe Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	119"
1941	28 Streamliner Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1941	29 Custom Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1942	25 Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	119"
1942	26 Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1942	27 Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	119"
1942	28 Streamliner Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1946	25 Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	119"
1946	26 Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1946	27 Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	119"
1946	28 Streamliner Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1947	25 Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	119"
1947	26 Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1947	27 Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	119"
1947	28 Streamliner Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1948	25 Torpedo Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	119"
1948	26 Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1948	27 Torpedo Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	119"
1948	28 Streamliner Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	122"
1949	25 Chieftain and Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	120"
1949	27 Chieftain and Streamliner Eight	8	3 $\frac{1}{4}$ "	3 $\frac{3}{4}$ "	33.8	248.9	120"
1950	25 Chieftain and Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	120"
1950	27 Chieftain and Streamliner Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	120"
1951	25 Chieftain and Streamliner Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	120"
1951	27 Chieftain and Streamliner Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	120"
1952	25 Chieftain Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	120"
1952	27 Chieftain Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	120"
1953	25 Chieftain Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1953	27 Chieftain Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	122"
1954	25 Chieftain Six	6	3 $\frac{9}{16}$ "	4"	30.4	239.2	122"
1954	27 Chieftain Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	122"
1954	28 Star Chief Eight	8	3 $\frac{3}{8}$ "	3 $\frac{3}{4}$ "	36.4	268.4	124"

CAR MODEL INFORMATION

Year	Model	Body Style	Car Weight	Body Style No.	Car Serial No.	Engine No.
1936	Master Six	Business Coupe	3085	2607A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Sport Coupe	3120	2657A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Convertible Coupe	3125	2667A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Two Door	3195	2601A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Two Door	3195	2601AB	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Two Door Touring	3195	2611A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Two Door	3195	2611AB	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Four Door	3235	2609A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
		Four Door Touring	3245	2619A	6BB-1001 to 6BB-91362	6-84001 to 6-219182
1936	De Luxe Six	Business Coupe	3130	2607	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Sport Coupe	3165	2657	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Convertible Coupe	3200	2667	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Two Door	3265	2601	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Two Door Touring	3270	2611	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Four Door	3300	2609	6BA-1001 to 6BA-41352	6-84001 to 6-219182
		Four Door Touring	3300	2619	6BA-1001 to 6BA-41352	6-84001 to 6-219182
1936	Eight	Business Coupe	3250	2807	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Sport Coupe	3285	2857	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Convertible Coupe	3335	2867	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Two Door	3390	2801	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Two Door Touring	3390	2811	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Four Door	3415	2809	8BA-1001 to 8BA-38371	8-44001 to 8-82040
		Four Door Touring	3420	2819	8BA-1001 to 8BA-38371	8-44001 to 8-82040
1937	Six	Business Coupe	3165	2627B	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Sport Coupe	3165	2627	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Convertible Coupe	3250	2667	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Two Door	3240	2601	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Two Door Touring	3240	2611	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Four Door	3265	2609	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Four Door Touring	3275	2619	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Convertible Sedan	3375	2649	6CA-1001 to 6CA-154827	6-220001 to 6-399286
		Station Wagon	3340		6CA-1001 to 6CA-154827	6-220001 to 6-399286
1937	Eight	Business Coupe	3305	2827B	8CA-1001 to 8CA-49442	8-83001 to 139968
		Sport Coupe	3305	2827	8CA-1001 to 8CA-49442	8-83001 to 139968
		Convertible Coupe	3360	2867	8CA-1001 to 8CA-49492	8-83001 to 139968
		Two Door	3385	2801	8CA-1001 to 8CA-49442	8-83001 to 139968
		Two Door Touring	3380	2811	8CA-1001 to 8CA-49442	8-83001 to 139968
		Four Door	3410	2809	8CA-1001 to 8CA-49442	8-83001 to 139968
		Four Door Touring	3400	2819	8CA-1001 to 8CA-49442	8-83001 to 139968
		Convertible Sedan	3505	2849	8CA-1001 to 8CA-49442	8-83001 to 139968
1938	Six	Business Coupe	3190	2627B	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Sport Coupe	3200	2627	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Convertible Coupe	3285	2667	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Two Door	3265	2601	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Two Door Touring	3265	2611	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Four Door	3295	2609	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Four Door Touring	3280	2619	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Convertible Sedan		2649	6DA-1001 to 6DA-60416	6-399501 to 6-486022
		Station Wagon	3420		6DA-1001 to 6DA-60416	6-399501 to 6-486022
1938	Eight	Business Coupe	3320	2827B	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Sport Coupe	3325	2827	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Convertible Coupe	3390	2867	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Two Door	3395	2801	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Two Door Touring	3385	2811	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Four Door	3415	2809	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Four Door Touring	3410	2819	8DA-1001 to 8DA-15729	8-14001 to 8-159441
		Convertible Sedan	3530	2849	8DA-1001 to 8DA-15729	8-14001 to 8-159441
1939	Special	Business Coupe	2875	2527B	6EA-1001 to 6EA-43679	6-486201 to 6-595763
		Sport Coupe	2920	2527	6EA-1001 to 6EA-43679	6-486201 to 6-595763
		Two Door Touring	2965	2511	6EA-1001 to 6EA-43679	6-486201 to 6-595763
		Four Door Touring	3000	2519	6EA-1001 to 6EA-43679	6-486201 to 6-595763
		Station Wagon	3175	Sta. Wag.	6EA-1001 to 6EA-43679	6-486201 to 6-595763

NOTE: 1938 6-cylinder cars with serial numbers from C6DA-1001 to C6DA-1615 were produced at Pontiac and are not California assembled JOBS.

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	Car Weight	Body Style No.	Car Serial No.	Engine No.
1939	26 De Luxe Six	Business Coupe	3020	2627B	6EB-1001 to 6EB-41263	6-486201 to 6-595763
		Sport Coupe	3055	2627	6EB-1001 to 6EB-41263	6-486201 to 6-595763
		Convertible Coupe	3155	2667	6EB-1001 to 6EB-41263	6-486201 to 6-595763
		Two Door Touring	3115	2611	6EB-1001 to 6EB-41263	6-486201 to 6-595763
		Four Door Touring	3165	2619	6EB-1001 to 6EB-41263	6-486201 to 6-595763
1939	28 De Luxe Eight	Business Coupe	3115	2827B	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Sport Coupe	3165	2827	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Convertible Coupe	3250	2867	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Two Door Touring	3225	2811	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Two Door Sun Roof	3260	2811A	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Four Door Touring	3265	2819	8EA-1001 to 8EA-27627	8-159601 to 8-194380
		Four Door Sun Roof	3305	2819A	8EA-1001 to 8EA-27627	8-159601 to 8-194380
1940	25 Special Six	Business Coupe	3060	2527B	6HA-1001 to 6HA-84545	6-595801 to 6-761162
		Sport Coupe	3045	2527	6HA-1001 to 6HA-84545	6-595801 to 6-761162
		Two Door Touring	3095	2511	6HA-1001 to 6HA-84545	6-595801 to 6-761162
		Four Door Touring	3125	2519	6HA-1001 to 6HA-84545	6-595801 to 6-761162
		Station Wagon	3295	Sta. Wag.	6HA-1001 to 6HA-84545	6-595801 to 6-761162
1940	26 De Luxe Six	Business Coupe	3115	2627B	6HB-1001 to 6HB-44296	6-595801 to 6-761162
		Sport Coupe	3105	2627	6HB-1001 to 6HB-44296	6-595801 to 6-761162
		Convertible Coupe	3190	2667	6HB-1001 to 6HB-44296	6-595801 to 6-761162
		Two Door Touring	3170	2611	6HB-1001 to 6HB-44296	6-595801 to 6-761162
		Four Door Touring	3210	2619	6HB-1001 to 6HB-44296	6-595801 to 6-761162
1940	28 De Luxe Eight	Business Coupe	3180	2827B	8HA-1001 to 8HA-16817	8-194401 to 8-246073
		Sport Coupe	3195	2827	8HA-1001 to 8HA-16817	8-194401 to 8-246073
		Convertible Coupe	3280	2867	8HA-1001 to 8HA-16817	8-194401 to 8-246073
		Two Door Touring	3250	2811	8HA-1001 to 8HA-16817	8-194401 to 8-246073
		Four Door Touring	3300	2819	8HA-1001 to 8HA-16817	8-194401 to 8-246073
1940	29 Torpedo Eight	Sport Coupe	3390	2927C	8HB-1001 to 8HB-24376	8-194401 to 8-246073
		Four Door Touring	3475	2919	8HB-1001 to 8HB-24376	8-194401 to 8-246073
1941	25 De Luxe Torpedo Six	Business Coupe	3145	2527B	6JA-1001 to 80460	6-761501 to 6-971788
		Sport Coupe	3180	2527	6JA-1001 to 80460	6-761501 to 6-971788
		Convertible Coupe	3335	2567	6JA-1001 to 80460	6-761501 to 6-971788
		Two Door	3190	2511	6JA-1001 to 80460	6-761501 to 6-971788
		Four Door 4 Window	3230	2569	6JA-1001 to 80460	6-761501 to 6-971788
		Four Door 6 Window	3235	2519	6JA-1001 to 80460	6-761501 to 6-971788
1941	26 Streamliner Six	Coupe	3305	2627	6JB-1001 to 62545	6-761501 to 6-971788
		Four Door	3365	2609	6JB-1001 to 62545	6-761501 to 6-971788
1941	26D Super Streamliner Six	Coupe	3320	2627D	6JB-1001 to 62545	6-761501 to 6-971788
		Four Door	3400	2609D	6JB-1001 to 62545	6-761501 to 6-971788
1941	24 Custom Six	Coupe	3260	2427	6JC-1001 to 6JC-6345	6-761501 to 6-971788
		Four Door 4 Window			6JC-1001 to 6JC-6345	6-761501 to 6-971788
		Four Door 6 Window	3355	2419	6JC-1001 to 6JC-6345	6-761501 to 6-971788
1941	27 De Luxe Torpedo Eight	Business Coupe	3220	2727B	8JA-1001 to 27219	8-246501 to 8-368240
		Sport Coupe	3250	2727	8JA-1001 to 27219	8-246501 to 8-368240
		Convertible Coupe	3390	2767	8JA-1001 to 27219	8-246501 to 8-368240
		Two Door	3250	2711	8JA-1001 to 27219	8-246501 to 8-368240
		Four Door 4 Window	3285	2769	8JA-1001 to 27219	8-246501 to 8-368240
		Four Door 6 Window	3295	2719	8JA-1001 to 27219	8-246501 to 8-368240
1941	28 Streamliner Eight	Coupe	3370	2827	8JB-1001 to 52428	8-246501 to 8-368240
		Four Door	3425	2809	8JB-1001 to 52428	8-246501 to 8-368240
1941	28D Super Streamliner Eight	Coupe	3385	2827D	8JB-1001 to 52428	8-246501 to 8-368240
		Four Door	3460	2809D	8JB-1001 to 52428	8-246501 to 8-368240
1941	29 Custom Eight	Coupe	3325	2927	8JC-1001 to 12576	8-246501 to 8-368240
		Four Door 4 Window	3430		8JC-1001 to 12576	8-246501 to 8-368240
		Four Door 6 Window		2919	8JC-1001 to 12576	8-246501 to 8-368240

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	Car Weight	Body Style No.	Car Serial No.
1942	25 Torpedo Six	Business Coupe	3185	2527B	P6KA-1001 to 25802
		Sport Coupe	3235	2527	P6KA-1001 to 25802
		Sedan Coupe	3230	2507	P6KA-1001 to 25802
		Convertible Coupe	3510	2567	P6KA-1001 to 25802
		Two Door	3240	2511	P6KA-1001 to 25802
		Four Door 4 Window	3270	2569	P6KA-1001 to 25802
		Four Door 6 Window	3280	2519	P6KA-1001 to 25802
1942	26 Streamliner Six	Coupe	3330	2607	P6KB-1001 to 11115
		Four Door 6 Window	3390	2609	P6KB-1001 to 11115
		Station Wagon	3785	Sta. Wag.	P6KB-1001 to 11115
1942	26D Streamliner (Chieftain)	Coupe	3375	2607D	P6KB-1001 to 11115
		Four Door 6 Window	3435	2609D	P6KB-1001 to 11115
		Station Wagon	3760	Sta. Wag.	P6KB-1001 to 11115
1942	27 Torpedo Eight	Business Coupe	3245	2727B	P8KA-1001 to 13146
		Sport Coupe	3295	2727	P8KA-1001 to 13146
		Sedan Coupe	3295	2707	P8KA-1001 to 13146
		Convertible Coupe	3580	2767	P8KA-1001 to 13146
		Two Door	3300	2711	P8KA-1001 to 13146
		Four Door 4 Window	3330	2769	P8KA-1001 to 13146
		Four Door 6 Window	3335	2719	P8KA-1001 to 13146
1942	28 Streamliner Eight	Coupe	3405	2807	P8KB-1001 to 22928
		Four Door 6 Window	3460	2809	P8KB-1001 to 22928
		Station Wagon	3860	Sta. Wag.	P8KB-1001 to 22928
1942	28D Streamliner (Chieftain)	Coupe	3435	2807D	P8KB-1001 to 22928
		Four Door 6 Window	3490	2809D	P8KB-1001 to 22928
		Station Wagon	3840	Sta. Wag.	P8KB-1001 to 22928
1946	25 Torpedo Six	Business Coupe	3261	2527B	P6LA-1001 to 17381
		Sport Coupe	3311	2527	P6LA-1001 to 17381
		Sedan Coupe	3326	2507	P6LA-1001 to 17381
		Convertible Coupe	3591	2567	P6LA-1001 to 17381
		Two Door	3326	2511	P6LA-1001 to 17381
		Four Door	3361	2519	P6LA-1001 to 17381
1946	26 Streamliner Six	Sedan Coupe	3435	2607	P6LB-1001 to 35238
		Four Door	3490	2609	P6LB-1001 to 35238
		Station Wagon Std.	3790	Sta. Wag.	P6LB-1001 to 35238
1946	27 Torpedo Eight	Business Coupe	3331	2727B	P8LA-1001 to 13652
		Sport Coupe	3376	2727	P8LA-1001 to 13652
		Sedan Coupe	3391	2707	P8LA-1001 to 13652
		Convertible Coupe	3651	2767	P8LA-1001 to 13652
		Two Door	3396	2711	P8LA-1001 to 13652
		Four Door	3436	2719	P8LA-1001 to 13652
1946	28 Streamliner Eight	Sedan Coupe	3495	2807	P8LB-1001 to 39764
		Four Door	3550	2809	P8LB-1001 to 39764
		Station Wagon Std.	3870	Sta. Wag.	P8LB-1001 to 39764
1947	25 Torpedo Six	Business Coupe	3245	2527B	P6MA-1001 to 37322
		Sport Coupe	3295	2527	P6MA-1001 to 37322
		Sedan Coupe	3300	2507	P6MA-1001 to 37322
		Convertible Coupe	3560	2567	P6MA-1001 to 37322
		Two Door	3295	2511	P6MA-1001 to 37322
		Four Door	3320	2519	P6MA-1001 to 37322
1947	26 Streamliner Six	Sedan Coupe	3400	2607	P6MB-1001 to 27844
		Four Door	3450	2609	P6MB-1001 to 27844
		Station Wagon Std.	3775	Sta. Wag.	P6MB-1001 to 27844
1947	27 Torpedo Eight	Business Coupe	3310	2727B	P8MA-1001 to 22682
		Sport Coupe	3360	2727	P8MA-1001 to 22682
		Sedan Coupe	3370	2707	P8MA-1001 to 22682
		Convertible Coupe	3635	2767	P8MA-1001 to 22682
		Two Door	3370	2711	P8MA-1001 to 22682
		Four Door	3405	2719	P8MA-1001 to 22682
1947	28 Streamliner Eight	Coupe	3455	2807	P8MB-1001 to 56382
		Four Door	3515	2809	P8MB-1001 to 56382
		Station Wagon Std.	3845	Sta. Wag.	P8MB-1001 to 56382

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	S.T.	Weight	H.T.	Body Style No.	Car Serial No.
1948	25 Torpedo Six	Business Coupe	3230		3355	2527B	P6PA-1001 to 25366
		Sport Coupe	3220		3355	2527	P6PA-1001 to 25366
		Sedan Coupe	3275		3385	2507	P6PA-1001 to 25366
		Sedan Coupe	3275		3415	2507D	P6PA-1001 to 25366
		Convertible	3525		3655	2567	P6PA-1001 to 25366
		Two Door	3280		3410	2511	P6PA-1001 to 25366
		Four Door	3320		3440	2519	P6PA-1001 to 25366
		Four Door	3340		3460	2519D	P6PA-1001 to 25366
1948	26 Streamliner Six	Coupe	3365		3490	2607	P6PB-1001 to 18146
		Coupe	3370		3495	2607D	P6PB-1001 to 18146
		Four Door	3450		3570	2609	P6PB-1001 to 18146
		Four Door	3455		3580	2609D	P6PB-1001 to 18146
		Station Wagon Std.	3755		3885	Sta. Wag.	P6PB-1001 to 18146
		Station Wagon Dlx.	3695		3830	Sta. Wag.	P6PB-1001 to 18146
1948	27 Torpedo Eight	Business Coupe	3295		3430	2727B	P8PA-1001 to 18933
		Sport Coupe	3295		3420	2727	P8PA-1001 to 18933
		Sedan Coupe	3340		3475	2707	P8PA-1001 to 18933
		Sedan Coupe	3340		3480	2707D	P8PA-1001 to 18933
		Convertible	3600		3725	2767	P8PA-1001 to 18933
		Two Door	3360		3490	2711	P8PA-1001 to 18933
		Four Door	3395		3520	2719	P8PA-1001 to 18933
		Four Door	3395		3530	2719D	P8PA-1001 to 18933
1948	28 Streamliner Eight	Coupe	3425		3555	2807	P8PB-1001 to 61682
		Coupe	3455		3570	2807D	P8PB-1001 to 61682
		Four Door	3525		3645	2809	P8PB-1001 to 61682
		Four Door	3530		3650	2809D	P8PB-1001 to 61682
		Station Wagon Std.	3820		3945	Sta. Wag.	P8PB-1001 to 61682
		Station Wagon Dlx.	3765		3890	Sta. Wag.	P8PB-1001 to 61682
1949	25 Chieftain Six	Business Coupe	3185			2527B	P6RS-1001 to 17919
		Business Coupe			3280	2527B	P6RH-1001 to 12320
		Sedan Coupe	3225			2527	P6RS-1001 to 17919
		Sedan Coupe			3330	2527	P6RH-1001 to 12320
		Sedan Coupe De Luxe	3230			2527D	P6RS-1001 to 17919
		Sedan Coupe De Luxe			3345	2527D	P6RH-1001 to 12320
		Convertible Coupe De Luxe	3485			2567DTX	P6RS-1001 to 17919
		Convertible Coupe De Luxe			3600	2567DTX	P6RH-1001 to 12320
		Two Door Sedan	3245			2511	P6RS-1001 to 17919
		Two Door Sedan			3355	2511	P6RH-1001 to 12320
		Two Door Sedan De Luxe	3260			2511D	P6RS-1001 to 17919
		Two Door Sedan De Luxe			3360	2511D	P6RH-1001 to 12320
		Four Door Sedan	3275			2569	P6RS-1001 to 17919
		Four Door Sedan			3385	2569	P6RH-1001 to 12320
		Four Door Sedan De Luxe	3290			2569D	P6RS-1001 to 17919
		Four Door Sedan De Luxe			3415	2569D	P6RH-1001 to 12320
1949	25 Streamliner Six	Sedan Coupe	3260			2507	P6RS-1001 to 17919
		Sedan Coupe			3360	2507	P6RH-1001 to 12320
		Sedan Coupe De Luxe	3270			2507D	P6RS-1001 to 17919
		Sedan Coupe De Luxe			3375	2507D	P6RH-1001 to 12320
		Four Door Sedan	3270			2508	P6RS-1001 to 17919
		Four Door Sedan			3385	2508	P6RH-1001 to 12320
		Four Door Sedan De Luxe	3315			2508D	P6RS-1001 to 17919
		Four Door Sedan De Luxe			3415	2508D	P6RH-1001 to 12320
		Station Wagon Wood	3680			2561	P6RS-1001 to 17919
		Station Wagon Wood			3745	2561	P6RH-1001 to 12320
		Sta. Wag. Wood De Luxe	3650			2561D	P6RS-1001 to 17919
		Sta. Wag. Wood De Luxe			3730	2561D	P6RH-1001 to 12320
		Station Wagon Metal	3580			2562	P6RS-1001 to 17919
		Station Wagon Metal			3650	2562	P6RH-1001 to 12320
		Sta. Wag. Metal De Luxe	3480			2562D	P6RS-1001 to 17919
		Sta. Wag. Metal De Luxe			3580	2562D	P6RH-1001 to 12320
		Sedan Delivery	3230			2571	P6RS-1001 to 17919
		Sedan Delivery			3335	2571	P6RH-1001 to 12320

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	S.T.	Weight	H.T.	Body Style No.	Car Serial No.
1949	27 Chieftain Eight	Business Coupe	3240			2527B	P8RS-1001 to 26054
		Business Coupe			3355	2527B	P8RH-1001 to 68436
		Sedan Coupe	3285			2527	P8RS-1001 to 26054
		Sedan Coupe			3390	2527	P8RH-1001 to 68436
		Sedan Coupe De Luxe	3300			2527D	P8RS-1001 to 26054
		Sedan Coupe De Luxe			3415	2527D	P8RH-1001 to 68436
		Convertible Coupe De Luxe	3560			2567DTX	P8RS-1001 to 26054
		Convertible Coupe De Luxe			3670	2567DTX	P8RH-1001 to 68436
		Two Door Sedan	3315			2511	P8RS-1001 to 26054
		Two Door Sedan			3430	2511	P8RH-1001 to 68436
		Two Door Sedan De Luxe	3325			2511D	P8RS-1001 to 26054
		Two Door Sedan De Luxe			3430	2511D	P8RH-1001 to 68436
		Four Door Sedan	3360			2569	P8RS-1001 to 26054
		Four Door Sedan			3475	2569	P8RH-1001 to 68436
		Four Door Sedan De Luxe	3380			2569D	P8RS-1001 to 26054
		Four Door Sedan De Luxe			3480	2569D	P8RH-1001 to 68436
1949	27 Streamliner Eight	Sedan Coupe	3315			2507	P8RS-1001 to 26054
		Sedan Coupe			3435	2507	P8RH-1001 to 68436
		Sedan Coupe De Luxe	3340			2507D	P8RS-1001 to 26054
		Sedan Coupe De Luxe			3445	2507D	P8RH-1001 to 68436
		Four Door Sedan	3360			2508	P8RS-1001 to 26054
		Four Door Sedan			3470	2508	P8RH-1001 to 68436
		Four Door Sedan De Luxe	3380			2508D	P8RS-1001 to 26054
		Four Door Sedan De Luxe			3500	2508D	P8RH-1001 to 68436
		Station Wagon Wood	3740			2561	P8RS-1001 to 26054
		Station Wagon Wood			3835	2561	P8RH-1001 to 68436
		Sta. Wag. Wood De Luxe	3695			2561D	P8RS-1001 to 26054
		Sta. Wag. Wood De Luxe			3800	2561D	P8RH-1001 to 68436
		Station Wagon Metal	3605			2562	P8RS-1001 to 26054
		Station Wagon Metal			3690	2562	P8RH-1001 to 68436
		Sta. Wag. Metal De Luxe	3550			2562D	P8RS-1001 to 26054
		Sta. Wag. Metal De Luxe			3640	2562D	P8RH-1001 to 68436
		Sedan Delivery	3295			2571	P8RS-1001 to 26054
		Sedan Delivery			3400	2571	P8RH-1001 to 68436
1950	25 Chieftain Six	Business Coupe	3209			2527B	P6TS-1001 to 47948
		Business Coupe			3319	2527B	P6TH-1001 to 15001
		Sedan Coupe	3249			2527	P6TS-1001 to 47948
		Sedan Coupe			3359	2527	P6TH-1001 to 15001
		Sedan Coupe De Luxe	3254			2527D	P6TS-1001 to 47948
		Sedan Coupe De Luxe			3364	2527D	P6TH-1001 to 15001
		Convertible Coupe De Luxe	3439			2567DTX	P6TS-1001 to 47948
		Convertible Coupe De Luxe			3549	2567DTX	P6TH-1001 to 15001
		Catalina Coupe De Luxe	3359			2537D	P6TS-1001 to 47948
		Catalina Coupe De Luxe			3469	2537D	P6TH-1001 to 15001
		Catalina Cpe. Sup. De Luxe	3359			2537SD	P6TS-1001 to 47948
		Catalina Cpe. Sup. De Luxe			3469	2537SD	P6TH-1001 to 15001
		Two Door Sedan	3274			2511	P6TS-1001 to 47948
		Two Door Sedan			3384	2511	P6TH-1001 to 15001
		Two Door Sedan De Luxe	3279			2511D	P6TS-1001 to 47948
		Two Door Sedan De Luxe			3389	2511D	P6TH-1001 to 15001
		Four Door Sedan	3299			2569	P6TS-1001 to 47948
		Four Door Sedan			3409	2569	P6TH-1001 to 15001
		Four Door Sedan De Luxe	3304			2569D	P6TS-1001 to 47948
		Four Door Sedan De Luxe			3414	2569D	P6TH-1001 to 15001
1950	25 Streamliner Six	Sedan Coupe	3269			2507	P6TS-1001 to 47948
		Sedan Coupe			3379	2507	P6TH-1001 to 15001
		Sedan Coupe De Luxe	3274			2507D	P6TS-1001 to 47948
		Sedan Coupe De Luxe			3384	2507D	P6TH-1001 to 15001
		Four Door Sedan	3304			2508	P6TS-1001 to 47948
		Four Door Sedan			3414	2508	P6TH-1001 to 15001
		Four Door Sedan De Luxe	3309			2508D	P6TS-1001 to 47948
		Four Door Sedan De Luxe			3419	2508D	P6TH-1001 to 15001
		Station Wagon	3574			2562	P6TS-1001 to 47948
		Station Wagon			3684	2562	P6TH-1001 to 15001
		Sta. Wag. De Luxe	3474			2562D	P6TS-1001 to 47948
		Sta. Wag. De Luxe			3584	2562D	P6TH-1001 to 15001
		Sedan Delivery	3309			2571	P6TS-1001 to 47948
		Sedan Delivery			3419	2571	P6TH-1001 to 15001
1950	27 Chieftain Eight	Business Coupe	3289			2527B	P8TS-1001 to 38315
		Business Coupe			3399	2527B	P8TH-1001 to 128647
		Sedan Coupe	3339			2527	P8TS-1001 to 38315
		Sedan Coupe			3449	2527	P8TH-1001 to 128647
		Sedan Coupe De Luxe	3344			2527D	P8TS-1001 to 38315
		Sedan Coupe De Luxe			3454	2527D	P8TH-1001 to 128647
		Convertible Coupe De Luxe	3534			2567DTX	P8TS-1001 to 38315
		Convertible Coupe De Luxe			3644	2567DTX	P8TH-1001 to 128647

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	S.T.	Weight	H.T.	Body Style No.	Car Serial No.
1950	27 Chieftain Eight (continued)	Catalina Coupe De Luxe	3439			2537D	P8TS-1001 to 38315
		Catalina Coupe De Luxe			3549	2537D	P8TH-1001 to 128647
		Catalina Cpe. Sup. De Luxe	3439			2537SD	P8TS-1001 to 38315
		Catalina Cpe. Sup. De Luxe			3549	2537SD	P8TH-1001 to 128647
		Two Door Sedan	3364			2511	P8TS-1001 to 38315
		Two Door Sedan			3474	2511	P8TH-1001 to 128647
		Two Door Sedan De Luxe	3354			2511D	P8TS-1001 to 38315
		Two Door Sedan De Luxe			3464	2511D	P8TH-1001 to 128647
		Four Door Sedan	3384			2569	P8TS-1001 to 38315
		Four Door Sedan			3494	2569	P8TH-1001 to 128647
		Four Door Sedan De Luxe	3389			2569D	P8TS-1001 to 38315
		Four Door Sedan De Luxe			3499	2569D	P8TH-1001 to 128647
1950	27 Streamliner Eight	Sedan Coupe	3354			2507	P8TS-1001 to 38315
		Sedan Coupe			3464	2507	P8TH-1001 to 128647
		Sedan Coupe De Luxe	3359			2507D	P8TS-1001 to 38315
		Sedan Coupe De Luxe			3469	2507D	P8TH-1001 to 128647
		Four Door Sedan	3389			2508	P8TS-1001 to 38315
		Four Door Sedan			3499	2508	P8TH-1001 to 128647
		Four Door Sedan De Luxe	3399			2508D	P8TS-1001 to 38315
		Four Door Sedan De Luxe			3509	2508D	P8TH-1001 to 128647
		Station Wagon	3594			2562	P8TS-1001 to 38315
		Station Wagon			3704	2562	P8TH-1001 to 128647
		Sta. Wag. De Luxe	3559			2562D	P8TS-1001 to 38315
		Sta. Wag. De Luxe			3669	2562D	P8TH-1001 to 128647
		Sedan Delivery	3384			2571	P8TS-1001 to 38315
		Sedan Delivery			3494	2571	P8TH-1001 to 128647
1951	25 Chieftain Six	Business Coupe	3193			2527B	P6US-1001 to 24016
		Business Coupe			3308	2527B	P6UH-1001 to 6543
		Sedan Coupe	3223			2527	P6US-1001 to 24016
		Sedan Coupe			3338	2527	P6UH-1001 to 6543
		Sedan Coupe De Luxe	3228			2527D	P6US-1001 to 24016
		Sedan Coupe De Luxe			3343	2527D	P6UH-1001 to 6543
		Convertible Coupe De Luxe	3488			2567DTX	P6US-1001 to 24016
		Convertible Coupe De Luxe			3603	2567DTX	P6UH-1001 to 6543
		Catalina Coupe De Luxe	3343			2537D	P6US-1001 to 24016
		Catalina Coupe De Luxe			3458	2537D	P6UH-1001 to 6543
		Catalina Cpe. Sup. De Luxe	3353			2537SD	P6US-1001 to 24016
		Catalina Cpe. Sup. De Luxe			3468	2537SD	P6UH-1001 to 6543
		Two Door Sedan	3243			2511	P6US-1001 to 24016
		Two Door Sedan			3358	2511	P6UH-1001 to 6543
		Two Door Sedan De Luxe	3243			2511D	P6US-1001 to 24016
		Two Door Sedan De Luxe			3358	2511D	P6UH-1001 to 6543
		Four Door Sedan	3273			2569	P6US-1001 to 24016
		Four Door Sedan			3388	2569	P6UH-1001 to 6543
		Four Door Sedan De Luxe	3273			2569D	P6US-1001 to 24016
		Four Door Sedan De Luxe			3388	2569D	P6UH-1001 to 6543
1951	25 Streamliner Six	Sedan Coupe	3248			2507	P6US-1001 to 24016
		Sedan Coupe			3363	2507	P6UH-1001 to 6543
		Sedan Coupe De Luxe	3263			2507D	P6US-1001 to 24016
		Sedan Coupe De Luxe			3378	2507D	P6UH-1001 to 6543
		Station Wagon	3603			2562	P6US-1001 to 24016
		Station Wagon			3718	2562	P6UH-1001 to 6543
		Sta. Wag. De Luxe	3523			2562D	P6US-1001 to 24016
		Sta. Wag. De Luxe			3638	2562D	P6UH-1001 to 6543
		Sedan Delivery	3288			2571	P6US-1001 to 24016
		Sedan Delivery			3403	2571	P6UH-1001 to 6543
1951	27 Chieftain Eight	Business Coupe	3273			2527B	P8US-1001 to 31777
		Business Coupe			3388	2527B	P8UH-1001 to 119780
		Sedan Coupe	3303			2527	P8US-1001 to 31777
		Sedan Coupe			3418	2527	P8UH-1001 to 119780
		Sedan Coupe De Luxe	3318			2527D	P8US-1001 to 31777
		Sedan Coupe De Luxe			3433	2527D	P8UH-1001 to 119780
		Convertible Coupe De Luxe	3568			2567DTX	P8US-1001 to 31777
		Convertible Coupe De Luxe			3683	2567DTX	P8UH-1001 to 119780
		Catalina Coupe De Luxe	3428			2537D	P8US-1001 to 31777
		Catalina Coupe De Luxe			3543	2537D	P8UH-1001 to 119780
		Catalina Cpe. Sup. De Luxe	3433			2537SD	P8US-1001 to 31777
		Catalina Cpe. Sup. De Luxe			3548	2537SD	P8UH-1001 to 119780
		Two Door Sedan	3328			2511	P8US-1001 to 31777
		Two Door Sedan			3443	2511	P8UH-1001 to 119780
		Two Door Sedan De Luxe	3333			2511D	P8US-1001 to 31777
		Two Door Sedan De Luxe			3448	2511D	P8UH-1001 to 119780
		Four Door Sedan	3363			2569	P8US-1001 to 31777
		Four Door Sedan			3478	2569	P8UH-1001 to 119780
		Four Door Sedan De Luxe	3373			2569D	P8US-1001 to 31777
		Four Door Sedan De Luxe			3488	2569D	P8UH-1001 to 119780

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	S.T.	Weight	H.T.	Body Style No.	Car Serial No.
1951	27 Streamliner Eight	Sedan Coupe	3343			2507	P8US-1001 to 31777
		Sedan Coupe			3458	2507	P8UH-1001 to 119780
		Sedan Coupe De Luxe	3348			2507D	P8US-1001 to 31777
		Sedan Coupe De Luxe			3463	2507D	P8UH-1001 to 119780
		Station Wagon	3698			2562	P8US-1001 to 31777
		Station Wagon			3813	2562	P8UH-1001 to 119780
		Sta. Wag. De Luxe	3628			2562D	P8US-1001 to 31777
		Sta. Wag. De Luxe			3743	2562D	P8UH-1001 to 119780
		Sedan Delivery	3393			2571	P8US-1001 to 31777
		Sedan Delivery			3508	2571	P8UH-1001 to 119780
1952	25 Chieftain Six	Convertible Coupe De Luxe	3478			2567DTX	P6WS-1001 to 10041
		Convertible Coupe De Luxe			3603	2567DTX	P6WH-1001 to 3457
		Catalina Coupe De Luxe	3358			2537D	P6WS-1001 to 10041
		Catalina Coupe De Luxe			3483	2537D	P6WH-1001 to 3457
		Catalina Cpe. Sup. De Luxe	3368			2537SD	P6WS-1001 to 10041
		Catalina Cpe. Sup. De Luxe			3493	2537SD	P6WH-1001 to 3457
		Two Door Sedan	3253			2511	P6WS-1001 to 10041
		Two Door Sedan			3378	2511	P6WH-1001 to 3457
		Two Door Sedan De Luxe	3253			2511D	P6WS-1001 to 10041
		Two Door Sedan De Luxe			3378	2511D	P6WH-1001 to 3457
		Four Door Sedan	3278			2569	P6WS-1001 to 10041
		Four Door Sedan			3403	2569	P6WH-1001 to 3457
		Four Door Sedan De Luxe	3278			2569D	P6WS-1001 to 10041
		Four Door Sedan De Luxe			3403	2569D	P6WH-1001 to 3457
		Station Wagon	3593			2562	P6WS-1001 to 10041
		Station Wagon			3718	2562	P6WH-1001 to 3457
		Station Wagon De Luxe	3528			2562D	P6WS-1001 to 10041
		Station Wagon De Luxe			3653	2562D	P6WH-1001 to 3457
		Sedan Delivery	3308			2571	P6WS-1001 to 10041
		Sedan Delivery			3433	2571	P6WH-1001 to 3457
1952	27 Chieftain Eight	Convertible Coupe De Luxe	3558			2567DTX	P8WS-1001 to 16833
		Convertible Coupe De Luxe			3683	2567DTX	P8WH-1001 to 89530
		Catalina Coupe De Luxe	3443			2537D	P8WS-1001 to 16833
		Catalina Coupe De Luxe			3568	2537D	P8WH-1001 to 89530
		Catalina Cpe. Sup. De Luxe	3448			2537SD	P8WS-1001 to 16833
		Catalina Cpe. Sup. De Luxe			3573	2537SD	P8WH-1001 to 89530
		Two Door Sedan	3333			2511	P8WS-1001 to 16833
		Two Door Sedan			3458	2511	P8WH-1001 to 89530
		Two Door Sedan De Luxe	3333			2511D	P8WS-1001 to 16833
		Two Door Sedan De Luxe			3458	2511D	P8WH-1001 to 89530
		Four Door Sedan	3378			2569	P8WS-1001 to 16833
		Four Door Sedan			3503	2569	P8WH-1001 to 89530
		Four Door Sedan De Luxe	3378			2569D	P8WS-1001 to 16833
		Four Door Sedan De Luxe			3503	2569D	P8WH-1001 to 89530
		Station Wagon	3688			2562	P8WS-1001 to 16833
		Station Wagon			3813	2562	P8WH-1001 to 89530
		Station Wagon De Luxe	3633			2562D	P8WS-1001 to 16833
		Station Wagon De Luxe			3758	2562D	P8WH-1001 to 89530
		Sedan Delivery	3413			2571	P8WS-1001 to 16833
		Sedan Delivery			3538	2571	P8WH-1001 to 89530
1953	25 Chieftain Six	Convertible Coupe De Luxe	3546			2567DTX	P6XS-1001
		Convertible Coupe De Luxe			3671	2567DTX	P6XH-1001
		Catalina Coupe De Luxe	3416			2537D	P6XS-1001
		Catalina Coupe De Luxe			3541	2537D	P6XH-1001
		Catalina Cpe. Super De Luxe	3416			2537SD	P6XS-1001
		Catalina Cpe. Super De Luxe			3541	2537SD	P6XH-1001
		Two Door Sedan	3341			2511W	P6XS-1001
		Two Door Sedan			3346	2511W	P6XH-1001
		Two Door Sedan De Luxe	3356			2511WD	P6XS-1001
		Two Door Sedan De Luxe			3481	2511WD	P6XH-1001
		Four Door Sedan	3381			2569W	P6XS-1001
		Four Door Sedan			3506	2569W	P6XH-1001
		Four Door Sedan De Luxe	3396			2569WD	P6XS-1001
		Four Door Sedan De Luxe			3521	2569WD	P6XH-1001
		Station Wagon Two Seat	3606			2562F	P6XS-1001
		Station Wagon Two Seat			3731	2562F	P6XH-1001
		Station Wagon Three Seat	3633			2562	P6XS-1001
		Station Wagon Three Seat			3758	2562	P6XH-1001
		Station Wagon De Luxe	3636			2562DF	P6XS-1001
		Station Wagon De Luxe			3761	2562DF	P6XH-1001
		Sedan Delivery	3421			2571	P6XS-1001
		Sedan Delivery			3546	2571	P6XH-1001

CAR MODEL INFORMATION—Continued

Year	Model	Body Style	S.T.	Weight	H.T.	Body Style No.	Car Serial No.
1953	27 Chieftain Eight	Convertible Coupe De Luxe	3626			2567DTX	P8XS-1001
		Convertible Coupe De Luxe			3751	2567DTX	P8XH-1001
		Catalina Coupe De Luxe	3496			2537D	P8XS-1001
		Catalina Coupe De Luxe			3621	2537D	P8XH-1001
		Catalina Cpe. Super De Luxe	3496			2537SD	P8XS-1001
		Catalina Cpe. Super De Luxe			3621	2537SD	P8XH-1001
		Two Door Sedan	3421			2511W	P8XS-1001
		Two Door Sedan			3546	2511W	P8XH-1001
		Two Door Sedan De Luxe	3436			2511WD	P8XS-1001
		Two Door Sedan De Luxe			3561	2511WD	P8XH-1001
		Four Door Sedan	3456			2569W	P8XS-1001
		Four Door Sedan			3581	2569W	P8XH-1001
		Four Door Sedan De Luxe	3471			2569WD	P8XS-1001
		Four Door Sedan De Luxe			3596	2569WD	P8XH-1001
		Station Wagon Two Seat	3686			2562F	P8XS-1001
		Station Wagon Two Seat			3811	2562F	P8XH-1001
		Station Wagon Three Seat	3713			2562	P8XS-1001
		Station Wagon Three Seat			3838	2562	P8XH-1001
		Station Wagon De Luxe	3716			2562DF	P8XS-1001
		Station Wagon De Luxe			3841	2562DF	P8XH-1001
		Sedan Delivery	3501			2571	P8XS-1001
		Sedan Delivery			3626	2571	P8XH-1001
1954	25 Chieftain Six	Catalina Coupe De Luxe	----			2537D	P-6ZS-1001
		Catalina Coupe De Luxe				2537D	P-6ZH-1001
		Catalina Cpe. Super De Luxe	----			2537SD	P-6ZS-1001
		Catalina Cpe. Super De Luxe				2537SD	P-6ZH-1001
		Two Door Sedan	----			2511W	P-6ZS-1001
		Two Door Sedan				2511W	P-6ZH-1001
		Two Door Sedan De Luxe	----			2511WD	P-6ZS-1001
		Two Door Sedan De Luxe				2511WD	P-6ZH-1001
		Four Door Sedan	----			2569W	P-6ZS-1001
		Four Door Sedan				2569W	P-6ZH-1001
		Four Door Sedan De Luxe	----			2569WD	P-6ZS-1001
		Four Door Sedan De Luxe				2569WD	P-6ZH-1001
		Station Wagon Three Seat	----			2562	P-6ZS-1001
		Station Wagon Three Seat				2562	P-6ZH-1001
		Station Wagon Two Seat	----			2562F	P-6ZS-1001
		Station Wagon Two Seat				2562F	P-6ZH-1001
1954	27 Chieftain Eight	Catalina Coupe De Luxe	----			2537D	P-8ZS-1001
		Catalina Coupe De Luxe				2537D	P-8ZH-1001
		Catalina Cpe. Super De Luxe	----			2537SD	P-8ZS-1001
		Catalina Cpe. Super De Luxe				2537SD	P-8ZH-1001
		Two Door Sedan	----			2511W	P-8ZS-1001
		Two Door Sedan				2511W	P-8ZH-1001
		Two Door Sedan De Luxe	----			2511WD	P-8ZS-1001
		Two Door Sedan De Luxe				2511WD	P-8ZH-1001
		Four Door Sedan	----			2569W	P-8ZS-1001
		Four Door Sedan				2569W	P-8ZH-1001
		Four Door Sedan De Luxe	----			2569WD	P-8ZS-1001
		Four Door Sedan De Luxe				2569WD	P-8ZH-1001
		Station Wagon Three Seat	----			2562	P-8ZS-1001
		Station Wagon Three Seat				2562	P-8ZH-1001
		Station Wagon Two Seat	----			2562F	P-8ZS-1001
		Station Wagon Two Seat				2562F	P-8ZH-1001
1954	28 Star Chief Eight	Convertible	----			2867DTX	P-8ZC-1001
		Convertible				2867DTX	P-8ZA-1001
		Catalina Custom	----			2837SD	P-8ZC-1001
		Catalina Custom				2837SD	P-8ZA-1001
		Four Door Sedan De Luxe	----			2869WD	P-8ZC-1001
		Four Door Sedan De Luxe				2869WD	P-8ZA-1001
		Four Door Sedan Custom	----			2869WSD	P-8ZC-1001
		Four Door Sedan Custom				2869WSD	P-8ZA-1001

All weights shown are for 5-wheel jobs, and do not include water or gasoline.

CAR MODEL INFORMATION — Continued

ASSEMBLY PLANT SERIAL NUMBERS

South Gate, P/6-37	C6CA-1001 to 16434	South Gate, 1948-25	C6PA-1001 to 5150
South Gate, P/8-37	C8CA-1001 to 4765	South Gate, 1948-26	C6PB-1001 to 4765
Linden, P/6-37	L6CA-1001 to 5510	South Gate, 1948-27	C8PA-1001 to 4368
Linden, P/8-37	L8CA-1001 to 5437	South Gate, 1948-28	C8PB-1001 to 13302
		Linden, 1948-25	L6PA-1001 to 5301
South Gate, P/6-38	C6DA-1001 to 8155	Linden, 1948-26	L6PB-1001 to 4350
South Gate, P/8-38	C8DA-1001 to 2530	Linden, 1948-27	L8PA-1001 to 5471
Linden, P/6-38	L6DA-1001 to 8942	Linden, 1948-28	L8PB-1001 to 12359
Linden, P/8-38	L8DA-1001 to 4071	Wilmington, 1948-25	W6PA-1001 to 4575
		Wilmington, 1948-26	W6PB-1001 to 3772
South Gate, P/6-39-25	C6EA-1001 to 4938	Wilmington, 1948-27	W8PA-1001 to 3854
South Gate, P/6-39-26	C6EB-1001 to 5120	Wilmington, 1948-28	W8PB-1001 to 10616
South Gate, P/8-39-28	C8EA-1001 to 3625	Kansas City, 1948-25	K6PA-1001 to 5303
Linden, P/6-39-25	L6EA-1001 to 7503	Kansas City, 1948-26	K6PB-1001 to 5552
Linden, P/6-39-26	L6EB-1001 to 8509	Kansas City, 1948-27	K8PA-1001 to 4134
Linden, P/8-39	L8EA-1001 to 6523	Kansas City, 1948-28	K8PB-1001 to 16561
		Atlanta, 1948-25	A6PA-1001 to 3429
South Gate, 1940-25	C6HA-1001 to 10328	Atlanta, 1948-26	A6PB-1001 to 2926
South Gate, 1940-26	C6HB-1001 to 5184	Atlanta, 1948-27	A8PA-1001 to 2820
South Gate, 1940-28	C8HA-1001 to 2363	Atlanta, 1948-28	A8PB-1001 to 7603
South Gate, 1940-29	C8HB-1001 to 4490	Framingham, 1948-25	F6PA-1001 to 3454
Linden, 1940-25	L6HA-1001 to 13111	Framingham, 1948-26	F6PB-1001 to 2951
Linden, 1940-26	L6HB-1001 to 10988	Framingham, 1948-27	F8PA-1001 to 2720
Linden, 1940-28	L8HA-1001 to 4253	Framingham, 1948-28	F8PB-1001 to 7776
Linden, 1940-29	L8HB-1001 to 5359		
		South Gate, 1949-25	C-6RS-1001 to 4767
South Gate, 1941-25	C6JA-1001 to 12260	South Gate, 1949-26	C-6RH-1001 to 4142
South Gate, 1941-26	C6JB-1001 to 7810	South Gate, 1949-27	C-8RS-1001 to 7209
South Gate, 1941-24	C6JC-1001 to 2033	South Gate, 1949-27	C-8RH-1001 to 19959
South Gate, 1941-27	C8JA-1001 to 4862	Linden, 1949-25	L-6RS-1001 to 4657
South Gate, 1941-28	C8JB-1001 to 6493	Linden, 1949-25	L-6RH-1001 to 3998
South Gate, 1941-29	C8JC-1001 to 2512	Linden, 1949-27	L-8RS-1001 to 7398
Linden, 1941-25	L6JA-1001 to 26504	Linden, 1949-27	L-8RH-1001 to 19989
Linden, 1941-26	L6JB-1001 to 17464	Wilmington, 1949-25	W-6RS-1001 to 4077
Linden, 1941-24	L6JC-1001 to 2879	Wilmington, 1949-25	W-6RH-1001 to 3425
Linden, 1941-27	L8JA-1001 to 8742	Wilmington, 1949-27	W-8RS-1001 to 6200
Linden, 1941-28	L8JB-1001 to 10366	Wilmington, 1949-27	W-8RH-1001 to 16062
Linden, 1941-29	L8JC-1001 to 4983	Kansas City, 1949-25	K-6RS-1001 to 7406
		Kansas City, 1949-25	K-6RH-1001 to 5887
South Gate, 1942-25	C6KA-1001 to 3260	Kansas City, 1949-27	K-8RS-1001 to 10608
South Gate, 1942-26	C6KB-1001 to 2170	Kansas City, 1949-27	K-8RH-1001 to 30890
South Gate, 1942-27	C8KA-1001 to 2070	Atlanta, 1949-25	A-6RS-1001 to 3404
South Gate, 1942-28	C8KB-1001 to 3127	Atlanta, 1949-25	A-6RH-1001 to 2903
Linden, 1942-25	L6KA-1001 to 3428	Atlanta, 1949-27	A-8RS-1001 to 4975
Linden, 1942-26	L6KB-1001 to 2181	Atlanta, 1949-27	A-8RH-1001 to 12657
Linden, 1942-27	L8KA-1001 to 2205	Framingham, 1949-25	F-6RS-1001 to 3613
Linden, 1942-28	L8KB-1001 to 3451	Framingham, 1949-25	F-6RH-1001 to 3012
		Framingham, 1949-27	F-8RS-1001 to 5188
South Gate, 1946-25	C6LA-1001 to 3314	Framingham, 1949-27	F-8RH-1001 to 13336
South Gate, 1946-26	C6LB-1001 to 3696		
South Gate, 1946-27	C8LA-1001 to 2786	South Gate, 1950-25	C6TS-1001 to 5571
South Gate, 1946-28	C8LB-1001 to 4257	South Gate, 1950-25	C6TH-1001 to 2553
Linden, 1946-25	L6LA-1001 to 4721	South Gate, 1950-27	C8TS-1001 to 4746
Linden, 1946-26	L6LB-1001 to 5357	South Gate, 1950-27	C8TH-1001 to 29630
Linden, 1946-27	L8LA-1001 to 3738	Linden, 1950-25	L6TS-1001 to 8011
Linden, 1946-28	L8LB-1001 to 6618	Linden, 1950-25	L6TH-1001 to 2999
Kansas City, 1946-25	K6LA-1001 to 2520	Linden, 1950-27	L8TS-1001 to 4619
Kansas City, 1946-26	K6LB-1001 to 2299	Linden, 1950-27	L8TH-1001 to 19508
Kansas City, 1946-27	K8LA-1001 to 2085	Wilmington, 1950-25	W6TS-1001 to 7475
Kansas City, 1946-28	K8LB-1001 to 2590	Wilmington, 1950-25	W6TH-1001 to 2534
		Wilmington, 1950-27	W8TS-1001 to 5558
Atlanta, 1947-25	A6MA-None	Wilmington, 1950-27	W8TH-1001 to 17360
Atlanta, 1947-26	A6MB-1001 to 1080	Kansas City, 1950-25	K6TS-1001 to 14626
Atlanta, 1947-27	A8MA-None	Kansas City, 1950-25	K6TH-1001 to 3696
Atlanta, 1947-28	A8MB-1001 to 1145	Kansas City, 1950-27	K8TS-1001 to 11497
South Gate, 1947-25	C6MA-1001 to 7794	Kansas City, 1950-27	K8TH-1001 to 42698
South Gate, 1947-26	C6MB-1001 to 3976	Atlanta, 1950-25	A6TS-1001 to 4925
South Gate, 1947-27	C8MA-1001 to 4150	Atlanta, 1950-25	A6TH-1001 to 1960
South Gate, 1947-28	C8MB-1001 to 8197	Atlanta, 1950-27	A8TS-1001 to 5257
Linden, 1947-25	L6MA-1001 to 13895	Atlanta, 1950-27	A8TH-1001 to 14851
Linden, 1947-26	L6MB-1001 to 7877	Framingham, 1950-25	F6TS-1001 to 8048
Linden, 1947-27	L8MA-1001 to 7387	Framingham, 1950-25	F6TH-1001 to 2575
Linden, 1947-28	L8MB-1001 to 15246	Framingham, 1950-27	F8TS-1001 to 4707
Wilmington, 1947-25	W6MA-1001 to 1850	Framingham, 1950-27	F8TH-1001 to 17242
Wilmington, 1947-26	W6MB-1001 to 1562		
Wilmington, 1947-27	W8MA-1001 to 1431	South Gate, 1951-25	C6US-1001 to 3519
Wilmington, 1947-28	W8MB-1001 to 1954	South Gate, 1951-25	C6UH-1001 to 1473
Kansas City, 1947-25	K6MA-1001 to 8096	South Gate, 1951-27	C8US-1001 to 6224
Kansas City, 1947-26	K6MB-1001 to 4569	South Gate, 1951-27	C8UH-1001 to 20125
Kansas City, 1947-27	K8MA-1001 to 4165	Linden, 1951-25	L6US-1001 to 4133
Kansas City, 1947-28	K8MB-1001 to 9184	Linden, 1951-25	L6UH-1001 to 1592

CAR MODEL INFORMATION—Continued

ASSEMBLY PLANT SERIAL NUMBERS (Continued)

Linden, 1951-27	L8US-1001 to 5984	Kansas City, 1953-25	K6XS-1001
Linden, 1951-27	L8UH-1001 to 22197	Kansas City, 1953-25	K6XH-1001
Wilmington, 1951-25	W6US-1001 to 4175	Kansas City, 1953-27	K8XS-1001
Wilmington, 1951-25	W6UH-1001 to 1562	Kansas City, 1953-27	K8XH-1001
Wilmington, 1951-27	W8US-1001 to 6068	Atlanta, 1953-25	A6XS-1001
Wilmington, 1951-27	W8UH-1001 to 23140	Atlanta, 1953-25	A6XH-1001
Kansas City, 1951-25	K6US-1001 to 6567	Atlanta, 1953-27	A8XS-1001
Kansas City, 1951-25	K6UH-1001 to 1954	Atlanta, 1953-27	A8XH-1001
Kansas City, 1951-27	K8US-1001 to 11644	Framingham, 1953-25	F6XS-1001
Kansas City, 1951-27	K8UH-1001 to 40060	Framingham, 1953-25	F6XH-1001
Atlanta, 1951-25	A6US-1001 to 3282	Framingham, 1953-27	F8XS-1001
Atlanta, 1951-25	A6UH-1001 to 1416	Framingham, 1953-27	F8XH-1001
Atlanta, 1951-27	A8US-1001 to 5406		
Atlanta, 1951-27	A8UH-1001 to 18117	South Gate, 1954-25	C6ZS-1001
Framingham, 1951-25	F6US-1001 to 3181	South Gate, 1954-25	C6ZH-1001
Framingham, 1951-25	F6UH-1001 to 1323	South Gate, 1954-27	C8ZS-1001
Framingham, 1951-27	F8US-1001 to 4117	South Gate, 1954-27	C8ZH-1001
Framingham, 1951-27	F8UH-1001 to 14080	South Gate, 1954-28	C8ZC-1001
		South Gate, 1954-28	C8ZA-1001
South Gate, 1952-25	C6WS-1001 to 1723	Linden, 1954-25	L6ZS-1001
South Gate, 1952-25	C6WH-1001 to 1883	Linden, 1954-25	L6ZH-1001
South Gate, 1952-27	C8WS-1001 to 3440	Linden, 1954-27	L8ZS-1001
South Gate, 1952-27	C8WH-1001 to 20083	Linden, 1954-27	L8ZH-1001
Linden, 1952-25	L6WS-1001 to 1986	Linden, 1954-28	L8ZC-1001
Linden, 1952-25	L6WH-1001 to 1210	Linden, 1954-28	L8ZA-1001
Linden, 1952-27	L8WS-1001 to 3920	Wilmington, 1954-25	W6ZS-1001
Linden, 1952-27	L8WH-1001 to 23732	Wilmington, 1954-25	W6ZH-1001
Wilmington, 1952-25	W6WS-1001 to 1967	Wilmington, 1954-27	W8ZS-1001
Wilmington, 1952-25	W6WH-1001 to 1223	Wilmington, 1954-27	W8ZH-1001
Wilmington, 1952-27	W8WS-1001 to 3736	Wilmington, 1954-28	W8ZC-1001
Wilmington, 1952-27	W8WH-1001 to 22776	Wilmington, 1954-28	W8ZA-1001
Kansas City, 1952-25	K6WS-1001 to 2745	Kansas City, 1954-25	K6ZS-1001
Kansas City, 1952-25	K6WH-1001 to 1406	Kansas City, 1954-25	K6ZH-1001
Kansas City, 1952-27	K8WS-1001 to 6109	Kansas City, 1954-27	K8ZS-1001
Kansas City, 1952-27	K8WH-1001 to 39194	Kansas City, 1954-27	K8ZH-1001
Atlanta, 1952-25	A6WS-1001 to 1669	Kansas City, 1954-28	K8ZC-1001
Atlanta, 1952-25	A6WH-1001 to 1165	Kansas City, 1954-28	K8ZA-1001
Atlanta, 1952-27	A8WS-1001 to 3444	Atlanta, 1954-25	A6ZS-1001
Atlanta, 1952-27	A8WH-1001 to 18358	Atlanta, 1954-25	A6ZH-1001
Framingham, 1952-25	F6WS-1001 to 1551	Atlanta, 1954-27	A8ZS-1001
Framingham, 1952-25	F6WH-1001 to 1103	Atlanta, 1954-27	A8ZH-1001
Framingham, 1952-27	F8WS-1001 to 2312	Atlanta, 1954-28	A8ZC-1001
Framingham, 1952-27	F8WH-1001 to 10897	Atlanta, 1954-28	A8ZA-1001
		Arlington, 1954-25	T6ZS-1001
South Gate, 1953-25	C6XS-1001	Arlington, 1954-25	T6ZH-1001
South Gate, 1953-25	C6XH-1001	Arlington, 1954-27	T8ZS-1001
South Gate, 1953-27	C8XS-1001	Arlington, 1954-27	T8ZH-1001
South Gate, 1953-27	C8XH-1001	Arlington, 1954-28	T8ZC-1001
Linden, 1953-25	L6XS-1001	Arlington, 1954-28	T8ZA-1001
Linden, 1953-25	L6XH-1001	Framingham, 1954-25	F6ZS-1001
Linden, 1953-27	L8XS-1001	Framingham, 1954-25	F6ZH-1001
Linden, 1953-27	L8XH-1001	Framingham, 1954-27	F8ZS-1001
Wilmington, 1953-25	W6XS-1001	Framingham, 1954-27	F8ZH-1001
Wilmington, 1953-25	W6XH-1001	Framingham, 1954-28	F8ZC-1001
Wilmington, 1953-27	W8XS-1001	Framingham, 1954-28	F8ZA-1001
Wilmington, 1953-27	W8XH-1001		

SPECIAL NOTE

All 1933 thru 41 engine numbers are stamped on a pad at the left front of the cylinder block, just below the cylinder head gasket.
The 1935 thru 38 models have car serial number on top of frame just ahead of steering gear bracket.
The 1939-40 car Serial Numbers are on the front frame cross member just below the generator.
1941 thru 48 car Serial Numbers are located beneath the Fisher Body Number plate under the Hood on the left side of the dash.
1949 thru 54 car Serial Numbers are located on a metal tag attached to the left front hinge pillar.
The 1942 thru 54 car Serial Number is also located on a raised Pad at the front of the L.H. side of the cylinder block.
In order to conserve space in the model column of this book it is necessary to use a model code rather than the name of the car.

CHASSIS ALPHABETICAL INDEX

The Alphabetical Index in this book is set up in straight alphabetical order so that all Accelerator Parts will come under "A", Brakes under "B", Clutch under "C", Transmission under "T" etc. Therefore, if a man knows a part is used in the Transmission (Trans. Countershaft) he can start with Transmission Assy., and follow it down until he finds (Trans. Countershaft) Group 4.428

and by turning to this group find the part for the model wanted. In this type index we have tried to keep away from Front Fenders and Rear Fenders, by showing Fenders (Front) 8.130, Fenders (Rear) 8.203. In this manner all Fenders are together and all Brake Parts are together, thereby making it unnecessary to list the part more than once and keeping down the size of this Index.

Name	Group No.	Name	Group No.	Name	Group No.
A		B		B	
Accelerator Cross Shaft.....	3.585	Brake Cable Anchor Felt.....	4.784	Brake Support to Knuckle Spacer (Frt.).....	5.002
Accelerator Cross Shaft Bracket-Spacer.....	3.589	Brake Cable Assy.....	4.779	Brake Wheel Cyl. Assy.....	4.665
Accelerator Cross Shaft Spring.....	3.591	Brake Cable to Brkt. Yoke.....	4.785	Brake Wheel Cyl. Bleeder Valve.....	4.666
Accelerator Cross Shaft Throttle Cracker Lever.....	3.581	Brake Cable Clamp.....	4.785	Brake Wheel Cyl. Boot.....	4.670
Accelerator Idler Lever.....	3.571	Brake Clevis Pin.....	4.823	Brake Wheel Cyl. Conn. Adapter.....	4.686
Accelerator Linkage Pkg.....	3.429	Brake Drum (Rear).....	5.809	Brake Wheel Cyl. Conn. Link.....	4.675
Accelerator Pedal.....	3.451	Brake Drum Bolt-Washer.....	5.812	Brake Wheel Cyl. Cup.....	4.667
Accelerator Pedal Brkt. to Floor Plate.....	3.456	Brake Drum Gasket.....	5.811	Brake Wheel Cyl. Piston.....	4.668
Accelerator Pedal Hinge Pin.....	3.452	Brake Drum & Hub (Front).....	6.306	Brake Wheel Cyl. Repair Kit.....	4.667
Accelerator Pedal Rod-Trunnion.....	3.431	Brake Drum Oil Deflector.....	5.815-6.037	Brake Wheel Cyl. Spring.....	4.669
Accelerator Pedal Support.....	3.456	Brake Drum Oil Deflector Gasket.....	5.819	Bulbs, Light.....	8.991
Accelerator Rod Return Spring.....	3.459	Brake Drum Silencer Spring Pkg.....	5.810	Bumper Apron.....	7.870
Accelerator Rod Toe Board Bellows.....	3.464	Brake Equalizer.....	4.765	Bumper Apron Cushion (Frt.).....	7.868
Accelerator Stud.....	3.472	Brake Fluid.....	4.683	Bumper Apron Ext. Anti-Squeak.....	7.871
Accessory Fuse and Terminal Block-Cover.....	2.483	Brake Hose.....	4.680	Bumper Apron Ext. Assy. (Rr.).....	7.871
Air Cleaner (Carburetor).....	3.402	Brake Hose Conn. Brkt.....	4.681	Bumper Apron to Grille Ret.....	7.868
Air Cleaner Brace.....	3.405	Brake Hose Conn. Breather Screw.....	4.687	Bumper Bar.....	7.831-7.836
Air Cleaner Element.....	3.410	Brake Hose Ret. Yoke.....	4.681	Bumper Bracket.....	7.836
Air Cleaner-Crankcase.....	1.780	Brake Lever to Shoe Strut.....	5.150	Bumper Center Bar Spacer.....	7.860
Air Intake Cover-Gasket.....	9.785	Brake Lever to Shoe Strut Spring-Washer.....	5.151	Bumper Emblem.....	7.852
Air Intake Duct Assy.....	9.802	Brake Lines.....	4.685	Bumper End Bolt.....	7.859
Air Intake Hose-Deflector-Tube.....	9.786	Brake Lining.....	5.018	Bumper Frame Brkt. (Rear).....	7.836
Air Intake Screen.....	9.802	Brake Lining Rivet.....	5.019	Bumper Guard Assy.....	7.828
Air Intake Valve Cont. Assy.....	9.787	Brake Master Cyl.....	4.650	Bumper Guard Bolt.....	7.828
Air Vent. Valve and Body Assy.....	9.789	Brake Master Cyl. Body.....	4.650	Bumper Guard Brace.....	7.829
Ammeter Assy.....	2.515	Brake Master Cyl. Boot.....	4.659	Bumper Guard Bracket.....	7.829
Antenna Parts.....	9.620 thru 9.674	Brake Master Cyl. Conn. Adapter-Gasket.....	4.661	Bumper Guard Retainer.....	7.829
Armature, Generator.....	2.279	Brake Master Cyl. Filler Cap-Gasket.....	4.651	Bumper Guard Spacer.....	7.828
Armature, Starter Motor.....	2.043	Brake Master Cyl. Head Nut-Gasket.....	4.652	Bumper Guard Tapping Plate (Frt.).....	7.830
Automatic Choke Parts.....	3.256	Brake Master Cyl. Pipe.....	4.685	Bumper Guard Washer.....	7.828
Axle Gear Lubricant.....	5.529	Brake Master Cyl. Piston Cup.....	4.654	Bumper Master Guard Clamp.....	7.829
Axle Housing.....	5.387	Brake Master Cyl. Piston Lock Ring.....	4.656	Bumper Pad.....	7.865
Axle Housing Cover Gasket.....	5.399	Brake Master Cyl. Piston Spring.....	4.655	Bumper Stabilizer.....	7.866
Axle Housing Filler Plug.....	5.400	Brake Master Cyl. Repair Kit.....	4.649		
Axle Housing Filler Plug Gasket.....	5.401	Brake Master Cyl. Rod.....	4.658	C	
Axle Housing Oil Deflector.....	5.815	Brake Master Cyl. Rod Clevis-Pin.....	4.662	Cable Clip.....	8.950
Axle Shaft.....	5.420	Brake Master Cyl. Rod Stop Plate.....	4.656	Cable, Electrical-100 ft. roll.....	2.530
Axle Shaft Lock-Spacer.....	5.422	Brake Master Cyl. Check Valve Assy.....	4.657	Camshaft Assy.....	0.519
		Brake Oil Drain.....	5.815-6.037	Camshaft Bearing (Ctr. & Frt. Ctr.).....	0.543
B		Brake Pedal.....	4.625	Camshaft Bearing (Front).....	0.539
Back-Up Lamp Parts.....	2.697	Brake Pedal Brkt.....	7.237	Camshaft Bearing (Rear).....	0.549
Ball Sleeve.....	8.963	Brake Pedal Bushing.....	4.626	Camshaft Bearing (Rr. Ctr.).....	0.546
Balls (Steel).....	8.899	Brake Pedal Pad.....	4.630	Camshaft Sprocket.....	0.736
Battery Clamp Bolt.....	2.334	Brake Pedal Pivot Parts-P.B.....	4.634	Camshaft Sprocket Lock Nut.....	0.736
Battery Cover.....	2.335	Brake Pedal Plate.....	9.038	Camshaft Thrust Plate.....	0.533
Battery Ground Strap.....	2.341	Brake Pedal Ret. Spring.....	4.625	Carb. Air Cleaner.....	3.402
Battery Positive Lead.....	2.342	Brake Pedal Return Spring.....	4.639	Carb. Air Horn.....	3.730
Battery Retainer-Bolt.....	2.334	Brake Pedal Shaft.....	4.625	Carb. Air Horn to Bowl Cover Gskt.....	3.731
Battery Support.....	2.333	Brake Pedal Shaft Pin.....	4.625	Carb. Anti-Perc. Arm-Cap-Spring.....	3.852
Battery Support to Fender Bumper.....	2.337	Brake Pipe Conn.....	4.686	Carb. Assy.....	3.725
Battery Terminal Clamp Bolt-Nut.....	2.343	Brake Pipe Conn. Washer.....	4.671	Carb. Bowl Cover Assy.....	3.737
Battery Terminal Clamp Cover.....	2.343	Brake Pipes.....	4.685	Carb. Bowl Cover Gasket-Nut-Screen.....	3.740
Bearing Clearance Checking Material Pkg.....	0.093	Brake Radius Rod Bolt (Front).....	5.012	Carb. Choke Housing.....	3.751
Body Bolt Cushion.....	9.023	Brake Radius Rod Seal.....	5.005	Carb. Choke Lever.....	3.753
Body Bolt Nut.....	9.011	Brake Shoe Adj. Screw.....	5.110	Carb. Choke Lever & Collar.....	3.752
Body Bolt Shim.....	9.023	Brake Shoe Adj. Screw Nut.....	5.111	Carb. Choke Piston.....	3.752
Body Bolt Washer.....	9.011	Brake Shoe Adj. Screw Socket.....	5.111	Carb. Choke Shaft.....	3.752
Body to Frame Bracket.....	7.330-7.334	Brake Shoe Anchor Pin.....	5.055	Carb. Choke Shaft Lever & Link Assy.....	3.752
Body Rocker Panel Ext.....	8.228	Brake Shoe Anchor Pin Guide.....	5.045	Carb. Choke Suction Packing.....	3.750
Body Rocker Panel Ext. Mat-Plate-Seal.....	8.229	Brake Shoe Anchor Pin Nut.....	5.057	Carb. Choke Suction Tube & Seal.....	3.750
Body Rocker Panel Mldg.....	8.231	Brake Shoe Anchor Pin Washer.....	5.056	Carb. Choke Valve.....	3.751
Body Rocker Panel Mldg. Clip.....	8.231	Brake Shoe Eccentric.....	5.050	Carb. Conversion Pkg.....	3.727
Body Splash Apron.....	8.228	Brake Shoe Eccentric Spacer.....	5.053	Carb. Dust Cover.....	3.732
Bolts (Std. Parts).....	8.900-8.913	Brake Shoe Equalizer Spring.....	5.026	Carb. Dust Cover Gasket.....	3.732
Brake Adj. Hole Cover.....	5.117	Brake Shoe Hold Down Spring.....	5.043	Carb. Fast Idle Arm-Spring-Screw.....	3.767
Brake to Axle Housing Bolt.....	5.024	Brake Shoe Hold Down Spring Cup.....	5.042	Carb. Fast Idle Cam-Lever.....	3.766
Brake to Axle Housing Gasket.....	5.022	Brake Shoe Hold Down Spring Pin.....	5.041	Carb. Fast Idle Conn.-Link-Rod-Spring.....	3.768
Brake Cable Anchor.....	4.785	Brake Shoe Lining.....	5.018	Carb. Float.....	3.745
		Brake Shoe & Lining Pkg.....	5.017	Carb. Float Lever Pin.....	3.747
		Brake Shoe Rivet.....	5.019	Carb. Gasket Pkg.....	3.724
		Brake Shoe Spring.....	5.026-5.043	Carb. Heat Deflector.....	3.326
		Brake Support.....	5.001		
		Brake Support Bolt.....	5.002		

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.
C	
Carb. Idle Adj. Screw.....	3.822
Carb. Idle Adj. Screw Spring.....	3.823
Carb. Idle Port Rivet Plug.....	3.821
Carb. Intake Check Ball.....	3.862
Carb. Intake Needle Pull Clip.....	3.814
Carb. Intake Needle & Seat.....	3.814
Carb. Low Speed Jet Assy.....	3.798
Carb. to Manifold Gasket.....	3.726
Carb. to Manifold Stud.....	3.288
Carb. Metering Rod.....	3.806
Carb. Metering Rod Arm.....	3.807
Carb. Metering Rod Disc.....	3.811
Carb. Metering Rod, Jet & Gasket.....	3.792
Carb. Metering Rod Spring.....	3.810
Carb. Nozzle.....	3.774
Carb. Power Valve Piston.....	3.858
Carb. Power Valve Piston Spring.....	3.859
Carb. Power Valve Support Assy.....	3.794
Carb. Pump Arm & Collar.....	3.845
Carb. Pump Check Ball.....	3.826
Carb. Pump Conn. Link.....	3.843
Carb. Pump Discharge Ball-Spring-Guide.....	3.825
Carb. Pump Discharge Check Needle—Plug.....	3.832
Carb. Pump Jet.....	3.844
Carb. Pump Operating Lever & Ctr/Shaft.....	3.842
Carb. Pump Lever Spring.....	3.845
Carb. Pump Plunger & Rod.....	3.838
Carb. Pump Relief Valve Plug Assy.....	3.844
Carb. Pump Ret.—Spring—Strainer.....	3.841
Carb. Repair Kit.....	3.725
Carb. Rod Anti-Rattle Spring.....	3.524
Carb. Rod Trunnion.....	3.425
Carb. Therm. Cover & Coil Assy.....	3.750
Carb. Therm. Housing & Coil Assy.....	3.750
Carb. Throttle Arm-Rod-Spring.....	3.762
Carb. Throttle Body.....	3.729
Carb. Throttle Body Gasket.....	3.735
Carb. Throttle Body Screw & Washer.....	3.741
Carb. Throttle Rod.....	3.430
Carb. Throttle Rod Idler Lever.....	3.450
Carb. Throttle Rod Spring.....	3.459
Carb. Throttle Shaft & Lever.....	3.759
Carb. Throttle Valve.....	3.758
Carb. Throttle Valve-Lever Adj. Screw.....	3.761
Carb. Vacuum Piston Assy.....	3.858
Carb. Vacuum Piston Spring.....	3.859
Chassis Wire Harness.....	2.480
Cigar Lighter Assy.....	9.709-9.712
Cigar Lighter Bracket.....	9.709
Clamp, Fuel Tank Pipe Hose.....	3.004
Clevis or End Yoke.....	8.946
Clevis Pin.....	8.942
Clip.....	8.950
Clock Parts (Electric).....	9.772
Clutch Ctr/Shaft.....	0.852
Clutch Ctr/Shaft Bracket.....	0.852
Clutch Ctr/Shaft Felt.....	0.851
Clutch Ctr/Shaft Roller.....	0.853
Clutch Ctr/Shaft Spacer.....	0.852
Clutch Ctr/Shaft Stud.....	0.851
Clutch Ctr/Shaft Support.....	0.852
Clutch Cover.....	0.861
Clutch Cover to Fly Wheel Bolt.....	0.862
Clutch Cover & Pressure Plate.....	0.859
Clutch Driven Plate.....	0.886
Clutch Driven Plate Facings.....	0.885
Clutch Driven Plate Facings Rivet.....	0.884
Clutch Fork to Ctr/Shaft Rod.....	0.839
Clutch Fork Guide Cover-Spring.....	0.797
Clutch Fork Return Spring.....	0.844
Clutch Housing.....	0.683
Clutch Housing Bottom Cover.....	0.679
Clutch Housing Dowel Pin.....	0.685
Clutch Housing Gasket.....	4.005
Clutch Inspection Cover.....	0.686
Clutch Pedal.....	0.830
Clutch Pedal Adj. Link—Rod.....	0.839
Clutch Pedal Adj. Screw.....	0.841

Name	Group No.
C	
Clutch Pedal Bracket.....	7.237
Clutch Pedal Bushing.....	0.831
Clutch Pedal to Ctr/Shaft Rod.....	0.839
Clutch Pedal Floor Hole Cover Plate.....	9.038
Clutch Pedal Over Center Spring.....	0.846
Clutch Pedal Pad.....	4.630
Clutch Pedal Return Spring.....	0.844
Clutch Pedal Return Spring Anchor.....	0.845
Clutch Pedal Return Spring Pin.....	0.849
Clutch Pedal Shaft.....	0.833
Clutch Pedal Shaft to Brkt. Bolt.....	0.834
Clutch Pedal Shaft Washer.....	0.837
Clutch Pilot Bearing.....	0.649
Clutch Pilot Bearing Ret.....	0.650
Clutch Press. Plate.....	0.863
Clutch Press. Plate Ret. Sprg.....	0.864
Clutch Press. Spring.....	0.865
Clutch Press. Spring Cup.....	0.867
Clutch Release Bearing.....	0.799
Clutch Release Bearing Plate.....	0.800
Clutch Release Bearing Spring.....	0.805
Clutch Release Bearing Support.....	0.821
Clutch Release Bearing Support Washer and Spring.....	0.803
Clutch Release Fork.....	0.795
Clutch Release Fork Ball.....	0.796
Clutch Release Fork Ball Ret.....	0.822
Clutch Release Fork Ball Sprg.....	0.823
Clutch Release Fork Guide Plate.....	0.785
Clutch Release Lever.....	0.874
Clutch Release Lever Pin.....	0.875
Clutch Release Lever Spring.....	0.878
Clutch Release Lever Trunnion.....	0.875
Cock (Drain).....	8.951
Coil to Dist. Wire Nipple.....	2.176
Coil to Dist. Wire Ret.....	2.175
Coil to Dist. Wire Support.....	2.175
Coil, Ignition.....	2.170
Coil Mounting Brkt.....	2.183
Coil Wire to Manifold Sleeve.....	2.174
Coil Wire Rubber Nipple.....	2.176
Compression Coupling.....	1.740-8.963
Connecting Rod.....	0.603
Connecting Rod Bearing.....	0.616
Connecting Rod Bolt.....	0.623
Connecting Rod Bolt Nut.....	0.626
Cotter Pin.....	8.938
Cover, Battery.....	2.335
Cowl Ledge Anti-Squeak.....	9.127
Cowl Ledge Lacing Ret.....	9.128
Crankcase Breather Cap.....	1.758
Crankcase Oil Filler.....	1.760
Crankcase Oil Filler Cap.....	1.758
Crankcase Outlet Air Cleaner.....	1.780
Crankcase Outlet Vent.....	1.762
Crankcase Outlet Vent. Pipe Clip.....	1.779
Crankcase Vent. Outlet to Block Screw.....	1.779
Crankcase Vent. Outlet Gasket.....	1.773
Ck/Shaft Assy.....	0.646
Ck/Shaft Balancer.....	0.659
Ck/Shaft Bearing (Frt.).....	0.096
Ck/Shaft Bearing (Frt. Ctr.).....	0.099
Ck/Shaft Bearing (Ctr.).....	0.101
Ck/Shaft Bearing (Rr.).....	0.106
Ck/Shaft Bearing (Rr. Ctr.).....	0.103
Ck/Shaft Bearing Cap Bolt.....	0.056
Ck/Shaft Bearing Cap Bolt Ret.....	0.060
Ck/Shaft Bearing Cap Oil Seal.....	0.137
Ck/Shaft Bearing Oil Seal Packing.....	0.137
Ck/Shaft Clutch Pilot Bearing.....	0.649
Ck/Shaft Oil Hole Plug.....	0.647
Ck/Shaft Rear Bearing Oil Drain.....	1.565
Ck/Shaft Sprocket.....	0.728
Ck/Shaft Sprocket Key.....	0.729
Cyl. Block Hole Plug.....	1.146
Cyl. Block Water Inlet Tube.....	1.135
Cyl. Block Valve Chamber Baffle.....	0.033
Cyl. Front End Plate Gasket.....	0.005
Cyl. Front End Plate.....	0.004
Cyl. Head.....	0.269
Cyl. Head Bolt.....	0.293

Name	Group No.
C	
Cyl. Head Gasket.....	0.289
Cyl. Head Plug.....	0.253
D	
Dash to Instrument Panel Brace.....	9.131
Defroster Parts.....	9.779
Diff. Carrier.....	5.504-5.505
Diff. Carrier to Housing Bolt.....	5.506
Diff. Carrier to Housing Gasket.....	5.508
Diff. Case.....	5.510
Diff. Gear Lubricant.....	5.529
Diff. Gear Package.....	5.527
Diff. Pinion Bearing Adj. Shim.....	5.460
Diff. Pinion Bearing Lock Ring.....	5.489
Diff. Pinion Bearing Lock Screw.....	5.452
Diff. Pinion Bearing Lock Sleeve.....	5.453
Diff. Pinion Bearing Splash Shield.....	5.468
Diff. Pinion Bearings.....	5.447-5.484
Diff. Pinion Shaft.....	5.517
Diff. Pinion Shaft Lock Screw.....	5.518
Diff. Pinion Shaft Packing.....	5.469
Diff. Pinion Thrust Washer.....	5.542
Diff. Ring Gear Bolt.....	5.531
Diff. Ring Gear & Pinion Set.....	5.529
Diff. Side Bearing.....	5.536
Diff. Side Bearing Adj. Nut.....	5.537
Diff. Side Bearing Nut Lock.....	5.539
Diff. Side Gear.....	5.528
Diff. Side Gear Thrust Washer.....	5.543
Dimmer Switch.....	2.459
Direction Sig. Bracket.....	2.902
Direction Sig. Cam.....	2.896
Direction Sig. Cont. Assy.....	2.895
Direction Sig. Flasher.....	2.892
Direction Sig. Lever Assy.....	2.897
Direction Sig. Loom Cover.....	2.901
Direction Sig. Socket & Wire.....	2.899
Direction Sig. Switch Base & Wire Assy.....	2.895
Direction Sig. Switch Housing.....	2.906
Direction Sig. Switch Ruby Jewel.....	2.895
Dist. Assy. & Parts.....	2.360 thru 2.421
Dist. to Block Gasket.....	2.363
Dist. Breaker Plate.....	2.385
Dist. to Carb. Fitting.....	1.720-2.201
Dist. to Carb. Pipe.....	2.201
Dist. Clamp.....	2.414
Dist. Drive Gear.....	1.643
Dist. Drive Spring.....	1.644
Door Fender Cap (See Fender Cap).....	8.131
Drain Cock.....	8.951
Duct Assy. Air Intake.....	9.802
E	
Engine Assy.....	0.033
Engine Conversion Package.....	0.033
Engine Fan.....	1.359
Engine Frt. Ins. Seat-Shield.....	0.027
Engine Insulator.....	0.027
Engine Overhaul Gasket Set.....	0.289
Engine Rr. Supt. Cross Member.....	7.011
Engine Side Apron.....	8.112
Engine Side Pan Bracket.....	8.120
Engine Support Bolt.....	0.002
Engine Support Plate.....	0.029
Engine Support Rr. Brkt.....	7.227
Engine Support Rebound Clamp.....	0.030
Engine Thermogage Unit.....	0.277
Exhaust Manifold.....	3.601
Exhaust Manifold Cover.....	3.602
Exhaust Manifold Riser Outlet.....	3.604
Exhaust Manifold Riser Outlet Gaskets.....	3.605
Exhaust Pipe.....	3.609
Exhaust Pipe Brace.....	3.616
Exhaust Pipe Flange.....	3.610
Exhaust Pipe Gasket.....	3.611
Exhaust Valve.....	0.297
Expansion Plug.....	8.970

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.	Name	Group No.	Name	Group No.
F		F		H	
Fan Assy.	1.359	Front Suspension Arm & Bush. Pkg.	6.168	Hand Brake Return Spring	4.597
Fan Belt	1.416	Front Suspension Fluid	6.386	Hand Brake Rod Clevis	4.781
Fan Hub	1.363	Front Wheel	5.803	Hand Brake Warning Lamp Flasher	4.589
Fan Pulley	1.406	Front Wheel Bearing	6.319	Hand Brake Warning Lamp Housing	4.589
Fasteners	8.987	Front Wheel Hub Oil Seal	6.326	Hand Brake Warning Lamp Switch	4.589
Fender Access Door (Frt.)	8.112	Front Wheel Tie Rod	6.230	Harmonic Balancer	0.659
Fender Anti-Squeak (Frt.)	8.154	Fuel Gauge, Inst. Panel	3.108	Harmonic Balancer Bolt-Washer	0.662
Fender Anti-Squeak (Rr.)	8.205	Fuel Gauge Gasket	3.112	Headlamp Anchor Nut	2.548
Fender Assy. (Frt.)	8.130	Fuel Gauge, Tank Unit	3.107	Headlamp Assy.	2.725
Fender Assy. (Rr.)	8.203	Fuel Gauge Wire & Grommet	2.525	Headlamp Beam Adj. Screw	2.737
Fender to Body Washer	8.136-8.206	Fuel Gauge Wire Clip	2.652	Headlamp Body	2.726
Fender Brace (Frt.)	8.155	Fuel Gauge Wire Connector	2.525	Headlamp Body to Fender Gasket	2.722
Fender Brace (Rr.)	8.212	Fuel Line Clip	3.158	Headlamp Body Tension Spring	2.721
Fender Cap (On Door)	8.131	Fuel Line Connections	3.908	Headlamp Body Trim Molding	2.724
Fender Cap Anti-Squeak	8.133	Fuel Pump Assy.	3.900	Headlamp Bracket	2.550
Fender Cap Clip	8.133	Fuel Pump Bail	3.906	Headlamp Bulb	8.991
Fender Cap to Door Clamp	8.133	Fuel Pump Bolt	3.936	Headlamp Door—Rim	2.728
Fender Cap to Fender Rubber Bumper	8.133	Fuel Pump Bowl	3.903	Headlamp Door Molding	2.731
Fender Cap Molding	8.132	Fuel Pump Bowl Gasket	3.904	Headlamp Door Screw	2.729
Fender Cap Support	8.133	Fuel Pump to Carb. Pipe	3.201	Headlamp Door Seal Ret. Spring	2.746
Fender Cowl Brkt. (Frt.)	8.150	Fuel Pump Connection-Tubing	3.908	Headlamp Lens	2.727
Fender Door (Rr.)	8.208	Fuel Pump Diaphragm Kit	3.925	Headlamp Lens Gasket	2.735
Fender Door Spring	8.209	Fuel Pump Gasket	3.932	Headlamp Lens Ret. Spring	2.730
Fender Gravel Deflector (Rr.)	8.217	Fuel Pump Hose	3.158	Headlamp Mounting Ring Screw	2.736
Fender Gravel Deflector Plate Assy.	8.217	Fuel Pump Oil Seal & Gasket Pkg.	3.925	Headlamp Reflector	2.734
Fender Gravel Deflector Seal (Rr.)	8.217	Fuel Pump Repair Kit	3.901	Headlamp Reflector Ret. Spring	2.736
Fender Lamp Assy.	2.585	Fuel Pump Pipe to Carb.	3.201	Headlamp Sealed Beam Unit	2.727
Fender Lamp Bulb	8.991	Fuel Tank	3.001	Headlamp Sealed Beam Unit Ring	2.731
Fender Lamp Cover	2.586	Fuel Tank Drain Plug	3.006	Headlamp Wire Clip	2.750
Fender Lamp Gasket-Seal	2.590-2.594	Fuel Tank Fender Barrel & Cap	8.209	Headlamp Wire Junction Block	2.560
Fender Lamp Lens	2.589	Fuel Tank Fender Door	8.208	Headlamp Wire & Socket	2.750
Fender Lamp Ornament	8.147-2.593	Fuel Tank Fender Door Bumper	8.210	Heat Control Valve (Manifold)	3.647
Fender Molding Bolt-Clip	8.148	Fuel Tank Fender Door Lock	8.209-8.211	Heat Indicator Fitting	0.277
Fender Moldings—Ornament	8.204-8.147	Fuel Tank Fender Door Lock Cyl.	8.211	Heater Air Inlet Cont. Assy.	9.787
Fender Outer Support (Frt.)	8.141	Fuel Tank Fender Door Spring	8.209	Heater Air Intake Baffle-Clamp	9.784
Fender Panel Shield (Rr.)	8.175	Fuel Tank Filler Cap	3.028	Heater Air Intake Elbow	9.782
Fender to Rad. Brkt. (Frt.)	8.141	Fuel Tank Filler Grommet	3.008	Heater Air Intake Gasket-Ret.	9.785
Fender Shield (Rr.)	8.175	Fuel Tank Filler Pipe	3.003	Heater Air Intake Hose	9.786
Fender Shield Brkt.	8.179	Fuel Tank Filler Pipe Hose	3.003	Heater Air Intake Screen	9.784
Fender Shield Mldg.	8.176	Fuel Tank Filler Pipe Hose Clamp	3.004	Heater Assy. (Hot Water)	8.845 thru 8.866
Fender Shield Seal (Rr.)	8.177	Fuel Tank Filler Pipe Suppt. Brkt.	3.010	Heater Blower	8.857
Fender Shield Seal Bolt (Rr.)	8.177	Fuel Tank to Pump Pipe	3.158	Heater Blower Case	8.845
Fender Shield Seal Ret. (Rr.)	8.177	Fuel Tank Strap Bolt	3.023	Heater Blower Impeller	8.857
Fender Shield Seal Screw (Rr.)	8.177	Fuel Tank Strap Brkt.	3.022	Heater Blower Screw	8.857
Fender to Shroud Baffle Assy.	8.155	Fuel Tank Bar	7.225	Heater Cont. Panel	8.866
Fender to Shroud Shim (Frt.)	8.136	Fuse	8.965	Heater Cont. Panel Elbow	8.866
Fender Side Emblem (Frt.)	8.147	Fuse Block—Cover	2.483	Heater Cont. Panel Knob	8.866
Fender Skirt (Frt.)	8.153	Fuse Block, Heater	8.852	Heater Cont. Panel Plate	8.866
Fender Skirt Baffle to Cowl Seal-Washer	8.154			Heater Cont. Panel Reflector	8.866
Fender Skirt Battery Bumper	2.337	G		Heater Cont. Panel Socket & Wire	8.866
Fender Skirt Felt (Frt.)	8.154	Gearshift	(See Trans. Gearshift)	Heater Cont. Panel Switch	8.852-8.866
Fender Stone Shield	8.162	Generator Adj. Strap	2.317	Heater Cont. Panel Transfer	8.866
Fender Stone Shield (Rr.)	8.214	Generator Adj. Strap Spacer	2.317	Heater Cont. Panel Wire	8.866
Fender Support	8.141	Generator Mounting Bolt	2.275	Heater Core Assy.	8.854
Fender Support Bolt Ret. (Frt.)	8.139	Generator Mounting Brkt.	2.277	Heater Hose	8.846
Fender Support Cushion (Frt.)	8.156	Generator & Parts	2.274 thru 2.317	Heater Hose Clamp	8.948
Fender Support Cushion Plate (Frt.)	8.157	Grease Fittings	8.984	Heater Motor Assy.	8.855
Fender Support Screw (Frt.)	8.143	Grommet (Rubber)	8.956-9.775	Heater Motor Spacer	8.856
Floor Board Plate	9.038			Heater Shutoff Valve	8.866
Flywheel Assy.	0.666	H		Heater Shutoff Valve Cable	8.866
Flywheel to Ck/Shaft Bolt	0.669	Hand Brake Actuating Lever	5.149	Heater Shutoff Valve Cam	8.866
Flywheel to Ck/Shaft Sealer	0.665	Hand Brake Actuating Lever Pivot	5.158	Heater Shutoff Valve Cont. Assy.	8.866
Flywheel Housing	0.683	Hand Brake Cable	4.779	Heater Shutoff Valve Elbow	8.866
Flywheel Housing Cover	0.679	Hand Brake Cable Anchor	4.785	Heater Shutoff Valve Nipple	8.866
Flywheel Housing Dowel Pin	0.685	Hand Brake Cable Anchor Felt	4.784	Hood Bumper	8.024
Flywheel Repair Pkg.	0.666	Hand Brake Cable Return Sprg.	4.597	Hood Catch Bolt	8.082
Flywheel Ring Gear	0.673	Hand Brake Cable to Support Anchor	4.786	Hood Catch Bolt Lever Spring	8.084
Fog Light Parts	9.774	Hand Brake Cross Lever	4.764	Hood Catch Cont. Cable Grommet	8.076
Frame Assy.	7.003	Hand Brake Equalizer Parts	4.765	Hood Catch Cont. Trunnion	8.077
Frame Body Brkt.	7.314-7.330-7.334	Hand Brake Lever—Dash	4.700	Hood Catch Hook Assy.	8.036
Frame Body Brkt.—Brace	7.332	Hand Brake Lever	4.591	Hood Catch Lock Plate Ret.	8.085
Frame Cross Member (Frt.)	7.010	Hand Brake Lever Pawl	4.595	Hood Catch Lock Plate Spring	8.081
Frame Cross Member (Frt. Ctr.)	7.011	Hand Brake Lever Pawl Rivet	4.596	Hood Catch Pilot Bolt	8.085
Frame Cross Member (Rr.)	7.014	Hand Brake Lever Pawl Rod Sprg.	4.597	Hood Catch Pilot to Hood Brkt. Assy.	8.035
Frame Cross Member (Rr. Ctr.)	7.013	Hand Brake Lever Pawl Sleeve	4.595	Hood Catch Plate Assy.	8.080-8.083
Front Axle King Pin	6.203	Hand Brake Lever Sector	4.603	Hood Catch Plate Brace	8.080
Front Bumper Grille Guard	7.831	Hand Brake Lever Sector Rivet	4.608	Hood Center Grille Finish Plate	8.049
Front Bumper Master Guard		Hand Brake Pawl Rivet	4.596	Hood Cross Brace Assy.	8.000
Clamp	7.829	Hand Brake Pull Rod Assy.	4.591	Hood Emblem	8.030
Front Fender	8.130	Hand Brake Pull Rod Brkt. Assy.	4.603	Hood Front Name Plate	1.303
Front Spring	7.412			Hood Front Name Plate Bar	1.303
				Hood Front Name Plate Bezel	1.303

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.
H	
Hood Grille	8.049
Hood Grille Attaching Parts	8.050
Hood Guide Assy.-Brkt. (Rear)	8.013
Hood Hinge	8.015
Hood Hinge Cowl Brkt.	8.019
Hood Hinge Link	8.015
Hood Hinge Rivet	8.015
Hood Hinge Rod	8.016
Hood Hinge Spring	8.013
Hood Hinge Sprg. Dash Brkt.	8.013
Hood Hinge Washer	8.015
Hood Lock Control	8.075
Hood Lock Eyebolt	8.036
Hood Lock Ornament Brkt.	8.032
Hood Lock Pilot	8.035
Hood Lock Pilot Guide	8.038
Hood Lock Pilot Reinf.	8.034
Hood Lock Pilot Spring	8.035
Hood Lock Pilot Spring Ret.	8.035
Hood Lock Rod Spring	8.036
Hood Lock Roller	8.036
Hood Lock Roller Rod	8.036
Hood Ornament	8.030
Hood Ornament Insert	8.030
Hood Panel	8.000-8.001
Hood Panel Bumper	8.024
Hood Panel Mldg.	8.054
Hood Prop Assy.	8.013
Hood to Shroud Water Baffle	9.127
Hood Side Ornament	8.039
Hood Side Panel Bracket	8.007
Hood Side Panel Louvre	8.005
Hood Side Panel Name Plate	8.039
Hood Top Panel Side Mldg.	8.054
Hood Upper Panel Mldg. Bolt	8.054
Hood Upper Panel Mldg. Fastener	8.054
Horn Assy.	2.810
Horn Blowing Key Ret.	2.829
Horn Blowing Ring	2.830
Horn Blowing Key	2.830
Horn Bracket	2.845
Horn Bracket Lamination	2.847
Horn Bracket Spacer	2.847
Horn Button	2.817
Horn Button Cable	2.859
Horn Button Cap	2.817
Horn Button Cap Ret.	2.821
Horn Button Cap Ret. Ins.	2.821
Horn Button Contact	2.822
Horn Button Contact Cup	2.821
Horn Button Contact Cup Clamp	2.821
Horn Button Contact Cup Ring	2.822
Horn Button Contact Cup Suppt.	2.821
Horn Button Contact Ret. Plate	2.822
Horn Button Contact Separator	2.822
Horn Button Contact Spring	2.822
Horn Button Cushion	2.816
Horn Button Ground Plate	2.823
Horn Button Lock Ring	2.829
Horn Button Operating Key	2.830
Horn Button Operating Ring	2.830
Horn Button Ring Spacer	2.831
Horn Button Ring Spacer Ins.	2.831
Horn Button Wire Separator	2.822
Horn Cable Conn.	2.819
Horn Cable Contact Sleeve	2.819
Horn Relay	2.815
Horn Wire	2.859
Horn Wire Clamp	2.859
Horn Wire Conn. Grommet	9.775
Hose (Radiator)	1.159
Hose Clamp	1.160-8.948
Hub (Front)	6.306
Hub Cap	5.858
Hydraulic Brake Parts	(See Brakes)

I	
Ignition Cable	2.241
Ignition Cable to Brace Clip	2.188
Ignition Coil (Also See Coil)	2.170
Ignition Coil Brkt.	2.183

Name	Group No.
I	
Ignition Key	2.187
Ignition Lock Cyl.	2.188
Ignition Switch	2.188
Ignition Switch Brkt.	2.189
Ignition Switch Ferrule	2.192
Ignition Timing Indicator	0.219
Ignition Wire Nipple	2.176
Ignition Wire Set	2.239
Instrument Lamp Bulb	8.991
Instrument Lamp Socket & Wire	2.776
Instrument Lamp Switch	2.765
Instrument Lamp Switch Knob	2.768
Instrument Panel Brace	9.131
Instrument Panel Gauge Case	9.743
Instrument Panel Radio Speaker	
Grille	9.655
Intake Manifold	3.265
Intake Manifold Riser Tube	3.264
Intake Valve	0.296

J	
Jack (Wheel)	8.820
Jack Handle	8.823
Jack Repair Kit	8.820

K	
Key (Woodruff)	8.960
Key, Lock	2.187
King Pin	6.203
King Pin Bearing Plug & Ring	6.223
King Pin Bushing	6.021
King Pin Lock Pin	6.216
King Pin Repair Kit	6.203
King Pin Thrust Bearing	6.210
King Pin Thrust Bearing Shim	6.214

L	
License Brkt. to Body Sealing Wshr.	2.674
License and Lamp Bracket (Rear)	2.705
License Lamp (Rear)	2.700
License Lamp Bar	2.670
License Lamp Cover (Rear)	2.706
License Lamp Gasket (Rear)	2.707
License Lamp Lens (Rear)	2.709
License Lamp Name Plate	2.710
License Lamp Pad (Rear)	2.702
License Lamp Screw (Rear)	2.708
License Lamp Spacer (Rear)	2.703
License Lamp Wire (Rear)	2.714
License Plate Brkt. (Rear)	2.670
License Plate Bumper	2.673
License Plate Cushion-Spacer	7.797
License Plate Support	2.672-7.796
License Plate Support Bar	2.670-7.796
License Support Brkt. (Frt.)	7.798
Light Bulbs	8.991
Light Switch	2.485
Light Switch Fuse	8.965
Light Switch Knob	2.486
Light Switch Knob Bushing-Ferrule	2.487
Light Switch Knob Spacer	2.487
Lower Cont. Arm	6.168
Lower Cont. Arm Bolt	6.172
Lower Cont. Arm Bushing Seal	6.166
Lower Cont. Arm Grease Cup	6.168
Lower Cont. Arm Pivot Pin Pkg.	6.174
Lower Cont. Arm Shaft Bushing	6.169
Lower Cont. Arm Shaft Pkg.	6.170
Lubrication Fittings	8.984

M	
Main Bearing Drain Pipe (Rr.)	1.565
Main Bearings	0.096-0.106
Main Wire Clamp & Fuse Holder	2.482
Manifold Clamp Washer	3.276
Manifold Cover (Exhaust)	3.602
Manifold Gasket Set	3.270
Manifold Gaskets	3.270

Name	Group No.
M	
Manifold Heat Control Valve	3.647
Manifold Heat Valve Air Tube	3.647
Manifold Heat Valve Bushing	3.646
Manifold Heat Valve Clip	3.641
Manifold Heat Valve Gasket	3.658
Manifold Heat Valve Plate-Stud	3.656
Manifold Heat Valve Spring	3.653
Manifold Heat Valve Therm.	3.640
Manifold Heat Valve Therm.	
Deflector	3.680
Manifold Intake—Exhaust	3.265-3.601
Manifold Stud	3.288
Master Cyl.	4.650
Master Cyl. Conn. Rod Clevis	4.662
Master Cyl. Frame Brkt.	7.056
Muffler Assy.	3.701
Muffler Bracket	3.704
Muffler Clamp	3.708
Muffler Support Strap	3.703
Muffler Tail Pipe	3.705
Muffler Tail Pipe Brkt.—Suppt.	3.706
Muffler to Tail Pipe Clamp	3.708
Muffler Tail Pipe Reinf. Plate	3.710

N	
Nuts	8.915 thru 8.925

O	
Oil Cleaner Assy.	1.660
Oil Cleaner Cover	1.660
Oil Cleaner Cup	1.663
Oil Cleaner Screen	1.656
Oil Cleaner Screen Cover	1.660
Oil Cleaner Screen Cover Spring	1.665
Oil Cleaner Screen Cover Washer	1.657
Oil Cleaner Screen Ret.	1.660
Oil Filler Cap	1.758
Oil Filler & Ventilator Inlet	1.760
Oil Filter Fittings	1.855
Oil Filter Gasket	1.844
Oil Filter Tube	1.853
Oil Gauge Pipe	1.729
Oil Gauge Pipe Clip	8.950
Oil Gauge Pipe Fittings	1.737
Oil Gauge Pipe Grommet	1.743
Oil Level Indicator Rod	1.516
Oil Pan	1.426
Oil Pan Drain Screw	1.453
Oil Pan Drain Screw Gasket	1.456
Oil Pan Gasket	1.429
Oil Pan Screen	1.656
Oil Press. Gauge	1.803
Oil Press. Gauge Pipe	1.729
Oil Press. Gauge Pipe Fittings	1.737
Oil Press. Reg. Ball	1.609
Oil Press. Reg. Gasket	1.604
Oil Press. Reg. Spring	1.610
Oil Press. Reg. Spring Ret.	1.613
Oil Pump Assy.	1.652
Oil Pump Body	1.653
Oil Pump Cover	1.723
Oil Pump Drive Gear	1.643
Oil Pump Drive Gear & Shaft	1.709
Oil Pump Driven Gear	1.659
Oil Pump Driven Gear Shaft	1.658
Oil Pump Gasket	1.655-1.724
Oil Screen Cover	1.660
Oil Screen Cover Packing	1.657
Oil Screen Ret.	1.660
Oil Suction Pipe	1.519
Oil Suction Pipe Gasket	1.520
Ornament, Hood Top Illum.	8.030

P	
Parking Lamp	2.585
Parking Lamp Parts	2.586 thru 2.628
Pedal Felt	9.039
Pedal Plate	9.038
Pedals	0.830-4.625
Pinion Bearings & Parts	5.447-5.484
Pins	8.938 thru 8.942

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.	Name	Group No.	Name	Group No.
P		S		S	
Pipe Clip	8.950	Safety Light Parts	9.773	Starter Pedal Button	2.012
Pipe Fittings	8.963	Set Screw	8.975	Starter Pedal Pad	2.020
Pipe Plug	8.971	Sheet Metal Plug	8.973	Starter Pedal Rod Guide	2.016
Piston Pin	0.636	Sheet Metal Screw	8.977	Starter Pedal Throttle Cracker Lever	3.430
Piston & Pin Assy.	0.629	Shock Absorber	7.345	Starting Crank Hole Cover	0.245
Piston Pin Bushing	0.613	Shk/Abs. Bolt—Nut	7.395	Starting Crank Nut Washer	0.662
Piston Pin Set Screw	0.639	Shk/Abs. Brkt. Assy.	7.364	Starting Motor & Parts	2.041 thru 2.113
Piston Pin Set Screw Lockwasher	0.640	Shk/Abs. Bushing	7.377	Starting Switch	2.100
Piston Ring	0.643	Shk/Abs. Fluid	6.386-7.377	Static Collector Parts	5.424-6.331-9.650
Pitman Arm (See Steering Gear)		Shk/Abs. Frame Brkt.	7.314	Strg. Arms	6.103-6.179
Planet Carrier Assy., Rear H.T.	4.177	Shk/Abs. Frame Spacer—Washer	7.397	Strg. Col. Bracket—Plate	6.750
Plug	8.970-8.971-8.973	Shk/Abs. Link	7.355	Strg. Col. Bracket Bolt	6.751
Power Steering Gear Parts	6.530-6.856	Shk/Abs. Pin	7.356	Strg. Col. Bracket Pad	6.758
Prop. Shaft	5.544	Shk/Abs. Shield	7.371	Strg. Col. Jacket	6.518
Prop. Shaft Bushing	5.552	Shroud Hood Ledge Lacing Clip—Ret.	9.128	Strg. Col. Housing Plug	6.519
Prop. Shaft Coupling & Gear	5.555	Sleeve, Ball	8.963	Strg. Col. & Pedal Plate Felt—Seal	9.039
Prop. Shaft Housing Gasket	5.560	Spare Wheel Clamp	7.629	Strg. Col. & Pedal Plate Ret. Screw	9.046
Prop. Shaft Packing Ret.	5.551	Spare Wheel Clamp Bolt	7.632	Strg. Col. Plate	9.038
Prop. Shaft Packing-Seal	5.550	Spare Wheel Clamp Bolt Nut	7.633	Strg. Col. Toe Board Collar	9.045
Prop. Shaft Snap Ring	5.545	Spare Wheel Lock Case (Rr.)	7.679	Strg. Col. & Toe Board Grommet	9.045
Prop. Shaft Splash Shield	5.556	Spare Wheel Lock Cyl. (Rr.)	7.680	Strg. Conn. Rod Ball Seat	6.874
Prop. Shaft to U/J Washer—Bolt	5.545	Spare Wheel Lock Plunger (Rr.)	7.680	Strg. Conn. Rod Ball Seat Spacer	6.883
R		Spark Plug	2.270	Strg. Conn. Rod Ball Seat Spacer Cover	6.883
Rad. Baffle—Upper	1.285	Spark Plug Gasket	2.271	Strg. Conn. Rod Dust Cover	6.886
Rad. Cap	1.203	Spark Plug Terminal Nipple	2.272	Strg. Conn. Rod Dust Cover Spring	6.888
Rad. Cap Sealing Washer	1.206	Spark Plug Wire	2.239	Strg. Conn. Rod End Plug	6.881
Rad. Center Panel	1.266	Spark Plug Wire Clamp	2.251	Strg. Conn. Rod Idler Arm Assy.	6.895
Rad. Center Panel Ret.	1.267	Spark Plug Wire Clamp Brkt.	2.251	Strg. Conn. Rod Idler Lever Brkt.	6.896
Rad. Core	1.219	Spark Plug Wire Manifold	2.251	Strg. Conn. Rod Idler Lever Bshg.	6.897
Rad. Drain Cock	1.229	Spark Plug Wire Manifold Cover	2.251	Strg. Conn. Rod Idler Lever Bshg. Oil Seal—Ret.	6.898
Rad. Drain Hose—Pipe	1.240	Speedo. Cable	4.342	Strg. Conn. Rod Safety Plug	6.882
Rad. & Eng. Suppt. Frame X Member	7.061	Speedo. Cable Clip	9.764	Strg. Conn. Rod Spring	6.876
Rad. to Fan Shroud	1.277	Speedo. Drive Gear	4.343	Strg. Conn. Rod or Tube	6.870
Rad. Grille	1.266	Speedo. Drive Gear Spacer	4.345	Strg. Conn. Rod Washer	6.885
Rad. Grille Bar-Blade	1.266	Speedo. Driven Gear & Shaft	4.337	Strg. Gear Adj. Plug Sleeve	6.830
Rad. Grille Clamp	1.273	Speedo. Head Assy.	4.339	Strg. Gear Bolt	6.509
Rad. Grille Emblem	1.303	Splash Apron	8.228	Strg. Gear Elbow	6.679
Rad. Grille Emblem Bezel—Plate	1.303	Splash Apron Frame Brace	8.230	Strg. Gear Elbow Bolt	6.679
Rad. Grille to Front Fender Support	1.268	Spring Assy. (Frt.)	7.412	Strg. Gear Elbow Seal	6.674
Rad. Grille Molding	1.268	Spring Assy. (Rr.)	7.503	Strg. Gear End Cover Brg.	6.826
Rad. Grille Name Plate	1.303	Spring Brkt. Bushing (Rr.)	7.524	Strg. Gear Flange Pivot Bolt	6.791
Rad. Grille Ornament	1.303	Spring Bumper (Rr.)	5.395	Strg. Gear Hose to Valve Union	6.673
Rad. Grille Plate	1.266	Spring Bumper Brkt.	7.421	Strg. Gear Hsg.	6.785-6.803
Rad. Grille Reinf.	1.268	Spring Bumper Ret. (Rr.)	5.394	Strg. Gear Hsg. Brg. Adapter (Upper)	6.519
Rad. Grille Ret.	1.266	Spring Bushing (Frt.)	7.413	Strg. Gear Hsg. End Plate—Cover	6.824
Rad. Grille Screw	1.269	Spring Bushing (Rr.)	7.504	Strg. Gear Hsg. End Plate Gasket—Packing	6.825
Rad. Grille Spinner	1.303	Spring Center Bolt	7.506	Strg. Gear Hsg. Side Plate	6.807
Rad. Hose	1.159	Spring Clip (Rr.)	7.516	Strg. Gear Hsg. Side Plate Gasket	6.809
Rad. Hose Clamp	1.166	Spring Clip Plate (Rr.)	7.518	Strg. Gear Lash Adj. Shim	6.828
Rad. Hose Spring	1.160	Spring Cover Pkg.	7.495	Strg. Gear Oil Hose Clip	6.671
Rad. Shell	1.263	Spring Front Bracket (Rr.)	7.112	Strg. Gear Oil Pressure Hose	6.670
Rad. Shell Hand Hole Cover	1.262	Spring Leaf Liner (Wood) (Rr.)	7.502	Strg. Gear Oil Pump Assy.	6.605
Rad. Shell to Hood Bumper	1.216	Spring Rear Brkt. (Rr.)	7.118	Strg. Gear Oil Pump Belt	6.660
Rad. Shell Support	1.264	Spring Retainers	8.934	Strg. Gear Oil Pump Body	6.608
Rad. Splash Apron	8.125	Spring Seat (Frt.)	7.418	Strg. Gear Oil Pump Body Cover	6.609
Rad. Support to Fender Baffle	1.272	Spring Seat Bolt	7.418	Strg. Gear Oil Pump Bracket	6.606
Rad. Supt. to Fender Baffle Welt	1.286	Spring Seat Ins. Bushing (Frt.)	7.422	Strg. Gear Oil Pump Brg. Ret. Ring	6.616
Rad. Support to Frame Spacer	8.156	Spring Seat Ins. Pad (Rr.)	7.545	Strg. Gear Oil Pump Control Valve	6.624
Rad. Support Frame Brkt.	7.061	Spring Seat Ins. Pad Bushing	7.547	Strg. Gear Oil Pump Drive Shaft	6.614
Rad. Tie Rod—Brace	1.309	Spring Seat Ins. Ret. (Rr.)	7.552	Strg. Gear Oil Pump Plate	6.612
Radio Antenna Parts	9.620 thru 9.647	Spring Shackle (Frt.)	7.436	Strg. Gear Oil Pump Pulley	6.655
Radio Assy.	9.649 thru 9.667	Spring Shackle (Rr.)	7.523	Strg. Gear Oil Pump Relief Valve	6.622
Radio Fuse	8.965-9.654	Spring Shackle Bolt (Frt.)	7.428	Strg. Gear Oil Pump Reservoir	6.635
Rear Axle (See Axle)		Spring Shackle Bolt (Rr.)	7.529	Strg. Gear Oil Pump Rotor	6.610
Rear Fender	8.203	Spring Shackle Bshg. Pkg. (Rr.)	7.504	Strg. Gear Oil Pump Rotor Ring	6.611
Rear Fender Door Parts	8.209	Spring Shackle Cork Washer (Frt.)	7.443	Strg. Gear Oil Pump Rotor Seal	6.611
Rear Fender Panel Shield	8.175	Spring Shackle Pin (Frt.)	7.427	Strg. Gear Oil Pump Shaft Brg.	6.615
Rear Fender Shield Seal (See Fender)	8.177	Spring U Bolt (Frt.)	7.417	Strg. Gear Oil Pump Shaft Seal	6.617
Rear License Lamp	2.700	Stab. Bar Bshg.	7.243	Strg. Gear Oil Pump Spring	6.612
Rear License Suppt. Bar—Brkt.	2.670	Stab. Bshg.—Ret.	7.244	Strg. Gear Oil Return Hose	6.671
Rear Wheel	5.803	Stab. Frame Brkt. (Frt.)	7.242	Strg. Gear Pitman Arm	6.859
Repair Kit—Safety Jack	8.820	Stab. Ins.—Bshg. (Frt.)	7.244	Strg. Gear Pitman Arm Nut	6.861
Rivets	8.967	Stab. Link Bolt Grommet Ret.	7.245	Strg. Gear Pitman Arm Pack. Ret.	6.856
Round Closed Gasket	8.955	Stab. Link Nut	7.238	Strg. Gear Pitman Shaft Bshg.	6.786
Rubber Hose Tubing	8.962	Stab. Link Pkg.—Spacer	7.240	Strg. Gear Pitman Shaft Hsg.	6.785
Running Board Assy.	8.299	Stab. Shaft	7.241	Strg. Gear Power Cyl.	6.576
Running Board Bolt	8.900-8.906	Standard Parts	8.899 thru 8.991	Strg. Gear Power Cyl. Adapter	6.584
Running Board Mldg.	8.304	Starter to G/Shift Neutralizer Lever	4.053	Strg. Gear Power Cyl. Gasket	6.577
Running Board Mldg. Ret.	8.309	Starter Mounting Bolt	2.041	Strg. Gear Power Cyl. Piston	6.578
Running Board Support	7.016	Starter Pedal	2.004		
		Starter Pedal Anti-Rattle Spring	2.010		

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.	Name	Group No.	Name	Group No.
S		T		T	
Strg. Gear Power Cyl. Piston Ring	6.579	Tail Lamp Lens	2.682-2.685	Trans. Cover Gasket	4.109
Strg. Gear Power Cyl. Piston Rod	6.580	Tail Lamp Lens Gasket	2.686	Trans. Floor Hole Cover Assy.	9.106
Strg. Gear Power Cyl. Rack	6.586	Tail Lamp Lens Ring	2.681	Trans. Fluid—Hydramatic	4.101
Strg. Gear Power Cyl. Rack Pin	6.587	Tail Lamp Ornament	2.680	Trans. Frt. Bearing	4.355
Strg. Gear Power Cyl. Rod-Nut-Washer	6.581	Tail Lamp Ornament Ret.	2.680	Trans. Frt. Brg. Washer	4.376
Strg. Gear Power Rack Cover Shim	6.591	Tail Lamp Pad	2.660	Trans. Frt. Brg. Oil Sling	4.374
Strg. Gear Power Rack Guide	6.590	Tail Lamp Reinf.	2.664	Trans. Frt. Brg. Ret.	4.356
Strg. Gear Power Rack Guide Cover	6.592	Tail Lamp Socket	2.694	Trans. Frt. Brg. Ret. Gasket	4.358
Strg. Gear Roller & Shaft	6.850	Tail Lamp Wire	2.646	Trans. Frt. Brg. Snap Ring	4.361
Strg. Gear Roller Shaft Packing	6.855	Tail Lamp Wire Clip	8.950	Trans. Frt. Clutch Drum Assy. H.T.	4.162
Strg. Gear Sector Adj. Screw	6.822	Tail Lamp Wire Connector	2.649	Trans. Frt. Drive Gear H.T.	4.158
Strg. Gear Sector Adj. Screw Nut	6.823	Tail Lamp Wire Sleeve	2.649	Trans. Frt. Drum Oil Delivery Sleeve Assy. H.T.	4.179
Strg. Gear Sector & Shaft	6.850	Tail Pipe	3.705	Trans. Frt. Oil Pump & Cover Assy. H.T.	4.226
Strg. Gear Shaft & Worm	6.524	Temperature, Water Gauge	1.148	Trans. Frt. Oil Pump Cover Gasket H.T.	4.124
Strg. Gear Thrust Bearing	6.530	Thermogauge Engine Unit	0.277	Trans. Frt. Oil Pump Cover Seal Assy. H.T.	4.125
Strg. Gear Thrust Bearing Race	6.527	Thermostat	1.246	Trans. Frt. Oil Pump Drive Gear Key H.T.	4.126
Strg. Gear Valve	6.550	Threaded Sleeve Elbow	8.963	Trans. Frt. Planet Carrier Assy. H.T.	4.161
Strg. Gear Valve Bleed Pipe	6.681	Threaded Sleeve Nipple	8.963	Trans. Frt. Pump Oil Inlet Pipe Assy. H.T.	4.222
Strg. Gear Valve Centering Plunger	6.551	Throttle Cont. Assy.	3.480	Trans. Frt. Servo H.T.	4.225 thru 4.234
Strg. Gear Valve Centering Spring	6.552	Throttle Cont. Idler Lever	3.450	Trans. Frt. Servo Exh. Body	4.265
Strg. Gear Valve Check Valve	6.553	Throttle Cont. Idler Lever Brkt.	3.455	Trans. Gasket Pkg. H.T.	4.100
Strg. Gear Valve Cover	6.554	Throttle Cont. Inter. Lever Brkt.	3.585	Trans. Gasket Set—S.T.	4.005
Strg. Gear Valve Cover Oil Seal	6.555	Throttle Cont. Lever	3.450	Trans. G/Shift Cont. Indicator Assy. H.T.	4.038
Strg. Gear Valve Housing Seal	6.556	Throttle Cont. Lever Assy. H.T.	3.454	Trans. G/Shift Cont. Indicator Cover & Lens	4.038
Strg. Gear Valve Oil Pipe	6.677-6.678	Throttle Cont. Return Spring Clip	3.465	Trans. G/Shift Cont. Lever H.T.	4.035
Strg. Gear Worm Ball	6.844	Throttle Cross Shaft w/Brkt.	3.585	Trans. G/Shift Cont. Lever Shaft Parts H.T.	4.039
Strg. Gear Worm Ball Clamp	6.843	Throttle Rod Anti-Rattle Spring	3.524	Trans. G/Shift Cont. Lower Lever Brkt.	4.018
Strg. Gear Worm Ball Guide	6.842	Tie Rod Adj. Sleeve	6.232	Trans. G/Shift Cont. Lower Relay Lever	4.040
Strg. Gear Worm Ball Nut	6.841	Tie Rod Assy.	6.230	Trans. G/Shift Cont. Lower Suppt. Bshg.—Cap	4.018
Strg. Gear Worm Screw	6.532	Tie Rod Ball Seat	6.241	Trans. G/Shift Cont. Rear Rod Parts	4.040
Strg. Gear Worm Seal	6.806	Tie Rod Bolt	6.235	Trans. G/Shift Cont. Rod Assy.	4.019
Strg. Inter. Arm	6.179	Tie Rod Dust Cover	6.111	Trans. G/Shift Cont. Rod Ball Seat	4.019
Strg. Inter. Arm Bshg.	6.181	Tie Rod Dust Cover Seal	6.111	Trans. G/Shift Control Rod Clevis	4.019
Strg. Inter. Arm Bshg. Sleeve	6.181	Tie Rod Dust Cover Spring	6.112	Trans. G/Shift Cont. Shaft Collar	4.021
Strg. Inter. Arm Frame Brkt.	6.186	Tie Rod End	6.233	Trans. G/Shift Cont. Shaft & Hsg. Assy.	4.039
Strg. Inter. Arm Pivot Bolt	6.187	Tie Rod End Clamp	6.234	Trans. G/Shift Cont. Shaft Lower Lever Bshg.	4.042
Strg. Inter. Arm Pivot Bolt Lock	6.188	Tie Rod End Plug	6.243	Trans. G/Shift Cont. Shaft Lower Seal—Washer	4.043
Strg. Inter. Arm Washer	6.180	Timing Chain	0.724	Trans. G/Shift Cont. Shaft Parts	4.017
Strg. Knuckle	6.020	Timing Hole Cover	0.714	Trans. G/Shift Cont. Shaft Upper Brkt. H.T.	4.038
Strg. Knuckle Bushing	6.021-6.024	Timing Indicator	0.219	Trans. G/Shift Cont. Suppt.	4.018
Strg. Knuckle Expansion Plug	6.223	Timing Sprocket Cover	0.206	Trans. G/Shift Cont. Upper Lever Boot—Cover	4.015
Strg. Knuckle Nut	6.022	Timing Sprocket Cover Bar	0.219	Trans. G/Shift Cont. Upper Lever Knob	4.035
Strg. Knuckle Spindle Washer	6.321	Timing Sprocket Cover Gskt.	0.207	Trans. G/Shift Cont. Upper Lever Parts	4.036
Strg. Knuckle Support	6.023	Timing Sprocket Cover Oil Seal	0.213	Trans. G/Shift Cont. Upper Suppt. Brg.	4.018
Strg. Knuckle Support Arm	6.178	Tire Valve Dust Cap	8.988	Trans. G/Shift Fork	4.303-4.304
Strg. Knuckle Suppt. Arm Bumper—Upper	6.176	Tire Valve Extension	5.875	Trans. G/Shift Lever Assy.	4.006
Strg. Knuckle Suppt. Arm Bumper—Lower	7.422	Toe Board Cover Plate	9.038	Trans. G/Shift Lever Cap—Cup	4.015-4.025
Strg. Knuckle to Support Bolt	5.002	Tool Kit	8.821	Trans. G/Shift Lever Fulcrum Spacer	4.028
Strg. Knuckle Support Bshg.	6.024	Tool Ret.—Hold Tools to Floor Pan	8.821	Trans. G/Shift Lever Knob	4.009
Strg. Knuckle Suppt. Bshg. Seal	6.166	Torus Assy. H.T.	4.121	Trans. G/Shift Lever Knob Washer	4.008
Strg. Knuckle Suppt. Clamp Bolt	6.018	Torus Check Valve—Ret.—Sprg.	4.121	Trans. G/Shift Lever Pivot Pin	4.025
Strg. Knuckle Suppt. Lower Arm	6.168	Torus Cover Assy.	4.118	Trans. G/Shift Lever Spring	4.047-4.026
Strg. Knuckle Suppt. Pivot Pin Pkg.	6.178	Torus Cover to Flywheel Gasket	4.119	Trans. G/Shift Lever Support Assy.	4.022
Strg. Knuckle Suppt. Upper Bshg. Seal	6.178	Trans. Assy.	4.003	Trans. G/Shift Low & Reverse Shift Fork	4.304
Strg. Knuckle Thrust Bearing	6.210	Trans. Brake Drum Assy. H.T.	4.169	Trans. G/Shift Low and Rev. Shift Shaft	4.309
Strg. Lash Adj. Sleeve	6.830	Trans. Breather Screw	4.104	Trans. G/Shift Lower Control Lever	4.041
Strg. Shaft Upper Brg.	6.521	Trans. Carrier Assy., Rr. Planet H.T.	4.177	Trans. G/Shift Second & High Shift Fork	4.303
Strg. Shaft Upper Brg. Spring—Seat	6.526	Trans. Case	4.103		
Strg. Wheel—Deluxe	6.513	Trans. Case Center Brg. Cap Lock Plate H.T.	4.131		
Strg. Wheel Hub Cover	6.512	Trans. Case Cover	4.105		
Strg. Wheel Nut	6.515	Trans. Case Oil Filler Sleeve	4.132		
Strg. Wheel Shaft Washer	6.515	Trans. Case Plug	4.103		
Stop Light Switch	2.447	Trans. Case Side Cover Gasket	4.109		
Stop Light Switch Screw	2.453	Trans. Clutch Annular Expander & Seal Pkg.	4.166		
Stop Light Wire Connector	2.649	Trans. Clutch Cont. Annular Piston H.T.	4.166		
Stud	8.981	Trans. Clutch Cont. Annular Piston H.T.	4.166		
Suspension Fluid (Frt.)	6.386	Trans. to Clutch Hsg. Gasket	4.005		
		Trans. Clutch Plate H.T.	4.163		
		Trans. Clutch Release Spring H.T.	4.164		
		Trans. Cont. Valve Lever Assy. H.T.	4.279		
		Trans. Counter Gear Brg. Ret. Washer	4.423		
		Trans. Ctr/Shaft	4.428		
		Trans. Ctr/Shaft Brg. Roller	4.422		
		Trans. Ctr/Shaft Gear Assy.	4.421		
		Trans. Ctr/Shaft Gear Bushing	4.422		
		Trans. Ctr/Shaft Gear Spacer	4.426		
		Trans. Ctr/Shaft Lock	4.429		
		Trans. Ctr/Shaft Spacer & Bshg.	4.422		
		Trans. Ctr/Shaft Washer	4.442		

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.	Name	Group No.	Name	Group No.
T		T		U	
Trans. G/Shift Second and High Shift Shaft.....	4.309	Trans. Reverse Anchor Retracting Spring H.T.....	4.295	Underhood & Trouble Light Assy.....	8.890
Trans. G/Shift Selector Cable Seal.....	4.043	Trans. Reverse Blocker Piston H.T.....	4.290	Underhood & Trouble Light Fuse.....	8.890
Trans. G/Shift Selector Cont. Cable Assy.....	4.020	Trans. Reverse Idler Gear.....	4.430	Underhood & Trouble Light Wire & Fuse Holder.....	8.890
Trans. G/Shift Selector Cont. Rod Assy.....	4.020	Trans. Reverse Idler Gear Bushing.....	4.431	U/J Assy.....	5.548
Trans. G/Shift Selector Control Lever.....	4.045	Trans. Reverse Idler Gear Shaft.....	4.433	U/J Bearing.....	5.566
Trans. G/Shift Selector Lever Pivot Pin.....	4.045	Trans. Reverse Idler Gear Thrust Washer.....	4.437	U/J Bearing Lock—Bolt.....	5.586
Trans. G/Shift Selector Rod—Cable Parts.....	4.021	Trans. Reverse Idler Shaft Lock Screw-Pin.....	4.435	U/J Bearing Ret. Ring—Plate.....	5.586
Trans. G/Shift Selector Rod Insulator.....	4.019	Trans. Reverse Internal Gear H.T.....	4.193	U/J Cork Washer Packing.....	5.560
Trans. G/Shift Shaft Assy.....	4.016	Trans. Reverse Internal Gear Suppt. H.T.....	4.194	U/J Dust Plug.....	5.557
Trans. G/Shift Strg. Col. Tube Assy.....	4.016	Trans. Reverse Shifter Crank Roller H.T.....	4.293	U/J Dust Shield.....	5.560
Trans. Gear Thrust Washer.....	4.398	Trans. Reverse Unit Center Gear H.T.....	4.190	U/J Flange.....	5.545
Trans. Gov. Assy. H.T.....	4.256	Trans. Reverse Unit Parts H.T.....	4.189	U/J Flange Bolt.....	5.546
Trans. Gov. Oil Delivery Sleeve H.T.....	4.255	Trans. Reverse Unit Planet Carrier Assy. H.T.....	4.192	U/J Flange Bolt Lock Plate.....	5.569
Trans. Gov. Oil Delivery Sleeve Plug H.T.....	4.255	Trans. Second & High Sleeve.....	4.414	U/J Flange to Pinion Nut.....	5.595
Trans. Gov. Plunger & Bshg. Assy. H.T.....	4.256	Trans. Second Speed Gear Oil Sleeve.....	4.335	U/J Flange to Prop. Shaft Pin.....	5.545
Trans. Inner Cont. Lever Pin, Seal & Washer Pkg. H.T.....	4.282	Trans. Second Speed Gear Thrust Washer.....	4.398	U/J Flange Spacer (Rear).....	5.549
Trans. Interlock Plate Ret.....	4.096	Trans. Selector Lever Shaft Oil Seal.....	4.302	U/J Repair Kit.....	5.548
Trans. Line Exhaust Valve—Retainer.....	4.106	Trans. Selector Lever Shaft Oil Seal Washer.....	4.302	U/J Ring Bolt.....	5.563
Trans. Low & Reverse Gear.....	4.417	Trans. Selector Shaft Lever.....	4.050	U/J Spider Journal.....	5.578
Trans. Main Drive Gear.....	4.351	Trans. Selector Shaft Lever Spring.....	4.047	U/J Yoke Pkg.....	5.555
Trans. Main Drive Gear Nut.....	4.375	Trans. Selector Shaft Lever Spring Yoke.....	4.048	U/J Yokes.....	5.555
Trans. Main Drive Gear Oil Seal.....	4.354	Trans. Selector Shaft Outer Lever.....	4.050	Upper Cont. Arm Bshg.....	6.178
Trans. Main Shaft.....	4.403	Trans. Selector Shaft Seal.....	4.313	Upper Cont. Arm Pivot Pin.....	6.178
Trans. Main Shaft Coupling Washer.....	4.404	Trans. Selector Shaft Shift Lever.....	4.314-4.315		
Trans. Main Shaft & Gear H.T.....	4.172	Trans. Selector Shift Shaft.....	4.301		
Trans. Main Shaft Parts.....	4.173	Trans. Servo Band Adj. Screw.....	4.253		
Trans. Main Shaft Pilot Brg.....	4.352	Trans. Servo Band & Lining H.T.....	4.251		
Trans. Main Shaft Pilot Brg. Spacer.....	4.353	Trans. Servo Release Cyl.....	4.225		
Trans. Main Shaft Rear Brg.....	4.408	Trans. Shift Bar.....	4.094		
Trans. Main Shaft 2nd Speed Gear.....	4.395	Trans. Shift Fork Poppet Spring—Ball.....	4.311		
Trans. Main Shaft Snap Ring.....	4.397	Trans. Shift Fork Screw.....	4.312		
Trans. Main Shaft Washer.....	4.404-4.406	Trans. Shift Interlock Plate.....	4.095		
Trans. Manual Cont. Shaft Seal H.T.....	4.282	Trans. Shift Lever H.T.....	4.152		
Trans. Name Plate.....	4.003	Trans. Shift Lever Spring.....	4.047		
Trans. Neutralizer Switch.....	4.054	Trans. Shift Lever Spring Ext.....	4.047		
Trans. Oil Cont. Valve Body H.T.....	4.265	Trans. Shift Lever Spring Yoke Suppt.....	4.048		
Trans. Oil Delivery Sleeve.....	4.179	Trans. Shift Lever to Trans. Screw.....	4.046		
Trans. Oil Level Indicator Assy. H.T.....	4.133	Trans. Shift Selector Cable.....	4.020		
Trans. Oil Pan Assy. H.T.....	4.195	Trans. Shift Selector Cont. Rod.....	4.020		
Trans. Oil Pan Gasket H.T.....	4.196	Trans. Shift Selector Inner Lever.....	4.302		
Trans. Oil Pipes H.T.....	4.248	Trans. Shift Selector Rod Plunger.....	4.021		
Trans. Oil Press. Reg. Valve H.T.....	4.216	Trans. Shift Shaft.....	4.309		
Trans. Oil Pump & Gov. Drive Gear H.T.....	4.210	Trans. Shift Shaft Assy. H.T.....	4.016		
Trans. Oil Pump & Gov. Driven Gear H.T.....	4.211	Trans. Shift Shaft Plug—Spring.....	4.017		
Trans. Oil Pump Inlet Pipe H.T.....	4.222	Trans. Shift Shaft Return Spring.....	4.017		
Trans. Oil Pump Inlet Pipe Gasket H.T.....	4.223	Trans. Shift Shaft Return Spring Clip.....	4.017		
Trans. Oil Screen Assy. H.T.....	4.224	Trans. Shift Shaft Return Spring Cup.....	4.017		
Trans. Oil Seal Ring H.T.....	4.127	Trans. Shifter Lever.....	4.046		
Trans. Outer Shift Lever.....	4.152	Trans. Sliding Sleeve.....	4.414		
Trans. Parking Brake Parts.....	4.290	Trans. Snap & Retaining Rings H.T.....	4.128		
Trans. Rear Brg. Oil Seal-Shield.....	4.335	Trans. Strg. Col. Shift Shaft.....	4.016		
Trans. Rear Brg. Ret.....	4.317	Trans. Synchro. Detent Spring.....	4.413		
Trans. Rear Brg. Ret. Gasket.....	4.318	Trans. Synchro. Drum.....	4.384		
Trans. Rear Brg. Shield.....	4.335	Trans. Synchro Drum Ret.....	4.383		
Trans. Rear Brg. Snap Ring.....	4.412	Trans. Throttle Cont. Lever H.T.....	4.286		
Trans. Rear Clutch Drum Assy. H.T.....	4.184	Trans. Throttle Rod Assy. H.T.....	4.040		
Trans. Rear Clutch Hub H.T.....	4.186	Trans. Throttle Rod Idler Lever Brkt. H.T.....	3.589		
Trans. Rear Drum H.T.....	4.187	Trans. Throttle Valve Inside Lever & Shaft H.T.....	4.278		
Trans. Rear Drum Rear Band Strut H.T.....	4.252	Trans. Thrust Washer H.T.....	4.129		
Trans. Rear Drum Rear Band Strut Pin H.T.....	4.254	Trouble Light Assy., Underhood.....	8.890		
Trans. Rear Oil Pump Assy. H.T.....	4.200	Tubing, Copper—Steel.....	8.964		
Trans. Rear Oil Pump Cover H.T.....	4.203	Tubing, Rubber.....	8.962		
Trans. Rear Oil Pump Gear Pkg. H.T.....	4.206				
Trans. Rear Oil Pump Gov. Drive Flange H.T.....	4.259				
Trans. Rear Servo H.T.....	4.236 thru 4.250				
Trans. Reverse Anchor H.T.....	4.294				

V	
Vacuum Cyl. Mtg. Bracket—Plate.....	4.898
Vacuum Cyl. Push Rod Pin.....	4.926
Vacuum Power Brake Clamp—Hose.....	4.931
Vacuum Power Brake Cyl. Assy.....	4.901
Vacuum Power Brake Pipe.....	4.930
Vacuum Power Brake Check Valve.....	4.955
Vacuum Reserve Tank.....	4.902
Valve & Body Assy. Air Vent.....	9.789
Valve Cover.....	0.439
Valve Cover Gasket.....	0.443
Valve Cover Screw.....	0.446
Valve Grind Gasket Set.....	0.289
Valve Guide.....	0.283-0.286
Valve Lifter.....	0.459
Valve Lifter Adj. Screw.....	0.476
Valve Spring.....	0.303
Valve Spring Cage.....	0.308
Valve Spring Cup.....	0.309
Valve Spring Cup Lock.....	0.310
Valve Spring Damper.....	0.309
Valve Spring Seat.....	0.309
Valves.....	0.296-0.297
Voltage Regulator.....	2.500

W	
Water Inlet Tube.....	1.135
Water Manifold Thermostat.....	1.246
Water Manifold Thermostat Ret.....	1.251
Water Outlet Elbow.....	1.153
Water Outlet Elbow Gasket.....	1.154
Water Pump Assy.....	1.069
Water Pump Body & Bolt.....	1.073
Water Pump Body Plate.....	1.113
Water Pump Bushing or Bearing.....	1.074
Water Pump Gasket.....	1.079-1.114
Water Pump Hub.....	1.363
Water Pump Impeller.....	1.109
Water Pump Packing.....	1.133
Water Pump Packing Nut.....	1.123
Water Pump Pulley.....	1.408
Water Pump Repair Kit.....	1.002
Water Pump Seal Pkg.....	1.123
Water Pump Seal Ret. Ring.....	1.121
Water Pump Shaft.....	1.003
Water Pump Shaft Ret.....	1.09
Water Temp. Dash Thermogage.....	1.148
Washers.....	8.927 thru 8.933
Wheel Front or (Rear).....	5.803
Wheel Assy.—Chassis.....	5.803
Wheel Balance Weight.....	6.36
Wheel Brg. (Front).....	6.31
Wheel Brg. (Rear).....	5.85

CHASSIS ALPHABETICAL INDEX—Continued

Name	Group No.	Name	Group No.	Name	Group No.
W		W		W	
Wheel Brg. Balls (Front).....	6.318 & 319	Wheel Hub Bolt Wrench.....	5.842	Wheel Wrench.....	5.842
Wheel Brg. Cone (Front).....	6.312	Wheel Hub Cap & Chip.....	5.320	W/W Washer Cowl Assy.....	8.719
Wheel Brg. Cup (Front).....	6.319	Wheel Hub Cap & Clip.....	6.320	W/W Washer Jar.....	8.780
Wheel Brg. Set (Front).....	6.318	Wheel Spindle Set (Front).....	6.323	W/W Washer Pump.....	8.787
Wheel Hub (Front).....	6.311	(See Toe Rod).....	6.384	Wire Hose.....	8.887
Wheel Hub (Front).....	6.311	Wheel Stud.....	5.815	Wire Wiper Pipe.....	2.668 & 850
Wheel Hub Bolt Kit.....	6.313	Wheel Trim Ring.....	5.809		
Wheel Nut (Steel).....	5.801	Wheel Weight.....	5.857		
Wheel Nut (Wire).....	5.802			Y	
Wheel Nut (Wire).....	5.804			Yoke, End.....	8.946
Wheel Rim (Steel).....	5.804				
Wheel Rim (Wire).....	5.805			Z	
Wheel Dust Cover.....	5.816			Zip Clip Kit.....	9.030
Wheel Dust Rotuimer.....	5.817				
Wheel House Frame Stop (Front).....	8.107				
Wheel Stud, Kit.....	5.815				
Wheel Hub Bolt Nut.....	5.813				

CHASSIS ILLUSTRATION INDEX

Name	Page No.	Name	Page No.
CHASSIS		BRAKES	
Chassis Assembly.....	33	Brake System—Complete.....	151-183
ENGINE		Rear Brake.....	183
Engine Assembly.....	34	Master Cylinder Repair Kit.....	142
Engine Gasket Sets.....	35	Brake Shoe Hold Down Package.....	184
Engine Supports.....	38	Hand Brake Levers.....	152
CLUTCH		Hand Brake Pull Rods.....	153
Clutch Controls.....	36	Power Brake Unit.....	154
Clutch and Flywheel.....	37	REAR AXLE	
Clutch Fork Packages.....	36	Prop. Shaft and U/Joint.....	184
COOLING AND OILING		U/Joint Repair Kits.....	185
Water Pump Assembly.....	57	Differential.....	186
Oil Pump Assembly.....	57	Rear Axle.....	186
GRILLE		FRONT SUSPENSION	
Radiator Grille—1947.....	58	Front Suspension—Complete.....	195
Radiator Grille—1949.....	58	Control Arm and Parts.....	196
Radiator Grille—1950.....	59	King Pin Repair Kit.....	197
Radiator Grille—1951.....	59	Front Shock Absorber.....	215
Radiator Grille—1953.....	60	Stabilizer Link Package.....	216
Radiator Grille—1954.....	60	REAR SUSPENSION	
ELECTRICAL		Rear Spring and Parts.....	215
Starting Motor.....	73	STEERING	
Generator.....	73	Steering Wheel.....	78
Distributor.....	74	Steering Control Linkage.....	197
Headlamp.....	75	Steering Gear (Conventional).....	198
Tail Lamp.....	75	Power Steering Gear.....	199
License Lamp.....	76	Power Steering Pump Unit.....	200
EXHAUST		BUMPER	
Exhaust System.....	107	Front Bumper (1946-48).....	217
FUEL AND CARBURETION		Front Bumper—1947.....	58
Carburetor (Carter).....	108-109-110	Front Bumper—1949.....	58
Carburetor (Rochester).....	111	Front Bumper—1950.....	59
Fuel Pumps.....	112-113	Front Bumper—1951.....	59
SYNCHRO-MESH TRANSMISSION		Wing Guards.....	216
Transmission Assembly.....	135	Master Guards.....	217-218
Gearshift Controls.....	136-137-138	HOOD	
Gearshift Control Bearing Package.....	141	Hood Assembly.....	233
Gearshift Control Insulator Package.....	141	Hood Ornament.....	236
Mainshaft Washer Package.....	142	ACCESSORIES	
Snap Ring Package.....	142	Radio and Antenna.....	266-267-268
HYDRAMATIC TRANSMISSION		Heater and Defroster.....	238-239
Gearshift Controls.....	139-140-141	Windshield Washers.....	237
Case and Covers.....	143	Direction Signal.....	78-79
Flywheel and Fluid Coupling.....	143	Back-Up Lights.....	76-77
Controls and Servo Units.....	144	Fog Lights.....	270
Front, Rear and Reverse Units.....	145	Safety Lights.....	269
Front Servo Unit.....	146	MISCELLANEOUS	
Rear Servo Unit.....	147	Instrument Panel Gauge Case.....	265
Front Pump.....	148	Front End Sheet Metal.....	234
Rear Pump and Governor.....	149	Door Rocker Panel.....	235
Reverse Unit.....	150	Fender Cap.....	235
Pressure Regulator.....	150	Rear Fender Shield.....	236

ACCESSORY SECTION

This Section lists only the *Accessory Packages*, available for the current Model; and should not be ordered on the same order with *Accessory Parts*.

Accessory Parts are listed in their regular Groups throughout the Catalog.

All *Accessory Packages*, except Seat Covers, should be ordered from the nearest *General Motors Parts Division Warehouse*.

Do Not send seat cover orders to G.M.P.D. Warehouses. Seat Cover orders will be shipped direct from source. Refer to seat cover order form for complete information.

ACCESSORY PACKAGES

GROUP	PART	DESCRIPTION	MODEL
11.561	984891	ADJUSTER , Front Seat (Comfort Control).....	1954
9.647	984808	ANTENNA , Radio—Std. 63".....	1953-1954
9.647	984809	ANTENNA , Radio—90".....	1953-1954
9.647	984831	ANTENNA , Motor Driven.....	1953-1954
2.459	984849	AUTRONIC-EYE , Automatic Headlamp Control.....	1953-1954
10.146	986882	BLADE , W/S Wiper (Arctic).....	1953-1954
4.898	984889	BRAKES , Power.....	1954
4.625	984904	ADAPTER , Power Brake (Use with 984889 on ST).....	1953-1954
3.402	984632	CLEANER , Air—8 Cyl.....	1953-1954
9.772	984882	CLOCK , Electric.....	1954
9.500	984674	COMPASS	1953-1954
3.712	984453	DEFLECTOR , Exhaust.....	1953-1954
8.891	984871	DISPENSER , Tissue.....	1953-1954
9.500	984752	FLARE , Reflector Type.....	All
9.777	984873	FRAME , License—less window.....	1953-1954
9.777	984874	WINDOW , License Frame.....	1953-1954
9.777	984875	WINDOW , License Frame.....	1953-1954
9.777	984876	WINDOW , License Frame.....	1953-1954
9.777	984877	WINDOW , License Frame.....	1953-1954
9.777	984878	WINDOW , License Frame.....	1953-1954
9.777	984879	WINDOW , License Frame.....	1953-1954
9.777	984880	WINDOW , License Frame.....	1953-1954
9.777	984881	WINDOW , License Frame.....	1953-1954
7.828	984899	GUARD , Bumper Master.....	1954
7.828	984746	GUARD , Bumper Wing—Front.....	1953-1954
7.828	984747	GUARD , Bumper Wing—Rear.....	1953-1954
10.352	986943	GUARD , Door Edge—2 Dr.....	1953-1954
10.352	986963	GUARD , Door Edge—4 Dr.....	1953-1954
10.536	986886	GUARD , Door Handle.....	1953-1954
8.845	984773	HEATER and DEFROSTER	1953-1954
8.845	984805	BLOWER and AIR TUBE	1953-1954
8.845	984449	DEFLECTOR , Air U/s Heater (Sedan Delivery).....	1949-1953
9.650	984819	PLATE , Instrument Panel Finish (Required when installing Radio & Heater).....	1953-1954
9.650	984828	PLATE , Instrument Panel Finish (Required when installing Heater only).....	1953-1954
9.500	984824	HOLDER , Purse (6 per unit) (Exc. Station Wagon).....	All
8.820	984578	JACK , Safti.....	All
9.500	984436	JUG , Portable (1 Gallon) (Order in multiples of three).....	All
12.009	984864	LAMP , Ash Tray and Floor.....	1953-1954
9.774	984861	LAMP , Auxiliary (pair).....	1954
2.697	984860	LAMP , Back-Up (Exc. Station Wagon).....	1954
2.697	984745	SWITCH , Back-Up Lamp (Use with 984830 & 984860 for S.T.).....	1953-1954
2.697	984830	LAMP , Back-Up (Station Wagon).....	1953-1954
10.275	984870	LAMP , Courtesy.....	1953-1954
10.275	984740	LAMP , Glove Compartment.....	1953-1954
9.773	986555	LAMP , Hand Spot Portable.....	1953-1954
9.998	984742	LAMP , Luggage Compartment—(25-27 Models).....	1953-1954
9.998	984896	LAMP , Luggage Compartment—(28 Models).....	1954
9.773	984812	LAMP , Safety and Bracket, LH (Exc. Station Wagon).....	1953-1954
9.773	984813	LAMP , Safety and Bracket, RH (Exc. Station Wagon).....	1953-1954
9.773	984814	LAMP , Safety and Bracket, LH (Station Wagon).....	1953-1954
8.890	984859	LAMP , Underhood and Trouble.....	1954
8.209	984673	LOCK , Fender Door.....	1953-1954
9.500	984646	MAGNATRAY (12 per part number).....	1953-1954
15.286	984836	MAT , Floor Throw—Black (Unit of 6).....	1953-1954
15.286	984837	MAT , Floor Throw—Blue (Unit of 6).....	1953-1954
15.286	984838	MAT , Floor Throw—Red (Unit of 6).....	1953-1954
15.286	984855	MAT , Floor Throw (Catalina Super Deluxe) (Unit of 6).....	1953-1954
15.286	984910	MAT , Floor Throw—Beige (Unit of 6).....	1954
15.286	984911	MAT , Floor Throw—Coral (Unit of 6).....	1954
15.286	984912	MAT , Floor Throw—Yellow (Unit of 6).....	1954
10.185	986692	MIRROR , Door Top.....	1949-1954
10.185	984801	MIRROR , O/S RV—RH (Exc. Convertible & Sedan Delivery).....	1953-1954
10.185	984802	MIRROR , O/S RV—LH (Exc. Convertible & Sedan Delivery).....	1953-1954
10.185	984825	MIRROR , RV Non-Glare Tilt.....	1953-1954
10.185	984856	MIRROR , Remote Controlled O/S RV—RH (Exc. Station Wagon).....	1953-1954
10.185	984857	MIRROR , Remote Controlled O/S RV—LH (Exc. Station Wagon).....	1953-1954

ACCESSORY PACKAGES — Continued

GROUP	PART	DESCRIPTION	MODEL
10.185	984858	MIRROR , Remote Controlled O/S RV—LH (Station Wagon).....	1953-1954
10.185	984174	MIRROR , Visor Vanity (Exc. Convertible & Catalina).....	1946-1954
10.185	984666	MIRROR , Visor Vanity (Convertible & Catalina).....	1950-1954
8.204	984800	NO MAR , Fuel Door Guard.....	1953-1954
8.030	984866	ORNAMENT , Hood—Illuminated.....	1954
4.630	984869	PAD , Wide Brake Pedal.....	1953-1954
4.630	984456	PEDAL EXTENSIONS	1949-1954
9.6F	984817	RADIO , Chieftain—8 Tubes.....	1953-1954
9.650	984818	PLATE , Instrument Panel Finish (Required when installing Radio only).....	1953-1954
9.650	984819	PLATE , Instrument Panel Finish (Required when installing Radio & Heater).....	1953-1954
9.500	984437	REFRIGERATOR , Portable (Order in multiples of three).....	All
8.780	984626	SCREEN , Radiator Insect.....	1953-1954
8.895	986418	SHAVER , Electric (Remington).....	All
8.175	984737	SHIELDS , Rear Fender.....	1953-1954
8.176	984840	MOLDING PACKAGE , Rear Fender Shields (Use with 984737 for Deluxe).....	1953-1954
4.589	984810	SIGNAL , Hand Brake.....	1953-1954
9.650	984820	SPEAKER , Rear Seat (Exc. Convertible).....	1953-1954
9.650	984907	SPEAKER , Rear Seat (28 Model).....	1954
9.500	984832	UMBRELLA , Folding—Nylon.....	All
9.500	984833	UMBRELLA , Folding—Rayon.....	All
9.500	984839	UMBRELLA , Package, Folding (2 Nylon, 4 Rayon and Display).....	All
9.694	986659	VENTISHADES —2 Dr.....	1953-1954
9.694	986662	VENTISHADES —4 Dr.....	1953-1954
9.694	984872	VENTISHADES (Catalina).....	1953-1954
10.200	984826	VIEWER , Traffic Light.....	1953-1954
10.203	984711	VISOR , O/S Sun and Viewer (Exc. Convertible & Station Wagon).....	1953-1954
10.203	984712	PLATE , Trim (Catalina).....	1953-1954
10.203	984718	PLATE , Trim (2 & 4 Drs.).....	1953-1954
10.203	984713	VISOR , O/S Sun and Viewer (Station Wagon)..... (Fits 1949-1952 Exc. Convertible & Sedan Delivery)	1953-1954
10.203	984451	PLATE , Trim (Station Wagon).....	1949-1954
10.203	984867	PLATE , Trim (2 & 4 Drs.).....	1949-1952
10.203	984717	PLATE , Trim (Catalina).....	1950-1952
8.798	984714	WASHER , Windshield.....	1953-1954
5.871	984895	WHEEL DISCS (Set of 4).....	1954
5.871	984868	WHEEL DISCS , Simulated Wire.....	1954
6.513	984806	WHEEL , Steering—Deluxe (See 984900).....	1953-1954
6.513	984900	WHEEL , Steering—Special (Station Wagon).....	1954
5.871	984357	WHEEL TRIM RINGS	1949-1954

MAINTENANCE ACCESSORIES

8.800	986042	ANTI-FREEZE FLUID , Wind. eld Washer (6 6-Oz. Bottles)
1.175	986952	ANTI-FREEZE , Ethylene Glycol (Case 6 1-Gal. Cans)
1.175	986953	ANTI-FREEZE , Ethylene Glycol (Case 24 Qt. Cans)
1.175	986954	ANTI-FREEZE , Methanol (Case 6 1-Gal. Cans)
1.175	986955	ANTI-FREEZE , Methanol (Case 24 Qt. Cans)
1.175	986956	ANTI-FREEZE , Methanol (1 54-Gal. Drum)
8.762	984788	BLUE CORAL POLISH (16 Oz. Bottle)
8.762	984789	BLUE CORAL SEALER (80 Gram Jar)
8.762	984790	BLUE CORAL SEALER (8 Oz. Can)
8.800	983715	CAROMA —(Card of 12)
8.800	985888	CLEANER , Wax & Polish Triple Action (1 Gal.)
8.800	986085	CLEANER , Wax & Polish Triple Action (12—16 Oz. Cans)
8.765	984664	CLEANER , Swaco White Sidewall (12—2 Lb. Cans)
8.765	984665	CLEANER , Swaco White Sidewall (4—1 Gal. Cans with brush)
8.800	986052	CLEANER , Cooling System (Unit of 12)
8.800	986077	CLOTH , Polish (12 Cloths)
8.777	984883	DYE , Leather—Black
8.777	984884	DYE , Leather—Beige
8.777	984885	DYE , Leather—Green
8.777	984886	DYE , Leather—Maroon
8.777	984759	ENAMEL , Air Dry Clear
8.761	984291	LUBRIPLATE
8.762	984784	LUSTUR-SEAL #1
8.762	984785	LUSTUR-SEAL #2

ACCESSORY PACKAGES — Continued

MAINTENANCE ACCESSORIES (Continued)

GROUP	PART	DESCRIPTION	MODEL
8.762	984786	LUSTUR-SEAL HAZE CREAM	
8.762	984793	LUSTUR-SEAL APPLICATOR & BUFF KIT	
8.762	984794	LUSTUR-SEAL APPLICATOR PACKAGE	
8.762	984795	LUSTUR-SEAL BUFFER PACKAGE	
8.762	984796	LUSTUR-SEAL BACKING PLATE	
8.800	986082	OIL , Dripless Penetrating	
8.777	984841	PAINT , Upholstery—Taupe	
8.777	984842	PAINT , Upholstery—Blue-Grey	
8.777	984843	PAINT , Upholstery—Light Brown	
8.762	984227	PORCELAINIZE WASH CREAM	
8.800	986363	PORCELAINIZE CLEANER	
8.762	984226	PORCELAINIZE LIQUID	
8.800	986047	RUGLYDE RUBBER LUBRICANT	
8.800	986086	RUST PREVENTIVE , Radiator	
8.800	986199	SEALZIT , Glass Sealer	
8.800	986087	STATIC-ELIMINATING POWDER	
8.800	986033	INJECTOR , Static-Eliminating Powder	
8.800	986088	STOP LEAK , Radiator	
8.777	984792	TIPON , Individual Duco Applicator	

USED CAR APPEARANCE RECONDITIONING KIT

8.777	984269	KIT , Used Car Appearance Reconditioning	
8.777	984256	ADHESIVE , Flock (1 Gallon)	
8.777	984258	ADHESIVE , All Purpose (1 Gallon)	
8.777	984259	BAK-O-CHROME (Kit)	
8.777	984253	CARPET , 3' x 12'	
8.777	984260	CHROME CLEANER (8 Oz.)	
8.777	984267	CLEANER , Upholstery (1 Gal.)	
8.777	984268	FLOCK , Grey (4 Lbs.)	
8.777	984292	FLOCK , White (2 Lbs.)	
8.777	984721	FLOCK , Goat Hair (4 Lbs.)	
8.777	984257	PAINT , Steering Wheel (4 Oz. Can)	
8.777	984722	PAINT , Blue Instrument Panel & Garnish Molding (8 Oz. Can)	
8.777	984723	PAINT , Brown Instrument Panel & Garnish Molding (8 Oz. Can)	
8.777	984724	PAINT , Mahogany Instrument Panel & Garnish Molding (8 Oz. Can)	
8.777	984261	PLASTIC DYE , Taupe (1 Qt.)	
8.777	984262	PLASTIC DYE , Brown (1 Qt.)	
8.777	984263	PLASTIC DYE , Black (1 Gal.)	
8.777	984254	PUTTY , Steering Wheel (4 Oz. Can)	
8.777	984725	RUBBER PATCH KIT	
8.777	984264	SPOTTER , Upholstery (16 Oz.)	
8.777	984265	TINT , Upholstery—Taupe (1 Qt.)	
8.777	984266	TINT , Upholstery—Blue (1 Qt.)	

UNDERCOATING

8.800	986359	GM UNDERCOATING —1 54-Gal. Drum	
8.800	*986635	GM UNDERCOATING —1 54-Gal. Drum	
		*Stocked only at Salt Lake City, Great Falls, Los Angeles, Oakland, and Portland.	
8.800	*986800	GM UNDERCOATING —1 54-Gal. Drum	
		*Stocked only at Long Island City and Bloomfield.	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 0.002 BOLT, ENGINE SUPPORT						
1937 thru 39	All	rear support insulator.....(Hex. $\frac{3}{8}$ "-24x $\frac{5}{8}$ ")	4	181629	-----	(8.900)
1937 thru 48	All	rear insulator to frame.....(Hex. $\frac{3}{8}$ "-24x $\frac{3}{4}$ ")	2	181635	-----	(8.900)
1937 thru 54	All	front support to engine.....(Hex. $\frac{7}{16}$ "-20x1")	2	181666	-----	(8.900)
1937 thru 54	All	front support to engine.....(Hex. $\frac{7}{16}$ "-14x2 $\frac{1}{2}$ ")	2	108609	-----	(8.900)
1939	P/8	front support to insulator.....(Hex. $\frac{7}{16}$ "-20x $\frac{3}{4}$ ")	2	181659	-----	(8.900)
1939-40	All	front insulator to frame.....(Fil. Hd. $\frac{1}{4}$ "-20x $\frac{3}{4}$ ")	1	132259	-----	(8.907)
1939 thru 48	All	engine front support.....(Hex. $\frac{3}{8}$ "-24x1 $\frac{1}{4}$ ")	2	181639	-----	(8.900)
1939 thru 48	All	front insulator to frame.....(Hex. $\frac{3}{8}$ "-24x $\frac{5}{8}$ ")	2	181636	-----	(8.900)
1940 thru 54	All	front support to insulator... (Spec. Hex. $\frac{7}{16}$ "-20x $\frac{1}{8}$ ")	2	509186	-----	
1948 thru 54	All H.T.	rear insulator to cross member.....(Hex. $\frac{7}{16}$ "-20x $\frac{1}{8}$ ")	4	509186	-----	
1940 thru 54	All	NUT , front support to insulator bolt.....($\frac{1}{16}$ "-20)	2	126022	-----	(8.917)
Group 0.004 PLATE, CYLINDER FRONT END						
1937 thru 54	All	1937 thru 47 use 6-145587 screw and 6-120395 washer.....	1	510309	-----	
1935 thru 54	All	BOLT , cylinder front end plate.....(Hex. $\frac{3}{8}$ "-16x $\frac{1}{4}$ ")	3	180121	-----	(8.900)
All	All	SCREW(Hex. $\frac{5}{16}$ "-18x $\frac{1}{2}$ ")	AR	145587	-----	(8.977)
1937-38	All	SUPPORT , cylinder front end plate.....	1	506998	-----	
1939-40	P/6	-----	1	506998	-----	
1940	P/8 29	-----	1	506998	-----	
1941 thru 54	All	-----	1	506998	-----	
Group 0.005 GASKET, CYLINDER FRONT END PLATE						
1933 thru 36	All	-----	1	495169	-----	
1937 thru 54	All	-----	1	499644	-----	
Group 0.027 INSULATOR, ENGINE SUPPORT						
1937 thru 39	All	-----Front	1	502408	-----	
1940 thru 54	All	-----Front	1	508748	-----	
1936	P/6	-----Intermediate	2	499296	-----	
1937-38	All	less bracket.....Rear	2	752676	-----	
1939 thru 54	All S.T.	(see note).....Rear R.H.	1	757472	-----	
1939 thru 54	All S.T.	(see note).....Rear L.H.	1	757471	-----	
1948 thru 54	All H.T.	-----Rear R.H.	1	510880	-----	
1948 thru 54	All H.T.	-----Rear L.H.	1	510881	-----	
1939	All	SEAT , engine front support insulator.....	1	501966	-----	
NOTE: Use 757471 and 757472 in sets on 1939 thru 49 models.						
Group 0.029 PLATE, ENGINE REAR SUPPORT						
1940 thru 54	All S.T.	insulator to frame.....	2	504992	-----	
1948 thru 54	All H.T.	to cross member reinf.....	2	510889	-----	
Group 0.030 CLAMP, ENGINE SUPPORT REBOUND						
1942	All	front support.....	1	508000	-----	
1946 thru 54	All	front support.....	1	508750	-----	
Group 0.033 BLOCK ASSEMBLY, CYLINDER						
NOTE: The following Cylinder Blocks are fitted with Pistons, Pins and Rings.						
1949 thru 52	P/6	-----	1	511912	-----	
1950 thru 52	P/8	-----	1	513908	-----	
1953-54	P/8	-----	1	517101	-----	
1953-54	P/6	-----	1	517303	-----	
Group 0.033 ENGINE ASSEMBLY, PARTIAL						
NOTE: The following Partial Engine Assemblies consist of Cylinder Blocks fitted with Pistons, Pins, Rings, Rods, Valves and Valve Parts, Camshaft, Crankshaft and Bearings. (Less Cylinder Head and Pan.)						
1937 thru 48	P/8	-----	1	513660	-----	
1937 thru 48	P/6	-----	1	517131	-----	
1949 thru 52	P/6	-----	1	517132	-----	
1949	P/8	-----	1	513661	-----	
1950 thru 54	P/8	-----	1	517107	-----	
1953-54	P/6	-----	1	517302	-----	
1953-54	P/6	BAFFLE , cylinder block valve chamber oil.....	9	517887	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.033 ENGINE ASSEMBLY, PARTIAL (Continued)					
1933 thru 48	All	COCK , cylinder block drain.....($\frac{1}{8}$ ")	1	120842	(8.951)
1949 thru 54	All	($\frac{1}{8}$ ")	1	134519	(8.951)
1933 thru 54	All	DOWEL PIN , cylinder block bottom flange oil hole.....($\frac{1}{2}$ "x $\frac{1}{2}$ ")	1	141275	(8.939)
1933 thru 46	All	PLUG , oil filter and camshaft bearing hole pipe.....($\frac{1}{8}$ " Sq. Hd.)	AR	103877	(8.971)
1933 thru 48	All	oil gallery side.....($\frac{1}{8}$ " Sq. Hd.)	AR	103877	(8.971)
1933 thru 49	All	cylinder block oil gallery pipe (end).....($\frac{1}{2}$ " Sq. Socket)	2	116566	(8.971)
1950-51	P/8		2	513512	
1936 thru 54	All	cylinder block core hole.....(1.952 O.D. cup type)	4	1330564	(1.146)
1940 thru 54	All	camshaft rear bearing hole.....($2\frac{1}{8}$ ")	1	172593	(8.970)
1952 thru 54	All	cylinder block oil gallery.....	2	444788	(5.400)

Group 0.033 CONVERSION PACKAGE, ENGINE					
1937 thru 39	P/6	-----	1	510427	-----
1937 thru 39	P/8	-----	1	513166	-----
1940	P/6	-----	1	510428	-----

Group 0.056 BOLT, CRANKSHAFT BEARING CAP					
1933 thru 38	All	----- Front or rear (Hex. Spec. $\frac{1}{2}$ "-13x2 $\frac{1}{2}$ ")	10-12	499515	-----
1939-40	P/8	----- Front or rear (Hex. Spec. $\frac{1}{2}$ "-13x2 $\frac{1}{2}$ ")	12	499515	-----
1939 thru 54	P/6	----- Rear (Hex. Spec. $\frac{9}{16}$ "-12x2 $\frac{1}{16}$ ")	2	501861	-----
1939 thru 51	P/6	----- All exc. Rear (Hex. $\frac{1}{2}$ "-13x2 $\frac{1}{16}$ ")	6	502143	-----
1941 thru 49	P/8	----- Front or rear (Hex. Hd. $\frac{1}{2}$ "-13x2 $\frac{1}{16}$ ")	12	502143	-----
1950 thru 54	P/8	----- All exc. rear (Hex. $\frac{1}{2}$ "-13x2 $\frac{1}{16}$ ")	8	513508	-----
1950 thru 54	P/8	----- Rear (Hex. $\frac{9}{16}$ "-12x2 $\frac{1}{16}$ ")	2	513509	-----
1952 thru 54	P/6	----- (Hex. $\frac{1}{2}$ "-13x2 $\frac{1}{16}$ ")	6	502143	-----

APPLICATION OF PARTIAL ENGINES ON 1937 THRU 1953 MODELS
AND ADDITIONAL PARTS REQUIRED FOR INSTALLATION

Part Name	Group No.	Part No.	1937 P/6 thru Engine No. 321922	1937 thru 39 P/6 After Engine No. 321922	1937-38 P/8	1939 P/8	1940 P/8	1940 P/6	1941 thru 48 P/6	1941-42 P/8	1946 thru 48 P/8	1949 P/8	1949 thru 52 P/6	1950 thru 52 P/8	1953-54 P/6	1953-54 P/8
Partial Engine	0.033	517131	1	1				1	1							
		517132											1			
		513660			1	1	1			1	1					
		513661										1				
		517107												1		1
		517302													1	
Flywheel	0.666	500944	1													
		510927			1	1	1		1							
Bolt	0.669	500946	6		6											
		508463				6	6			6						
Lockwasher	0.669	131101	6		6											
Fuel Pump	3.900	1523539			1	1	1									
		5592657	1	1				1	1				1			
Water Pump	1.069	514289			1	1	1			1	1					
Conversion Pkg.	0.033	510427	1	1												
		513166			1	1										
		510428						1								
Bearing	0.649	907109					1									
Indicator	1.516	515091	1	1	1	1	1	1	1	1	1		1	1		

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
------	-------	-----------	---------	----------	---------

PARTIAL ENGINE SERVICE PARTS

Partial Engine No. Year and Model	513807 P/6 1937-48	513809 P/6 1949-52	513660 P/8 1937-48	513661 P/8 1949	513662 P/8 1950-52
Crankshaft—Group 0.646	506176	506176	513513	513513	513513
Camshaft—Group 0.519	511261	511261	505175	505175	505175
Exh. Valve Stem Guide—Group 0.286	509041	509041	513511	513511	513511
Valve Spring—Group 0.303	499618	499618	513519	513519	513519
Valve Spring Cup—Group 0.309	499598	499598	513518	513518	513518
Valve Spring Damper—Group 0.309	---	---	408194	408194	408194
Valve Spring Seat—Group 0.309	---	---	513520	513520	513520
Crankshaft Rr. Brg.—Group 0.106	512957	512957	512957	512957	512957
Crankshaft Brg. Cap Oil Seal—Group 0.137	514251	514251	514251	514251	514251
Crankshaft Brg. Oil Seal Packing	501850	501850	501850	501850	501850

Group 0.060

RETAINER, CRANKSHAFT BEARING CAP BOLT

1935 thru 39	All exc. P/6 1939	-----Rear	2	497698	-----
1937 thru 39	All exc. P/6 1939	-----All exc. Rear	4	499577	-----

Group 0.093

PACKAGE, BEARING CLEARANCE CHECKING MATERIAL

NOTE: Package consists of 12 pieces of Plastigage Type PR-1 for checking bearing clearance within a range of .002 to .006.

All	All	-----	1	513599	-----
-----	-----	-------	---	--------	-------

CRANKSHAFT BEARING PACKAGES CHART

Each Part No. consists of 1 Upper and 1 Lower Brg.

Year	Model	Standard or Undersize	0.096 Front	0.099 Front Ctr.	0.101 Center	0.103 Rear Ctr.	0.106 Rear
1935-36	P/6	Standard	512945	512935		512931	
1935-36	P/8	Standard		512935			
1935-36	P/6	.001	512947	512949		512932	512948
1935-36	P/8	.001	512941	512949		512943	512944
1937-38	P/8	Standard	512958	512959	512960	512950	512962
1937-38	P/6	Standard	512958	512959		512950	512962
1937-38	P/8	.001	512969	512970	512971	512933	512973
1937-38	P/6	.001	512969	512970		512933	512973
1937-38	P/8	.002	512982	512984	512985	512978	512989
1937-38	P/6	.002	512982	512984		512978	512989
1939-40	P/8	Standard	512958	512959	512960	512950	512962
1939-40	P/6	Standard	512954	512955		512952	512957
1939-40	P/8	.001	512969	512970	512971	512933	512973
1939-40	P/6	.001	512965	512966		512953	512968
1939-40	P/8	.002	512982	512984	512985	512978	512989
1939-40	P/6	.002	512981	512983		512977	512988
1941 thru 49	P/8	Standard	512958	512959	512960	512961	512962
1941 thru 49	P/6	Standard	512954	512955		512956	512957
1941 thru 49	P/8	.001	512969	512970	512971	512972	512973
1941 thru 49	P/6	.001	512965	512966		512967	512968
1941 thru 49	P/8	.002	512982	512984	512985	512987	512989
1941 thru 49	P/6	.002	512981	512983		512986	512988
1950 thru 54	P/8	Standard	512958	512959	512960	512961	512957
1950 thru 54	P/6	Standard	512954	512955		512956	512957
1950 thru 54	P/8	.001	512969	512970	512971	512972	512968
1950 thru 54	P/6	.001	512965	512966		512967	512968
1950 thru 54	P/8	.002	512982	512984	512985	512987	512988
1950 thru 54	P/6	.002	512981	512983		512986	512988

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.096 BEARING PKG., CRANKSHAFT FRONT (1 Upper and 1 Lower)					
1937-38	All	standard.....	1	512958	-----
1939 thru 54	P/6	standard.....	1	512954	-----
1939 thru 54	P/8	standard.....	1	512958	-----
1935-36	P/6	.001 U.S.....	1	512947	-----
1935-36	P/8	.001 U.S.....	1	512941	-----
1937-38	All	.001 U.S.....	1	512969	-----
1939 thru 54	P/6	.001 U.S.....	1	512965	-----
1939 thru 54	P/8	.001 U.S.....	1	512969	-----
1937-38	All	.002 U.S.....	1	512982	-----
1939 thru 54	P/6	.002 U.S.....	1	512981	-----
1939 thru 54	P/8	.002 U.S.....	1	512982	-----
Group 0.099 BEARING PKG., CRANKSHAFT FRONT CENTER (1 Upper and 1 Lower)					
1935-36	All	standard.....	1	512935	-----
1937-38	All	standard.....	1	512959	-----
1939 thru 54	P/6	standard.....	1	512955	-----
1939 thru 54	P/8	standard.....	1	512959	-----
1935-36	All	.001 U.S.....	1	512949	-----
1937-38	All	.001 U.S.....	1	512970	-----
1939 thru 54	P/6	.001 U.S.....	1	512966	-----
1939 thru 54	P/8	.001 U.S.....	1	512970	-----
1937-38	All	.002 U.S.....	1	512984	-----
1939 thru 54	P/6	.002 U.S.....	1	512983	-----
1939 thru 54	P/8	.002 U.S.....	1	512984	-----
Group 0.101 BEARING PKG., CRANKSHAFT CENTER (1 Upper and 1 Lower)					
1937 thru 54	P/8	standard.....	1	512960	-----
1937 thru 54	P/8	.001 U.S.....	1	512971	-----
1937 thru 54	P/8	.002 U.S.....	1	512985	-----
Group 0.103 BEARING PKG., CRANKSHAFT REAR CENTER (1 Upper and 1 Lower)					
1935-36	P/6	standard.....	1	512931	-----
1937-38	All	standard.....	1	512950	-----
1939-40	P/6	standard.....	1	512952	-----
1939-40	P/8	standard.....	1	512950	-----
1941 thru 54	P/6	standard.....	1	512956	-----
1941 thru 54	P/8	standard.....	1	512961	-----
1935-36	P/6	.001 U.S.....	1	512932	-----
1935-36	P/8	.001 U.S.....	1	512943	-----
1937-38	All	.001 U.S.....	1	512933	-----
1939-40	P/6	.001 U.S.....	1	512953	-----
1939-40	P/8	.001 U.S.....	1	512933	-----
1941 thru 54	P/6	.001 U.S.....	1	512967	-----
1941 thru 54	P/8	.001 U.S.....	1	512972	-----
1937-38	All	.002 U.S.....	1	512978	-----
1939-40	P/6	.002 U.S.....	1	512977	-----
1939-40	P/8	.002 U.S.....	1	512978	-----
1941 thru 54	P/6	.002 U.S.....	1	512986	-----
1941 thru 54	P/8	.002 U.S.....	1	512987	-----
Group 0.106 BEARING PKG., CRANKSHAFT REAR (1 Upper and 1 Lower)					
1937-38	All	standard.....	1	512962	-----
1939 thru 54	P/6	standard.....	1	512957	-----
1939 thru 49	P/8	standard.....	1	512962	-----
1950 thru 54	P/8	standard.....	1	512957	-----
1935-36	P/6	.001 U.S.....	1	512948	-----
1935-36	P/8	.001 U.S.....	1	512944	-----
1937-38	All	.001 U.S.....	1	512973	-----
1939 thru 54	P/6	.001 U.S.....	1	512968	-----
1939 thru 49	P/8	.001 U.S.....	1	512973	-----
1950 thru 54	P/8	.001 U.S.....	1	512968	-----
1937-38	All	.002 U.S.....	1	512989	-----
1939 thru 54	P/6	.002 U.S.....	1	512988	-----
1939 thru 49	P/8	.002 U.S.....	1	512989	-----
1950 thru 54	P/8	.002 U.S.....	1	512988	-----
1936 thru 49	All exc. P/6	PLUG , crankshaft rear bearing cap			
1939 thru 49		(5/8" Expansion)	1	172529	(8.970)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 0.137 SEAL—PACKAGING, CRANKSHAFT BEARING CAP OIL						
1935 thru 50	All	beveled wooden wedge block.....	Rear 2	494754	-----	
1950 thru 54	All	tapered wooden wedge block.....	Rear 2	514251	-----	
1939 thru 54	P/6	PACKING , rear bearing oil seal.....	2	501850	-----	
1950 thru 54	P/8		2	501850	-----	
Group 0.206 COVER, TIMING SPROCKET						
1937 thru 54	P/8		1	499642	-----	
1937 thru 54	P/6		1	514546	-----	
1935 thru 54	All	BOLT , timing cover..... (Hex. $\frac{3}{8}$ "-16x $\frac{1}{8}$ ")	1	180121	-----	(8.900)
1935 thru 54	All	SCREW (Hex. $\frac{5}{16}$ "-18x $\frac{1}{2}$ ")	6	145587	-----	(8.977)
Group 0.207 GASKET SET, TIMING SPROCKET COVER						
1933 thru 54	All	contains 1 R.H. and 1 L.H.....	1	510410	-----	
Group 0.213 SEAL, TIMING COVER OIL						
1933 thru 54	All		1	492085	-----	
Group 0.219 BAR, TIMING SPROCKET COVER						
1933 thru 54	All		1	499641	-----	
1933 thru 54	All	BOLT , timing cover bar..... (Hex. $\frac{7}{16}$ "-14x2 $\frac{1}{8}$ ")	2	108609	-----	(8.900)
1949 thru 54	All	INDICATOR , ignition timing.....	1	511500	-----	
Group 0.245 COVER, STARTING CRANK HOLE						
1938	All		1	501201	-----	
Group 0.253 PLUG, CYLINDER HEAD						
1948 thru 54	All	core hole..... (cup type 1 $\frac{1}{4}$ " dia.)	1	410845	-----	
Group 0.269 HEAD, CYLINDER						
1937 thru 40	P/6	6.5 ratio.....	1	503571	-----	
1937 thru 49	P/8	7.5 ratio.....	1	506311	-----	
1937 thru 49	P/8	6.5 ratio.....	1	505176	-----	
1940	P/6	7.2 ratio.....	1	503968	-----	
1941 thru 51	P/6	6.5 ratio.....	1	505213	-----	
1941 thru 51	P/6	7.5 ratio.....	1	506310	-----	
1950 thru 54	P/8	6.8 ratio.....	1	514364	-----	
1950-51	P/8	7.5 ratio.....	1	513824	-----	
1952	P/6	6.8 ratio.....	1	514367	-----	
1952	P/6	7.7 ratio.....	1	516340	-----	
1952 thru 54	P/8	7.7 ratio.....	1	514369	-----	
1953-54	P/6	7.0 ratio.....	1	517261	-----	
1953-54	P/6	7.7 ratio.....	1	517290	-----	
Group 0.277 FITTING, HEAT INDICATOR TO MOTOR						
1933 thru 38	All		1	597630	-----	
1953-54	All		1	515385	-----	
1939 thru 52	All	THERMOGAGE UNIT , engine electric.....	1	1512015	-----	
1953-54	All	w/tube and inst. panel gage.....	1	1512458	-----	(1.148)
Group 0.283 GUIDE, INTAKE VALVE STEM						
1933 thru 54	All		6-8	513510	-----	
Group 0.286 GUIDE, EXHAUST VALVE STEM						
1933 thru 49	All		6-8	509041	-----	
1950 thru 54	P/6		6	509041	-----	
1950 thru 54	P/8		8	513511	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.289 GASKET, CYLINDER HEAD					
1933 thru 49	P/8	standard.....	Steel 1	501397	-----
1935 thru 54	P/6		Steel 1	514366	-----
1950 thru 54	P/8	standard.....	Steel 1	513791	-----
Group 0.289 GASKET SET, ENGINE OVERHAUL					
NOTE: The gasket sets listed in this group consist of the following gaskets: cyl. hd., valve cover, water outlet, oil pan set, manifold set, exhaust pipe flange, timing cover, rear bearing cap oil seal, front end plate, water pump to block, oil pump to block, fuel pump to block, dist. to block, carb. to manifold, intake to exhaust manifold, spark plug and valve cover screw gaskets.					
1935-36	P/6	use 1—495169 Gr. 0.005, 1—494949 Gr. 1.079 and 1—497652 Gr. 3.932 with this set	1	514253	-----
1937 thru 52	P/6		1	514253	-----
1937 thru 49	P/8		1	517123	-----
1950 thru 52	P/8		1	514254	-----
1953-54	P/6		1	517121	-----
1953-54	P/8		1	517122	-----
Group 0.289 GASKET SET, VALVE GRIND					
NOTE: The gasket sets listed in this group consist of 1 cyl. hd., 2 valve covers, 1 water outlet, 1 intake and exhaust manifold set, and 1 exhaust pipe flange gasket.					
1935 thru 54	P/6		1	514252	-----
1934 thru 49	P/8		1	510353	-----
1950 thru 54	P/8		1	513890	-----
Group 0.293 BOLT, CYLINDER HEAD					
1933 thru 54	All	 (Hex. $\frac{7}{16}$ "-14x2 $\frac{11}{16}$ ")	AR	486193	-----
1935 thru 54	All	with stud on head..... ($\frac{3}{8}$ "-24x $\frac{9}{16}$ "- $\frac{7}{16}$ "-14x2 $\frac{11}{16}$ ")	AR	489409	-----
Group 0.296 VALVE, INTAKE					
1933 thru 36	P/8	stem slotted for 1 piece key.....	8	494933	-----
1935-36	P/6	stem slotted for 1 piece key.....	6	497092	-----
1937 thru 54	P/8	stem grooved for 2 piece key.....	8	499608	-----
1937 thru 54	P/6	stem grooved for 2 piece key.....	6	499610	-----
Group 0.297 VALVE, EXHAUST					
1933 thru 36	P/8	stem slotted for 1 piece key.....	8	494934	-----
1935-36	P/6	stem slotted for 1 piece key.....	6	497091	-----
1937 thru 54	P/8	stem grooved for 2 piece key.....	8	499609	-----
1937 thru 54	P/6	stem grooved for 2 piece key.....	6	499611	-----
Group 0.303 SPRING, VALVE					
1937 thru 49	All		12-16	499618	-----
1950 thru 54	P/6		12	499618	-----
1950 thru 54	P/8		16	513519	-----
Group 0.308 CAGE, VALVE SPRING					
1933 thru 49	All		12-16	526795	-----
1950 thru 54	P/6		12	526795	-----
Group 0.309 CUP, VALVE SPRING					
1933 thru 36	All		12-16	836117	-----
1937 thru 49	All		12-16	499598	-----
1950 thru 54	P/6		12	499598	-----
1950 thru 54	P/8		16	513518	-----
1950 thru 54	P/8	DAMPER , valve spring.....	16	408194	-----
1950 thru 54	P/8	SEAT , valve spring upper.....	16	513520	-----
Group 0.310 LOCK, VALVE SPRING CUP					
1933 thru 36	All	key—1 piece type.....	12-16	836120	-----
1937 thru 54	All	2 piece type.....	24-32	499599	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 0.439 COVER, ENGINE VALVE						
1937 thru 39	P/8	 Front	1	499612	-----	
1940 thru 54	P/6	 Front	1	503544	-----	
1940 thru 54	P/6	 Rear	1	503546	-----	
1940 thru 54	P/8	 Front	1	503545	-----	
1940 thru 54	P/8	 Rear	1	503547	-----	
Group 0.443 GASKET, ENGINE VALVE COVER						
1933 thru 54	P/8		2	494872	-----	
1935 thru 54	P/6		2	497544	-----	
Group 0.446 SCREW, ENGINE VALVE COVER						
1936 thru 54	All	 (Hex. $\frac{5}{16}$ "-18NCx $3\frac{7}{8}$ ")	4	513564	-----	
1933 thru 54	All	GASKET, engine valve cover screw..... ($\frac{5}{16}$ " I.D.)	4	114622	-----	(8.955)
Group 0.459 LIFTER, VALVE						
1933 thru 54	All	less adjusting screw (Std.).....	12-16	505633	-----	
1936 thru 54	All	.005 O.S.....	12-16	495624	-----	
Group 0.476 SCREW, VALVE LIFTER ADJUSTING						
1933 thru 54	All	 (Hex. $\frac{3}{8}$ "-24x $\frac{29}{32}$ ")	12-16	392167	-----	
1935 thru 54	All	NUT, valve lifter adjusting screw check. (Hex. $\frac{3}{8}$ "-24)	12-16	124925	-----	(8.916)
Group 0.519 CAMSHAFT, ENGINE						
1937 thru 40	P/8		1	499603	-----	
1937 thru 48	P/6		1	502130	-----	
1949 thru 52	P/6		1	511261	-----	
1941 thru 54	P/8		1	505175	-----	
1953-54	P/6		1	517283	-----	
Group 0.533 PLATE, CAMSHAFT THRUST						
1937 thru 54	All		1	499601	-----	
1933 thru 54	All	BOLT, camshaft thrust plate..... (Hex. $\frac{5}{16}$ "-18x $\frac{3}{4}$ ")	AR	180077	-----	(8.900)
Group 0.539 BEARING, CAMSHAFT FRONT						
1933 thru 54	All		1	494877	-----	
Group 0.543 BEARING, CAMSHAFT CENTER AND FRONT CENTER						
1933 thru 54	P/8	 Center	1	494879	-----	
1933 thru 54	All	 Front center	1	494878	-----	
Group 0.546 BEARING, CAMSHAFT REAR CENTER						
1933 thru 54	P/8		1	494880	-----	
1935 thru 54	P/6		1	494879	-----	(0.543)
Group 0.549 BEARING, CAMSHAFT REAR						
1933 thru 54	P/8		1	494881	-----	
1935 thru 54	P/6		1	494880	-----	(0.546)
Group 0.603 ROD ASSEMBLY, CONNECTING						
1936	P/8	less bearing.....	8	498805	-----	
1937 thru 54	P/8	less bearing.....	8	499625	-----	
1937-38	P/6	less bearing.....	6	499635	-----	
1939 thru 52	P/6	less bearing.....	6	502129	-----	
1953-54	P/6	less bearing.....	6	517270	-----	
Group 0.613 BUSHING, PISTON PIN						
1933 thru 54	P/8		16	505321	-----	
1935 thru 54	P/6		12	505320	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.616 BEARING PKG., CONNECTING ROD (1 Upper and 1 Lower)					
NOTE: When installing grooveless connecting rod bearings on 1933 thru 35 models, also use 1 each 498820 Group 1.613 and 498821 Group 1.610.					
1935-36	P/6	standard.....	6	512937	-----
1937-38	P/6	standard.....	6	512951	-----
1937 thru 54	P/8	standard.....	8	512964	-----
1939 thru 52	P/6	standard.....	6	512963	-----
1953-54	P/6	standard.....	6	517341	-----
1933 thru 36	P/8	.001 U.S.....	8	512938	-----
1935-36	P/6	.001 U.S.....	6	512939	-----
1937-38	P/6	.001 U.S.....	6	512934	-----
1937 thru 54	P/8	.001 U.S.....	8	512975	-----
1939 thru 52	P/6	.001 U.S.....	6	512974	-----
1953-54	P/6	.001 U.S.....	6	517329	-----
1937 thru 54	P/8	.002 U.S.....	8	512980	-----
1939 thru 52	P/6	.002 U.S.....	6	512979	-----
1953-54	P/6	.002 U.S.....	6	517332	-----
Group 0.616 BEARING PACKAGE, CONNECTING ROD (COMPLETE)					
NOTE: Bearing package consists of 12 bearings for P/6 and 16 bearings for P/8.					
1937-38	P/6	standard.....	1	513307	-----
1939 thru 52	P/6	standard.....	1	513308	-----
1953-54	P/6	standard.....	1	517376	-----
1937-38	P/6	.001 U.S.....	1	513310	-----
1937 thru 54	P/8	.001 U.S.....	1	513317	-----
1939 thru 52	P/6	.001 U.S.....	1	513311	-----
1953-54	P/6	.001 U.S.....	1	517330	-----
1937-38	P/6	.002 U.S.....	1	513312	-----
1937 thru 54	P/8	.002 U.S.....	1	513318	-----
1939 thru 52	P/6	.002 U.S.....	1	513313	-----
1953-54	P/6	.002 U.S.....	1	517333	-----
Group 0.623 BOLT AND NUT, CONNECTING ROD					
1937-38	All	-----	12-16	510360	-----
1939 thru 54	P 8	-----	16	510360	-----
1939 thru 54	P 6	-----	12	510359	-----
Group 0.626 NUT, CONNECTING ROD BOLT					
1936 thru 39	All	----- (Hex. Slotted $\frac{25}{64}$ "-24)	AR	499182	-----
1940 thru 54	All	----- (Self Locking $\frac{25}{64}$ "-24)	12-16	503908	-----
Group 0.629 PISTON AND PIN					
1939-40	P/6	3.437 Standard.....	6	503047	-----
1939 thru 49	P/8	3.247 Standard.....	8	503048	-----
1939 thru 49	P/8	3.248 Standard.....	8	503049	-----
1939 thru 49	P/8	3.249 Standard.....	8	503050	-----
1941 thru 52	P/6	3.561 Standard (see note 1).....	6	507554	-----
1941 thru 52	P/6	3.562 Standard (see note 1).....	6	507555	-----
1941 thru 52	P/6	3.563 Standard (see note 1).....	6	507556	-----
1950 thru 52	P/8	3.373 Standard (see note 1).....	8	513884	-----
1950 thru 52	P/8	3.374 Standard (see note 1).....	8	513885	-----
1950 thru 52	P/8	3.375 Standard (see note 1).....	8	513886	-----
1952	P/6	3.561 Standard (see note 2).....	6	516684	-----
1952	P/6	3.562 Standard (see note 2).....	6	516685	-----
1952	P/6	3.563 Standard (see note 2).....	6	516686	-----
1952 thru 54	P/8	3.373 Standard (see note 2).....	8	516687	-----
1952 thru 54	P/8	3.374 Standard (see note 2).....	8	516688	-----
1952 thru 54	P/8	3.375 Standard (see note 2).....	8	516689	-----
1953-54	P/6	3.562 Standard.....	6	517828	-----
1953-54	P/6	3.563 Standard.....	6	517829	-----
1953-54	P/6	3.564 Standard.....	6	517830	-----
1939 thru 49	P/8	.005 O.S.....	8	503008	-----
1941 thru 52	P/6	.005 O.S. (see note 1).....	6	507546	-----
1950 thru 52	P/8	.005 O.S. (see note 1).....	8	513876	-----
1952	P/6	.005 O.S. (see note 2).....	6	516668	-----
1952 thru 54	P/8	.005 O.S. (see note 2).....	8	516676	-----
1953-54	P/6	.005 O.S.....	6	517832	-----
1939 thru 49	P/8	.010 O.S.....	8	503009	-----
1941 thru 52	P/6	.010 O.S. (see note 1).....	6	507547	-----
1950 thru 52	P/8	.010 O.S. (see note 1).....	8	513877	-----
1952	P/6	.010 O.S. (see note 2).....	6	516669	-----
1952 thru 54	P/8	.010 O.S. (see note 2).....	8	516677	-----
1953-54	P/6	.010 O.S.....	6	517822	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.629 PISTON AND PIN (Continued)					
1937-38	P/6	.020 O.S.	6	492173	-----
1939 thru 49	P/8	.020 O.S.	8	503010	-----
1941 thru 52	P/6	.020 O.S. (see note 1)	6	507548	-----
1950 thru 52	P/8	.020 O.S. (see note 1)	8	513878	-----
1952	P/6	.020 O.S. (see note 2)	6	516670	-----
1952 thru 54	P/8	.020 O.S. (see note 2)	8	516678	-----
1953-54	P/6	.020 O.S.	6	517823	-----
1937-38	P/6	.030 O.S.	6	492174	-----
1939-40	P/6	.030 O.S.	6	503019	-----
1939 thru 49	P/8	.030 O.S.	8	503011	-----
1941 thru 52	P/6	.030 O.S. (see note 1)	6	507549	-----
1950 thru 52	P/8	.030 O.S. (see note 1)	8	513879	-----
1952	P/6	.030 O.S. (see note 2)	6	516671	-----
1952 thru 54	P/8	.030 O.S. (see note 2)	8	516679	-----
1953-54	P/6	.030 O.S.	6	517824	-----
NOTE 1: Uses set screw type pin retainer.					
NOTE 2: Uses ring type pin retainer.					
Group 0.636 PIN, PISTON					
1933 thru 52	P/8	Standard (see note 1)	8	494998	-----
1935 thru 52	P/6	Standard (see note 1)	6	507517	-----
1952 thru 54	P/6	Standard (see note 2)	6	514530	-----
1952 thru 54	P/8	Standard (see note 2)	8	514531	-----
1933 thru 52	P/8	.001 O.S. Red and Brown (see note 1)	8	495620	-----
1935 thru 52	P/6	.001 O.S. Red and Brown (see note 1)	6	507543	-----
1952 thru 54	P/6	.001 O.S. Green (see note 2)	6	516690	-----
1952 thru 54	P/8	.001 O.S. Green (see note 2)	8	516693	-----
1933 thru 52	P/8	.003 O.S. Red (see note 1)	8	495621	-----
1935 thru 52	P/6	.003 O.S. Red (see note 1)	6	507544	-----
1952 thru 54	P/6	.003 O.S. Red (see note 2)	6	516691	-----
1952 thru 54	P/8	.003 O.S. Red (see note 2)	8	516694	-----
1933 thru 52	P/8	.005 O.S. Blue (see note 1)	8	495622	-----
1935 thru 52	P/6	.005 O.S. Blue (see note 1)	6	507545	-----
1952 thru 54	P/6	.005 O.S. Blue (see note 2)	6	516692	-----
1952 thru 54	P/8	.005 O.S. Blue (see note 2)	8	516695	-----
NOTE 1: Uses piston pin set screw.					
NOTE 2: Uses piston pin retainer ring.					
Group 0.639 SCREW, PISTON PIN SET					
1932 thru 52	All	(see note 1)	AR	505319	-----
1952 thru 54	All	RING, piston pin retainer (see note 2)	12-16	514977	-----
NOTE 1: Use with set screw type piston and pin.					
NOTE 2: Use with retainer ring type piston and pin.					
Group 0.640 WASHER, PISTON PIN SET SCREW LOCK					
1932 thru 48	All	(²⁶ / ₆₄ " I.D. x ³³ / ₆₄ " O.D.)	AR	487462	-----
Group 0.643 RING, PISTON					
SIZE CHART					
		Type	Diameter Width		
1932	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1933 thru 35	P/8	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	24	
1935	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	18	
1936	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1936 thru 38	P/8	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	16	
1937-38	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1939-40	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1939 thru 49	P/8	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	16	
1941 thru 52	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1950 thru 54	P/8	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	16	
1953-54	P/6	Compression	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	12	
1932	P/6	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	6	
1933 thru 35	P/8	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	8	
1933 thru 35	P/8	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	8	
1935	P/6	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	6	
1936	P/6	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	6	
1936 thru 49	P/8	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	8	
1937 thru 40	P/6	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	6	
1941 thru 54	P/6	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	6	
1950 thru 54	P/8	Oil	3 ⁵ / ₁₆ " x 1 ¹ / ₈ "	8	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.643 RING, PISTON (Continued)					
1939 thru 49	P/8	Compression, Standard.....	16	502816	-----
1941 thru 52	P/6	Compression, Standard.....	12	508007	-----
1950 thru 54	P/8	Compression, Standard.....	16	513572	-----
1953-54	P/6	Compression, Standard—upper.....	6	517266	-----
1953-54	P/6	Compression, Standard—lower.....	6	517267	-----
1939 thru 49	P/8	Compression, .005 O.S.....	16	503028	-----
1950 thru 54	P/8	Compression, .005 O.S.....	16	513892	-----
1941 thru 52	P/6	Compression, .005 O.S.....	12	506776	-----
1953-54	P/6	Compression, .005 O.S.—upper.....	6	517835	-----
1953-54	P/6	Compression, .005 O.S.—lower.....	6	517836	-----
1939 thru 49	P/8	Compression, .010 O.S.....	16	503029	-----
1941 thru 52	P/6	Compression, .010 O.S.....	12	506777	-----
1950 thru 54	P/8	Compression, .010 O.S.....	16	513893	-----
1953-54	P/6	Compression, .010 O.S.—upper.....	6	517364	-----
1953-54	P/6	Compression, .010 O.S.—lower.....	6	517367	-----
1939 thru 49	P/8	Compression, .020 O.S.....	16	503030	-----
1941 thru 52	P/6	Compression, .020 O.S.....	12	506778	-----
1950 thru 54	P/8	Compression, .020 O.S.....	16	513894	-----
1953-54	P/6	Compression, .020 O.S.—upper.....	6	517365	-----
1953-54	P/6	Compression, .020 O.S.—lower.....	6	517368	-----
1939 thru 49	P/8	Compression, .030 O.S.....	16	503031	-----
1941 thru 52	P/6	Compression, .030 O.S.....	12	506779	-----
1950 thru 54	P/8	Compression, .030 O.S.....	16	513895	-----
1953-54	P/6	Compression, .030 O.S.—upper.....	6	517366	-----
1953-54	P/6	Compression, .030 O.S.—lower.....	6	517369	-----
1941 thru 52	P/6	Oil, Standard.....	6	508008	-----
1946 thru 49	P/8	Oil, Standard.....	8	498824	-----
1950 thru 54	P/8	Oil, Standard.....	8	513573	-----
1936 thru 49	P/8	Oil, .005 O.S.....	8	499063	-----
1941 thru 52	P/6	Oil, .005 O.S.....	6	506780	-----
1950 thru 54	P/8	Oil, .005 O.S.....	8	513896	-----
1936 thru 49	P/8	Oil, .010 O.S.....	8	499064	-----
1941 thru 52	P/6	Oil, .010 O.S.....	6	506781	-----
1950 thru 54	P/8	Oil, .010 O.S.....	8	513897	-----
1936 thru 49	P/8	Oil, .020 O.S.....	8	499066	-----
1941 thru 52	P/6	Oil, .020 O.S.....	6	506782	-----
1950 thru 54	P/8	Oil, .020 O.S.....	8	513898	-----
1936 thru 49	P/8	Oil, .030 O.S.....	8	499067	-----
1941 thru 52	P/6	Oil, .030 O.S.....	6	506783	-----
1950 thru 54	P/8	Oil, .030 O.S.....	8	513899	-----
1953-54	P/6	RING AND SPRING, oil—standard	6	517863	-----
1953-54	P/6	Oil, .005 O.S.....	6	517864	-----
1953-54	P/6	Oil, .010 O.S.....	6	517865	-----
1953-54	P/6	Oil, .020 O.S.....	6	517866	-----
1953-54	P/6	Oil, .030 O.S.....	6	517867	-----

Group 0.643 RING SETS, PISTON (STEEL SECTION)

NOTE: Piston ring sets contain all rings necessary for complete replacement.

1936 thru 38	P/8	standard.....	1	513468	-----
1937-38	P/6	standard.....	1	513465	-----
1939 thru 49	P/8	standard.....	1	513469	-----
1939-40	P/6	standard.....	1	513466	-----
1941 thru 52	P/6	standard.....	1	513467	-----
1950 thru 54	P/8	standard.....	1	513948	-----
1939 thru 49	P/8	.020 O.S.....	1	513596	-----
1939-40	P/6	.020 O.S.....	1	513590	-----
1941 thru 52	P/6	.020 O.S.....	1	513592	-----
1950 thru 54	P/8	.020 O.S.....	1	513949	-----
1937-38	P/6	.030 O.S.....	1	513589	-----
1939 thru 49	P/8	.030 O.S.....	1	513597	-----
1939-40	P/6	.030 O.S.....	1	513591	-----
1941 thru 52	P/6	.030 O.S.....	1	513593	-----
1950 thru 54	P/8	.030 O.S.....	1	513950	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.646 CRANKSHAFT ASSEMBLY					
1937-38	P/6 after Eng. No. 321923	for 1/2" flywheel bolts.....	1	500943	-----
1937 thru 42	P/8	-----	1	506232	-----
1939 thru 54	P/6	use 907109 clutch pilot bearing Gr. 0.649 for P/6 1939-40.....	1	506176	-----
1946 thru 49	P/8	-----	1	508454	-----
1950 thru 54	P/8	-----	1	513513	-----
Group 0.647 PLUG, CRANKSHAFT OIL HOLE					
1935 thru 54	P/8	----- (Spec. 1 1/2")	2	494858	-----
Group 0.649 BEARING, CRANKSHAFT CLUTCH PILOT					
1933-34	All	ball type.....	1	907109	-----
1935 thru 40	All	roller type.....	1	142655	-----
1935 thru 40	All	durex type for special repair.....	1	412562	-----
1941 thru 54	All	ball type.....	1	907109	-----
Group 0.650 RETAINER, CLUTCH PILOT BEARING					
1935 thru 40	All	-----	1	836713	-----
Group 0.659 BALANCER, HARMONIC					
1935 thru 54	P/6-S.S.	includes pulley—use 1 508404 spacer for 1935-36	1	511498	-----
1937 thru 54	P/8-S.S.	includes pulley.....	1	511499	-----
1953-54	P/6-P.S.	includes pulley.....	1	517357	-----
1953-54	P/8-P.S.	includes pulley.....	1	517358	-----
1933 thru 54	All	KEY, balancer to crankshaft.....	1	495152	----- (0.729)
Group 0.662 BOLT-WASHER, STARTING CRANK NUT OR BALANCER					
1939	P/8	----- (Hex. 3/4"-16x1 1/4")	1	181822	----- (8.900)
1939	P/6	----- (Hex. 9/16"-18x1 1/4")	1	181725	----- (8.900)
1940 thru 54	All	----- (Hex. 9/16"-18x1 1/4")	1	181725	----- (8.900)
1939	P/8	LOCK WASHER, balancer to crankshaft (3/4" heavy)	1	103332	----- (8.931)
1939	P/6	----- (9/16" heavy)	1	131139	----- (8.931)
1940 thru 54	All	----- (9/16" heavy)	1	131139	----- (8.931)
1929 thru 38	All	WASHER, starting crank nut.....	1	500065	-----
1939	P/8	balancer to crankshaft.....	1	500065	-----
1939	P/6	-----	1	502059	-----
1940 thru 54	All	-----	1	502059	-----
Group 0.665 SEALER, FLYWHEEL TO CRANKSHAFT					
1948 thru 54	All H.T.	2 oz. bottle..... (ES-25)	1	512333	-----
Group 0.666 FLYWHEEL, ENGINE					
1937-38	P/6 after Eng. No. 321923	for 1/2" flywheel bolts.....	1	500944	-----
1939 thru 42	P/8	-----	1	503496	-----
1939 thru 42	P/6 exc. taxi	-----	1	503495	-----
1939 thru 42	P/6 S.T. taxi,	use 6-508463 BOLT on 1939 thru 42 models—see Group 0.669.....	1	510927	-----
1946 thru 54	All S.T.	-----	1	510927	-----
1948 thru 54	All H.T.	-----	1	511732	-----
1948 thru 54	All H.T.	DOWEL, flywheel to crankshaft.....	1	511733	-----
Group 0.666 PACKAGE, FLYWHEEL REPAIR					
1948 thru 54	All H.T.	(see note).....	1	517185	-----

NOTE: Package consists of 1-511733 dowel, 6-508463 bolt, 2-512110 plate, 1 512111 plate, 1-511734 installation drawing, 1-512333 sealer (2 oz. bottle).

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.669 BOLT, FLYWHEEL TO CRANKSHAFT					
1935-36	All	----- (1/16"-20x13/16")	6	497876	-----
1937 thru 42	P/8	----- (1/16"-20x13/16")	6	497876	-----
1937	P/6 to Eng. 321924	----- (1/16"-20x13/16")	6	497876	-----
1937 thru 42	P/6 after Eng. 321923	----- (1/2"-20x13/8")	6	500946	-----
1946 thru 50	All S.T.	optional in sets of 6 with 510332... (Spec. 1/2"-20x13/8")	6	508463	-----
1946 thru 54	All S.T.	optional in sets of 6 with 508463... (Spec. 1/2"-20x13/8")	6	510832	-----
1948 thru 54	All H.T.	----- (1/2"-20x13/8")	6	508463	-----
1948 thru 54	All H.T.	PLATE, flywheel to c/shaft bolt ----- Long	2	512110	-----
1948 thru 54	All H.T.	----- Short	1	512111	-----
1935-36	All	LOCKWASHER ----- (1/16" heavy)	6	131100	----- (8.931)
1937	P/6 to Eng. 321924	----- (1/16" heavy)	6	131100	----- (8.931)
1937 thru 42	P/6 after Eng. 321923	----- (1/2" heavy)	6	131101	----- (8.931)
1937 thru 42	P/8	----- (1/16" heavy)	6	131100	----- (8.931)
Group 0.673 GEAR, FLYWHEEL RING					
1933 thru 54	All S.T.	-----	1	502153	-----
Group 0.679 COVER, CLUTCH HOUSING					
1937-38	All	----- Bottom	1	499592	-----
1939 thru 52	All S.T.	----- Bottom	1	501860	-----
1953-54	All S.T.	----- Bottom	1	515107	-----
1948 thru 52	All H.T.	COVER, flywheel housing ----- Bottom	1	516704	-----
1953-54	All H.T.	----- Bottom	1	515090	-----
Group 0.683 HOUSING, CLUTCH L.H.D.					
1939-40	P/8	-----	1	503784	-----
1939-40	P/6 exc. taxi	-----	1	503783	-----
1941-42	All exc. taxi	-----	1	503784	-----
1941-42	P/6 taxi	-----	1	514001	-----
1946 thru 54	All S.T.	-----	1	514001	-----
1948 thru 50	All H.T.	HOUSING ASSEMBLY, flywheel ----- Front and rear	1	511843	-----
1951 thru 54	All H.T.	----- Front and rear	1	514300	-----
1948 thru 54	All H.T.	SHIM, front flywheel housing to cyl. block ----- AR	AR	510943	-----
1937 thru 54	All	BOLT, clutch housing to block ----- (Hex. 1/16"-14x1 3/8")	6	499590	-----
Group 0.685 PIN, CLUTCH HOUSING DOWEL					
1933 thru 54	All	----- (Spec. 3/8"x15/16")	2	836453	-----
1937 thru 54	All	use to align flywheel hsg.----- (O.S. 13/32"x1 1/4")	2	509107	-----
1948 thru 52	All H.T.	PIN, flywheel rear housing to front housing dowel -----			
		(.499 dia.)-----	2	510805	-----
1952 thru 54	All H.T.	(.495 dia.)-----	2	516314	-----
Group 0.686 COVER, CLUTCH INSPECTION HOLE					
1937 thru 54	All S.T.	-----	1	499591	-----
Group 0.714 COVER, TIMING HOLE					
1937 thru 54	All	-----	1	503447	-----
Group 0.724 CHAIN, TIMING					
1933 thru 54	P/8	-----	1	495149	-----
1935-36	P/6	-----	1	497704	-----
1937 thru 54	P/6	-----	1	507043	-----
Group 0.728 SPROCKET, CRANKSHAFT					
NOTE: When necessary to install new crankshaft sprocket on P/8 1933 thru 36 use one each 497702, 497703, 497704.					
1935-36	P/6	(see note)-----	1	497702	-----
1937 thru 54	P/6	-----	1	499606	-----
1937 thru 54	P/8	-----	1	499604	-----
Group 0.729 KEY, CRANKSHAFT SPROCKET					
1933 thru 54	All	-----	1	495152	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 0.736 SPROCKET, CAMSHAFT						
1935-36	P/6	-----	1	497703	-----	
1937 thru 54	P/6	discard old spacer washer.....	1	507044	-----	
1937 thru 54	P/8	discard old spacer washer.....	1	503454	-----	
1933 thru 54	All	KEY, camshaft sprocket..... (No. 9— $\frac{3}{16}$ "x $\frac{3}{4}$ ")	1	106751	-----	(8.960)
1933 thru 54	All	NUT, camshaft sprocket lock.....	1	503909	-----	
Group 0.738 WASHER						
		see Gr. 9.011 and 10.627 for use.....		1285607	-----	
Group 0.785 PLATE, CLUTCH RELEASE FORK GUIDE						
1937-38	All	-----	1	499834	-----	
1939	All L.H.D.	-----	1	501871	-----	
1939	P/6 L.H.D.	use with 503783 Group 0.683.....	1	503789	-----	
1940 thru 54	All L.H.D. S.T.	-----	1	503789	-----	
Group 0.795 FORK, CLUTCH RELEASE						
1933 thru 38	All	includes ball seat and spring.....	1	364495	-----	
1939 thru 42	All exc. taxi	-----	1	501868	-----	
1939 thru 42	P/6 taxi	-----	1	502865	-----	
1946 thru 54	All S.T.	-----	1	508923	-----	
1933 thru 38	All	FORK PKG., 1933 thru 36 also use 1-836628 Gr. 0.821	1	510325	-----	
1939 thru 42	All exc. taxi	-----	1	510324	-----	
1946 thru 54	All S.T.	-----	1	510326	-----	
Group 0.796 BALL, CLUTCH RELEASE FORK						
1933 thru 38	All	-----	1	836414	-----	
1939 thru 54	All S.T.	-----	1	501866	-----	
1933 thru 36	All	SUPPORT, clutch fork ball.....	1	836628	-----	
1939 thru 54	All	BOLT, clutch fork ball support..... (Hex. $\frac{1}{16}$ "-20x $\frac{1}{8}$ ")	1	181665	-----	(8.900)
Group 0.797 COVER, CLUTCH FORK GUIDE PLATE						
1939 thru 54	All S.T.	-----	1	501862	-----	
1939 thru 54	All S.T.	SPRING, cover.....	1	501872	-----	
1935 thru 38	All L.H.D.	SPRING, clutch fork and countershaft rod.....	1	499150	-----	
Group 0.799 BEARING, CLUTCH RELEASE						
1933 thru 42	All exc. taxi L.H.D.	with collar.....	1	503466	-----	
1939 thru 46	P/6 taxi	with collar.....	1	909422	-----	
1946 thru 54	All S.T.	ball type.....	1	2140122	-----	
1937 thru 42	All exc. taxi	FITTING, clutch release bearing lubrication.....	1	508375	-----	
Group 0.800 PLATE, CLUTCH RELEASE BEARING						
1935 thru 38	All	-----	1	497087	-----	
Group 0.803 WASHER, CLUTCH BEARING SUPPORT SPRING						
1939 thru 42	P/6 taxi	-----	1	1302021	-----	(4.361)
1946 thru 54	All S.T.	-----	1	1302021	-----	(4.361)
Group 0.805 SPRING, CLUTCH RELEASE BEARING						
1933 thru 38	All	release fork to bearing collar.....	2	838541	-----	
1939 thru 42	All exc. taxi	release fork to bearing collar.....	2	501880	-----	
Group 0.821 SUPPORT, CLUTCH RELEASE BEARING						
1939 thru 42	P/6 taxi	-----	1	1308585	-----	
1946 thru 54	All S.T.	-----	1	509158	-----	
1937-38	All	with 1941-42 clutch and flywheel.....	1	508990	-----	
1937-38	All	-----	1	499843	-----	
1946 thru 54	All S.T.	GASKET, support.....	1	1302022	-----	
Group 0.822 RETAINER, CLUTCH RELEASE FORK BALL						
1939 thru 42	P/6 taxi	clip type.....	1	502864	-----	
1939 thru 42	All	BOLT, clutch fork ball retainer spring..... (Rd. Hd. $\frac{1}{4}$ "-28x $\frac{5}{8}$ ")	1	143317	-----	(8.906)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 0.823 SPRING, CLUTCH RELEASE FORK BALL SEAT						
1933 thru 38	All	includes retainer.....	1	838987	-----	
1939 thru 42	All taxi	-----	1	501870	-----	
1939 thru 42	All exc. taxi	-----	1	502820	-----	
1946 thru 54	All S.T.	-----	1	502820	-----	
Group 0.830 PEDAL, CLUTCH						
1941 thru 53	All L.H.D. S.T.	-----	1	505192	-----	
1954	All L.H.D. S.T.	-----	1	518278	-----	
Group 0.831 BUSHING, CLUTCH PEDAL						
1929 thru 32	P/6 L.H.D.	-----	1	1266804	-----	(4.626)
1933 thru 40	All	-----	1	1266804	-----	(4.626)
Group 0.833 SHAFT, CLUTCH PEDAL						
NOTE: See Group 7.237 for pedal shaft brackets.						
1937-38	All	-----	1	499868	-----	
1939 thru 54	All L.H.D. S.T.	-----	1	505310	-----	
1935-36	All	SPRING, clutch pedal retainer.....(3/4" Dia. Shaft)	1	142590	-----	(8.934)
Group 0.834 PIN, CLUTCH PEDAL SHAFT						
1937 thru 40	All	grooved.....(1/8"x1 1/2")	1	142358	-----	(8.940)
1941 thru 54	All S.T.	BOLT, clutch pedal shaft to bracket ----- (Hex. 1/4"-28x1 3/4")	1	123762	-----	(8.900)
Group 0.837 WASHER, CLUTCH PEDAL SHAFT						
1934 thru 36	All	-----	1	496456	-----	
1940	29 All	-----	1	496456	-----	
1941 thru 54	All S.B.	-----	1	496456	-----	
		see Group 6.898 for use.....		402453	-----	
Group 0.839 LINK-ROD, CLUTCH PEDAL ADJUSTING						
1941 thru 48	All S.T.	clutch pedal to countershaft.....	1	505883	-----	
1949 thru 54	All S.T.	-----	1	511319	-----	
1937	All L.H.D.	ROD, clutch pedal to countershaft.....	1	499835	-----	
1938	All L.H.D.	-----	1	501252	-----	
1939	25 All	-----	1	502106	-----	
1939-40	26-28 All	-----	1	502107	-----	
1940	25 L.H.D.	-----	1	504014	-----	
1939-40	All P/8 exc. 29	ROD, clutch fork to countershaft.....	1	502729	-----	
1939-40	P/6	-----	1	502109	-----	
1940	29 All	-----	1	502109	-----	
1941 thru 48	All S.T.	-----	1	505887	-----	
1949 thru 52	All S.T.	-----	1	511270	-----	
1953-54	All L.H.D. S.T.	-----	1	516440	-----	
1939 thru 54	All S.T.	NUT, clutch countershaft rod adjuster... (Spec. 3/8"-24)	1	502110	-----	
1953-54	All S.T.	SPRING, clutch fork rod to fork.....	1	516441	-----	
Group 0.841 SCREW, CLUTCH PEDAL ADJUSTING						
1940	29 All	----- (Hex. 5/16"-18x2 1/4")	1	504013	-----	
1941 thru 54	All L.H.D. S.T.	----- (Hex. 5/16"-18x2 1/4")	1	504013	-----	
Group 0.844 SPRING, CLUTCH PEDAL RETURN						
1934 thru 36	All	-----	1	498950	-----	(4.597)
1937	All	-----	1	497526	-----	(4.639)
1938	All	SPRING, clutch pedal strut return.....	1	501257	-----	
1938	All	-----	1	501255	-----	
1939 thru 54	All S.T.	SPRING, clutch fork return.....	1	502117	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.845 ANCHOR, CLUTCH PEDAL RETURN SPRING					
1949 thru 52	All L.H.D. S.T.	-----	1	511266	-----
Group 0.846 SPRING, CLUTCH PEDAL OVER CENTER					
1941 thru 54	All L.H.D. S.T.	-----	1	505894	-----
1941	26-29	ANCHOR, clutch pedal over center.....	1	506585	-----
1941 thru 48	25 S.T.	-----	1	505879	-----
1949 thru 54	All L.H.D. S.T.	-----	1	511744	-----
1941 thru 54	25 L.H.D. S.T.	EXTENSION, clutch over center spring.....	1	505880	-----
1941 thru 48	26-29	-----	1	505881	-----
	L.H.D. S.T.	-----	1	505882	-----
1941	26-29 L.H.D.	GUIDE, clutch pedal over center spring.....	1	507821	-----
1942 thru 48	26 L.H.D. S.T.	-----	1	507821	-----
Group 0.849 PIN, CLUTCH PEDAL RETURN SPRING					
1939 thru 54	All S.T.	-----	1	502105	-----
Group 0.851 FELT, CLUTCH COUNTERSHAFT					
1937-38	All	oiling.....	1	499567	-----
1939 thru 48	All S.T.	oiling.....	2	502099	-----
1949 thru 54	All S.T.	oiling.....	1	511745	-----
1937-38	All	STUD, clutch countershaft frame pivot.....	1	499842	-----
Group 0.852 COUNTERSHAFT, CLUTCH CONTROL					
1935-36	All L.H.D.	-----	1	499149	-----
1937-38	All	-----	1	499838	-----
1939	25 All	with lever.....	1	502111	-----
1939-40	P/8 all exc. 29 L.H.D.	with lever.....	1	502114	-----
1939-40	P/6 exc.	with lever.....	1	502114	-----
	1939-25 L.H.D.	-----	1	505888	-----
1941 thru 48	25-27 L.H.D. S.T.	with lever.....	1	505889	-----
1941 thru 48	26-29	with lever.....	1	505889	-----
	L.H.D. S.T.	-----	1	511271	-----
1949 thru 54	All L.H.D. S.T.	with lever.....	1	511271	-----
Group 0.852 SUPPORT, CLUTCH COUNTERSHAFT					
1937-38	All L.H.D.	to clutch housing.....	1	499829	-----
1949 thru 52	All L.H.D. S.T.	BRACKET, to clutch housing.....	1	511267	-----
1953-54	All L.H.D. S.T.	countershaft to clutch housing.....	1	516437	-----
1939-40	P/8 all exc. 29 L.H.D.	to engine.....	1	502726	-----
1939 thru 48	All exc.	to engine.....	1	502096	-----
	1939-40 28 L.H.D.	-----	1	501898	-----
1939-40	All exc. 1940 25-29	to frame.....	1	503614	-----
1940 thru 48	All exc. 1940	to frame.....	1	503614	-----
	26-28 L.H.D.	-----	1	511208	-----
1949 thru 54	All S.T.	to frame.....	1	511208	-----
1937-38	All	SPACER, countershaft to bracket.....	1	502099	----- (0.851)
Group 0.853 ROLLER, CLUTCH CONTROL COUNTERSHAFT					
1940	29 All	-----	1	503999	-----
1940	29 All	PIN, clutch control roller..... (1/2"x2 1/2")	1	141292	----- (8.939)
Group 0.859 COVER AND PRESSURE PLATE, CLUTCH					
1941-42	All exc. taxi	-----	1	753991	-----
1946 thru 49	All exc. 2571, taxi & heavy duty S.T.	-----	1	755959	-----
1950 thru 54	P/6 All exc.	-----	1	755959	-----
	2571, taxi & heavy duty S.T.	-----	1	757370	-----
1950 thru 54	P/8 S.T.	-----	1	758645	-----
1950 thru 54	P/6 2571, taxi & heavy duty S.T.	-----	1	758645	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
------	-------	-----------	---------	----------	---------

APPLICATION OF 1942 CLUTCH ON 1937-38 MODELS

6 Cylinder—1937 thru Engine No. 321922

1	0.859	753991	-----	Clutch assembly	
1	0.666	503496	-----	Flywheel	
1	0.886	508403	-----	Plate assembly, clutch driven	
1	0.821	508990	-----	Support, clutch fork ball	

6 Cylinder—1937 Engine No. 321923 and Up, 1938

1	0.859	753991	-----	Clutch assembly	
1	0.666	503496	-----	Flywheel	
1	0.886	508403	-----	Plate, assembly, clutch driven	
1	0.821	508990	-----	Support, clutch fork ball	

8 Cylinder—1937-38

1	0.859	753991	-----	Clutch assembly	
1	0.666	503496	-----	Flywheel	
1	0.886	505473	-----	Plate assembly, clutch driven	
1	0.821	508990	-----	Support, clutch fork ball	

Group 0.861

COVER, CLUTCH

1934 All Eng. No. 993377 Up	with support	1	837994	-----
1939-40 All exc. taxi	includes spring	1	753615	-----
1939 thru 48 P/6 taxi S.T.	includes spring	1	753412	-----
1949 2571 & heavy duty S.T.	includes spring	1	753412	-----

Group 0.862

BOLT, CLUTCH COVER TO FLYWHEEL

1937 thru 54 All S.T.	----- (Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{16}$ ") AR	500177	-----
-----------------------	---	--------	-------

Group 0.863

PLATE, CLUTCH PRESSURE

1933-34 All to Eng. No. 993377	-----	1	836621	-----
1935 thru 38 All	-----	1	497088	-----
1939-40 All exc. taxi	-----	1	753410	-----
1939 thru 48 P/6 taxi S.T.	-----	1	753802	-----
1949 2571, Taxi & heavy duty S.T.	-----	1	753802	-----

Group 0.864

SPRING, CLUTCH PRESSURE PLATE RETURN

1939-40 All	clip type	3	838646	-----
1941 thru 48 P/6 taxi S.T.	clip type	3	838646	-----
1949 2571, Taxi & heavy duty S.T.	clip type	3	838646	-----
1939-40 All	BOLT, clutch pressure plate return spring	3	754381	-----
1941 thru 48 Taxi S.T.	-----	3	754381	-----
1949 2571, Taxi & heavy duty S.T.	-----	3	754381	-----
1939-40 Exc. taxi	SPRING, clutch pressure plate anti-rattle	1	753432	-----

Group 0.865

SPRING, CLUTCH PRESSURE

1934 All Eng. No. 993377 up	-----	9	837461	-----
1935 thru 38 All	-----	9	499674	-----

Group 0.867

CUP, CLUTCH PRESSURE SPRING

1937-38 All	-----	9	837557	-----
-------------	-------	---	--------	-------

Group 0.870

BOLT, CLUTCH PRESSURE LEVER PLATE

1934 All Eng. No. 993377 up	----- (Hex. $\frac{3}{8}$ "-16x $\frac{3}{4}$ ")	6	837445	-----
-----------------------------	--	---	--------	-------

Group 0.874

LEVER, CLUTCH RELEASE

1935 thru 38 All	-----	3	497082	-----
------------------	-------	---	--------	-------

Group 0.875

PIN, CLUTCH RELEASE LEVER

1934 All Eng. No. 993377 up	-----	3	837492	-----
1935 thru 38 All	TRUNNION, clutch release lever	3	497083	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 0.878 SPRING, CLUTCH RELEASE LEVER					
1933-34 All to Eng. No. 993377	All	retainer.....	3	473174	-----
1935 thru 38	All		3	500157	-----
Group 0.884 RIVET, CLUTCH FACING					
1936 thru 54	All S.T.	facing to plate..... (Tubular $\frac{5}{32} \times \frac{3}{16}$)	AR	499303	-----
1936 thru 49	All S.T.	cushion plate to driven..... (Flat Hd. $\frac{5}{32} \times 1\frac{1}{4}$)	AR	499304	-----
Group 0.885 FACINGS, CLUTCH DRIVEN PLATE					
NOTE: Each part number consists of two facings and rivets.					
1936 thru 38	All	 (with Long clutch)	1	544321	-----
1939-40	P/8	 (with Long clutch)	1	503204	-----
1939-40	P/6 exc. taxi	 (with Long clutch)	1	503203	-----
1939 thru 48	P/6 taxi	 (with Long clutch)	1	544321	-----
1941-42	P/6 exc. taxi		1	513965	-----
1941-42	P/8		1	506480	-----
1946 thru 49	All exc. 2571, taxi & heavy duty S.T.		1	506480	-----
1949	2571, taxi & heavy duty S.T.		1	544321	-----
1950 thru 54	P/6 exc. 2571 & taxi S.T.		1	506480	-----
Group 0.886 PLATE, CLUTCH DRIVEN (With Facings)					
1937-38	All		1	500402	-----
1939-40	P/8		1	502559	-----
1939-40	P/6 exc. 2571 taxi		1	508402	-----
1939 thru 49	P/6 taxi & heavy duty S.T.		1	502834	-----
1941 thru 48	P/6 exc. taxi S.T.		1	508403	-----
1941 thru 48	P/8 S.T.		1	505473	-----
1949 thru 54	P/6 exc. 2571, Taxi & heavy duty S.T.		1	508403	-----
1949	P/8 exc. 2571, Taxi & heavy duty S.T.		1	505473	-----
1949	P/8 2571 Taxi & heavy duty S.T.		1	513583	-----
1950 thru 54	P/6 2571, Taxi & heavy duty S.T.		1	513582	-----
1950 thru 54	P/8 S.T.		1	513583	-----

PONTIAC CHASSIS PARTS SECTION

[illegible]

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 1.002 REPAIR KIT, WATER PUMP						
NOTE: The kits consist of gaskets, impeller, shaft and bearing, spring, seals, washers and retainers.						
1939-40	P/6	for packless pump.....	1	509120	-----	
1938 thru 48	All exc.	-----	1	509119	-----	
1949 thru 54	P/6 1939-40	-----				
	All	-----	1	513164	-----	
Group 1.003 SHAFT AND BEARING PACKAGE, WATER PUMP						
1933 thru 48	All exc.	for packless pump.....	1	509138	-----	
1939-40	P/6 1939-40	-----	1	509137	-----	
1949 thru 54	P/6	-----	1	509137	-----	
	All	-----				
Group 1.069 PUMP ASSEMBLY, WATER						
1937 thru 48	All exc.	less body back plate.....	1	514289	-----	
	P/6 1939-40	-----				
1939-40	P/6	less body back plate.....	1	514290	-----	
1949 thru 54	All	less body back plate.....	1	515804	-----	
1937	All	PUMP AND FAN PKG.				
		----- (for replacing packed type pump)	1	500804	-----	
Group 1.073 BOLT, WATER PUMP TO BLOCK						
1937 thru 48	All	----- (Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{2}$ ")	3	180126	-----	(8.900)
1949 thru 54	All	----- (Hex. $\frac{3}{8}$ "-16x1 $\frac{3}{4}$ ")	4	180128	-----	(8.900)
Group 1.074 BEARING, WATER PUMP						
1932 thru 37	All exc.	with roller bearing pump on 1937.....Rear	1	493644	-----	
	P/8 1932	-----				
1933 thru 37	All	with roller bearing pump.....Front	1	148446	-----	
Group 1.079 GASKET, WATER PUMP TO BLOCK						
NOTE: See Group 1.114 for body to plate gasket.						
1937 thru 48	All	-----	1	503539	-----	
1949	All	use with 511242 pump.....	1	511247	-----	
1949 thru 54	All	use with 513609 pump or 513610 plate.....	1	513611	-----	
Group 1.091 RETAINER, WATER PUMP SHAFT						
1933 thru 52	All	with packless pump.....	1	408073	-----	
Group 1.109 IMPELLER, WATER PUMP						
1938 thru 54	All	with packless pump.....	1	501182	-----	
Group 1.113 PLATE, WATER PUMP BODY						
1937 thru 48	All	with service pump on 1940 thru 48.....	1	508968	-----	
1940 thru 48	All	with standard equipment.....	1	503538	-----	
1949 thru 54	All	use 513611 gasket—Gr. 1.079.....	1	513610	-----	
1940 thru 48	All	BOLT , water pump body to plate..... (Hex. $\frac{5}{16}$ "-24x1 $\frac{1}{2}$ ")	3	181614	-----	(8.900)
1949-50	All	----- (Hex. $\frac{3}{8}$ "-24x2")	1	181648	-----	(8.900)
1949 thru 54	All	----- (Flt. Hd. $\frac{5}{16}$ "-18x $\frac{3}{8}$ ")	1	133822	-----	(8.908)
Group 1.114 GASKET, WATER PUMP BODY TO PLATE						
NOTE: See Group 1.079 for plate to block gasket.						
1933 thru 36	All	-----	1	494956	-----	
1937 thru 48	All	-----	1	499887	-----	
1949 thru 54	All	-----	1	511245	-----	
Group 1.121 RING, WATER PUMP SEAL WASHER RETAINER						
1933 thru 48	All	with round seal washer.....	1	500580	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.123 SEAL PACKAGE, WATER PUMP					
NOTE: This package consists of 1 each: retainer, seal, spring, washer and wire.					
1933 thru 54	All	-----	1	509121	-----
Group 1.129 NUT, WATER PUMP PACKING					
1933 thru 37	All	with packing type pump.....	1	494959	-----
Group 1.133 PACKING, WATER PUMP					
1934 thru 37	All	full packing, with packing type pump.....	1	494958	-----
1934 thru 37	All	refill packing, with packing type pump.....	1	495581	-----
Group 1.135 TUBE, WATER INLET					
1933 thru 36	P/8	inside cylinder block.....	1	494961	-----
1935-36	P/6	inside cylinder block.....	1	497010	-----
1937 thru 54	P/6	inside cylinder block.....	1	508708	-----
1937 thru 54	P/8	inside cylinder block.....	1	508710	-----
Group 1.146 PLUG, CYLINDER BLOCK CORE HOLE					
1936 thru 54	All	cup type.....(1.952 O.D.)	4	1330564	-----
Group 1.148 GAUGE, WATER TEMPERATURE, INSTRUMENT PANEL					
1939	All	-----	1	1510771	-----
1940	All	-----	1	1510916	-----
1941	All	-----	1	1511053	-----
1942	All	-----	1	1511190	-----
1946	All	-----	1	1511661	-----
1947	All	-----	1	1511874	-----
1948	All	-----	1	1512027	-----
1949-50	All	-----	1	1512126	-----
1951-52	All	-----	1	1512287	-----
1953-54	All	w/tube and engine unit.....	1	1512458	-----
Group 1.153 ELBOW, WATER OUTLET					
1937 thru 54	All	to cylinder head.....	1	499629	-----
Group 1.154 GASKET, WATER OUTLET ELBOW					
1933 thru 54	All	to cylinder head.....	1	494904	-----
Group 1.159 HOSE, RADIATOR					
All	All	marked off in inches.....(1½"x3 ft.)	AR	3701363	-----
All	All	marked off in inches.....(1¾"x3 ft.)	AR	393881	-----
1933 thru 36	All	inlet, curved.....(1½"x9¾")	1	495192	-----
1937-38	All	inlet, cut 9½" long, from 393881.....	1		-----
1939-40	All	inlet to cylinder head, curved.....(1¾"x9¾")	1	502025	-----
1941 thru 48	P/6	inlet to cylinder head, curved.....(1¾"x13½")	1	506226	-----
1941 thru 48	P/8	inlet to cylinder head, curved.....(1¾"x8½")	1	506227	-----
1949 thru 54	P/6	inlet to cylinder head, curved.....(1¾"x13½")	1	511596	-----
1949 thru 54	P/8	inlet to cylinder head, curved.....(1¾"x8½")	1	511597	-----
1933-34	P/8	outlet, cut 6½" long, from 1255503.....	1		-----
1935-36	All	outlet, cut 7¼" long, from 1255503.....	1		-----
1937-38	All	outlet, curved.....(1½"x9¾")	1	495192	-----
1939-40	All exc. 28	outlet to pump, curved.....(1½"x14½")	1	502024	-----
1939 thru 48	P/8	outlet to pump, curved.....(1½"x13½")	1	502671	-----
1941 thru 48	P/6	outlet to pump, curved.....(1½"x16½")	1	506228	-----
1949 thru 54	P/6	outlet to pump, curved.....(1¾"x17¾")	1	511746	-----
1949 thru 54	P/8	outlet to pump, curved.....(1¾"x15½")	1	511747	-----
1953	P/8	outlet to pump, curved.....(1¾"x16")	1	517411	-----
Group 1.160 SPRING, RADIATOR OUTLET HOSE					
1937 thru 48	All	to pump.....	1	506229	-----
1949 thru 54	All	to pump.....	1	511765	-----
		see Group 4.931 for use.....		111603	-----
Group 1.166 CLAMP, RADIATOR HOSE					
1933 thru 54	All	inlet or outlet.....(1½" to 2¾" I.D. dia.)	4	3692864	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 1.203 CAP, RADIATOR FILLER						
1935-36	All exc. P/8 1936		1	497778	-----	
1937 thru 40	P/6	except special.....	1	594498	-----	
1937 thru 48	All	pressure valve type.....	1	850594	-----	
1949-50	All	pressure valve type.....	1	850501	-----	
1951 thru 54	All	pressure valve type.....	1	850549	-----	
Group 1.206 WASHER, RADIATOR FILLER CAP						
1937 thru 48	All	sealing.....	1	499561	-----	
Group 1.216 BUMPER, RADIATOR SHELL TO HOOD						
1936	All	rubber.....	4	499379	-----	
1937	All	large.....	4	500221	-----	
1937	All	small.....	8	500222	-----	
1939	P/6 Special	small.....	2	500222	-----	
1940	All	small..... At side panel	10	503865	-----	
1940	All	large..... At bonnet	2	506351	-----	(8.024)
Group 1.219 CORE, RADIATOR						
1936	P/6	 2 1/8" thick	1	310662	-----	
1937-38	P/6	 2" thick	1	3109138	-----	
1937-38	P/8	 3 1/2" thick	1	3109140	-----	
1939-40	P/6	 2" thick	1	3113436	-----	
1939-40	P/8	 3" thick	1	3113437	-----	
1941 thru 48	P/6	 2" thick	1	3121015	-----	
1941 thru 48	P/8	 2 1/2" thick	1	3115919	-----	
1949 thru 54	P/6	 2" thick	1	3128996	-----	
1949 thru 52	P/8	 2 1/2" thick	1	3127575	-----	
1953-54	P/8	 2" thick	1	3129947	-----	
1937 thru 39	All	BOLT , radiator core to shell..... (Hex. 5/16"-24x5/8")	6	181593	-----	(8.900)
1939-40	All	radiator to frame..... (Carr. 3/8"-16x2")	2	126419	-----	(8.903)
1941 thru 54	All	radiator to frame..... (Carr. 3/8"-16x1 3/4")	2	126416	-----	(8.903)
1949 thru 54	All	SCREW , radiator to support..... (Hex. hd. 5/16"-18x3/4")	6	171104	-----	(8.977)
Group 1.229 COCK, RADIATOR						
1935 thru 54	All	drain—use w/505304 pipe..... (1/8" pipe thread)	1	111668	-----	(8.951)
1948 thru 54	All	 (1/4"x1 1/8" long—closed)	1	511771	-----	
Group 1.240 HOSE, RADIATOR DRAIN						
All thru 1938	All	 (1 1/32" I.D.x1 5/32" O.D.x9" long)	1	500084	-----	
1939 thru 54	All	PIPE , radiator drain—use w/111668 drain cock.....	1	505304	-----	
Group 1.246 THERMOSTAT, WATER MANIFOLD						
1937 thru 54	All	high opening, with permanent anti-freeze..... 160 degree	1	3126562	-----	
1933 thru 54	All	 151 degree	1	3126560	-----	
1937 thru 54	All	with permanent anti-freeze..... 170 degree	1	3126590	-----	
Group 1.251 RETAINER, WATER MANIFOLD THERMOSTAT						
1933 thru 36	All		1	494906	-----	
1937 thru 54	All		1	500171	-----	
Group 1.262 COVER, RADIATOR SHELL HAND HOLE						
1940	All		1	503879	-----	
Group 1.263 SHELL, RADIATOR (In Prime)						
1939	26 All		1	502477	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.264 SUPPORT, RADIATOR SHELL					
1938	All	Upper and lower	1	501122	-----
1939	All	-----	1	502155	-----
1940	All exc. 29	with yoke	1	503870	-----
1940	29	with yoke	1	503881	-----
1941	All	with baffle	1	505241	-----
1942 thru 47	All	with baffle	1	506967	-----
1948	All	with baffle	1	510580	-----
1949 thru 52	All	with baffle	1	513762	-----
1953-54	All	with baffle	1	515640	-----
1939	All	NUT, radiator shell to fender clip (No. 12 Spec.)	10	502443	(1.273)
1953	All	radiator supt. seal to radiator supt. (spring type)	6	516618	-----
1953	All	SEAL, radiator supt. to radiator lower tank	1	516621	-----
1939	All	SCREW, radiator shell to support (Hex. No. 12x $\frac{1}{2}$ ")	AR	145415	(8.977)
Group 1.266 GRILLE, RADIATOR					
1937	All	Center	1	544418	-----
1937	All	Side upper R.H.	2	544411	-----
1937	All	Side upper L.H.	2	544412	-----
1937	All	Side lower R.H.	1	544413	-----
1937	All	Side lower L.H.	1	544414	-----
1937	All	Side center R.H.	1	544415	-----
1937	All	Side center L.H.	1	544416	-----
1938	All	R.H.	1	501059	-----
1938	All	L.H.	1	501060	-----
1939	All	in fender Side inner R.H.	1	502081	-----
1939	All	in fender Side inner L.H.	1	502082	-----
1939	All	in fender Side outer R.H.	1	502083	-----
1939	All	in fender Side outer L.H.	1	502084	-----
1939	All exc. 25	Center	1	502145	-----
1939	25 All	Center	1	502144	-----
1940	All	in fender Side R.H.	1	503674	-----
1940	All	in fender Side L.H.	1	503675	-----
1941	All	Side L.H.	1	505123	-----
1942	All	Center R.H.	1	506979	-----
1942	All	Center L.H.	1	506980	-----
1946	All	Inner R.H.	1	508869	-----
1946	All	Inner L.H.	1	508870	-----
1946	All	Outer R.H.	1	508879	-----
1946	All	Outer L.H.	1	508880	-----
1947	All	one piece	1	509597	-----
1948	All	one piece, less name plate and No. 1 blade	1	510697	-----
Group 1.266 PANEL, RADIATOR CENTER					
1940	All	-----	1	504734	-----
1941	All	-----	1	505196	-----
1942	All	-----	1	507129	-----
1946	All	-----	1	508656	-----
Group 1.266 BLADE, RADIATOR GRILLE					
1947	All	No. 1	1	509532	-----
1947	All	No. 2	1	509533	-----
1947	All	No. 3	1	509534	-----
1947	All	No. 4	1	509536	-----
1948	All	No. 1	1	510527	-----
1948	All	No. 2	1	510528	-----
1948	All	No. 3	1	510530	-----
1948	All	No. 4	1	510523	-----
Group 1.266 BAR, RADIATOR GRILLE—CURVED					
1949	All	Upper outer R.H.	1	511259	-----
1949	All	Upper outer L.H.	1	511260	-----
1950	All	Upper outer R.H.	1	513717	-----
1950	All	Upper outer L.H.	1	513718	-----
1951-52	All	Upper outer R.H.	1	515760	-----
1951-52	All	Upper outer L.H.	1	515761	-----
1953	All	Upper outer R.H.	1	516764	-----
1953	All	Upper outer L.H.	1	516765	-----
1954	All	Upper outer R.H.	1	517625	-----
1954	All	Upper outer L.H.	1	517626	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.266 BAR ASSY., RADIATOR GRILLE—HORIZONTAL					
1949	All	between curved bars—on hood..... Upper center	1	511994	-----
1949	All	above vertical bars..... Center	1	512151	-----
1949	All	below vertical bars..... Lower	1	512161	-----
1950	All	between curved bars—on hood..... Upper center	1	513735	-----
1950	All	behind vertical bars..... Center R.H.	1	513913	-----
1950	All	behind vertical bars..... Center L.H.	1	513914	-----
1950	All	below vertical bars..... Lower	1	513746	-----
1951	All	between curved bars—on hood..... Upper center	1	516245	-----
1952	All	between curved bars—on hood..... Upper center	1	516450	-----
1951-52	All	above parking lamp..... Center R.H.	1	515762	-----
1951-52	All	above parking lamp..... Center L.H.	1	515763	-----
1951-52	All	 Lower	1	515764	-----
1953	All	holds grille emblem..... Center	1	516766	-----
1953	All	between curved bars—on hood..... Upper center	1	516762	-----
1953	All	parking lamp mounted inside..... R.H.	1	516768	-----
1953	All	parking lamp mounted inside..... L.H.	1	516769	-----
1953	All	 Lower	1	516767	-----
1954	All	on hood..... Upper center	1	517630	-----
1954	All	 Center	1	517663	-----
1954	All	 Outer center R.H.	1	517665	-----
1954	All	 Outer center L.H.	1	517666	-----
1954	All	 Lower	1	517670	-----
1954	All	BRACKET , center bar to baffle brace.....	1	517741	-----
1953	All	EXTENSION , outer bar..... R.H.	1	516771	-----
1953	All	outer bar..... L.H.	1	516772	-----
1954	All	lower bar..... R.H.	1	517677	-----
1954	All	lower bar..... L.H.	1	517678	-----
1954	All	INSERT , center bar.....	1	517639	-----
1951-52	All	SUPPORT , lower bar to bumper apron.....	1	514791	-----
Group 1.266 BAR, RADIATOR GRILLE—VERTICAL					
1948	All	includes retainers..... Center No. 1	1	510506	-----
1948	All	includes retainers..... No. 2 R.H.	1	510510	-----
1948	All	includes retainers..... No. 2 L.H.	1	510511	-----
1948	All	 No. 3 R.H.	1	510517	-----
1948	All	 No. 3 L.H.	1	510518	-----
1948	All	 No. 4 R.H.	1	510519	-----
1948	All	 No. 4 L.H.	1	510520	-----
1949	All	 R.H.	4	512158	-----
1949	All	 L.H.	4	512159	-----
1950	All	 Inner R.H.	1	513723	-----
1950	All	 Inner L.H.	1	513724	-----
1950	All	 Outer R.H.	1	513725	-----
1950	All	 Outer L.H.	1	513726	-----
1951-52	All	 R.H.	2	515765	-----
1951-52	All	 L.H.	2	515766	-----
Group 1.266 PLATE, RADIATOR GRILLE					
1949	All	center bar to upper curved bar..... R.H.	1	512087	-----
1949	All	center bar to upper curved bar..... L.H.	1	512088	-----
1950	All	center bar to upper curved bar..... R.H.	1	513719	-----
1950	All	center bar to upper curved bar..... L.H.	1	513720	-----
1950	All	grille to fender finish—outside parking lamp..... R.H.	1	513736	-----
1950	All	grille to fender finish—outside parking lamp..... L.H.	1	513737	-----
1951	All	grille to fender finish—outside parking lamp..... R.H.	1	514631	-----
1951	All	grille to fender finish—outside parking lamp..... L.H.	1	514632	-----
1951-52	All	center bar to upper curved bar..... R.H.	1	514629	-----
1951-52	All	center bar to upper curved bar..... L.H.	1	514630	-----
1953	All	center bar to upper curved bar..... R.H.	1	515181	-----
1953	All	center bar to upper curved bar..... L.H.	1	515182	-----
1954	All	center bar to lower bar..... R.H.	1	517738	-----
1954	All	center bar to lower bar..... L.H.	1	517739	-----
Group 1.266 RETAINER, RADIATOR GRILLE					
1947	All	 Center	1	509537	-----
1947	All	 Outer center R.H.	1	509538	-----
1947	All	 Outer center L.H.	1	509539	-----
1947	All	 Outer R.H.	1	509540	-----
1947	All	 Outer L.H.	1	509541	-----
1948	All	blade to vertical bar.....	13	510554	-----
1949	All	center bar to ornament.....	1	512100	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.266 RETAINER, RADIATOR GRILLE (Continued)					
1950	All	vertical bar to lower bar	4	513730	-----
1950	All	vertical bar to center bar rear	4	513731	-----
1950	All	vertical bar to center bar front	4	513732	-----
1950	All	center bar to ornament	1	513740	-----
1950	All	lower bar to ornament	1	513741	-----
1951-52	All	center bar to lower bar	4	514633	-----
1951-52	All	spinner to lower bar support	1	514790	-----
1951-52	All	spinner to center bar	2	514829	-----
Group 1.267 RETAINER, RADIATOR CENTER PANEL					
1940	All	Upper	1	503773	-----
1940	All	Center	1	503774	-----
1940	All	Lower	1	503775	-----
1941 thru 47	All	BOLT , center panel to support (Spec. $\frac{1}{4}$ "-20x $\frac{3}{8}$ ")	AR	505097	-----
1946	All	SPACER , inner to outer grille R.H.	3	508628	-----
1946	All	L.H.	3	508629	-----
Group 1.268 MOLDING—REINFORCEMENT—SUPPORT, RADIATOR GRILLE					
1942	All	MOLDING , radiator grille R.H.	1	507168	-----
1942	All	L.H.	1	507169	-----
1946	All	R.H.	1	508623	-----
1946	All	L.H.	1	508624	-----
1947	All	R.H.	1	509566	-----
1947	All	L.H.	1	509567	-----
1938	All	BRACE ASSEMBLY , radiator center grille	1	501055	-----
1953	All	center bar to lower bar	1	515117	-----
1938	All	REINFORCEMENT , radiator outer grille center	1	501130	-----
1941	All	SUPPORT , center panel to fender	1	505250	-----
1942 thru 47	All		1	507128	-----
1948	All	SUPPORT ASSY. , radiator grille to front fender	1	510526	-----
Group 1.269 SCREW, RADIATOR GRILLE					
1934 thru 38	All	grille to fender (Hex. spec. $\frac{1}{4}$ "-20x $\frac{15}{16}$ ")	AR	496120	-----
1937 thru 39	All	center, side upper and lower (Hex. No. 7x $\frac{3}{8}$ ")	AR	504971	-----
1941	All	grille to center panel (Hex. Hd. Tapping No. 10-12x $\frac{3}{8}$ ")	6	178781	(8.977)
1941-42	All	grille to fender (Spec. $\frac{1}{4}$ "-20x $\frac{3}{4}$ ")	4	504368	(8.309)
1941 thru 47	All	grille to support (Spec. Hd. $\frac{1}{4}$ "-20x $\frac{5}{8}$ ")	AR	505097	(1.267)
1942	All	grille mldg. to center panel (Hex. Hd. Tapping No. 14-10x $\frac{3}{4}$ ")	4	3650059	(8.143)
1946, 1950	All	grille to fender (Hex. Hd. Tapping No. 15-10x $\frac{1}{8}$ ")	2	426648	-----
1946-47	All	grille to fender (Hex. Hd. Spec. No. 14-10x $\frac{1}{8}$ ")	2	3651216	(8.206)
1949-50	All	grille to fender (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	4	178781	(8.977)
1950 thru 52	All	center bar to lower bar	AR	426648	-----
1951-52	All	grille to fender (Hex. Hd. No. 14-10x $\frac{1}{2}$ ")	10	189694	(8.977)
1951-52	All	grille to spinner (Hex. Hd. Tapping No. 14-10 x $\frac{3}{4}$ ")	4	3650039	-----
1953	All	grille to fender (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	16	451625	(8.977)
1953	All	center bar to outer bar (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	10	451625	(8.977)
1953	All	lower bar to outer bar (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	6	451625	(8.977)
1953	All	extension to outer bar (Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	8	451625	(8.977)
1954	All	(Hex. Hd. Tapping No. 10-12x $\frac{5}{8}$ ")	AR	444267	(8.977)
1954	All	center bar to outer center bar	6	444267	(8.977)
1954	All	center bar to upper outer bar	4	444267	(8.977)
1954	All	lower bar ext. to lower and center outer bar	8	444267	(8.977)
1954	All	end plate to lower bar, center bar and ext.	10	444267	(8.977)
1947	All	NUT , radiator grille to fender (Spec. No. 14-10)	2	509573	-----
1948	All	grille to fender Spring type	16	509862	-----
1951-52	All	grille lower bar to apron Spring type (No. 14-10)	4	514310	-----
1953-54	All	outer bar to apron Spring type (No. 14-10)	6	514310	-----
Group 1.272 BAFFLE, RADIATOR SUPPORT TO FENDER					
1939	All	R.H.	1	502748	-----
1940	All exc. 29	R.H.	1	503687	-----
1940	All exc. 29	L.H.	1	503688	-----
1940	29 All	R.H.	1	503732	-----
1940	29 All	L.H.	1	503733	-----
1942 thru 47	All	R.H.	1	517036	-----
1942 thru 47	All	L.H.	1	517037	-----
1948	All	R.H.	1	510503	-----
1948	All	L.H.	1	510504	-----
1949 thru 52	All	R.H.	1	513763	-----
1949 thru 52	All	L.H.	1	513764	-----
1953-54	All	R.H.	1	515638	-----
1953-54	All	L.H.	1	515639	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.273 CLAMP, RADIATOR GRILLE					
1939	All	outer grille.....	R.H. 4	503287	-----
1939	All	outer grille.....	L.H. 4	503288	-----
1939	All	inner grille upper.....	R.H. 1	502529	-----
1939	All	inner grille upper.....	L.H. 1	502530	-----
1939	All	inner grille inside lower.....	R.H. 1	502531	-----
1939	All	inner grille inside lower.....	L.H. 1	502532	-----
1939	All	inner grille outside lower.....	R.H. 1	503287	-----
1939	All	inner grille outside lower.....	L.H. 1	503288	-----
1939	All	inner grille center.....	R.H. 1	503157	-----
1939	All	inner grille center.....	L.H. 1	503158	-----
1940	All	side grille.....	16	503676	-----
Group 1.277 SHROUD, RADIATOR FAN					
1941 thru 48	P/6	-----	1	505355	-----
1941 thru 48	P/8	-----	1	505436	-----
1949 thru 54	P/6	-----	1	511378	-----
1949 thru 54	P/8	-----	1	517406	-----
Group 1.285 BAFFLE, RADIATOR (UPPER)					
1947	All	-----	1	510012	-----
1948	All	also support for hood catch plate, see Group 8.080.	1	510534	-----
1949-50	All	also support for hood catch plate, see Group 8.080.	1	511761	-----
1951-52	All	-----	1	514569	-----
1953-54	All	-----	1	515175	-----
1953-54	All	COVER, radiator upper baffle hole.....	2	516790	-----
1948	All	FILLER, rad. baffle to frt. fender.....	2	510579	-----
1949 thru 52	All	SUPPORT, rad. baffle to front fender.....	Upper 1	511931	-----
1953-54	All	radiator baffle to front fender.....	Upper 1	515370	-----
1947-48	All	BOLT, baffle to fender support.....	2	132259	----- (8.907)
		brkt. (Fl. Hd. 1/4"-20x5/8")	2	509862	----- (1.269)
1949-50	All	NUT, rad. supt. baffle to inner baffle—spring type.....	2	516618	----- (1.264)
1953-54	All	radiator upper baffle seal to baffle—spring type.....	7	516622	-----
1953-54	All	SEAL, radiator upper baffle to radiator upper tank.....	1	516622	-----
1949 thru 54	All	SCREW, upper baffle to frt. fender.....	4	3650059	----- (8.143)
		support (No. 14-10x3/4")	7	444267	----- (8.977)
1954	All	upper baffle seal to baffle.....	7	444267	-----
Group 1.286 WELT, RADIATOR SUPPORT TO FENDER BAFFLE					
1942 thru 47	All	-----	2	506975	-----
Group 1.303 PLATE, RADIATOR GRILLE EMBLEM					
1938	P/8	-----	Lower 1	501221	-----
1941	P/8	on radiator center panel.....	1	505207	-----
1942	All	on radiator center panel.....	1	507091	-----
1953	All	BEZEL, radiator grille emblem.....	1	516770	-----
1946	All	EMBLEM, radiator grille name plate.....	1	508941	-----
1949	All	on radiator grille ornament.....	Lucite 1	512099	-----
1950	All	on radiator grille ornament.....	Lucite 1	513703	-----
1951	All	on radiator grille spinner.....	Lucite 1	514692	-----
1952	All	on radiator grille spinner.....	Lucite 1	516466	-----
1953	All	on radiator grille center bar.....	Lucite 1	514692	-----
1950	All	NUT, radiator grille emblem plate to ornament—spring type.....	4	513704	-----
1951-52	All	-----	4	514130	-----
1953	All	bezel to center bar.....	3	120361	----- (8.915)
1949	All	RETAINER, radiator grille emblem.....	1	512176	-----
Group 1.303 PLATE, RADIATOR GRILLE NAME					
1937	P/6	on radiator center grille.....	1	500447	-----
1938	All	on radiator center grille.....	Upper 1	501197	-----
1939	All	on hood center grille.....	1	502822	-----
1940	All	on hood center grille.....	Inner 1	503788	-----
1940	All	on hood center grille.....	Outer 1	504260	-----
1941	All	on hood front.....	1	505353	-----
1946	All	on radiator grille.....	1	508940	-----
1947	All	on radiator grille.....	1	509565	-----
1948	All	on radiator grille.....	1	510524	-----
1951	All	on upper center bar.....	1	515771	-----
1952	All	on upper center bar.....	1	516482	-----
1953	All	on hood front—red.....	1	516773	-----
1953	All	on hood front—black.....	1	517417	-----
1954	All	on hood front.....	1	517548	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 1.303 PLATE, RADIATOR GRILLE NAME (Continued)						
1954	All	BAR, hood front name plate.....	1	517544	-----	
1954	All	BEZEL, hood front name plate.....	1	517546	-----	
1940	All	CLAMP, hood center grille name plate.....	2	494157	-----	(3.483)
1941	All	NUT, name plate to center panel—spring type.....	2	505303	-----	
1952	All	name plate to center bar—spring type.....	2	516934	-----	
1953-54	All	name plate to hood.....	AR	446059	-----	(8.148)
1954	All	name plate to bar.....	1	517611	-----	
1948	All	RETAINER, radiator grille name plate to grille.....	1	510525	-----	
1954	All	SPACER, hood front name plate stud.....	2	517600	-----	
1947	All	SUPPORT, radiator grille name plate.....	1	509572	-----	
1953-54	All	WASHER, radiator grille name plate.....	4	511948	-----	(8.039)
1954	All	name plate to bar.....	1	517603	-----	
Group 1.303 ORNAMENT, RADIATOR GRILLE						
1949	All	less lucite emblem plate.....	1	512164	-----	
1950	All	less lucite emblem plate.....	1	513698	-----	
1951-52	All	SPINNER, radiator grille—less lucite emblem.....	1	515975	-----	
1949	All	BRACE, rad. grille ornament to fender support.....	1	512149	-----	
1950	All		1	513739	-----	
1951-52	All	BRACKET, rad. grille spinner to rad. supt. brace.....	1	514793	-----	
1951-52	All	SPACER, rad. grille spinner retainer.....	2	514447	-----	
Group 1.309 BRACE, RADIATOR SUPPORT						
1941	All	to splash apron.....	1	505830	-----	
Group 1.359 FAN, ENGINE						
1937	All	with packing type pump.....	1	500060	-----	
1937 thru 39	All	with packless type pump, for high altitude and hot climate.....	Special	501751	-----	
1937 thru 40	All	with packless type pump.....	Standard	501398	-----	
1941 thru 48	All		1	505074	-----	
1949 thru 54	All		1	511289	-----	
1939 thru 54	All	BOLT, engine fan attaching..... (Hex. $\frac{5}{16}$ "-24x $\frac{5}{8}$ ")	4	181593	-----	(8.900)
Group 1.363 HUB, WATER PUMP AND FAN						
1937 thru 54	All	with packless pump.....	1	507036	-----	
Group 1.406 PULLEY, WATER PUMP AND FAN						
1937	All	with packing type pump.....	1	500063	-----	
1937 thru 48	All exc.	with packless type pump.....	1	500709	-----	
1939-40	P/6	with packless type pump.....	1	501911	-----	
1949 thru 54	All	with packless type pump.....	1	512481	-----	
Group 1.416 BELT, FAN AND GENERATOR						
1933 thru 36	All	 approximate length 20 $\frac{1}{2}$ "	1	494967	-----	
1937 thru 48	All	 approximate length 22 $\frac{1}{2}$ "	1	500064	-----	
1949 thru 51	All exc.	 approximate length 18"	1	511312	-----	
1949 thru 51	police gen.		1	512361	-----	
1949 thru 51	All w/police gen.		1	512361	-----	
1952 thru 54	All		1	516636	-----	
Group 1.426 PAN, OIL						
1935 thru 38	P/6		1	497120	-----	
1935 thru 52	P/8	use 1—504093 oil level rod on 1935 thru 39.....	1	511310	-----	
1939 thru 52	P/6		1	511294	-----	
1953-54	P/6		1	515093	-----	
1953-54	P/8		1	515096	-----	
1933 thru 54	All	BOLT, oil pan to block..... (Hex. $\frac{5}{16}$ "-18x $\frac{5}{8}$ ")	AR	180075	-----	(8.900)
Group 1.429 GASKET SET, OIL PAN						
1933 thru 54	P/8		1	517100	-----	
1935 thru 52	P/6		1	544351	-----	
1953-54	P/6		1	517099	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 1.453 SCREW, OIL PAN DRAIN						
1933 thru 54	All	See Groups 4.105 & 4.195 for use.....	1	514395 1307238	----- -----	
Group 1.456 GASKET, OIL PAN DRAIN SCREW						
1935 thru 54	All	See Group 4.105 and 4.195 for use.....	1	513975 1307237	----- -----	
Group 1.516 ROD, OIL LEVEL INDICATOR						
1935 thru 52	All exc.	-----	1	497109	-----	
1940 thru 48	P/8 1940 thru 48	-----	1	504093	-----	
1953-54	All	-----	1	515091	-----	
1953-54	All	TUBE , oil level indicator rod.....	1	514989	-----	
Group 1.519 PIPE, OIL SUCTION						
1940	P/8	-----	1	503649	-----	
1940	P/6	-----	1	503648	-----	
1941	P/8	cleaner to pump.....	1	506115	-----	
1933 thru 54	All	NUT , oil suction pipe, 1/2" threaded sleeve.....	1	120243	-----	(8.963)
1941	All	SCREW , suction pipe to cleaner... (Fil. Hd. 1/4"-20x5/8")	2	132259	-----	(8.907)
Group 1.520 GASKET, OIL PUMP SUCTION PIPE FLANGE						
1941	All	at oil cleaner pipe flange.....	1	506119	-----	
Group 1.565 DRAIN, CRANKSHAFT REAR BEARING OIL						
1936 thru 49	All exc.	pipe.....	1	501723	-----	
1936 thru 49	P/6 1939 thru 49	-----	1	498844	-----	
	All exc.	GASKET , rear bearing cap oil return pipe.....	1		-----	
	P/6 1939 thru 49	-----			-----	
Group 1.604 GASKET, OIL PRESSURE REGULATOR						
1933 thru 54	All	round closed..... (5/8" I.D.)	1	105453	-----	(8.955)
Group 1.609 BALL, OIL PRESSURE REGULATOR						
1936 thru 54	All	----- (3/16" Dia.)	1	104923	-----	(8.899)
Group 1.610 SPRING, OIL PRESSURE REGULATOR						
1936 thru 54	All	use with 513603 Retainer prior to 1950.....	1	513604	-----	
Group 1.613 RETAINER, OIL PRESSURE REGULATOR SPRING						
1936 thru 49	All	-----	1	498820	-----	
1950 thru 54	All	-----	1	513603	-----	
Group 1.643 GEAR, DISTRIBUTOR AND OIL PUMP DRIVE						
1948 thru 54	All	-----	1	505078	-----	
1936 thru 52	All	OIL PUMP GEAR & SHAFT PKG. (with dist. gear)	1	510942	-----	(1.709)
1953-54	All	-----	1	517183	-----	(1.709)
Group 1.644 SPRING, DISTRIBUTOR DRIVE FLAT						
1933 thru 54	All	in gear.....	3	495016	-----	
1933 thru 54	All	RING , distributor drive spring retainer.....	1	495061	-----	
1933 thru 47	All	PIN , distributor gear grooved..... (1/8"x3/8")	1	142487	-----	(8.940)
Group 1.652 PUMP ASSEMBLY, OIL						
1936 thru 54	All	-----	1	517091	-----	
Group 1.653 BODY, OIL PUMP						
1933 thru 52	All	-----	1	495011	-----	
1953-54	All	-----	1	517092	-----	
Group 1.655 GASKET, OIL PUMP TO BLOCK						
1933 thru 54	All	-----	1	495009	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 1.656 SCREEN, OIL CLEANER					
1933 thru 40	All	-----	1	494931	-----
1942 thru 54	All	-----	1	507243	-----
Group 1.657 WASHER, OIL SCREEN COVER PACKING					
1933 thru 40	All	steel.....(Spec. 1/2")	2	494929	-----
Group 1.658 SHAFT, OIL PUMP DRIVEN GEAR					
1933 thru 47	All	-----	1	495017	-----
1948 thru 52	All	-----	1	511237	-----
1953-54	All	-----	1	517096	-----
Group 1.659 GEAR, OIL PUMP DRIVEN					
NOTE: Do not use 525093 on P/6 1940 between Engine No. 662596 and 663049, use Oil Pump Assembly.					
1929 thru 52	All	-----	1	525093	-----
1953-54	All	-----	1	517093	-----
Group 1.660 CLEANER ASSEMBLY, ENGINE OIL					
1941 thru 54	P/6	-----	1	508343	-----
1941 thru 54	P/8	-----	1	508344	-----
Group 1.660 COVER, OIL CLEANER SCREEN					
1939-40	All exc. P/8 1939	-----	1	503563	-----
1942 thru 54	P/6	includes oil line	1	508345	-----
1942 thru 54	P/8	includes oil line	1	508346	-----
1933 thru 40	All	RETAINER, OIL SCREEN	1	494932	-----
1941	All	-----	1	506180	-----
Group 1.663 CUP, OIL CLEANER					
1942 thru 54	All	-----	1	507237	-----
1942 thru 54	All	GASKET, oil cleaner cup	1	507438	-----
1941	All	SCREW, oil cleaner cup to cover			
		(Fil. Hd. No. 10-32x5/8")	10	132119	(8.907)
1942 thru 54	All	(Fil. Hd. No. 10-32x3/8")	12	132105	(8.907)
Group 1.664 BOLT, OIL PUMP TO BLOCK					
1933 thru 54	All	----- (Hex. 3/8"-16x1 1/4")	2	180124	(8.900)
Group 1.665 SPRING, OIL SCREEN COVER PACKING					
1933 thru 40	All	-----	1	494930	-----
Group 1.709 GEAR AND SHAFT ASSY., OIL PUMP DRIVE					
1948 thru 52	All	-----	1	511234	-----
1953-54	All	-----	1	517094	-----
1936 thru 52	All	OIL PUMP GEAR & SHAFT PKG. (with dist. gear)	1	510942	-----
1953-54	All	-----	1	517183	-----
1928 thru 47	All	KEY, oil pump drive gear(Woodruff 1/8"x1/2")	1	106749	(8.960)
Group 1.723 COVER, OIL PUMP BODY					
1933 thru 47	All	-----	1	495021	-----
1948 thru 54	All	-----	1	511233	-----
Group 1.724 GASKET, OIL PUMP COVER					
1933 thru 54	All	-----	1	495020	-----
Group 1.729 PIPE, OIL GAUGE					
1935 thru 54	All	copper, cut to required length.....(1/8"x10 ft. coil)	AR	1399637	(8.964)
Group 1.737 ELBOW, OIL GAUGE PIPE					
1935 thru 54	All	to block.....(Threaded sleeve 1/8")	1	134251	(8.963)
1933 thru 54	All	NUT, oil gauge pipe(Threaded sleeve 1/8" tubing)	2-4	121534	(8.963)
1938 thru 54	All	UNION, oil gauge pipe(Threaded sleeve 1/8" tubing)	1	144414	(8.963)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 1.740 CONNECTOR, COMPRESSION COUPLING						
1934 thru 54	All	distributor to carburetor line (Threaded sleeve $\frac{3}{16}$ " tubing)	1	152120	-----	
1935 thru 54	All	vac. pump to w/s cleaner (Threaded sleeve $\frac{1}{4}$ " tubing)	1	148330	-----	(8.963)
Group 1.743 GROMMET, OIL GAUGE LINE						
1937 thru 52	All	 (2 hole type $\frac{1}{4}$ " dia.)	1	493908	-----	(9.775)
Group 1.758 CAP, CRANKCASE BREATHER						
1940	All	with Std. air cleaner.....	1	1529238	-----	
1940 thru 54	All	with heavy duty air cleaner.....	1	1529885	-----	
1941 thru 54	All	with Std. air cleaner.....	1	1529884	-----	
Group 1.760 INLET ASSEMBLY, OIL FILLER AND VENTILATOR						
1940	28-29 All	except police car generator.....	1	504301	-----	
1940 thru 51	P/6	except police car generator.....	1	506731	-----	
1940 thru 51	P/8		1	506731	-----	
1941 thru 51	P/6	for police car generator.....	1	506297	-----	
1952 thru 54	All		1	506731	-----	
Group 1.762 PIPE, CRANKCASE VENTILATOR OUTLET						
1936 thru 39	All		1	501415	-----	
1940 thru 54	All	with Std. air cleaner.....	1	504081	-----	
1941 thru 54	All	with heavy duty air cleaner.....	1	506160	-----	
Group 1.773 GASKET, VENTILATOR OUTLET						
1933 thru 39	All	outlet pipe screw..... (Rd. closed $\frac{5}{16}$ " I.D.)	1	114622	-----	(8.955)
1936 thru 39	All		1	498747	-----	
Group 1.779 SCREW, VENTILATOR OUTLET TO BLOCK						
1935 thru 39	P/8	 (Hex. $\frac{5}{16}$ "-18x3 $\frac{7}{8}$ ")	1	513564	-----	(0.446)
1936 thru 39	P/6	 (Hex. $\frac{5}{16}$ "-18x6")	1	498758	-----	
Group 1.779 CLIP, VENTILATOR OUTLET PIPE						
1940 thru 54	All L.H.D.	to pan.....	1	504082	-----	
1940 thru 54	All	CLAMP, ventilator outlet pipe..... (1 $\frac{1}{2}$ ")	1	111614	-----	(8.948)
Group 1.780 AIR CLEANER, CRANKCASE OUTLET						
1941 thru 54	All	with heavy duty air cleaner.....	1	1529886	-----	
Group 1.803 GAUGE, OIL PRESSURE						
1938	All		1	1505763	-----	
1939	All		1	1505920	-----	
1941	All		1	1506183	-----	
1946	All		1	1506803	-----	
1947	All		1	1507056	-----	
1948	All		1	1507221	-----	
1949-50	All		1	1507350	-----	
1951-52	All		1	1507535	-----	
1953-54	All		1	1507707	-----	
Group 1.844 GASKET, OIL FILTER COVER						
1940	All	top opening A.C. No. 140.....	1	853908	-----	
1941	All	top opening A.C. No. 130.....	1	853463	-----	
Group 1.853 TUBE, OIL FILTER						
1939-40	All	inlet or outlet, flexible.....	2	5570851	-----	
1941	All	inlet or outlet, flexible.....	2	853510	-----	

[illegible]

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 2.004 PEDAL, STARTER						
1939-40	P/8 L.H.D.	-----	1	502911	-----	
1941 thru 48	All L.H.D.	-----	1	512180	-----	
Group 2.010 SPRING, STARTER PEDAL ANTI-RATTLE						
1939-40	P/8	-----	1	503398	-----	
Group 2.012 BUTTON, STARTER PEDAL						
1939-40	P/8 L.H.D.	-----	1	502910	-----	
Group 2.016 GUIDE, STARTER PEDAL ROD						
1939-40	P/8	rubber.-----	1	4095471	-----	
Group 2.020 PAD, STARTER PEDAL						
1937-38	P/6 L.H.D.	-----	1	408232	-----	
1939 thru 48	All L.H.D.	-----	1	408232	-----	
Group 2.041 MOTOR AND SWITCH ASSEMBLY, STARTER						
1939-40	P/6 L.H.D.	-----	1	1107022	-----	
1939-40	P/8 L.H.D.	-----	1	1107914	-----	
1941 thru 48	P/6 L.H.D.	-----	1	1107070	-----	
1941 thru 48	P/8 L.H.D.	use 510965 Gr. 3.430 with this assy. on 1941 thru 47	1	1107947	-----	
1949 thru 54	P/6 L.H.D.	-----	1	1107079	-----	
1949 thru 54	P/8 L.H.D.	-----	1	1107957	-----	
1935 thru 54	All	BOLT , starter to clutch housing.....(Hex. $\frac{1}{16}$ "-14x1 $\frac{1}{8}$ ")	1	497289	-----	
Group 2.043 ARMATURE, STARTER MOTOR						
1935 thru 38	All	-----	1	823881	-----	
1939 thru 54	All	-----	1	1917855	-----	
Group 2.049 COIL, STARTER MOTOR FIELD						
1935 thru 38	P/6	-----Upper	1	820153	-----	
1935 thru 38	P/6	-----Lower	1	820154	-----	
1935 thru 38, 1949 thru 54	P/8	-----Upper	1	826282	-----	
1935 thru 38, 1949 thru 54	P/8	-----Lower	1	826281	-----	
1939 thru 48	P/6	-----R.H.	1	1921607	-----	
1939 thru 48	P/6	-----L.H.	1	1921608	-----	
1939 thru 48	P/8	-----Upper	1	820153	-----	
1939 thru 48	P/8	-----Lower	1	820154	-----	
1949 thru 54	P/6	-----R.H.	1	1921195	-----	
1949 thru 54	P/6	-----L.H.	1	1921196	-----	
Group 2.051 BRUSH, STARTER MOTOR						
1935 thru 54	All	-----	4	811553	-----	
1935 thru 48	All	SCREW , brush attaching.....(No. 6-32x $\frac{1}{2}$ ")	AR	132705	-----	(8.906)
Group 2.052 HOLDER, STARTER MOTOR BRUSH						
1935 thru 54	All	-----	4	810226	-----	
Group 2.053 SPRING, STARTER MOTOR BRUSH						
1935 thru 54	All	-----	4	813521	-----	
Group 2.054 PIN, STARTER MOTOR END FRAME						
1935 thru 54	All	brush holder stop (w/insulation)-----	2	812015	-----	
1935 thru 54	All	brush holder hinge (w/insulation)-----	2	812016	-----	
1935 thru 54	All	brush holder hinge-----	2	817313	-----	
1935 thru 54	All	brush holder stop-----	2	817314	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.055 LEAD, STARTER MOTOR BRUSH					
1935 thru 54	All	ground.....	2	813554	-----
1935 thru 54	All	field.....	1	819362	-----
Group 2.063 WASHER, STARTER MOTOR THRUST					
1935 thru 54	All	commutator end—leather.....	1	818265	-----
1936 thru 38	P/6	drive end.....	1	1838568	-----
1939 thru 54	All	drive end.....	1	1838568	-----
1933 thru 38	P/8	washer, spacer—drive end.....	1	1853917	-----
Group 2.067 FRAME, STARTER MOTOR (C.E.)					
1935 thru 38	All		1	1908580	-----
1939 thru 54	P/8		1	1908580	-----
1939 thru 54	P/6		1	1907038	-----
Group 2.070 BAND, STARTER MOTOR COMMUTATOR COVER					
1935 thru 54	All		1	817114	-----
Group 2.077 BOLT, STARTER MOTOR THRU					
1935 thru 54	All	 (1/4"-20x6 ⁵ / ₁₆ ")	2	809053	-----
Group 2.083 BUSHING, STARTER MOTOR DRIVE END					
1935 thru 54	All		1	1839345	-----
Group 2.085 HOUSING, STARTER MOTOR DRIVE, WITH BUSHING					
1935 thru 38	P/6 L.H.D.		1	1858179	-----
1935 thru 38	P/8 L.H.D.		1	1858408	-----
1939-40	P/6		1	1873778	-----
1939-40	P/8		1	1874242	-----
1941 thru 48	P/6		1	1881794	-----
1941 thru 48	P/8		1	1881846	-----
1949 thru 54	P/6		1	1912392	-----
1949 thru 54	P/8		1	1912389	-----
Group 2.086 DRIVE GEAR ASSEMBLY, STARTER MOTOR					
1934 thru 54	All		1	1873789	-----
Group 2.100 SWITCH ASSY., STARTER MOTOR					
1935 thru 38	P/6		1	820052	-----
1939 thru 48	All		1	820052	-----
1949 thru 52	All L.H.D.	push button.....	1	1996053	-----
1953-54	All	starter and ignition.....	1	1116472	-----
1934	P/8	solenoid, use with 738-B Starter.....	1	001546	-----
1935 thru 38	P/8 L.H.D.	solenoid.....	1	001546	-----
1949 thru 54	All L.H.D.	solenoid.....	1	1118140	-----
1949 thru 52	All L.H.D.	BUSHING ASSY., starter switch to instrument panel.....	1	1911548	-----
Group 2.102 CONNECTOR, SOLENOID SWITCH					
1949 thru 54	P/6	to starting motor.....	1	1912117	-----
1949 thru 54	P/8	to starting motor.....	1	1912920	-----

(2.188)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.108 LEVER, STARTER MOTOR DRIVE SHIFT					
1939-40	P/6	-----	1	1878729	-----
1939-40	P/8	-----	1	1882077	-----
1941 thru 48	All	use 510965 throttle cracker stud on S.T.—	1	1885353	-----
		use 510841 throttle cracker stud on H.T.-----	1	1912114	-----
1949 thru 54	All	-----	1	1874248	-----
1939-40	P/8	auxiliary, with hub-----	1	1874245	-----
1939-40	P/8	LINK ASSEMBLY , drive shift lever w/stud-----	1	805258	-----
1935 thru 54	All	NUT , drive shift lever stud-----	1	1853305	-----
1935 thru 38	P/8	PIN , gearshift lever-----	1	1853305	-----
1949 thru 54	All	-----	1	1845936	-----
1934 thru 38	P/8	SPRING , lever return—use w/738B Str. on 1934-----	1	1859742	-----
1935 thru 40	P/6	-----	1	1881861	-----
1941 thru 54	All	-----	1	1874253	-----
1939-40	P/8	gearshift lever tension-----	1	1874251	-----
1939-40	P/8	pedal return-----	1	1848796	-----
1935 thru 54	P/8 exc.	STUD , drive shift lever-----	1	1848796	-----
	1939-40 L.H.D.	-----	1	1868003	-----
1937 thru 54	P/6 L.H.D.	-----	1	1874250	-----
1939-40	P/8	STUD , shift lever auxiliary-----	1		-----
1939-40	P/8	-----			-----
Group 2.111 SUPPORT, STARTING MOTOR GEARSHIFT LEVER RETURN SPRING					
1935 thru 54	All	-----	1	1835998	-----
Group 2.113 SCREW AND LINK ASSEMBLY, STARTER MOTOR GEAR SHIFT					
1934 thru 38	P/8	use with 738B starter in 1934-----	1	1853301	-----
1949 thru 54	All	PLUNGER AND LINK ASSY. , starter solenoid-----	1	1912055	-----
1949 thru 54	All	BOOT , starter motor solenoid plunger-----	1	1912448	-----
Group 2.170 IGNITION COIL					
1935 thru 47	All	-----	1	1911441	-----
1948 thru 54	All	-----	1	1115378	-----
Group 2.174 SLEEVE, COIL WIRE TO MANIFOLD					
1934 thru 48	P/8	rubber-----	1	496465	-----
Group 2.175 RETAINER, COIL TO DISTRIBUTOR WIRE					
1935 thru 48	All	-----	1	494104	-----
1935 thru 48	P/6 S.T.	SUPPORT , coil to distributor wire-----	2	497561	-----
Group 2.176 NIPPLE, COIL TO DISTRIBUTOR WIRE					
1935 thru 48, 1950 thru 54	All	ignition wire to dist. cap, rubber----w/small towers	AR	431508	----- (2.258)
1948-49	All	ignition wire to dist. cap-----w/large towers	AR	1885405	----- (2.258)
1948 thru 54	All	at coil for 7 m/m wire, rubber-----	1	510267	-----
Group 2.183 BRACKET, IGNITION COIL MOUNTING					
1949 thru 54	P/6	-----	1	512170	-----
Group 2.187 KEY, LOCK (UNCODED)					
1935 thru 54	All	door and ignition blank, octagon head-----	2	3694624	-----
1935 thru 54	All	tire, deck, trunk, and inst. panel compt, blank----	2	7002238	-----
Group 2.188 CYLINDER, IGNITION LOCK					
1935 thru 52	All	less keys uncoded-----	1	1097319	-----
1953-54	All	-----	1	1458180	-----
Group 2.188 SWITCH, IGNITION (LESS CYLINDER & KEYS)					
1935-36	All L.H.D.	with cable-----	1	1116255	-----
1937	All L.H.D.	-----	1	1865299	-----
1940 thru 47	All L.H.D.	with cable-----	1	1116255	-----
1948	All	less cable-----	1	1116455	-----
1949 thru 52	All	less cable-----	1	1116464	-----
1953-54	All	starter and ignition-----	1	1116472	-----
1940, 1942	All	CLIP , ignition cable to brace-----	1	504556	-----
1946-47	26 All	-----	1	504556	-----
1949 thru 52	All	NUT , ignition switch to bracket (Hex No. 10-24)-----	1	510266	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.189 BRACKET, IGNITION SWITCH					
1940	25 L.H.D.	-----	1	504473	-----
1940	26-29 L.H.D.	-----	1	504268	-----
1941 thru 48	All L.H.D.	-----	1	505860	-----
1949 thru 52	All	BRACKET ASS'Y. , ignition switch sup't.	1	512165	-----
1942 thru 48	All	SCREW , ignition switch to inst. panel	1	512165	-----
		(Pilot pt. No. 10-32x $\frac{3}{8}$ ")	2	507261	-----
Group 2.192 FERRULE, IGNITION SWITCH LOCK					
1940	All	at instrument panel	1	504343	-----
1941	All	at instrument panel	1	505824	-----
1942 thru 48	All	-----	1	507109	-----
1949 thru 52	All	-----	1	515703	-----
1953-54	All	-----	1	1923766	-----
1953-54	All	INSERT , ignition and starter switch	1	515377	-----
Group 2.201 PIPE, DISTRIBUTOR TO CARBURETOR					
1935 thru 54	All	copper tubing—cut to required length ($\frac{3}{16}$ "x10' coil)	AR	217276	----- (8.964)
1934 thru 54	All	CONNECTOR , distributor to carb. line	AR	152120	----- (1.740)
		(Threaded sleeve $\frac{3}{16}$ " tubing)	AR	114890	----- (8.963)
1935 thru 52	P/6	ELBOW , distributor to carburetor	AR	114962	----- (8.963)
1934 thru 54	All	NUT , distributor to carb. line	AR	114962	----- (8.963)
		(Threaded sleeve $\frac{3}{16}$ " tubing)	AR	114962	----- (8.963)
Group 2.239 PACKAGE, SPARK PLUG AND COIL WIRES					
1935 thru 48	P/6	-----	1	509151	-----
1937 thru 47	P/8	-----	1	509152	-----
1948	P/8	-----	1	511653	-----
1948-49	P/6	for large towers	1	511870	-----
1948-49	P/8	for large towers	1	511871	-----
1950 thru 53	P/6	-----	1	5290888	-----
1950 thru 53	P/8	-----	1	5290889	-----
Group 2.241 CABLE, HIGH TENSION IGNITION					
All	All	7 m/m-----100 ft. roll	AR	1851208	-----
Group 2.251 BRACKET, SPARK PLUG WIRE CLAMP					
1935 thru 48	P/6	-----	1	497560	-----
1949 thru 54	P/6	-----	1	512169	-----
1935 thru 48	P/6	CLAMP , spark plug wire	2	404438	-----
1954	P/8	-----	2	517746	-----
1933 thru 47	P/8	COVER , wire manifold	1	496462	-----
1948	P/8	-----	1	511171	-----
1949 thru 53	P/8	-----	1	511172	-----
1933 thru 47	P/8	MANIFOLD , spark plug wire	1	498988	-----
1948	P/8	-----	1	511173	-----
1949 thru 53	P/8	-----	1	512172	-----
1954	P/8	SUPPORT , spark plug wires	1	517747	-----
Group 2.258 NIPPLE					
		See Group 2.176 for use		431508	-----
		See Group 2.176 for use		1885405	-----
Group 2.270 PLUG, SPARK					
1934 thru 51	All	type 45, 14 m/m	AR	1559493	-----
1952 thru 54	All	type 44-5, 14 m/m	AR	5569761	-----
Group 2.271 GASKET, SPARK PLUG					
1935 thru 54	All	for 14 m/m plugs	AR	1555475	-----
Group 2.272 NIPPLE, SPARK PLUG TERMINAL INSULATING					
1937 thru 52	All	for type 45 plug	AR	510269	-----
1952 thru 54	All	for type 44-5 plug	AR	515604	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes				
Group 2.274 PULLEY AND FAN, GENERATOR									
1940 thru 48	All	----- (3½" dia.)	1	1885475	-----				
1946 thru 51	All w/police gen.	----- (3" dia.)	1	1880689	-----				
1949 thru 52	All exc.	----- (3" dia.)	1	1923266	-----				
1953-54	All exc. heavy duty	-----	1	1925294	-----				
1937 thru 39	All	FAN , use with 1100003 generator on 1937	1	1856936	-----				
1951 thru 54	All w/heavy duty gen.	FAN -----	1	1880558	-----				
1951 thru 54	All w/heavy duty gen.	PULLEY ----- (3" dia.)	1	1881158	-----				
Group 2.275 NEW GENERATOR ASSEMBLIES									
1935 thru 39	All	less pulley (60U) exchange item	1	1100502	-----				
1940 thru 48	All	less pulley (72U) exchange item	1	1102737	-----				
1949-50	All	less pulley (9U) exchange item	1	1102719	-----				
1946 thru 51	All w/police gen.	less pulley—no exchange item	1	1106403	-----				
1951 thru 54	All w/heavy duty gen.	less pulley—no exchange item	1	1105898	-----				
1951	All exc. police and heavy duty gen.	less pulley (7U) (40 amp.)—exchange item	1	1102717	-----				
1951-52	All exc. heavy duty gen.	less pulley (45 amp.)	1	1102785	-----				
1953-54	All exc. heavy duty	-----	1	1102797	-----				
Group 2.275 REBUILT GENERATOR ASSEMBLIES									
1935 thru 39	All	less pulley (60U) exchange item	1	1100503	-----				
1940 thru 48	All	less pulley (72U) exchange item	1	1102744	-----				
1949-50	All	less pulley (9U) exchange item	1	1102742	-----				
The following list of used Delco Remy Generators are acceptable for \$2.00 exchange credit each on the purchase of either new or rebuilt generator assemblies. These model numbers are stamped on the generator identification plate.									
9-U	935-C	935-V	936-M	937-B	948-G	948-Z	1100007	1102664	1102711
60-U	935-F	935-W	936-N	943-B	948-N	1100001	1100008	1102665	1102717
72-U	935-K	935-X	936-P	943-J	948-R	1100002	1100009	1102667	1102719
918-F	935-L	936-C	936-R	943-Y	948-S	1100003	1100460	1102680	1102737
918-G	935-M	936-H	936-T	946-C	948-U	1100004	1100502	1102701	1102742
935-B	935-U	936-J	936-U	948-B	948-Y	1100005	1100503	1102710	1102744
NOTE: Return used Generators to GMPD Warehouse for exchange credit.									
Group 2.275 BOLT, GENERATOR MOUNTING									
1933 thru 54	All	bracket to block	(Hex. 5/16"-18x3/4")	1	180077	-----	(8.900)		
1937 thru 54	All	generator to bracket, long	(Hex. 5/16"-24x1 1/4")	2	181610	-----	(8.900)		
1940 thru 48	All with Police Gen.	to front end plate	(Hex. Spec. 5/16"-18x1 3/8")	1	500757	-----			
1940 thru 51	All with Police Gen.	generator to bracket	(Hex. 7/16"-20x2")	2	124133	-----	(8.900)		
1933 thru 54	All exc. Police Gen.	NUT , generator mounting bolt	Special	2	517011	-----			
Group 2.277 BRACKET, GENERATOR MOUNTING									
1935 thru 39	All exc. Police Gen.	-----	Rear	1	505573	-----			
1940	All exc. Police Gen.	-----	Rear	1	503631	-----			
1940 thru 48	All with Police Gen.	-----	Front	1	504945	-----			
1941 thru 51	All exc. Police Gen.	-----	Rear	1	505573	-----			
1941 thru 51	All with Police Gen.	-----	Rear	1	512362	-----			
1952 thru 54	All exc. heavy duty	-----	Rear	1	505573	-----			
Group 2.279 ARMATURE, GENERATOR									
1935 thru 39	All	-----	1	1871826	-----				
1940 thru 50	All	-----	1	1921235	-----				
1951	All exc. Police Gen.	use w/40 amp. gen.	1	1912599	-----				
1951 thru 54	All heavy duty	-----	1	1918009	-----				
1951-52	All exc. heavy duty gen.	use w/45 amp. gen.	1	1921621	-----				
1953-54	All exc. heavy duty	-----	1	1912599	-----				

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.280 NUT, GENERATOR ARMATURE SHAFT					
1935 thru 54	All	-----	1	806915	-----
Group 2.285 BRUSH, GENERATOR					
1940 thru 51	All	-----	2	1906917	-----
1952 thru 54	All exc. heavy duty gen.	-----	2	1923295	-----
1933 thru 39	All	BRUSH PACKAGE -----	1	1857963	-----
Group 2.286 SPRING, GENERATOR BRUSH					
1934 thru 39	All	main brush-----	2	1850760	-----
1934 thru 39	All	third brush-----	1	1850767	-----
1940 thru 51	All	-----	2	1878184	-----
1952 thru 54	All exc. heavy duty gen.	-----	2	1908829	-----
Group 2.287 PLATE, GENERATOR BRUSH					
1937 thru 39	All	main brush, use with 1100003 generator on 1937 -	1	1871806	-----
1940 thru 48	All	-----	1	1878177	-----
Group 2.291 ARM, GENERATOR BRUSH					
1934 thru 39	All	-----	3	1850759	-----
1940 thru 54	All	-----	2	1878183	-----
Group 2.297 FRAME, GENERATOR COMMUTATOR END (With Bushing)					
1940 thru 51	All exc. Police Gen.	-----	1	1913990	-----
1952 thru 54	All exc. heavy duty gen.	-----	1	1923069	-----
Group 2.298 BUSHING, GENERATOR COMMUTATOR END FRAME					
1935 thru 48	All	-----	1	812823	-----
Group 2.299 BAND, GENERATOR COMMUTATOR COVER					
1935 thru 51	All	use with 1100003 generator on 1937-----	1	816340	-----
1937	All	use with all generators except 1100003-----	1	1861502	-----
Group 2.300 CAP, GENERATOR COMMUTATOR END DUST					
1935 thru 48	All	-----	1	820524	-----
1935 thru 48	All	GASKET , dust cap-----	1	817220	-----
Group 2.301 OIL FITTINGS, GENERATOR COMMUTATOR END					
1935 thru 48	All	wick, oil-----felt	1	804076	-----
Group 2.305 FRAME PACKAGE, GENERATOR DRIVE END					
NOTE: Package consists of 1 drive end frame, 1 plate and 1 gasket.					
1937 thru 52	All	use with 1100003 Generator on 1937-----	1	1910404	-----
1953-54	All exc. heavy duty	-----	1	1925295	-----
Group 2.306 BEARING, GENERATOR					
1935 thru 54	All exc. Police Gen.	drive end-----	1	954378	-----
Group 2.307 COLLAR—GASKET—PLATE—SCREW—WASHER, GENERATOR DRIVE END					
1929 thru 34	All	COLLAR , spacer-----	1	817224	-----
1935 thru 54	All	-----	1	1858603	-----
1935 thru 54	All	GASKET , bearing retainer plate-----	1	1912008	-----
1935 thru 54	All	PLATE , bearing retainer-----	1	1911263	-----
1937 thru 54	All	SCREW , bearing retainer plate-----	3	1904370	-----
1935 thru 54	All	LOCKWASHER , bearing retainer plate screw---($\frac{3}{16}$ ")-----	3	802731	-----
1935 thru 54	All	WASHER , bearing spacer—inside-----	1	809945	-----
1935 thru 54	All	bearing felt-----	1	809961	-----
1935 thru 54	All	OILER -----	1	125609	-----

(8.984)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 2.310 COIL UNIT, GENERATOR FIELD						
1934 thru 39	All	-----	1	1902105	-----	
1940 thru 48	All	-----	1	1902111	-----	
1949-50	All exc.	-----	1	1912654	-----	
1951 thru 54	Police Gen. All exc. heavy duty gen.	-----	1	1922702	-----	
Group 2.313 STUD AND LEAD, GENERATOR						
1935 thru 48	All	w/terminal -----	1	1858754	-----	
Group 2.316 BOLT, GENERATOR THRU						
1940 thru 54	All	-----	2	809763	-----	
Group 2.317 STRAP, GENERATOR ADJUSTING						
1937 thru 48	All	-----	1	499777	-----	
1949 thru 51	All with	-----	1	512363	-----	
1949 thru 51	Police Gen. All exc.	-----	1	516634	-----	
1952 thru 54	Police Gen. All	-----	1	516634	-----	
1935 thru 54	All exc.	SPACER , generator adjusting strap -----	1	499778	-----	
1933 thru 54	Police Gen. All	WASHER , generator adj. strap to gen... (Special $\frac{5}{16}$ ") -----	1	525083	-----	
Group 2.333 SUPPORT, BATTERY						
1937	All	-----	1	499780	-----	
1938 thru 54	All	-----	1	501214	-----	
1939-40	26 All	BRACKET , battery support to frame ----- Rear	1	501983	-----	
1940	29 All	----- Rear	1	503866	-----	
1941 thru 48	25 All	----- Rear	1	505415	-----	
1941 thru 48	26-29 All	----- Rear	1	505416	-----	
1949 thru 52	All	----- Rear	1	511863	-----	
1949 thru 52	All	----- Front	1	511862	-----	
1953-54	All	----- Front	1	515405	-----	
1953-54	All	----- Rear	1	515406	-----	
1949 thru 52	All	BRACE , battery to fender skirt -----	2	511864	-----	
1953-54	All	-----	2	515382	-----	
1938 thru 48	All	FELT , battery support -----	2	501218	-----	
1940 thru 48	All	SCREW , battery support to frame... (Hex. $\frac{5}{16}$ "-18x $\frac{3}{4}$ ") -----	1	171104	-----	(8.977)
1949 thru 54	All	battery support to frame... (Hex. $\frac{3}{8}$ "-16x $\frac{3}{8}$ ") -----	5	171121	-----	(8.977)
1939 thru 48	All	WASHER , battery support to frame... (Spec. $1\frac{1}{32}$ " I.D.) -----	2	365685	-----	(4.664)
Group 2.334 RETAINER, BATTERY						
1938 thru 48	All	-----	1	508673	-----	
1938 thru 54	All	BOLT , battery hold down... (Carr. $\frac{5}{16}$ "-18x $8\frac{3}{4}$ ") -----	2	508676	-----	
1928 thru 42	All	NUT , battery clamp bolt... (Hex. $\frac{5}{16}$ "-18) -----	AR	120376	-----	(8.915)
1946 thru 54	All	----- (Hex. Spec. $\frac{5}{16}$ "-18) -----	2	508677	-----	
Group 2.335 COVER, BATTERY						
1949 thru 54	All	-----	1	417420	-----	
1949 thru 54	All	CLIP , cover -----	1	554834	-----	
1949 thru 54	All	PLATE , battery filler hole cover -----	1	417422	-----	
Group 2.337 BUMPER, BATTERY TO FENDER APRON						
1938 thru 40	25-26 All	-----	3	499379	-----	(1.216)
1946 thru 48	All	-----	1	508931	-----	
1949 thru 54	All	-----	2	506351	-----	(8.024)
Group 2.341 STRAP, BATTERY GROUND						
1933 thru 37	All	----- 9 $\frac{1}{2}$ " long	1	5286922	-----	
1938 thru 54	All	16 $\frac{1}{2}$ " C to C of holes -----	1	5286925	-----	
		see Group 2.342 for use -----		5286911	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.342 LEAD, BATTERY POSITIVE					
1934, 1937	All	30" C to C of holes.....	1	5286913	-----
1935-36	All	27½" C to C of holes.....	1	1858527	-----
1938	P/8	12½" C to C of holes.....	1	5270318	-----
1938 thru 48	All exc. P/8 1938	16½" C to C of holes.....	1	5286909	-----
1949 thru 54	P/6	27" C to C of holes.....	1	5286912	-----
1949 thru 54	P/8	23½" C to C of holes.....	1	5286911	----- (2.341)
Group 2.343 COVER, BATTERY TERMINAL CLAMP					
All thru 48	All	rubber.....	1	5270405	-----
All thru 48	All	NUT AND BOLT, battery terminal.....	2	1846532	-----
1949 thru 54	All		2	1846534	-----
Group 2.360 DISTRIBUTOR REPAIR KIT					
1937 thru 48	P/8		1	1913500	-----
1937 thru 48	P/6		1	1913502	-----
1949 thru 54	P/6		1	1912609	-----
1949 thru 54	P/8		1	1917253	-----
Group 2.361 DISTRIBUTOR, IGNITION					
1937 thru 39	P/8	(663X).....	1	1865281	-----
1948	P/6	with large towers (radio).....	1	1110217	-----
1937 thru 52	P/6	less cap and rotor.....	1	1912884	-----
1940 thru 54	P/8	less cap and rotor.....	1	1912885	-----
1953	P/6	less cap and rotor—w/7.7 ratio head.....	1	1925987	-----
1953	P/6	less cap and rotor—w/7.0 ratio head.....	1	1925988	-----
1954	P/6	less cap and rotor—w/7.7 ratio head.....	1	1928820	-----
1954	P/6	less cap and rotor—w/7.0 ratio head.....	1	1928821	-----
Group 2.362 HOUSING, DISTRIBUTOR					
1937 thru 48	P/6		1	1866161	-----
1937 thru 39	P/8		1	1866454	-----
1940 thru 48	P/8		1	1878878	-----
1949 thru 53	P/6		1	1912602	-----
1949 thru 54	P/8		1	1912670	-----
1954	P/6		1	1927351	-----
Group 2.363 BUSHING, DISTRIBUTOR HOUSING					
1937 thru 54	P/8		1	1874335	-----
1949 thru 54	P/6		1	1874335	-----
1933 thru 54	All	GASKET, distributor to block.....	1	495206	-----
Group 2.364 WICK, DISTRIBUTOR SHAFT OIL					
1935 thru 48	P/6		1	816803	-----
1935 thru 48	P/8		1	819639	-----
1949 thru 54	All		1	819639	-----
1935 thru 54	All	GREASE CUP, distributor hsg.....	AR	805579	-----
Group 2.367 CAP, DISTRIBUTOR					
1935 thru 48, 1950 thru 54	P/8	with small towers.....	1	1837974	-----
1935 thru 48, 1950 thru 53	P/6	with small towers.....	1	824735	-----
1948-49	P/8	with large towers (radio).....	1	1911566	-----
1948-49	P/6	with large towers (radio).....	1	1911597	-----
1954	P/6		1	1924248	-----
Group 2.368 SPRING, DISTRIBUTOR CAP RETAINER					
1935 thru 54	P/6		2	1871838	-----
1949 thru 54	P/8		2	1909594	-----
Group 2.369 SUPPORT, DISTRIBUTOR CAP RETAINER SPRING					
1935 thru 48	P/6		2	1847289	-----
1949 thru 54	All		2	1847289	-----
1935 thru 54	P/8	SUPPORT PKG. (Contains 1 spring and 1 support).....	2	1911336	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.372 SHAFT, DISTRIBUTOR MAIN					
1937 thru 48	P/8	-----	1	1866458	-----
1937 thru 48	P/6	-----	1	1866886	-----
1949 thru 51	P/8	-----	1	1912673	-----
1949 thru 52	P/6	-----	1	1912607	-----
1952-54	P/8	-----	1	1923045	-----
1953	P/6	-----	1	1925242	-----
1954	P/6	-----	1	1927354	-----
Group 2.379 PIN, DISTRIBUTOR SHAFT COLLAR ATTACHING					
1937 thru 54	All	-----	1	813131	-----
1935 thru 48	P/8	COLLAR , distributor shaft.....	1	819741	-----
1935 thru 48	P/6	-----	1	1858578	-----
1949 thru 54	All	-----	1	821865	-----
1935 thru 54	All	WASHER , dist. shaft spacer.....(.005" thick)	AR	810074	-----
1935 thru 54	All	-----(.010" thick)	AR	810078	-----
Group 2.381 CAM ASSEMBLY, DISTRIBUTOR					
1937 thru 48	P/8	-----	1	1866456	-----
1937 thru 48	P/6	-----	1	1867181	-----
1949 thru 54	P/8	-----	1	1912674	-----
1949 thru 52	P/6	-----	1	1912605	-----
1953	P/6	-----	1	1913882	-----
1954	P/6	-----	1	1927356	-----
Group 2.382 ROTOR, DISTRIBUTOR					
1935 thru 54	P/8	-----	1	1836893	-----
1935 thru 54	P/6	-----	1	820445	-----
Group 2.384 POINT PACKAGE, DISTRIBUTOR					
NOTE: Point Package consists of 1 Breaker Arm and 1 Support with Points.					
1935-36	P/6	-----	1	1882391	-----
1937 thru 54	P/6	-----	1	1871678	-----
1937 thru 54	P/8	-----	1	1918148	-----
Group 2.385 PLATE, DISTRIBUTOR BREAKER					
1949 thru 54	P/6	-----	1	1912783	-----
1949 thru 54	P/8	-----	1	1912784	-----
1935 thru 48	All	BALL , steel.....($\frac{1}{4}$ " dia.)	3	104918	-----
1937 thru 48	P/8	REPAIR PKG. , dist. breaker plate and brgs.....	1	1914446	-----
1937 thru 48	P/6	-----	1	1914448	-----
1949 thru 54	P/6	RETAINER , dist. breaker plate.....	1	1912614	-----
1949 thru 54	P/8	-----	1	1912226	-----
1949 thru 54	All	SPRING , dist. breaker plate washer.....	1	1912227	-----
1949 thru 54	All	WASHER , dist. breaker plate.....	AR	1912225	-----
1949 thru 54	All	dist. breaker plate brg.....	1	1912224	-----
1949 thru 54	All	dist. breaker plate stop.....	1	1869357	-----
Group 2.387 SCREW, DISTRIBUTOR CONTACT POINT SUPPORT CLAMP					
1935 thru 54	All	----- (No. 8-32x $\frac{5}{16}$ ")	1	816784	-----
1935 thru 54	All	NUT , distributor contact point support clamp screw.....	1	817363	-----
1937 thru 54	All	SCREW , distributor contact arm spring.....	1	1858576	-----
1937 thru 48	P/8	LOCK CLIP , distributor contact arm tension spring.....	1	1868992	-----
1949 thru 54	All	screw.....	1	1868992	-----
1937 thru 48	All	WASHER , distributor contact arm spring screw.....	1	1865977	-----
		insulator.....	1		-----
Group 2.388 WEIGHT, DISTRIBUTOR					
1935-36	P/6	-----	2	1880902	-----
1935 thru 54	P/8	-----	2	1880902	-----
1937 thru 52	P/6	-----	2	1881371	-----
1953-54	P/6	-----	2	1880902	-----

(8.899)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.389 SPRING, DISTRIBUTOR WEIGHT					
1935 thru 48	P/6	-----	2	823238	-----
1937 thru 48	P/8	-----	2	829567	-----
1949 thru 51	P/8	-----	2	1887553	-----
1949 thru 52	P/6	-----	2	1887743	-----
1953-54	P/6	-----	2	1925251	-----
1952 thru 54	P/8	-----	2	1884610	-----
Group 2.390 PLATE, DISTRIBUTOR WEIGHT HOLD DOWN					
1949 thru 54	All	-----	1	1885557	-----
Group 2.393 CONDENSER, DISTRIBUTOR					
1937 thru 54	All	with bracket and lead.....	1	1869704	-----
Group 2.400 LEAD-NUT-STUD, DISTRIBUTOR TERMINAL					
1937 thru 54	All	LEAD ASSEMBLY, distributor terminal.....	1	1865978	-----
1937 thru 54	All	LEAD, distributor breaker plate ground.....	1	1879140	-----
1935 thru 54	All	NUT, distributor terminal stud.....	1	817363	-----
1935 thru 50	All	STUD, distributor terminal, w/bushing.....	1	1853625	-----
Group 2.401 BUSHING—CLIP—SCREW, DISTRIBUTOR TERMINAL					
1935 thru 48	All	BUSHING, distributor contact arm screw.....	1	1904600	-----
1937 thru 48	All	distributor terminal stud—inside housing.....	1	1865985	-----
1949	All	-----	1	1912229	-----
1935 thru 50	All	CLIP, distributor terminal.....	1	026153	-----
1935 thru 48	All	SCREW, distributor terminal... (Rd. Hd. No. 8-32x $\frac{3}{8}$ ")	3	121832	-----
Group 2.410 VACUUM CONTROL, DISTRIBUTOR					
1937 thru 39	P/8	(681N).....	1	1865777	-----
1937 thru 52	P/6	-----	1	1116051	-----
1940 thru 54	P/8	-----	1	1116050	-----
1953	P/6	-----	1	1116077	-----
1954	P/6	-----	1	1116079	-----
Group 2.414 CLAMP, DISTRIBUTOR ADJUSTING					
1935 thru 39	All exc.	-----	1	1858458	-----
	P/6 1939	-----	1	1873331	-----
1939-40	All exc. P/8 1939	with arm.....	1	1873331	-----
1941 thru 49	P/8	with arm.....	1	1914530	-----
1941 thru 49	P/6	with arm.....	1	1914530	-----
1950 thru 54	All	with arm.....	1	1914530	-----
Group 2.420 COUPLING, DISTRIBUTOR VACUUM CONTROL					
1937 thru 48	P/8	-----	1	1866166	-----
1937 thru 48	P/6	-----	1	1865656	-----
Group 2.421 GASKET, DISTRIBUTOR VACUUM CONTROL COUPLING					
1935 thru 48	All	-----	1	1841901	-----
Group 2.447 SWITCH, STOPLIGHT					
1935 thru 39	All	-----	1	403936	-----
1940 thru 54	All	-----	1	1997725	-----
Group 2.453 SCREW, STOPLIGHT SWITCH TERMINAL					
1935 thru 39	All	----- (No. 5-40x $\frac{3}{16}$ ")	2	403949	-----
Group 2.459 SWITCH, DIMMER					
1935 thru 54	All	-----	1	1997008	-----

(2.387)

(8.906)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.480 HARNESS, CHASSIS AND BODY WIRING, L.H.D.					
1937	P/6 Std.	-----	1	1866899	-----
1941	All	WIRING ASSEMBLY, main -----	1	1882504	-----
1942 thru 47	All	-----	1	1885004	-----
1948	All	except cars with direction signal-----	1	5288134	-----
1948	All	cars with direction signal-----	1	5288490	-----
1949-50	All	except cars with direction signal-----	1	5291191	-----
1949-50	All	cars with direction signal-----	1	5291192	-----
1951-52	All	except cars with direction signal-----	1	5291063	-----
1951-52	All	cars with direction signal-----	1	5291062	-----
1953-54	All	cars with direction signal-----	1	5292828	-----
Group 2.482 CLAMP, WIRE ASSEMBLY THRU DASH					
1936 thru 40	All	-----	2	498709	-----
1941 thru 48	25 L.H.D.	for cars w/o direction signal-----	1	505915	-----
1941 thru 48	26-29 L.H.D.	-----	1	505903	-----
1949-50	All	CLAMP ASSY., main wire and speedo. cable dash—	1	514117	-----
		includes fuse holder-----	1	514372	-----
1951 thru 54	All	accessory wires-----	1	512260	-----
1949 thru 54	All exc. 1949	-----	1	512262	-----
	2567	accessory wires-----	1	512452	-----
1949	2567	MANIFOLD ASSY., wires to dash -----	1	515449	-----
1953-54	All	Left side-----	1	512517	-----
1953-54	All	Center-----	1	512518	-----
1949 thru 54	All	PLATE, speedo. cable and wiring harness cover -----	1		
1949 thru 54	All	FELT, speedo. cable and wiring harness cover plate -----	1		
Group 2.483 BLOCK, ACCESSORY FUSE AND TERMINAL					
1949-50	All	-----	1	1998777	-----
1951-52	All	-----	1	1998783	-----
1953-54	All	-----	1	1998785	-----
1949-50	All	COVER, accessory fuse and terminal block -----	1	512109	-----
1951	All	-----	1	514681	-----
1952	All	-----	1	516514	-----
1953-54	All	-----	1	515446	-----
Group 2.485 SWITCH, LIGHT					
1935-36	P/6 1935	-----	1	1859427	-----
	Mstr., 1936 All	-----	1	1995002	-----
1938	All L.H.D.	-----	1	1995006	-----
1939	All L.H.D.	-----	1	1995018	-----
1941	All	-----	1	1995035	-----
1942 thru 48	All	-----	1	1995032	-----
1949 thru 52	All	-----	1	1995052	-----
1953-54	All	-----	1		
Group 2.486 KNOB, LIGHT SWITCH CONTROL					
1941	All	-----	1	505715	-----
1942 thru 48	All	-----	1	507216	-----
1949-50	All	-----	1	511828	-----
1951-52	All	black-----	1	515708	-----
1953-54	All	black—chrome insert-----	1	516942	-----
Group 2.487 SPACER, KNOB TO INSTRUMENT PANEL					
1940	All	light switch and throttle-----	2	504263	-----
1941 thru 48	All	light switch mounting—behind panel-----	1	511508	-----
1941 thru 48	All	BUSHING, light switch knob -----	1	505825	-----
1949 thru 52	All	-----	1	511754	-----
1953-54	All	-----	1	515441	-----
1949 thru 52	All	FERRULE, lighting switch -----	1	515699	-----
1953-54	All	-----	1	516921	-----
1941 thru 48	All	FLANGE, light switch mounting -----	1	505826	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 2.500		REGULATOR ASSEMBLY, VOLTAGE AND CURRENT CONTROL				
1935 thru 38	All exc. P/6 1938	-----	1	1118315	-----	
1938-39	1938 P/6, 39 All	-----	1	1118309	-----	
1940 thru 50	All exc.	-----	1	1118301	-----	
1948 thru 51	Police Gen. All w/ Police Gen.	-----	1	1118352	-----	
1951	All w/40 amp. gen.	-----	1	1118300	-----	
1951 thru 53	All w/heavy duty gen.	-----	1	1118722	-----	
1951	All w/45 amp. gen.	-----	1	1118725	-----	
1952-53	All	-----	1	1118725	-----	
1954	All exc. heavy duty	-----	1	1118827	-----	
1954	All w/heavy duty gen.	-----	1	1118835	-----	
Group 2.515		AMMETER, INSTRUMENT PANEL				
1939	All	-----	1	857875	-----	
1940	All	-----	1	857886	-----	
1941	All	-----	1	1500383	-----	
1942	All	-----	1	1500464	-----	
1946	All	-----	1	1500759	-----	
1947	All	-----	1	1500880	-----	
1948	All	-----	1	1501065	-----	
1949-50	All	-----	1	1501156	-----	
1951-52	All	-----	1	1501286	-----	
1953-54	All	-----	1	1501357	-----	
Group 2.525		CONNECTOR-GROMMET, FUEL GAUGE WIRE				
1941 thru 48	All exc. Sta. Wag.	CONNECTOR , fuel gauge wire-----	1	3114169	-----	(2.649)
1939	All	GROMMET , fuel gauge wire rear compartment-----	1	216551	-----	(9.775)
1949 thru 52	2561-62-71 All	fuel tank to body harness-----	1	5289293	-----	
Group 2.530		CABLE, ELECTRICAL				
All	All	16 gauge-----100 ft. roll	AR	1847835	-----	
All	All	14 gauge-----100 ft. roll	AR	1847837	-----	
		see Group 2.697 for use-----		5289849	-----	
Group 2.548		NUT, HEADLAMP ANCHOR				
1939 thru 48	All	-----	8	120375	-----	(8.915)
		see Group 2.725 for use-----		413395	-----	
Group 2.550		BRACKET, HEADLAMP				
1936	All	-----R.H.	1	498852	-----	
1936	All	-----L.H.	1	498853	-----	
1937	All	-----R.H.	1	500180	-----	
1937	All	-----L.H.	1	500181	-----	
1938	All	SCREW , headlamp bracket plate-----	AR	133634	-----	(8.908)
		(Flt. Hd. No. 10-32x $\frac{1}{2}$ ")				
Group 2.560		BLOCK ASSEMBLY, HEADLAMP WIRE JUNCTION				
1939 thru 54	All	-----	2	1865535	-----	
1948	All L.H.D.	-----	2	1998763	-----	
1949 thru 54	All L.H.D.	with direction signal-----	2	1998756	-----	
Group 2.585		LAMP ASSEMBLY, FENDER				
1940	All	-----R.H.	1	916996	-----	
1940	All	-----L.H.	1	916995	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.585 LAMP ASSY., PARKING					
NOTE: When Parking Lamp Assy. is used with direction signal see Group 2.899 for Wire and Socket.					
1941	All	 L.H.	1	916359	-----
1942	All	glass lens—painted..... R.H.	1	917172	-----
1942	All	glass lens—painted..... L.H.	1	917171	-----
1942	All	lucite lens—chrome..... R.H.	1	917058	-----
1942	All	lucite lens—chrome..... L.H.	1	917057	-----
1946	All	glass lens—chrome..... R.H.	1	917302	-----
1946	All	glass lens—chrome..... L.H.	1	917301	-----
1947	All	 R.H.	1	928512	-----
1947	All	 L.H.	1	928511	-----
1948	All	 L.H.	1	928529	-----
1948	All	 R.H.	1	928530	-----
1949	All	 R.H.	1	928550	-----
1949	All	 L.H.	1	928549	-----
1950	All	 R.H.	1	928094	-----
1950	All	 L.H.	1	928093	-----
1951	All	w/die cast chrome door..... R.H.	1	928594	-----
1951	All	w/die cast chrome door..... L.H.	1	928593	-----
1951-52	All	w/stamped chrome door..... R.H.	1	928696	-----
1951-52	All	w/stamped chrome door..... L.H.	1	928695	-----
1953	All	 R.H.	1	928282	-----
1953	All	 L.H.	1	928281	-----
1954	All	 R.H.	1	928804	-----
1954	All	 L.H.	1	928803	-----
Group 2.586 BODY—COVER, PARKING LAMP					
1941	All	BODY, parking lamp.....	2	5931910	-----
1942	All	painted.....	2	5934152	-----
1946	All		2	5935892	-----
1940	All	COVER, fender lamp.....	2	5930724	-----
Group 2.587 PLATE-SUPPORT, PARKING LAMP					
1954	All	PLATE ASSY., parking lamp mounting..... Inner	2	5945171	-----
1954	All	 Outer	2	5945173	-----
1941	All	SUPPORT.....	2	505340	-----
1946	All		4	508494	-----
1947	All		4	509546	-----
1948	All		4	510541	-----
1941, 1946 thru 48	All	BOLT, parking lamp support..... (Hex. No. 10-24x $\frac{1}{8}$ ")	2	187572	-----
1954	All	SCREW, mounting plate to body.....	8	5942856	-----
Group 2.589 LENS, PARKING LAMP					
1935	All exc. P/6 Mstr.	fender lamp.....	2	918747	-----
1940	All	fender lamp.....	2	5930136	-----
1938	P/8		2	922357	-----
1942	All	with direction signal.....	2	5932902	-----
1942	All	without direction signal, lucite.....	2	5933423	-----
1946	All		2	5935895	-----
1947	All	 R.H.	1	5936792	-----
1947	All	 L.H.	1	5936791	-----
1948	All		2	5937577	-----
1949	All		2	5938308	-----
1950	All		2	5939313	-----
1951-52	All		2	5939984	-----
1953	All		2	5940671	-----
1954	All	 R.H.	1	5945178	-----
1954	All	 L.H.	1	5945177	-----
Group 2.590 GASKET, PARKING LAMP LENS					
1940	All	fender lamp.....	2	5930153	-----
1938	P/8		2	922366	-----
1941	All		2	5931648	-----
1942	All		2	5932958	-----
1946	All		2	5935896	-----
1947-48	All		2	5936778	-----
1949	All		2	5938311	-----
1950 thru 53	All		2	5939312	-----
1954	All		2	5945179	-----
		see Group 2.697 for use.....		5935956	-----

(8.900)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.591 SPRING, PARKING LAMP LENS RETAINER					
1942	All	retainer, painted for glass lens, inner.....	2	5934153	-----
1942	All	retainer, painted for glass lens, outer.....	2	5934154	-----
Group 2.593 CAP—FRAME—DOOR, PARKING LAMP					
1942	All	CAP.....R.H.	1	507137	-----
1942	All	L.H.	1	507138	-----
1941	All	FRAME.....R.H.	1	5931646	-----
1941	All	L.H.	1	5931645	-----
1946	All	R.H.	1	5935894	-----
1946	All	L.H.	1	5935893	-----
1949	All	DOOR.....R.H.	1	5938310	-----
1949	All	L.H.	1	5938309	-----
1950	All	R.H.	1	5939316	-----
1950	All	L.H.	1	5939315	-----
1951	All	die cast—chrome 1st type.....R.H.	1	5942576	-----
1951	All	die cast—chrome 1st type.....L.H.	1	5939999	-----
1951-52	All	stamped—chrome 2nd type on 1951.....R.H.	1	5942184	-----
1951-52	All	stamped—chrome 2nd type on 1951.....L.H.	1	5942183	-----
1953	All	R.H.	1	5943806	-----
1953	All	L.H.	1	5943805	-----
1954	All	R.H.	1	5945176	-----
1954	All	L.H.	1	5945175	-----
1940	All	ORNAMENT, fender lamp.....	2	5930082	-----
		see Group 2.697 for use.....		5933049	-----
Group 2.594 SEAL, PARKING LAMP					
1949-50	All	Rubber	2	511432	-----
1951 thru 53	All	Rubber	2	514749	-----
Group 2.596 SOCKET AND WIRE, PARKING LAMP					
1940	All		2	5930319	-----
1941	All	without direction signal.....	2	5931911	-----
1942	All	without direction signal.....	2	5932995	-----
1946-47	All	without direction signal.....	2	5935897	-----
1948	All	without direction signal.....	2	5937342	-----
1949	All	without direction signal.....	2	5938314	-----
1950 thru 52	All	without direction signal.....	2	5939328	-----
1954	All	RETAINER, parking lamp wire seal.....	2	517660	-----
1954	All	SEAL, parking lamp wire.....	2	517695	-----
1939	All	SCREW, fender lamp door.....(No. 8-32x1")	2	923315	-----
Group 2.628 RETAINER, PARKING LAMP					
1941	All	welds to radiator grille.....	2	505339	-----
Group 2.646 WIRE ASSEMBLY, TAIL LAMP					
1939	All exc. Sta. Wag.	with cup.....R.H.	1	923534	-----
1941 thru 47	All	tail lamp fuse.....	1	1882029	-----
1948	All	tail lamp fuse.....	1	5287898	-----
1941 thru 47	Sta. Wag.	dual tail lamp jumper.....	1	506482	-----
Group 2.649 CONNECTOR, TAIL LAMP WIRE					
1939-40	All exc. sta. wag.	2-wire—single lamp.....	2	3114169	-----
1939 thru 52	All exc. sta. wag.	3-wire—dual lamps.....	2	1872486	-----
1940 thru 54	All exc. sta. wag. & 2571	plug type terminal.....	2	1242002	-----
Group 2.652 CLIP, FUEL GAUGE WIRE					
1939 thru 48	All	wire to frame.....(Snap spring type 1/4")	2	177952	-----

(2.688)

(8.950)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.660		PAD, TAIL LAMP			
1940	2611-19	to body.....	R.H.	1	504706
1940	2627-27B-67	to body.....	L.H.	1	504709
1941 thru 47	25 All	to body, with die cast lamp.....		2	506405
1941 thru 47	2607 All	to body, with die cast lamp.....	R.H.	1	506039
1941 thru 47	2607 All	to body, with die cast lamp.....	L.H.	1	506060
1941 thru 47	2609 All	to body, with die cast lamp.....		2	506173
1942	25 All exc. 2569	to body, with stamped lamp.....	R.H.	1	508066
1942	25 All exc. 2569	to body, with stamped lamp.....	L.H.	1	508067
1948	25 All	to body.....		2	511516
1948	26 All exc. sta. wag.	to body.....		2	510962
1949-50	All exc. 2561-62-71	to fender.....		2	511661
1949 thru 52	2562 All	to body.....	L.H.	1	512479
1949 thru 52	2562 All	to body.....	R.H.	1	512478
1949	2571			2	3688914
1950 thru 52	2571		R.H.	1	514053
1950 thru 52	2571		L.H.	1	514054
1951-52	All exc. 2562-71	to fender.....		2	514648
1953-54	All exc. 2562-71	to fender.....		2	515259
1953-54	2562-71 All	to fender.....		2	5943402
1954	28 All			2	5945161
Group 2.662		BRACKET, TAIL LAMP			
1936	All exc. 2611-19	dual lamp—first type (see Note Group 2.679).....		1	919612
1936	All exc. taxi	second type (see Note Group 2.679).....	L.H.	1	920085
1939	All exc. sta. wag.	prime.....	R.H.	1	923436
1939	All exc. sta. wag.	prime.....	L.H.	1	923435
1939 thru 46	Sta. wag.	1946 with plain trunnion pins.....	Outer	1-2	503337
1939 thru 46	Sta. wag.		Inner	1	507761
1946 thru 48	Sta. wag.	inner mounting—w/screw type trunnion.....		1-2	5937103
1946 thru 48	Sta. wag.	outer mounting—w/screw type trunnion.....		1-2	5937104
1949	2571	mounting.....	R.H.	1	512208
1949	2571	mounting.....	L.H.	1	512209
1950 thru 52	2571	mounting.....	R.H.	1	513910
1950 thru 52	2571	mounting.....	L.H.	1	513911
1949 thru 52	2562 All		Outer	2	512451
1949 thru 52	2562 All		Inner	2	512450
1949	2561 All			2	512457
1942-46	Sta. wag.	BOLT , lamp bracket to body..... (Step $\frac{3}{8}$ "-16x2 $\frac{1}{4}$ ")	AR		128701
1949	2561 All	tail lamp link.....		2	512550
1939 thru 47	Sta. wag.	PIN , tail lamp bracket pivot.....		2	502495
1949	2561 All	tail lamp clevis.....		2	512552
1949 thru 52	2562 All	tail lamp outer bracket.....		2	502495
1939 thru 48	Sta. wag.	SPRING , tail lamp bracket pivot pin.....		2	3655726
1939 thru 48	Sta. wag.	tail lamp bracket.....		1	503338
1949	2561 All	tail lamp anti-rattle.....		2	512454
1946 thru 48	Sta. wag.	SCREW , tail lamp brkt. pivot..... (Cup pt. $\frac{1}{4}$ "-20x $\frac{1}{2}$ ")	2-4		216278
1949 thru 52	2562 All	LINK , tail lamp.....		2	512472
1949	2561 All			2	512553
1949	2561 All	ANCHOR , tail lamp link.....	Lower	2	512456
1949	2561 All	BRACKET , tail lamp link anchor.....		2	512551
1949 thru 52	2562 All	tail lamp link.....	Lower L.H.	1	512516
1949 thru 52	2562 All		Lower R.H.	1	512515
1949 thru 52	2562 All		Upper	2	512453
1949 thru 52	2571	REINFORCEMENT , tail lamp brkt.....	R.H.	1	512211
1949 thru 52	2571		L.H.	1	512212
Group 2.664		SPRING, TAIL LAMP			
1949 thru 52	2561-62 All L.H.D.	outer brkt. pivot pin.....		4	3687624
Group 2.670		BAR, REAR LICENSE SUPPORT			
1936 thru 38	All	second type exc. taxi on 1936 (see Note Gr. 2.679).....		1	920124
1937 thru 52	Sta. wag.	BRACKET ASSY. , rear license.....		1	5938846
1939 thru 42	All exc. sta. wag.			1	921007
1946 thru 48	All exc. sta. wag.			1	5935891
1949 thru 52	All exc.			1	5938180
	2561-62-71				
1953-54	2562-71 All			1	5944018
1941 thru 48	All exc. sta. wag.	SPRING , rear license anti-rattle.....		1	506073

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.672 BRACKET, TAIL LAMP LICENSE SUPPORT					
1936	All exc. taxi	second type (see Note Group 2.679).....	1	920082	-----
1937-38	All exc. sta. wag.		1	921188	-----
1949	2571	SUPPORT ASSY., rear license plate lamp	1	5938741	-----
1950 thru 52	2571		1	5939348	-----
Group 2.673 BUMPER—WASHER, LICENSE PLATE BRACKET					
1949 thru 52	All exc. rear on 2561-62-71	BUMPER, license plate	1-2	5937956	-----
1953-54	All exc. 2562-71		1	515590	-----
1953	All		1	516785	-----
1953-54	2562-71 All		1	5937956	-----
1948	All exc. sta. wag.	WASHER, sealing—rubber	1	511186	-----
1954	All		1	517850	-----
Group 2.674 WASHER, REAR LICENSE SUPPORT TO BODY SEALING					
1940 thru 48	All		1	505984	-----
1949 thru 52	All exc. 2561-62-71		2	512178	-----
1953-54	2562-71 All		2	512178	-----
1941 thru 48	26-29 exc. sta. wag.	CAP, rear license holder to body screw	1	506121	-----
Group 2.679 LAMP ASSEMBLY, TAIL					
NOTE: 1936 second type tail lamp started on the following serial numbers: P/6 1936 Dlx. except touring sedans 6BA 12126, P/6 1936 Master except touring sedans 6BB 21971, P/8 1936 all 8BA 13142, P/6 1936 Dlx. touring sedans 6BA 14120, P/6 1936 Master touring sedans 6BB 25891, first type was used up to the above serial numbers.					
1936	All exc. 2611-19	black (see note), first type.....	Std. L.H. lamp	1	916675
1936	All exc. 2611-19	black (see note), first type.....	Std. R.H. lamp	1	916676
1936	All exc. taxi	black (see note), second type.....	Std. L.H. lamp	1	916715
1937-38	All	black.....	Std. L.H. lamp	1	916759
1937-38	All	with dual lamp.....	Std. R.H. lamp	1	916760
1937 thru 48	Sta. wag.		1	926017	-----
1939	All	prime.....	R.H.	1	916862
1939	All	prime.....	L.H.	1	916861
1940	2511-19	prime.....	R.H.	1	927016
1940	2627-27B-67	prime.....	R.H.	1	927028
1940	2627-27B-67	prime.....	L.H.	1	927027
1940	2611-19	prime.....	R.H.	1	927024
1940	2611-19	prime.....	L.H.	1	927023
1940	29 All	prime.....	L.H.	1	927031
1941 thru 47	25 All exc. 2569		R.H.	1	927134
1941 thru 47	25-27 All exc. 2569		L.H.	1	927133
1941-42	2569 All		R.H.	1	927192
1941-42	2569 All		L.H.	1	927191
1941 thru 47	26 All exc. sta. wag.		R.H.	1	927136
1941 thru 47	26 All exc. sta. wag.		L.H.	1	927135
1941	29 All		R.H.	1	927038
1941	29 All		L.H.	1	927037
1942	25 All	painted.....	R.H.	1	927220
1942	25 All	painted.....	L.H.	1	927219
1948	25 All		R.H.	1	927604
1948	25 All		L.H.	1	927603
1948	26 exc. sta. wag.		R.H.	1	927606
1948	26 exc. sta. wag.		L.H.	1	927605
1949-50	All exc. 2561-62-71		R.H.	1	927608
1949-50	All exc. 2561-62-71		L.H.	1	927607
1951-52	All exc. 2562-71		R.H.	1	927870
1951-52	All exc. 2562-71		L.H.	1	927869
1953-54	All exc. 2562-71		2	927995	-----
1954	28 All		2	928682	-----
1949 thru 52	2561-62 All		R.H.	1	927866
1949 thru 52	2561-62 All		L.H.	1	927865
1949	2571		R.H.	1	927610
1949	2571		L.H.	1	927609
1950 thru 52	2571		R.H.	1	927868
1950 thru 52	2571		L.H.	1	927867
1952	2571	with back-up light.....	R.H.	1	927864
1953-54	2562-71 All		2	928283	-----
1946 thru 48	Sta. wag.	LAMP AND BRACKET ASSEMBLY	R.H.	1	929970
1946 thru 48	Sta. wag.		L.H.	1	929969

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 2.680		ORNAMENT, TAIL LAMP				
1940	All exc. sta. wag.	-----	2	924656	-----	
1953-54	2562-71 All	MEDALLION , tail lamp	2	5943918	-----	
1940	All	RETAINER , tail lamp ornament, nut type	2	3695282	-----	(8.040)
Group 2.681		DOOR, TAIL LAMP				
1935-36	All 1935	less lens, 1936 first type (see Note Group 2.679)				
		----- Pear shape	1	918699	-----	
1936	All exc. taxi	less lens, second type (see Note Gr. 2.679)....Round	1	918918	-----	
1937-38	All exc. sta. wag.	with lens	1	921185	-----	
1937 thru 41	Sta. wag.	painted with lens	1	914458	-----	
1939	All exc. sta. wag.	less lens	1	923531	-----	
1949	2571	less lens	2	5942056	-----	
1950 thru 52	2571	less lens	2	5940987	-----	
1949-50	All exc. 2561-62-71	less lens.....R.H.	1	5937854	-----	
1949-50	All exc. 2561-62-71	less lens.....L.H.	1	5937853	-----	
1951-52	All exc. 2562-71	less lens.....R.H.	1	5940986	-----	
1951-52	All exc. 2562-71	less lens.....L.H.	1	5940985	-----	
1941 thru 52	2562 All	with lens	1-2	5941289	-----	
1953-54	2511-37-67-69 All	less lens	2	5943801	-----	
1953-54	2562-71 All	less lens	2	5943917	-----	
1954	28 All		2	5945158	-----	
1940-41	1940 All, 1941 29	RING , tail lamp lens, chrome	2	924655	-----	
Group 2.682		LENS, TAIL LAMP DOOR				
1936	All exc. taxi	second type (see Note Group 2.679)....Round	1	918898	-----	
1937 thru 47	Sta. wag.	-----	1	919044	-----	
1939	All exc. sta. wag.	-----	1-2	920696	-----	
1940-41	1940 All,	-----	2	924653	-----	
	1941 29 exc. sta. wag.					
1941 thru 47	All exc.	with die cast lamp	2	5931535	-----	
	1941 29 and sta. wag.					
1942	25 All	with stamped lamp.....R.H.	1	5933578	-----	
1942	25 All	with stamped lamp.....L.H.	1	5933577	-----	
1942	26 exc. Sta. wag.	with stamped lamp.....R.H.	1	5933580	-----	
1942	26 exc. Sta. wag.	with stamped lamp.....L.H.	1	5933579	-----	
1948 thru 50	All exc. sta. wag.		2	5937590	-----	
	& 1949 2571					
1949	2571	-----	2	5937162	-----	
1950 thru 52	2571	-----	2	5937590	-----	
1951-52	All exc. 2562-71	-----	2	5939888	-----	
1953-54	2511-37-67-69 All	-----	2	5942453	-----	
1953-54	2562-71 All	-----	2	5939888	-----	
1953-54	2562-71 All	tail lamp ornamental	4	5943919	-----	
1954	28 All	w/ring	2	5945163	-----	
Group 2.683		CLAMP, TAIL LAMP TO BODY				
1941 thru 47	All exc. sta. wag.	----- Inner R.H.	1	505907	-----	
	and 1941 29					
1941 thru 47	All exc. sta. wag.	----- Inner L.H.	1	505908	-----	
	and 1941 29					
1941 thru 47	All exc. sta. wag.	----- Outer R.H.	1	505909	-----	
1941 thru 47	All exc. sta. wag.	----- Outer L.H.	1	505910	-----	
	and 1941 26					
1948	All exc. sta. wag.	(toothed)	4	510977	-----	
1948	All exc. sta. wag.	(plain)	4	510976	-----	
Group 2.684		GASKET, TAIL LAMP DOOR				
1935-36	1935 All	first type on 1936 (see Note Gr. 2.679)....Pear shape	1	918701	-----	
1936	All second type exc. taxi	round (see Note Group 2.679)....	1	918899	-----	
1937-38	All exc. sta. wag.	-----	1	920679	-----	
1937 thru 42	Sta. wag.	-----	1	911771	-----	
1939	All exc. sta. wag.	-----	1-2	921874	-----	
1940-41	All 1940, 1941 29	-----	2	924657	-----	
	exc. sta. wag.					
1941 thru 47	All exc. 29	with die cast lamp	2	5931534	-----	
	and sta. wag.					
1948-49	All exc. 2561-62-71	-----	2	5937599	-----	
1949	2571	-----	2	920625	-----	
1950 thru 52	2571	-----	2	5937599	-----	
1950	All exc. 2562	-----	2	5937599	-----	
1951-52	All exc. 2562-71	-----	2	5939889	-----	
1953-54	2511-37-67-69 All	-----	2	5942457	-----	
1953-54	2562-71 All	-----	2	5939889	-----	
1953-54	2562-71 All	tail lamp ornament lens	4	5943920	-----	
1954	28 All	-----	2	5945162	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.697		LAMP, BACK UP (Continued)			
1949 thru 52	2561-62-71 All	-----	1	5938015	-----
1953-54	All exc. 2562-71	-----	2	5940663	-----
1953-54	2562-71 All	-----	2	5938297	-----
1949-50	All exc. 2561-62-71	NUT, door to body	4	5933049	(2.593)
1942 thru 52	All	switch mounting	1	509294	-----
1949-50	All exc. 2561-62-71	PAD, to body	R.H. 1	512320	-----
1949-50	All exc. 2561-62-71	-----	L.H. 1	512321	-----
1951-52	All exc. 2562-71	-----	2	514750	-----
1953-54	All exc. 2562-71	-----	2	515479	-----
1953-54	2562-71 All	-----	R.H. 1	512320	-----
1953-54	2562-71 All	-----	L.H. 1	512321	-----
1949-50	All exc. 2561-62-71	RETAINER, back-up lamp	R.H. 1	512356	-----
1949-50	All exc. 2561-62-71	-----	L.H. 1	512357	-----
1949 thru 52	2561-62-71 All	SCREW, back-up lamp door	AR	912048	(2.688)
1951	All exc. 2562-71	w/die cast door (Fill. Hd. No. 6-32x $\frac{1}{8}$ ")	4	224535	-----
1951-52	All exc. 2562-71	w/stamped door (Pan Head No. 6-32 x $\frac{1}{4}$ ")	4	451323	-----
1953-54	2562-71 All	-----	4	451323	-----
1953-54	All exc. 2562-71	SOCKET AND WIRE ASSY., back-up lamp	2	5940664	-----
1953-54	All exc. 2562-71	SPACER, back-up lamp to body	4	5939849	-----
1942 thru 48	All L.H.D., S.T.	STOP, switch	1	509258	-----
1948	All L.H.D., H.T.	-----	1	510764	-----
1949 thru 52	All L.H.D., S.T.	-----	1	512323	-----
1953-54	All exc. 2562-71	STRIP, back-up lamp lens decorative	4	5940666	-----
1942 thru 48	All L.H.D., S.T.	SUPPORT, switch	1	509257	-----
1948	All L.H.D., H.T.	-----	1	510438	-----
1949 thru 52	All L.H.D., S.T.	-----	1	512325	-----
1942 thru 48	All	SWITCH ASSEMBLY	1	510964	-----
1949 thru 52	All S.T.	-----	1	512541	-----
1953-54	All S.T.	-----	1	1997895	-----
1949 thru 52	All H.T.	also trans. neutralizer switch Gr. 4.054	1	1997846	(4.054)
1953-54	All H.T.	also trans. neutralizer switch Gr. 4.054	1	1998039	(4.054)
1949 thru 52	All	WIRE ASSY., switch to fuse block	1	5289339	-----
1953-54	All S.T.	back-up lamp	1	5293127	-----
1953-54	All H.T.	back-up lamp	1	5293128	-----
Group 2.700		LAMP ASSEMBLY, REAR LICENSE			
1940	2919	-----	1	927094	-----
1940	All 2927	-----	1	927095	-----
1941	2919	-----	1	927167	-----
1941	2927	-----	1	927159	-----
1946 thru 48	2607 All	-----	1	927420	-----
1946 thru 48	All exc. 2607	-----	1	927421	-----
	& sta. wag.	-----			
1949-50	All exc. 2561-62-71	-----	2	927582	-----
1951-52	All exc. 2562-71	-----	1	927784	-----
1953-54	All exc. 2562-71	-----	1	928796	-----
1953-54	2562-71 All	-----	1	928358	-----
Group 2.702		PAD, REAR LICENSE LAMP BODY			
1939	2511-19	rubber	1	502240	-----
1940	2611-19	rubber	1	502240	-----
1946 thru 48	2607 All	-----	1	508700	-----
1946 thru 48	2609 All	-----	1	3663783	-----
1946 thru 48	2507 All	-----	1	3663782	-----
1946 thru 48	All exc. 2507	-----	1	3663703	-----
1949-50	All exc. 2561-62-71	-----	2	512555	-----
1951-52	All exc. 2562-71	GROMMET, lamp wire thru floor pan	1	514383	-----
1953-54	All exc. 2562-71	-----	1	515506	-----
Group 2.703		SPACER, REAR LICENSE LAMP			
1939	2527-27B, 2627-27B	holder to body (3 $\frac{1}{8}$ " long)	1	508702	-----
1940	All exc. 2919-27C	holder to body (3 $\frac{1}{8}$ " long)	1	508702	-----
1940	2527-27B	lamp to body (3 $\frac{1}{8}$ " long)	1	508702	-----
1941-42	All exc. 2419-27, 2919-27	holder to body (3 $\frac{1}{8}$ " long)	1	508702	-----
1941-42	2569 All	support to body	1	506699	-----
1942	2507 All	support to body	1	506699	-----
1946 thru 48	2607 All	lamp to body Upper (9 $\frac{1}{16}$ " long)	1	508701	-----
1946 thru 48	All exc. 2609	holder to body—cut to required length (3 $\frac{1}{8}$ " long)	1	508702	-----
Group 2.705		BRACKET ASSY., REAR LICENSE AND LAMP			
1953-54	All exc. 2562-71	-----	1	5942458	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 2.706 COVER, REAR LICENSE LAMP						
1939 thru 42	All	chrome.....	1	5930151	-----	
1946 thru 48	All exc. sta. wag.	retainer, zinc plated.....	1	5932763	-----	
1949-50	All exc. 2561-62-71	-----	2	5937942	-----	
1951-52	All exc. 2562-71	-----	1	5939872	-----	
1953-54	All exc. 2562-71	-----	1	5943380	-----	
1953-54	2562-71 All	-----	1	5939957	-----	
Group 2.707 GASKET, LICENSE LAMP OUTLOOK LENS						
1939 thru 42	All exc. sta. wag.	-----	1	922043	-----	
1946 thru 48	All exc. sta. wag.	-----	1	5932762	-----	
1949-50	All exc. 2561-62-71	-----	2	5937940	-----	
1951-52	All exc. 2562-71	-----	1	5939870	-----	
1953-54	All exc. 2562-71	rubber.....	1	5935949	-----	
1953-54	All exc. 2562-71	felt.....	1	5936537	-----	
1953-54	2562-71 All	-----	1	5939870	-----	
Group 2.708 SCREW, LICENSE LAMP COVER RETAINER						
1949-50	All exc. 2561-62-71	cover to body.....(No. 6-32x $\frac{5}{16}$ "	4	426701	-----	(8.909)
1939 thru 42	All	BOLT, rear license lamp.....(Carr. $\frac{1}{4}$ "-20x2 $\frac{3}{4}$ "	1	126614	-----	(8.903)
1940-41	29 All	lamp to body.....(Cl. recess $\frac{1}{4}$ "-20x $\frac{5}{8}$ "	2	186546	-----	(8.977)
1939-40	25-26 All	lamp to body.....(Hex. $\frac{1}{4}$ "-20x2"	1	180044	-----	(8.900)
1953-54	All exc. 2562-71	NUT, rear license lamp door.....	2	5943619	-----	
1946 thru 48	All	SCREW, lamp to body—Lower (ov. hd. No. 10-24x1 $\frac{1}{4}$ "	AR	134305	-----	(8.909)
1949 thru 52	All exc. 2561-62-71	bracket to body.....	2	3651216	-----	(8.206)
1953-54	2562-71 All	-----	2	3651216	-----	
Group 2.709 LENS, REAR LICENSE LAMP OUTLOOK						
1939 thru 42	All exc. sta. wag.	-----	1	922042	-----	
1946 thru 48	All exc. sta. wag.	-----	1	5932761	-----	
1949-50	All exc. 2561-62-71	-----	2	5938832	-----	
1951-52	All exc. 2562-71	-----	1	5940540	-----	
1953-54	All exc. 2562-71	-----	1	5935947	-----	
1953-54	2562-71 All	-----	1	5940540	-----	
Group 2.710 PLATE, REAR LICENSE LAMP NAME						
1940-41	All	-----	1	504242	-----	
1942	All exc. sta. wag.	painted.....	1	508198	-----	
1946	All exc. sta. wag.	-----	1	508619	-----	
1947-48	All exc. sta. wag.	-----	1	509512	-----	
1940-41	All	NUT, license lamp name plate.....(Clip type $\frac{1}{4}$ "	2	186463	-----	(8.921)
Group 2.714 WIRE ASSEMBLY, REAR LICENSE LAMP						
1939 thru 41	All exc. 29 and sta. wag.	-----	1	5931931	-----	
1940	29 All	-----	1	922036	-----	
1942	All exc. sta. wag.	-----	1	5931692	-----	
1946 thru 48	All exc. sta. wag.	-----	1	5932806	-----	
1949-50	All exc. 2561-62-71	-----	1	5937937	-----	
1946 thru 48	All exc. sta. wag.	SOCKET, lamp bulb.....	1	5932764	-----	
1946 thru 48	All exc. sta. wag.	GASKET, lamp socket.....	1	5932793	-----	
Group 2.721 SPRING, HEADLAMP INNER BODY TENSION						
1941 thru 46	All	-----	12	5931749	-----	
1947 thru 54	All	-----	2	5937452	-----	
Group 2.722 GASKET, HEADLAMP BODY TO FENDER						
1940-41	All	-----	2	3961000	-----	
1942 thru 48	All	-----	2	507005	-----	
1949 thru 52	All	-----	2	509478	-----	
1953-54	All	-----	2	515258	-----	
Group 2.724 MOLDING, HEADLAMP BODY TRIM						
1937-38	All	-----	2	1294345	-----	
1939	All	-----	2	502452	-----	
1941	All	ORNAMENT, headlamp lower.....	2	505617	-----	
1942	All	NUT, headlamp ornament.....(Clip type $\frac{3}{16}$ "	2	3695282	-----	(8.040)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.725 HEADLAMP ASSEMBLY					
1937-38	P/6 All, P/8 with fender lamp	-----L.H.	1	917451	-----
1938	P/8 exc. with fender lamp	includes parking lamp-----R.H.	1	917576	-----
1938	P/8 exc. with fender lamp	includes parking lamp-----L.H.	1	917575	-----
1939	All	prime-----R.H.	1	917646	-----
1939	All	prime-----L.H.	1	917645	-----
1940	All L.H.D.	with door-----	2	917714	-----
1941	All L.H.D.	with door, chrome-----	2	925012	-----
1942 thru 48	All L.H.D.	sealed beam type—with door-----	2	925177	-----
1949 thru 52	All L.H.D.	sealed beam type—less door-----	2	5940989	-----
1953-54	All L.H.D.	sealed beam type—less door-----	2	5943787	-----
1939	All	PLUG, headlamp screw hole button----- ^(11/16" chr.)	2	142050	(8.973)
1940 thru 54	All	SCREW, headlamp to fender----- ^(No. 10-12x1/8")	16	161901	(8.977)
1940 thru 54	All	NUT, headlamp to fender screw----- ^(Clip type)	AR	413395	(2.548)
Group 2.726 BODY, HEADLAMP					
1949 thru 52	All	-----	2	5937072	-----
1953-54	All	-----	2	5940667	-----
1940 thru 54	All	RING, inner-----	2	924535	-----
Group 2.727 LENS, HEADLAMP					
1935-36	All	-----L.H.	1	918805	-----
1937-38	All L.H.D.	-----R.H.	1	920426	-----
1937-38	All L.H.D.	-----L.H.	1	920425	-----
1939	All	-----R.H.	1	923428	-----
1939	All	-----L.H.	1	923427	-----
1940 thru 54	All	SEALED BEAM UNIT, headlamp—metal back-----	2	193195	-----
1940 thru 54	All	glass back-----	2	193142	-----
Group 2.728 DOOR, HEADLAMP					
1935-36	All	black-----R.H.	1	918874	-----
1935-36	All	black-----L.H.	1	918873	-----
1937	All	RIM, headlamp-----R.H.	1	920450	-----
1937	All	-----L.H.	1	920449	-----
1939	All	-----R.H.	1	923454	-----
1939	All	-----L.H.	1	923453	-----
1940	All L.H.D.	-----	2	5941977	-----
1941	All	DOOR ASSY., includes door, clip, gasket and spring-----	2	5931865	-----
1942 thru 48	All	-----	2	5932754	-----
1949 thru 52	All "D" & 2571	chrome-----	2	5942016	-----
1949 thru 52	All exc. "D" & 2571	prime-----	2	5940567	-----
1953-54	All	chrome-----	2	5943789	-----
Group 2.729 SCREW, HEADLAMP DOOR CLAMPING					
1935 thru 39	All	----- ^(Fil. Hd. No. 10-24x7/8")	2	918824	-----
1940-41	All	----- ^(Fil. Hd. No. 8-32x1/2")	2	924622	-----
1942 thru 48	All	----- ^(Oval Hd. No. 10-32x13/16")	2	507004	-----
1949 thru 54	All	-----	2	446869	(8.977)
Group 2.730 SPRING, HEADLAMP LENS RETAINER					
1932 thru 36	All	-----	4	914255	-----
1937 thru 39	All	-----	4	918107	-----
Group 2.731 MOLDING, HEADLAMP DOOR INNER TRIM					
1935 thru 39	All	-----	2	918811	-----
1940 thru 54	All	RING, headlamp sealed beam unit retainer-----	2	5940988	-----
Group 2.734 REFLECTOR, HEADLAMP					
1935-36	P/6 1935 Mstr., All 1936	with socket and wire-----	2	918970	-----
1937-38	All 1937, P/6 1938	with socket and wire-----	2	920427	-----
Group 2.735 GASKET, HEADLAMP LENS					
1940 thru 48	All L.H.D.	at door, rubber-----	2	5930594	-----
1949 thru 54	All	-----	2	5930594	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.736 SPRING, HEADLAMP REFLECTOR RETAINER					
1937	All	-----	6	920429	-----
1940 thru 54	All	SCREW, headlamp mounting ring (Bind. Hd. No. 8-32x $\frac{3}{4}$ ")	6	924552	-----
Group 2.737 SCREW, HEADLAMP					
1939	All	vertical adjusting	2	923099	-----
1940 thru 50	All	beam adjuster ($\frac{1}{4}$ "-28x1")	4	924561	-----
1940 thru 48	All	NUT, beam adjuster screw	4	5930896	-----
1949 thru 54	All	-----	4	5939769	-----
Group 2.746 SPRING, HEADLAMP DOOR SEAL RETAINER					
1942 thru 52	All	-----	AR	914127	-----
1951-52	All	Bottom	2	5939791	-----
1951-52	All	Top	2	5939983	-----
1953-54	All	Top	2	5940578	-----
1953-54	All	Side and bottom	2	5940579	-----
Group 2.750 WIRE AND SOCKET, HEADLAMP					
1935 thru 38	All	inside	2	915945	-----
1939	All	inside	2	923367	-----
1940	All L.H.D.	-----	2	924615	-----
1941	All	with sealed beam type	2	5931866	-----
1942 thru 48	All L.H.D.	with sealed beam type	2	5932941	-----
1949 thru 52	All	with sealed beam type	2	5937970	-----
1953-54	All	with sealed beam type	2	5942852	-----
1935 thru 38	All	CLIP, headlamp wire to fender	AR	497614	(2.344)
1940	All	snap on type ($\frac{5}{8}$ ")	AR	127983	(8.950)
Group 2.765 SWITCH, INSTRUMENT PANEL LAMP					
1932, 1936 thru 39	All	-----	1	001406	-----
1940	All	-----	1	1997719	-----
1941	All	-----	1	1997740	-----
Group 2.766 WASHER, INSTRUMENT LIGHT SWITCH ESCUTCHEON					
1941	All	-----	1	505828	-----
Group 2.768 KNOB, INSTRUMENT LAMP SWITCH CONTROL					
1941	All	-----	1	505827	-----
1941	All	SCREW, instrument panel switch knob (No. 9-32x $\frac{1}{4}$ ") (Hd. less cup pt.)	1	187419	(8.975)
Group 2.776 SOCKET AND WIRE, INSTRUMENT LAMP					
1936	All	radio and key hole	1	1862155	-----
1937-38	All	beam indicator	1	1862155	-----
1940	All	panel cluster	1	1879280	-----
1941	All	panel cluster	1	1882145	-----
1941	All	ignition key hole	1	1882146	-----
1942 thru 48	All	panel light	1	1885070	-----
Group 2.810 HORN ASSEMBLY					
1937 thru 41, 1946 thru 48	All	high note—die cast L.H.	1	1999688	-----
1937 thru 41, 1946 thru 48	All	low note—die cast R.H.	1	1999519	-----
1941	All	low note—stamping R.H.	1	1999841	-----
1942	All	low note R.H.	1	1999571	-----
1942	All	high note L.H.	1	1999572	-----
1949 thru 54	All	low note R.H.	1	1999645	-----
1949 thru 54	All	high note L.H.	1	1999646	-----
Group 2.815 RELAY ASSEMBLY, HORN					
1934 thru 54	All	for dual horns	1	1116775	-----
Group 2.816 CUSHION, HORN BUTTON RUBBER					
1940	29 All	key cushion rubber ring, w/std. wheel	1	753772	-----
1941-42	All	key spring—key blowing type, w/std. wheel	2	754126	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.817					
		BUTTON, HORN			
1938	All	-----	1	264440	-----
1939	All	-----	1	265171	-----
1940	All	w/"D" wheel	1	504337	-----
1940	25-26 All	w/std. wheel	1	266203	-----
1940	29 All	w/std. wheel	1	753768	-----
1941	All	w/"D" wheel	1	505917	-----
1942	All	w/"D" wheel	1	507088	-----
1941-42	All 1941,	w/std. key type wheel—steering wheel cap	1	506745	-----
	1942-25 only				
1942 thru 48	All	w/std. center blowing type wheel—steering wheel cap	1	507532	-----
1946-47	All	w/"D" wheel	1	508698	-----
1948	All	w/"D" wheel	1	509557	-----
1949-50	All	CAP, steering wheel, w/std. wheel	1	511934	-----
1951-52	All	w/std. wheel	1	514650	-----
1953-54	All	w/std. wheel	1	516940	-----
1949	All	CAP ASSEMBLY, horn ring w/"D" wheel	1	512418	-----
1950	All	w/"D" wheel	1	513826	-----
1951	All	red—w/"D" wheel	1	515706	-----
1952	All	red—w/"D" wheel	1	515706	-----
1952	2537 "SD"	green	1	516525	-----
1953	All	red—w/"D" wheel	1	516842	-----
1953	2537 "SD"	green	1	517175	-----
1954	All "D"—S.S.	red	1	516842	-----
1954	All "SD"—S.S.	beige	1	518346	-----
1954	All "SD"—S.S.	coral red	1	518347	-----
1954	All "SD"—S.S.	yellow	1	518348	-----
1954	All "D"—P.S.	red	1	517903	-----
1954	All "SD"—P.S.	beige	1	517904	-----
1954	All "SD"—P.S.	coral red	1	518349	-----
1954	All "SD"—P.S.	yellow	1	518350	-----
1939 thru 42	All	PACKAGE, horn button—use with 507490 wheel	1	544408	-----
Group 2.819					
		SLEEVE, HORN CABLE CONTACT			
1937-38	All	on shaft	1	263287	-----
1937-38	All	CONNECTOR ASSEMBLY, horn cable—on column	1	263549	-----
1941 thru 48	All	horn wire	1	3114169	-----
1939 thru 52	All	INSULATOR, horn button connector	1	5660044	-----
1953-54	All	w/std. wheel	1	759230	-----
1953-54	All	use w/5660046 assy.—w/"D" wheel	1	5660044	-----
1939 thru 52	All	CONTACT AND SPRING ASSEMBLY, horn button			
		connector—use 5660044 with this assy.	1	5660046	-----
1953-54	All	use w/5660044 insulator—w/"D" wheel	1	5660046	-----
1953-54	All	w/std. wheel	1	759037	-----
Group 2.821					
		RETAINER, HORN BUTTON CAP			
1937-38	All	-----	1	263504	-----
1939-40	25-26 All	w/std. wheel	1	265174	-----
1942 thru 52	All	w/std. wheel	1	506741	-----
1942 thru 48	All	-----	2	507440	-----
1953-54	All	BUSHING, horn button cup spacer—w/std. wheel	3	757440	-----
1940	29 All	CLAMP, horn button contact cup, w/std. wheel	1	753794	-----
1940	29 All	CUP, horn button contact, w/std. wheel	1	753771	-----
1953-54	All	w/std. wheel	1	758409	-----
1941	All	INSULATOR, horn button, ring guide	2	506097	-----
1951 thru 54	All	-----	1	514412	-----
1953-54	All	SCREW, steering wheel horn button cup bushing—w/std. wheel	3	759146	-----
1937 thru 52	All exc.	RING, cap retaining, center blowing type on 1942-25			
	1940-29	and w/std. wheel on 1942 thru 52 except 1942-25	1	263703	-----
1940	29 All	SUPPORT, horn button contact cup, w/std. wheel	1	753770	-----
1949 thru 52	All	SPACER, strg. wheel cap, w/std. wheel	1	511935	-----
Group 2.822					
		CONTACT, HORN BUTTON			
1939 thru 52	All exc. 1940-29	w/std. wheel, center blowing type on 1942-25	1	265172	-----
1941	All	w/"D" wheel	1	512246	-----
1942 thru 48	All	w/"D" wheel	1	504339	-----
1949 thru 54	All	w/"D" wheel	1	512246	-----
1953	All	CABLE, with contact	1	5296935	-----
1941-42	All	RING, horn button contact, w/std. key type wheel	1	754077	-----
1940, 1942 thru 47	All	w/"D" wheel	1	507519	-----
1941, 1949 thru 54	All	w/"D" wheel	1	506075	-----
1948	All	w/"D" wheel	1	509556	-----
1937 thru 39	All	SEPARATOR, horn button contact Rubber	1	264584	-----

(2.649)

(2.859)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.822 CONTACT, HORN BUTTON (Continued)					
1940, 1942 thru 52	All exc. 1940-29	center blowing type on 1942-25.....Rubber	1	264584	-----
1940	All	w/"D" wheel.....	1	504342	-----
1941	All	w/"D" wheel.....	1	506076	-----
1942 thru 54	All	w/"D" wheel.....	1	507722	-----
1949 thru 52	All	SPRING , horn ring ground—w/"D" wheel.....	1	512247	-----
1953-54	All	horn button—w/std. wheel.....	1	758408	-----
1940	All	PLATE , contact separator backing—w/"D" wheel.....	1	504340	-----
1941 thru 48	All	w/"D" wheel.....	1	506309	-----
1941	All	horn button contact retainer—w/"D" wheel.....	1	506074	-----
1949 thru 52	All	contact retainer—w/"D" wheel.....	1	512734	-----
1953-54	All	horn ring contact retainer—w/"D" wheel.....	1	517258	-----
1953-54	All	horn button contact—w/std. wheel.....	1	758407	-----
Group 2.823 PLATE, HORN BUTTON GROUND					
1940	29 All	cup grounding, w/std. wheel.....	1	753657	-----
1941-42	All	key, w/std. key type wheel.....	1	754076	-----
1942 thru 48	All	w/"D" wheel.....	1	509553	-----
Group 2.829 RING, HORN BUTTON LOCK					
1938	All	with std. wheel, center blowing type on 1942-25.....	1	264583	-----
1939 thru 52	All exc. 1940-29	with std. wheel.....	1	265173	-----
1940	29 All	with std. wheel.....	1	753769	-----
1941-42	All 1941, 1942-25 only	RETAINER , horn blowing key, with std. wheel.....	2	754073	-----
1941	All	SCREW , horn blowing key retainer, with std. wheel.....(Fil. Hd. No. 6-32x $\frac{1}{2}$ ")	2	131899	----- (8.907)
Group 2.830 RING, HORN OPERATING					
1940	29 All	KEY , horn operating with std. wheel.....(chrome)	1	753767	-----
1941-42	All 1941, 1942-25 only	with std. key blowing wheel.....(plastic)	2	754128	-----
1941	All	RING , horn button—w/"D" wheel.....	1	505750	-----
1942	All	w/"D" wheel.....	1	507721	-----
1946-47	All	w/"D" wheel.....	1	508755	-----
1948	All "D"		1	510693	-----
1949-50	All "D"		1	511993	-----
1951-52	All "D"		1	515701	-----
1953-54	All "D"		1	516941	-----
Group 2.831 SPACER, HORN BUTTON RING					
1941	All	w/"D" wheel.....Upper	1	506077	-----
1941	All	w/"D" wheel.....Lower	1	506078	-----
1942 thru 48	All	with std. center blowing wheel.....	1	507537	-----
1942 thru 48	All	w/"D" wheel.....	1	507442	-----
1942 thru 48	All	INSULATOR —w/"D" wheel.....	1	507959	-----
Group 2.845 BRACKET, HORN MOUNTING					
1938 thru 41, 1946 thru 54	All	with die cast horns.....	2	505716	-----
1941	All	with stamped horns.....	1	507508	-----
Group 2.847 LAMINATION—SPACER, HORN MOUNTING BRACKET					
1935 thru 41	All	LAMINATION , horn bracket.....	1	1849037	-----
1938 thru 54	All	SPACER , horn bracket.....	1	1860729	-----
Group 2.859 CABLE, HORN BUTTON					
1937-38	All	with terminal, at horn button.....	1	264249	-----
1939-40	All L.H.D.		1	265076	-----
1941 thru 48	All		1	266918	-----
1949 thru 52	All		1	5660683	-----
1953-54	All	with contact.....	1	5296935	-----
1946 thru 54	All	CLAMP , horn wire dual horns.....	1	269521	-----
1939	All	SCREW , horn wire junction block.....(Hex. No. 7-16x $\frac{3}{4}$ ")	1	508100	-----
1946 thru 54	All	horn wire clamp to steering column.....(Rd. Hd. No. 10-16x $\frac{1}{4}$ ")	1	145111	----- (8.977)
Group 2.892 FLASHER, DIRECTION SIGNAL					
1940 thru 42	All		1	5930991	-----
1946 thru 48	All exc. sta. wag.		1	5936281	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 2.892 FLASHER, DIRECTION SIGNAL (Continued)					
1949 thru 54	All	-----	1	1335220	-----
1949-50	All	WIRE ASSY. , dir. signal and flasher socket—w/field installed dir. signal	1	5938733	-----
1951-52	All	w/field installed dir. signal	1	5940264	-----
Group 2.895 SWITCH ASSEMBLY, DIRECTION SIGNAL					
1946-47	All	SWITCH BASE AND WIRE ASSEMBLY	1	5936275	-----
1948	All	w/factory installed direction signal	1	5937832	-----
1948	All	w/field installed direction signal	1	5937763	-----
1949-50	All	w/direction signal	1	5938246	-----
1951-52	All	w/direction signal	1	5943132	-----
1953-54	All	w/direction signal	1	5942764	-----
1949-50	All	CONTROL ASSEMBLY —includes: cover, wire, switch and lever	1	928542	-----
1951-52	All	-----	1	928874	-----
1953	All S.T.	-----	1	928486	-----
1953	All H.T.	-----	1	928487	-----
1954	All S.T.	-----	1	928459	-----
1954	All H.T.	-----	1	928460	-----
1940 thru 48	All	RUBY-JEWEL , direction signal switch	1	924855	-----
1953	All	RING ASSY. , direction signal switch	1	5942763	-----
1953-54	All	RING AND SCREW PKG. , direction signal switch	1	897064	-----
1953	All	SCREW , direction signal switch ring pivot (1 $\frac{13}{16}$ " long)	1	5942768	-----
1953-54	All	(1 $\frac{13}{16}$ " long)	1	5944866	-----
1953-54	All	SPRING , direction signal switch pawl	2	5942766	-----
Group 2.896 CAM, STEERING WHEEL DIRECTION SIGNAL					
1949 thru 52	All	w/direction signal	1	512425	-----
1953-54	All	w/direction signal	1	5942639	-----
Group 2.897 LEVER ASSEMBLY, DIRECTION SIGNAL SWITCH					
1942 thru 47	All exc. sta. wag.	-----	1	5936282	-----
1948	All	-----	1	5937982	-----
1949 thru 52	All	w/black knob	1	5940946	-----
1950	2537 "SD"	w/rust knob	1	5939468	-----
1953-54	All	-----	1	5943803	-----
Group 2.899 SOCKET AND WIRE, DIRECTION SIGNAL PARKING LAMP					
1941 thru 47	All exc. sta. wag.	-----	2	5936274	-----
1948	All	R.H.	1	5937806	-----
1948	All	L.H.	1	5937805	-----
1949	All	R.H.	1	5938264	-----
1949	All	L.H.	1	5938263	-----
1950	All	R.H.	1	5939330	-----
1950	All	L.H.	1	5939329	-----
1951-52	All	R.H.	1	5939996	-----
1951-52	All	L.H.	1	5939995	-----
1953	All	R.H.	1	5940676	-----
1953	All	L.H.	1	5940675	-----
1954	All	R.H.	1	5945168	-----
1954	All	L.H.	1	5945167	-----
Group 2.901 COVER, DIRECTION SIGNAL LOOM					
1940	All	-----	1	5930708	-----
1949-50	All	-----	1	5939393	-----
1951	All	-----	1	5940086	-----
1952	All	-----	1	5943134	-----
1949 thru 52	All	SPRING , loom cover	1	513750	-----
Group 2.902 BRACKET, DIRECTION SIGNAL					
1949 thru 52	All	flasher socket and multiple connector	1	512426	-----
1953-54	All	-----	1	515464	-----
Group 2.906 HOUSING ASSEMBLY, DIRECTION SIGNAL SWITCH					
1948	All	-----	1	5937167	-----
1953-54	All S.T.	-----	1	5944623	-----
1953-54	All H.T.	-----	1	5944624	-----

[illegible]

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 3.001		TANK, FUEL				
1937-38	All	-----	1	499645	-----	
1939	25 All	-----	1	501944	-----	
1939-40	26-28 All	-----	1	501945	-----	
1940	29 All	-----	1	504095	-----	
1941 thru 48	All exc. sta. wag.	-----	1	505089	-----	
1941 thru 48	Sta. wag.	-----	1	506415	-----	
1949 thru 52	All exc.	-----	1	514301	-----	
	2561-62-71	-----				
1949 thru 52	2561-62-71 All	-----	1	512217	-----	
1953-54	All exc. 2562-71	-----	1	515310	-----	
1953-54	2562-71 All	-----	1	515319	-----	
Group 3.003		PIPE, FUEL TANK FILLER				
1937-38	All	-----	1	499649	-----	
1940	25 All	-----	1	504098	-----	
1941 thru 48	All exc. sta. wag.	-----	1	505093	-----	
1941 thru 48	Sta. wag.	-----	1	506419	-----	
1949 thru 52	All exc.	-----	1	511256	-----	
	2561-62-71	-----				
1949 thru 52	2561-62-71 All	-----	1	512222	-----	
1953-54	All exc. 2562-71	-----	1	515315	-----	
1953-54	2562-71 All	-----	1	515316	-----	
1949 thru 52	2561-62-71 All	HOSE, fuel tank filler pipe	1	512248	-----	
1953-54	2562-71 All	-----	1	516713	-----	
Group 3.004		CLAMP, FUEL TANK FILLER PIPE HOSE				
1949 thru 54	2561-62-71 All	-----	2	432737	-----	
Group 3.006		PLUG, FUEL TANK DRAIN				
1937 thru 52	All	----- (Hex. head 1/8")	1	508220	-----	
1953-54	All	less gasket	1	514395	-----	(1.453)
1953-54	All	GASKET, drain plug	1	513975	-----	(1.456)
Group 3.008		GROMMET, FUEL TANK FILLER PIPE				
1936	All	through fender	1	499118	-----	
1937-38	All	through fender	1	500499	-----	
1939-40	All exc. 25	through fender	1	501959	-----	
1939-40	25 All	through fender	1	502285	-----	
1949 thru 52	2561-62-71 All	through fender	1	3688073	-----	
1949 thru 52	2561-62-71 All	through body	1	512433	-----	
Group 3.010		BRACKET, FUEL TANK FILLER PIPE SUPPORT				
1949 thru 54	2561-62-71 All	-----	1	512225	-----	
Group 3.022		STRAP, FUEL TANK				
1937-38	All	Lower	2	500271	-----	
1939-40	25 All	Upper	2	502071	-----	
1939-40	25 All	Lower	2	502072	-----	
1939-40	All exc. 25	Lower	2	502184	-----	
1941 thru 48	All exc. sta. wag.	Lower	2	505338	-----	
1941 thru 48	Sta. wag.	Front	1	506474	-----	
1941 thru 48	Sta. wag.	Rear	1	506475	-----	
1949 thru 52	All exc.	-----	2	513600	-----	
	2561-62-71	-----				
1949 thru 52	2561-62-71 All	-----	1	513287	-----	
1953-54	All 2511-37-67-69	-----	2	515327	-----	
1953-54	2562-71 All	-----	2	515329	-----	
1954	28 All	-----	2	517559	-----	
1941 thru 54	Sta. wag. & 2571	BRACKET, fuel tank strap	2	506472	-----	
Group 3.023		BOLT, FUEL TANK LOWER STRAP END				
1936 thru 48	All	----- (Spec. 3/8"-24x2 3/8")	2	497875	-----	
1949 thru 53	2561-62-71 All	-----	1	497875	-----	
1949 thru 53	All exc.	support hook	1	556014	-----	
	2561-62-71	-----				
1954	2562-71 All	strap end	2	517883	-----	
1954	All exc. 2562-71	support hook	2	517884	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 3.028 CAP, FUEL TANK FILLER						
1933 thru 40	All exc. 1940 29	-----	1	595857	-----	
1940 thru 54	All exc. 1940 25-26	-----	1	511124	-----	
Group 3.107 GAUGE, FUEL, TANK UNIT						
1939-40	All	-----	1	1515481	-----	
1941 thru 48	All exc. sta. wag.	-----	1	1516316	-----	
1941 thru 50	Sta. wag. & 2571 All	-----	1	1517122	-----	
1949-50	All exc. 2561-62-71	-----	1	1517249	-----	
1951 thru 53	All exc. 2562-71	-----	1	1517411	-----	
1951 thru 54	2562-71 All	-----	1	1517410	-----	
1954	All exc. 2571	-----	1	1518093	-----	
Group 3.108 GAUGE, FUEL, INSTRUMENT PANEL						
1940	All	-----	1	1515371	-----	
1941	All	-----	1	1516295	-----	
1942	All	-----	1	1516391	-----	
1946	All	-----	1	1516818	-----	
1947	All	-----	1	1516946	-----	
1948	All	-----	1	1517065	-----	
1949-50	All	-----	1	1517117	-----	
1951-52	All	-----	1	1517378	-----	
1953-54	All	-----	1	1517603	-----	
Group 3.112 GASKET, FUEL GAUGE, TANK UNIT						
1935 thru 54	All	outlet fitting	1	1516061	-----	
1935 thru 54	All	GASKET, mounting screw (5/16" I.D.)	5	105450	-----	(8.955)
Group 3.158 PIPE, FUEL TANK TO FUEL PUMP						
1933-34	All	to pump, cut off 134 1/2" copper tubing (5/16")	AR	348750	-----	(8.964)
1933 thru 54	All	to hose, cut copper tubing to required length (5/16")	AR	348750	-----	(8.964)
1935 thru 46	All	CLIP, fuel line to frame, snap-on type (5/16")	AR	127753	-----	(8.950)
1939 thru 54	All exc. 1939-25	bolt on type	1	502896	-----	
1935-36, 1939 thru 50	All	HOSE, fuel line to pump with compression nut (10 13/16" long)	1	503485	-----	
1937-38	All	(13" long)	1	499947	-----	
1951 thru 54	All	(10 13/16" long)	1	514607	-----	
1940 thru 48	All P/8 exc. 1940-28	UNION, tank to pump hose pipe (5/16")	1	120452	-----	(8.963)
Group 3.201 PIPE, FUEL PUMP TO CARBURETOR						
1935 thru 54	All	cut copper tubing to required length (5/16")	AR	348750	-----	(8.964)
1935 thru 48	All	ELBOW, threaded sleeve, carburetor inlet (5/16")	1	114920	-----	(8.963)
1953-54	P/6	carburetor inlet (5/16")	1	114920	-----	(8.963)
1935 thru 54	All	NIPPLE, threaded sleeve, carburetor inlet (5/16")	1	114919	-----	(8.963)
1935 thru 54	All	NUT, carburetor inlet (5/16")	1	114964	-----	(8.963)
Group 3.256 TUBE, AUTOMATIC CHOKE TO MANIFOLD						
1937 thru 54	All	cut copper tubing to required length (1/4")	AR	364934	-----	(8.964)
1937 thru 54	All	NUT, carburetor to heat tube coupling (1/4")	1	114627	-----	(8.963)
1937 thru 54	All	SLEEVE, carburetor to heat tube coupling (1/4")	1	114628	-----	(8.963)
Group 3.264 TUBE, INTAKE MANIFOLD RISER						
1937 thru 39	P/8	(3 3/16" x 1.565)	1	500340	-----	
1940	P/8	with single carburetor (2 13/16" x 1.690)	1	503603	-----	
1941-42	P/6	(3 1/16" x 1.690)	1	505182	-----	
1946 thru 52	P/6	(2 7/8" x 1.690)	1	508526	-----	
Group 3.265 MANIFOLD, INTAKE						
1933 thru 36	All P/8 L.H.D.	-----	1	497566	-----	
1935-36	All P/6 L.H.D.	-----	1	498876	-----	
1937-38	All P/8 L.H.D.	-----	1	500114	-----	
1937-38	All P/6 L.H.D.	-----	1	500334	-----	
1939	P/8	-----	1	503254	-----	
1939-40	P/6	-----	1	508362	-----	
1940	28 All	-----	1	503651	-----	
1940 thru 53	All P/8 exc. 1940 28	-----	1	504628	-----	
1941 thru 52	P/6	-----	1	508527	-----	
1953-54	P/6	-----	1	517316	-----	
1954	P/8	-----	1	518551	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 3.270 GASKET SET, INTAKE AND EXHAUST MANIFOLD						
1933 thru 54	P/8	-----	1	503434	-----	
1935 thru 54	P/6	-----	1	503433	-----	
Group 3.276 WASHER, MANIFOLD CLAMP						
1933 thru 54	All	small-----	2	502306	-----	
1933 thru 54	All	large-----	8	501215	-----	
Group 3.288 STUD, MANIFOLD						
1933 thru 40	All exc. 1939-40	STUD, manifold to carb. ----- $(\frac{3}{8}"-24 \times \frac{7}{8}")$	2	111123	-----	(8.981)
	25-26-29	----- $(\frac{3}{8}" \times 1 \frac{9}{16}" \text{ long})$	2	178453	-----	(8.981)
1939 thru 52	P/6	----- $(\frac{3}{16}" \times 1 \frac{5}{8}" \text{ long})$	4	186895	-----	(8.981)
1941 thru 48	P/8	with WCD-530S carb.----- $(\frac{5}{16}" \times 1 \frac{3}{4}")$	4	117245	-----	(8.981)
1947 thru 54	P/8	----- $(\frac{5}{16}" \times 1 \frac{3}{4}")$	4	117245	-----	(8.981)
1953-54	P/6	STUD, intake to exhaust manifold				
1940	28 All	-----Inner (Hex. $\frac{3}{8}"-16 \times 1 \frac{1}{2}")$	2	180126	-----	(8.900)
		-----Inner (Hex. $\frac{3}{8}"-16 \times 3 \frac{3}{4}")$	2	127949	-----	(8.900)
1940 thru 54	All P/8 exc.	STUD, manifold to block ----- $(\frac{3}{8}" \times 1 \frac{13}{16}" \text{ long})$	10	494520	-----	
1933 thru 54	1940 28 All					
Group 3.326 DEFLECTOR, CARBURETOR HEAT						
1939 thru 50	P/6	-----	1	505251	-----	
1947 thru 53	P/8	with WCD-630S carburetor on 1947-----	1	510945	-----	
1951-52	P/6	-----	1	514824	-----	
1953-54	P/6	-----	1	517278	-----	
1954	P/8	-----	1	518567	-----	
Group 3.402 CLEANER AND SILENCER, CARBURETOR AIR						
1933 thru 40	All P/8 exc.	standard, 1940 28 w/out dual carburetor-----	1	1528128	-----	
	1940 29					
1935 thru 40	P/6	standard (also use 499142 Gr. 3.405 and 489409 Gr. 0.293)-----	1	1528944	-----	
1940	P/8	standard, 1940 28 with dual carburetor, 1941 thru 48 with die cast carburetor-----	1	1544256	-----	
1941 thru 48	P/8	heavy duty-----	1	1544342	-----	
1941 thru 50	P/6	standard-----	1	1529871	-----	
1946 thru 48	P/6	heavy duty-----	1	1544341	-----	
1941 thru 54	P/8	standard-----	1	1544256	-----	
1949-50	P/6	heavy duty-----	1	1544486	-----	
1949-50	P/8	heavy duty-----	1	1544530	-----	
1951-52	P/6	standard-----	1	1544966	-----	
1951-52	P/6	heavy duty-----	1	1544967	-----	
1951 thru 54	P/8	heavy duty-----	1	1551930	-----	
1953	P/6	heavy duty-----	1	1551001	-----	
1954	P/6	heavy duty-----	1	1551931	-----	
Group 3.405 BRACE, AIR CLEANER TO ENGINE						
1940 thru 47	P/8	use on 1947 to engine 12,388-----	1	504769	-----	
1946 thru 52	P/6 exc. taxi	w/standard air cleaner-----	1	508757	-----	
1947-48	P/8	use with WCD-630S carb. after engine 12,387-----	1	509509	-----	
1949 thru 54	P/8	w/standard air cleaner-----	1	509509	-----	
1949 thru 52	P/6 taxi	w/heavy duty air cleaner-----	1	512438	-----	
1949-50	P/8	w/heavy duty air cleaner-----	1	512573	-----	
1951 thru 54	P/8	w/heavy duty air cleaner-----	1	514885	-----	
1953-54	P/6	w/standard air cleaner-----	1	517280	-----	
1953	P/6	w/heavy duty air cleaner-----	1	517281	-----	
1954	P/6	w/heavy duty air cleaner-----	1	518439	-----	
1936 thru 54	All	INSULATOR, air cleaner brace -----	1	499465	-----	
1936 thru 54	All	RETAINER, air cleaner brace insulator -----	1	499466	-----	
1936 thru 54	All	WASHER, air cleaner brace bolt ----- (Spec. lock $1 \frac{1}{2}"$)	1	499467	-----	
Group 3.410 ELEMENT, AIR CLEANER						
1937 thru 54	P/6	standard—type No. 1-----	1	1528439	-----	
1937 thru 48	P/8	standard—type No. 3-----	1	1528441	-----	
1937-38	All	heavy duty—type No. 7S-----	1	1529681	-----	
1939-40	28 All	heavy duty—type No. 7S-----	1	1529681	-----	
1939 thru 48	P/6	heavy duty—type No. 8-----	1	1529494	-----	
1940 thru 48	All P/8 exc.	heavy duty-----	1	1542335	-----	
	1940 28					
1949-50	P/8	heavy-duty—type No. 7S-----	1	1529681	-----	
1949 thru 54	P/8	standard—type No. 6-----	1	1528698	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.425 TRUNNION, CARBURETOR ROD					
1933 thru 46	All	throttle cross bar.....	1	495480	-----
1934 thru 38	P/8	accelerator control rod idler lever.....	1	496229	-----
1937-38	P/6	accelerator control rod.....	1	495483	-----
1940 thru 54	All L.H.D., S.T.	accelerator control rod.....	1	504300	-----
1948 thru 54	All H.T.	carburetor throttle rod.....	1	512476	-----
1948-49	All H.T.	throttle control rear rod.....	1	512476	-----
1934 thru 54	All	SPRING , anti-rattle, throttle & acc. trunnion.....	1	495472	(3.524)
All	All	NUT , carburetor throttle rod jam..... (1/4"-25 thread)	2	120613	(8.916)
Group 3.429 LINKAGE PACKAGE, ACCELERATOR					
1941 thru 48	25 S.T.	-----	1	513607	-----
1941 thru 48	26 S.T.	-----	1	513667	-----
1941 thru 48	27 S.T.	-----	1	513606	-----
1941 thru 48	28 S.T.	-----	1	513668	-----
Group 3.430 ROD, CARBURETOR TO IDLER LEVER THROTTLE					
NOTE: C to C means center to center of holes.					
1935 thru 39	P/6	4" C to C of holes.....	1	502946	-----
1933, 1937-38	P/8	3 3/8" C to C of holes.....	1	499999	-----
1939-40	28 All	3 1/2" C to C of holes, without dual carburetor.....	1	502987	-----
1940, 1946 thru 52	P/6 S.T.	-----	1	514827	-----
1940	28-29 All	7 1/2" C to C of holes, with dual carburetor.....	1	504606	-----
1941-42	P/6	4 1/4" C to C of holes.....	1	505852	-----
1941 thru 46	P/8	8 5/16" C to C of holes.....	1	505853	-----
1947 thru 53	P/8 S.T.	9" C to C of holes, with WCD 630S carburetor.....	1	509501	-----
1953-54	P/6 S.T. L.H.D.	-----	1	515229	-----
1940	25 All	LEVER , starter pedal throttle cracker.....	1	504624	-----
1937-38	P/6 L.H.D.	PIN , throttle cracker rod.....	1	499792	-----
1940	P/6 L.H.D.	-----	1	504296	-----
1941	All L.H.D.	-----	1	505878	-----
1948	All H.T.	starter pedal throttle cracker.....	1	510841	-----
1942 thru 48	All L.H.D.	SCREW , starter pedal throttle cracker.....	1	510965	-----
1942 thru 48	All L.H.D. S.T.	adjusting.....	1	507571	-----
Group 3.430 ROD, THROTTLE CONTROL					
1948 thru 52	P/6 H.T.	carburetor throttle.....	1	510842	-----
1948 thru 53	P/8 H.T.	carburetor throttle.....	1	510843	-----
1953-54	P/6 H.T.	carburetor throttle.....	1	517256	-----
1954	P/8	carburetor throttle.....	1	510843	-----
1948, 1950 thru 54	P/6 H.T.	intermediate.....	1	510857	-----
1948	P/8 H.T.	intermediate.....	1	510860	-----
1949	P/6 H.T.	intermediate.....	1	511443	-----
1949 thru 53	P/8 H.T.	intermediate.....	1	511444	-----
1954	P/8	intermediate.....	1	511444	-----
1948	All H.T.	rear.....	1	510853	-----
1949	All H.T.	rear.....	1	511446	-----
1948 thru 54	P/8 H.T.	WASHER , intermediate rod to lever.....	2	510851	-----
Group 3.431 ROD, ACCELERATOR PEDAL					
NOTE: C to C means center to center of hole. Hole to end means center of hole to end of rod.					
1933 thru 36	All L.H.D.	3 11/16" ball to end.....	1	495471	-----
1937-38	All L.H.D.	3 13/16" C to C of holes.....	1	499978	-----
1939	P/8	4 3/4" C to C of holes.....	1	502986	-----
1939	26 L.H.D.	4 5/16" C to C of holes.....	1	503242	-----
1939	25 L.H.D.	3 7/8" C to C of holes.....	1	502351	-----
1940	P/6 L.H.D.	4 1/16" C of hole to ball.....	1	504302	-----
1940	28 All	5 5/16" C of hole to ball.....	1	504303	-----
1940	29 All	4 11/16" C of hole to ball.....	1	504304	-----
1941 thru 48	All exc. 25-27 L.H.D. S.T.	4 1/2" long.....	1	505837	-----
1941 thru 48	25-27 L.H.D. S.T.	4 1/2" long.....	1	506694	-----
1948	25-27 H.T.	-----	1	510855	-----
1948	26-28 H.T.	-----	1	510856	-----
1949	All L.H.D.	-----	1	511299	-----
1950 thru 52	All H.T.	-----	1	513954	-----
1950 thru 52	All L.H.D. S.T.	-----	1	514004	-----
1953	All L.H.D. S.T.	-----	1	515225	-----
1954	P/6 S.T.	-----	1	515225	-----
1953-54	All H.T.	-----	1	515246	-----
1954	P/8 S.T.	-----	1	515246	-----
1937-38	P/8 L.H.D.	ROD , cross shaft to idler lever (throttle control)-----			
		14 7/8" hole to end.....	1	499996	-----
1937-38	P/6 L.H.D.	13 5/8" hole to end.....	1	500000	-----
1939	P/8	11 1/2" hole to end.....	1	502985	-----
1939	P/6 L.H.D.	14" hole to end.....	1	502350	-----
1940	P/6 L.H.D.	11 7/8" C of hole to end.....	1	504298	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.431					
		ROD, ACCELERATOR PEDAL (Continued)			
1940	28	12 $\frac{5}{16}$ " C of hole to end.....	1	504299	-----
1941 thru 48	P/6 L.H.D. S.T.	11 $\frac{1}{2}$ " long.....	1	505848	-----
1941 thru 48	P/8 L.H.D. S.T.	12 $\frac{3}{8}$ " long.....	1	505850	-----
1949 thru 52	All L.H.D. S.T.	-----	1	511300	-----
1953	P/8 S.T.	-----	1	517285	-----
1953-54	P/6 S.T.	-----	1	517285	-----
1938 thru 54	All	SPRING, accelerator pedal rod anti-rattle	1-2	495472	-----
1950 thru 54	All H.T.	TRUNNION, accelerator pedal rod	1	512397	-----
1954	P/8 S.T.	-----	1	512397	-----
Group 3.450					
		LEVER, THROTTLE CONTROL IDLER			
1937-38	P/8 L.H.D.	hand throttle control idler.....	1	499971	-----
1937-38	P/8	throttle control idler.....	1	499993	-----
1941 thru 46	All L.H.D.	hand throttle cross shaft idler.....	1	506696	-----
1948	All H.T.	trans. throttle rod idler.....	1	510839	-----
1949 thru 51	All H.T.	trans. throttle rod idler.....	1	511441	-----
1952 thru 54	All H.T.	trans. throttle rod idler.....	1	516651	-----
1937 thru 53	All S.T.	PIN, throttle idler lever manifold	1	496784	-----
1954	P/6 S.T.	-----	1	496784	-----
Group 3.451					
		PEDAL, ACCELERATOR			
1933 thru 36	All L.H.D.	-----	1	399623	-----
1937-38	All	-----	1	499976	-----
1939	25 All	-----	1	502347	-----
1939	26 All	-----	1	502348	-----
1940	P/6 L.H.D.	-----	1	504292	-----
1940	28 All	-----	1	504293	-----
1940	29 All	-----	1	504294	-----
1941-42	All L.H.D.	-----	1	505730	-----
1946 thru 54	All L.H.D.	-----	1	511007	-----
Group 3.452					
		PIN, ACCELERATOR PEDAL HINGE			
1946 thru 48	All L.H.D.	-----	1	508930	-----
1949 thru 54	All	-----	1	508930	-----
Group 3.454					
		LEVER ASSEMBLY, THROTTLE CONTROL			
1948	All H.T.	to dash rocker.....	1	510833	-----
1949	All H.T.	to dash rocker.....	1	511435	-----
1948	All H.T.	PIN, dash rocker lever to bracket	1	510837	-----
Group 3.455					
		BRACKET ASSEMBLY, THROTTLE CONTROL IDLER LEVER			
1948-49	P/8 H.T.	to cylinder block.....	1	510820	-----
1950	P/8 H.T.	to cylinder block.....	1	514088	-----
1951 thru 53	P/8 H.T.	to cylinder block.....	1	514355	-----
1954	P/8	-----	1	514355	-----
Group 3.456					
		SUPPORT, ACCELERATOR PEDAL			
1946 thru 48	All L.H.D.	-----	1	4147496	-----
1949 thru 52	All L.H.D.	-----	1	4562315	-----
1953-54	All	-----	1	4599925	-----
1948	All L.H.D. H.T.	PLATE, bracket to floor tapping	1	4559195	-----
Group 3.459					
		SPRING, ACCELERATOR ROD RETURN			
1941 thru 48	All exc. 25	-----	1	505835	-----
	L.H.D. S.T.	-----			
1941 thru 48	25 L.H.D. S.T.	-----	1	506697	-----
1949 thru 53	All S.T.	-----	1	505835	-----
1954	P/6 S.T.	-----	1	505835	-----
1934 thru 36	P/8 L.H.D.	SPRING, acc. control idler lever	1	496624	-----
1937-38	P/8	throttle control idler lever.....	1	499997	-----
1948 thru 54	All H.T.	throttle control return.....	2	510877	-----
1954	P/8 S.T.	-----	1	518435	-----
1948 thru 54	All H.T.	STUD, return spring anchor	1	510878	-----
Group 3.464					
		BELLOWS, ACCELERATOR ROD TOE BOARD			
1937-38	All	-----	1	500207	-----
1939-40	P/6	-----	1	500207	-----
1939-40	P/8	-----	1	502944	-----
1941 thru 48	All L.H.D.	-----	1	505779	-----
1949	All L.H.D.	-----	1	512652	-----
1950 thru 52	All L.H.D.	-----	1	514003	-----
1953-54	All L.H.D.	-----	1	515244	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.465 CLIP, THROTTLE CONTROL RETURN SPRING					
1948 thru 52	All H.T.	-----	1	511418	-----
Group 3.472 STUD, ACCELERATOR					
1933 thru 39	All	pedal to floor anchor.....	2	499977	-----
1940	25 All	pedal to floor anchor.....	2	504625	-----
1940	26 All	pedal to floor anchor.....	2	499977	-----
1940	29 All	pedal to floor anchor.....	2	504295	-----
1941-42	All	pedal to floor anchor.....	2	499977	-----
Group 3.480 CONTROL ASSEMBLY, THROTTLE					
1940	25 L.H.D.	-----	1	504623	-----
1940	26-28-29 L.H.D.	-----	1	504216	-----
1941	All	-----	1	505714	-----
1942-46 Spec. equip. and taxi		wire and knob assembly.....	1	507332	-----
1941 thru 46	All	SPACER , throttle control.....	1	511508	-----
Group 3.483 CLIP, THROTTLE CONTROL CABLE DASH					
		See Groups 1.303, 10.257, and 12.182 for use.....		494157	-----
		See Group 8.077 for use.....		375437	-----
Group 3.524 SPRING, ANTI-RATTLE					
1933 thru 54	All	accelerator and throttle rod... ($\frac{5}{16}$ " long x $\frac{7}{32}$ " dia.)	AR	495472	-----
1937 thru 54	All S.T.	throttle control lever... ($\frac{3}{8}$ " long x $\frac{3}{8}$ " dia.)	1	499991	-----
1940	29 All	throttle control idler... ($\frac{1}{2}$ " long x $\frac{1}{4}$ " dia.)	AR	504288	-----
1940	All L.H.D.	accelerator pedal—accelerator control rod.....	2	504288	-----
1950 thru 54	H.T.	accelerator pedal rod to throttle idler lever.....	1	504288	-----
Group 3.571 LEVER, ACCELERATOR IDLER					
1937 thru 39	P/6 1937-38 L.H.D., 1939	-----	1	499995	-----
1940	P/6	-----	1	504290	-----
1940	28-29 All	with dual carburetor.....	1	504604	-----
1940	28 All	without dual carburetor.....	1	504291	-----
1941 thru 54	P/6 S.T.	L.H.D. only on 1950 thru 54.....	1	505846	-----
1941 thru 53	P/8 S.T.	-----	1	505847	-----
1948	All H.T.	LEVER , throttle control idler.....	1	510830	-----
1949	All H.T.	throttle control idler.....	1	511438	-----
1950 thru 54	All H.T.	throttle control idler.....	1	513951	-----
1954	P/8 S.T.	-----	1	513951	-----
1948 thru 54	P/6 H.T.	STUD , throttle control idler lever to cylinder block.....	1	510817	-----
Group 3.581 LEVER, ACCELERATOR CROSS SHAFT THROTTLE CRACKER					
1942 thru 48	All L.H.D., S.T.	-----	1	507566	-----
1948	All H.T.	starter pedal throttle cracker.....	1	510838	-----
1942 thru 48	All L.H.D., S.T.	SPRING , throttle cracker lever anti-rattle.....	1	507567	-----
Group 3.585 SHAFT, ACCELERATOR CROSS					
1937-38	P/6 L.H.D.	-----	1	499981	-----
1940	P/6 L.H.D.	-----	1	504306	-----
1940	29 All	-----	1	504607	-----
1941	All L.H.D.	-----	1	505831	-----
1942 thru 48	All L.H.D., S.T.	-----	1	507568	-----
1949	All L.H.D., S.T.	-----	1	511302	-----
1950 thru 52	All L.H.D., S.T.	-----	1	513766	-----
1953	All L.H.D., S.T.	-----	1	515230	-----
1954	P/6 S.T.	-----	1	515230	-----
Group 3.585 SHAFT AND BRACKET, THROTTLE CONTROL INTER. LEVER					
1948	P/6 H.T.	-----	1	512584	-----
1949	P/6 H.T.	-----	1	512588	-----
1950 thru 54	P/6 H.T.	-----	1	513957	-----
1948 thru 54	P/8 H.T.	throttle cross.....	1	510831	-----
1954	P/8 S.T.	-----	1	510831	-----
1948	P/6 H.T.	bracket.....	1	510818	-----
Group 3.589 BRACKET, ACCELERATOR CROSS SHAFT					
1940	26 L.H.D.	----- R.H.	1	504995	-----
1941	All L.H.D.	----- R.H.	1	504995	-----
1942 thru 48	All L.H.D., S.T.	-----	2	507656	-----
1949 thru 53	All L.H.D., S.T.	-----	2	511297	-----
1954	P/6 S.T.	-----	2	511297	-----
1949 thru 53	All L.H.D., S.T.	SPACER , accelerator cross shaft.....	1	511306	-----
1954	P/6 S.T.	-----	1	511306	-----

(2.487)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.589		BRACKET, ACCELERATOR CROSS SHAFT (Continued)			
1949-50	All L.H.D., S.T.	-----	1	511297	-----
1948 thru 50	All H.T.	BRACKET ASSY., trans. throttle rod idler lever....	1	510822	-----
1948	All H.T.	throttle control rocker lever to dash.....	1	510824	-----
1949	All H.T.	-----	1	511433	-----
1951 thru 54	All H.T.	throttle rod idler lever.....	1	514388	-----
Group 3.591		SPRING, ACCELERATOR CROSS SHAFT			
1940	29 All	-----	1	504331	-----
1941 thru 53	All L.H.D., S.T.	cross shaft anti-rattle..... (7/16" I.D. x 1 9/32")	1	505836	-----
1954	P/6 S.T.	-----	1	505836	-----
Group 3.601		MANIFOLD, EXHAUST			
1937-38	P/6	-----	1	500220	-----
1939-40	P/6	-----	1	503590	-----
1940	29 All	-----	1	504611	-----
1941 thru 51	P/6	-----	1	505341	-----
1952	P/6	-----	1	516167	-----
1941 thru 54	P/8	-----	1	516168	-----
1953-54	P/6	-----	1	517273	-----
Group 3.602		COVER, EXHAUST MANIFOLD			
1935 thru 54	All exc. P/6 1935	choke heat.....	1	497612	-----
Group 3.604		OUTLET ASSEMBLY, EXHAUST MANIFOLD RISER			
1935-36	All	-----	1	497585	-----
1937-38	All L.H.D.	-----	1	497585	-----
1939	P/8	-----	1	497585	-----
Group 3.605		GASKET, EXHAUST MANIFOLD OUTLET			
1934 thru 39	All exc. P/6 1939	intake to exhaust.....	1	496215	-----
1939 thru 54	P/6	intake to exhaust.....	1	502288	-----
1940	28 All	intake to exhaust.....	1	508248	-----
1940 thru 54	P/8 exc. 1940 28	intake to exhaust.....	1	504610	-----

EXHAUST PIPE, MUFFLER AND TAIL PIPE CHART

Year	Model	Muffler Group 3.701	Exhaust Pipe Group 3.609	Tail Pipe Group 3.705	Muffler Clamp Front Group 3.708	Muffler Clamp Rear Group 3.708	Flange Gasket Exhaust Pipe Group 3.611	Support Tail Pipe Group 3.706
1935	P/6	500867			502392		496783	
1935	P/8	500867			502392		496783	
1936	P/6	500867			502392		496783	498684
1936	P/8	500867			502392		496783	498684
1937	P/6 L.H.D.	500867			502392	499952	496783	500067
1937	P/8 L.H.D.	500867	500073		502392	499952	496783	500067
1938	P/6 L.H.D.	500867			502392	499952	496783	500067
1938	P/8 L.H.D.	500867	500073		502392	499952	496783	500067
1939	25	500867	502393	502395	502392		496783	502397
1939	26	500867	502770	502774	502392	499952	496783	502778
1939	28	500867	502772	502774	502392	499952	496783	502778
1940	25	500867	504119	504121	502392	499952	496783	502778
1940	26	500867	502770	502774	502392	499952	496783	502778
1940	28	500867	504117	502774	502392	499952	496783	502778
1940	29	500867		504113	502392	499952	496783	504115
1941	25	500867	505276	508601	502392	499952	496783	502778
1941	24-26	500867	505278	508602	502392	499952	496783	505290
1941	27	500867	505277	508601	502392	499952	496783	502778
1941	28-29	500867	505279	508602	502392	499952	496783	505290
1942	25	500867	505276	508601	502392	499952	496783	502778
1942	26	500867	505278	508602	502392	499952	496783	505290*
1942	27	500867	505277	508601	502392	499952	496783	502778
1942	28	500867	505279	508602	502392	499952	496783	505290*
1946	25	500867	505276	508601	502392	499952	496783	502778
1946	26	500867	505278	508602*	502392	499952	496783	505290*
1946	27	500867	505277	508601	502392	499952	496783	502778
1946	28	500867	505279	508602*	502392	499952	496783	505290*
1947	25	500867	505276	508601	502392	499952	496783	502778
1947	26	500867	505278	508602*	502392	499952	496783	505290*

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
------	-------	-----------	---------	----------	---------

EXHAUST PIPE, MUFFLER AND TAIL PIPE CHART (Continued)

Year	Model	Muffler Group 3.701	Exhaust Pipe Group 3.609	Tail Pipe Group 3.705	Muffler Clamp Front Group 3.708	Muffler Clamp Rear Group 3.708	Flange Gasket Exhaust Pipe Group 3.611	Support Tail Pipe Group 3.706
1947	27	500867	505277	508601	502392	499952	496783	502778
1947	28	500867	505279	508602*	502392	499952	496783	505290*
1948	25 S.T.	500867	505276	508601	502392	499952	496783	502778
1948	26 S.T.	500867	505277	508602*	502392	499952	496783	505290*
1948	27 S.T.	500867	505278	508601	502392	499952	496783	502778
1948	28 S.T.	500867	505279	508602*	502392	499952	496783	505290*
1948	25 H.T.	500867	510947	508601	502392	499952	496783	505290*
1948	26 H.T.	500867	510949	508602*	502392	499952	496783	505290*
1948	27 H.T.	500867	510948	508601	502392	499952	496783	505290*
1948	28 H.T.	500867	510950	508602*	502392	499952	496783	505290*
1949	P/6	500867	511278	511282*	502392	499952	496783	512565*
1949	P/8	500867	511279	511282*	502392	499952	496783	512565*
1950 thru 52	P/6	500867	511278	511282*	502392	499952	496783	512322*
1950 thru 52	P/8	500867	511279	511282*	502392	499952	496783	512322*
1953-54	P/6	500867	511278	515265*	502392	499952	496783	512322*
1953-54	P/8	500867	511279	515265*	502392	499952	496783	512322*
1954	28 All	500867	511279	517562	502392	499952	496783	516292
1941	24 Sta. wag.	500867	505278	508602	502392	499952	496783	505290
1941	29 Sta. wag.	500867	505279	508602	502392	499952	496783	505290
1942	26 Sta. wag.	500867	505278	508602	502392	499952	496783	502778
1942	28 Sta. wag.	500867	505279	508602	502392	499952	496783	502778
1946	26 Sta. wag.	500867	505278	508603	502392	499952	496783	502778
1946	28 Sta. wag.	500867	505279	508603	502392	499952	496783	502778
1947	26 Sta. wag.	500867	505278	508603	502392	499952	496783	502778
1947	28 Sta. wag.	500867	505279	508603	502392	499952	496783	502778
1948	26 Sta. wag.	500867	505278	508603	502392	499952	496783	502778
1948	28 Sta. wag.	500867	505279	508603	502392	499952	496783	502778
1949	P/6 2561-62-71	500867	511278	511522	502392	499952	496783	505290
1949	P/8-2561-62-71	500867	511279	511522	502392	499952	496783	505290
1950 thru 52	P/6 2562-71	500867	511278	511522	502392	499952	496783	505290
1950 thru 52	P/8 2562-71	500867	511279	511522	502392	499952	496783	505290
1953-54	P/6 2562-71	500867	511278	516290	502392	499952	496783	516292
1953-54	P/8 2562-71	500867	511279	516290	502392	499952	496783	516292

*All models exc. Station Wagon & Sedan Delivery.

Group 3.609

PIPE, EXHAUST

1937-38	P/8 L.H.D.	34 $\frac{3}{16}$ " long	1	500073	-----
1939	P/8	33 $\frac{3}{16}$ " long	1	502772	-----
1939	25 All	32" long	1	502393	-----
1939-40	26 All	34 $\frac{1}{2}$ " long	1	502770	-----
1940	25 All	29 $\frac{3}{8}$ " long	1	504119	-----
1940	28 All	33 $\frac{1}{2}$ " long	1	504117	-----
1941 thru 48	25 S.T.	35 $\frac{11}{16}$ " long	1	505276	-----
1941 thru 48	27 S.T.	38" long	1	505277	-----
1941 thru 48	24-26 S.T.	36 $\frac{3}{16}$ " long	1	505278	-----
1941 thru 48	28-29 S.T.	38 $\frac{1}{2}$ " long	1	505279	-----
1948	25 L.H.D. H.T.	-----	1	510947	-----
1948	26 L.H.D. H.T.	-----	1	510949	-----
1948	27 L.H.D. H.T.	-----	1	510948	-----
1948	28 L.H.D. H.T.	-----	1	510950	-----
1949 thru 54	P/8	34 $\frac{19}{32}$ " long	1	511279	-----
1949 thru 54	P/6	32 $\frac{1}{4}$ " long	1	511278	-----

Group 3.610

FLANGE, EXHAUST PIPE

1933 thru 54	All	-----	1	501719	-----
--------------	-----	-------	---	--------	-------

Group 3.611

GASKET, EXHAUST PIPE FLANGE

1935 thru 54	All	-----	2	496783	-----
--------------	-----	-------	---	--------	-------

Group 3.616

BRACE, EXHAUST PIPE

1937-38	All	-----	1	500077	-----
1939	25 All	-----	1	502389	-----
1939-40	28 All	to clutch housing	1	502769	-----
1939-40	26 All	to clutch housing	1	502768	-----
1940	25 All	to clutch housing	1	504085	-----
1940	29 All	to clutch housing	1	504110	-----
1941 thru 48	All	to clutch housing	1	502768	-----
1949 thru 54	All S.T.	to clutch housing	1	511277	-----
1949 thru 54	All H.T.	to flywheel housing	1	511646	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.640 THERMOSTAT, MANIFOLD HEAT CONTROL VALVE					
1933 thru 36	All	7½ coils.....	1	495828	-----
1937 thru 39	All exc. P/6 1939	6 coils.....	1	499581	-----
1939 thru 51	P/6	3½ coils.....	1	502453	-----
1940 thru 50	P/8	3½ coils.....	1	502453	-----
1951	P/8	-----	1	516304	-----
1952	P/6	-----	1	516177	-----
1952 thru 54	P/8	-----	1	516303	-----
1953-54	P/6 H.T.	-----	1	517276	-----
1953-54	P/6 S.T.	-----	1	517009	-----
Group 3.641 CLIP, MANIFOLD HEAT CONTROL VALVE SPRING					
1934 thru 39	All exc. P/6 1939	-----	1	496375	-----
Group 3.646 BUSHING, MANIFOLD HEAT CONTROL VALVE					
1933 thru 51	All exc. P/6 1939	-----	2	497586	-----
1939	P/6	-----	1	502291	-----
Group 3.647 VALVE, MANIFOLD HEAT CONTROL					
1939	P/6	shaft and counterweight, heat control valve.....	1	502296	-----
1935 thru 39	All exc. P/6 1939	VALVE, manifold heat control air tube.....	1	498126	-----
1937 thru 39	P/8	TUBE, manifold heat control air.....	1	499890	-----
Group 3.653 SPRING, MANIFOLD HEAT CONTROL VALVE					
1933 thru 36	All	valve tension.....	1	495508	-----
1937-38	All L.H.D.	valve tension.....	1	495508	-----
1939	P/8	valve tension.....	1	495508	-----
1939	P/6	anti-rattle.....	1	502875	-----
Group 3.656 PIN-PLATE, HEAT CONTROL VALVE ANCHOR					
1935 thru 37	Used after Engs. 8-6464 & 6-10951	PIN.....	1	498181	-----
1938-39	All 1938 exc. taxi, P/8 1939	-----	1	498181	-----
1940 thru 54	All exc. P/8 1940	-----	1	502293	-----
1939	P/6	PLATE, thermostat anchor.....	1	504261	-----
1940	P/8	-----	1	504261	-----
Group 3.658 GASKET, EXHAUST MANIFOLD VALVE					
1933 thru 39	All exc. P/6 1939	-----	1	496436	-----
Group 3.680 DEFLECTOR, MANIFOLD VALVE THERMOSTAT					
1937 thru 39	All exc. P/6 1939	-----	1	499582	-----
1941 thru 51	All	-----	1	505575	-----
1952 thru 54	All	-----	1	516166	-----
Group 3.701 MUFFLER					
1934 thru 54	All	-----	1	500867	-----
Group 3.703 STRAP, MUFFLER SUPPORT					
1935 thru 54	All	fabric.....	2	497935	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.704 BRACKET, MUFFLER					
1937-38	All	support to frame.....	1	499953	-----
1937-38	All	support.....	1	499951	-----
1939	25 All	to frame.....	1	502390	-----
1939, 1941 thru 48	26-28 All	support.....	1	502776	-----
1940	All	support.....	1	502776	-----
1941	29 All	support.....	1	502776	-----
1941 thru 48	25 All	support.....	1	505288	-----
1949 thru 54	All	support.....	1	502776	-----
Group 3.705 PIPE, MUFFLER TAIL					
1939	25 All	76 $\frac{1}{2}$ " long	1	502395	-----
1939-40	26-28 All	82 $\frac{3}{8}$ " long	1	502774	-----
1940	25 All	84 $\frac{9}{16}$ " long	1	504121	-----
1940	29 All	88 $\frac{13}{16}$ " long	1	504113	-----
1941 thru 48	26-29 All	94 $\frac{1}{8}$ " long	1	508602	-----
	exc. sta. wag.				
1941 thru 48	25 All	80 $\frac{11}{32}$ " long	1	508601	-----
1946 thru 48	Sta. wag.	91 $\frac{15}{16}$ " long	1	508603	-----
1949 thru 52	All exc.	85 $\frac{1}{2}$ " long	1	511282	-----
	2561-62-71				
1949 thru 52	2561-62-71 All	86 $\frac{1}{4}$ " long	1	511522	-----
1953-54	2511-37-67-69 All	87 $\frac{1}{2}$ " long	1	515265	-----
1953	2562-71 All	89" long	1	516290	-----
1954	28 All	97 $\frac{1}{2}$ " long	1	517562	-----
1954	2562	86 $\frac{1}{2}$ " long	1	518642	-----
Group 3.706 BRACKET—SUPPORT, MUFFLER TAIL PIPE					
1949	All exc. 2561-62-71		1	512565	-----
1941 thru 48	Sta. wag.	tail pipe support to frame.....	1	506259	-----
1937-38	All	SUPPORT , tail pipe.....	1	500067	-----
1939	25 All		1	502397	-----
1939-40	All exc. 29		1	502778	-----
	and 1939 25				
1940	29 All		1	504115	-----
1941 thru 48	25 All		1	502778	-----
1941 thru 48	26-28 All		1	505290	-----
	exc. sta. wag.				
1942 thru 48	Sta. wag.		1	502778	-----
1941	29 All		1	505290	-----
1949 thru 52	2561-62-71 All		1	505290	-----
1949 thru 54	All exc.		1	512322	-----
	2561-62-71				
1953	2562-71 All		1	516292	-----
1954	2562		1	518644	-----
Group 3.708 CLAMP, MUFFLER					
1933 thru 54	All	to exhaust pipe.....	1	502392	-----
1937 thru 54	All exc. 1939 25	muffler support.....	1	499952	-----
Group 3.710 PLATE, TAIL PIPE SUPT. INSULATOR REINFC'T.					
1939 thru 54	All exc.		1	502780	-----
	1939 25				
Group 3.724 GASKET PACKAGE, CARBURETOR					
1936-37	All	(Carter 123).....	1	7001300	-----
1938	All	(Carter 132).....	1	7001301	-----
1939-40	All exc. P/8 1940	(Carter 139A).....	1	7001302	-----
1940	28 All	(Carter 146).....	1	7001334	-----
1940	29 All	(Carter 134).....	1	7001307	-----
1941 thru 50	P/6	(Carter 146) used w/426S, 494S, 537S, 717S & 718S carb.....	1	7001334	-----
1941 thru 47	P/8	(Carter 134) used to engine no. 12388 on 1947....	1	7001307	-----
1942	P/6	(Carter 167).....	1	7001304	-----
1947	P/8	(Carter 190) used after 12388 engines used w/630S, SA & SB carb.....	1	7001346	-----
1948 thru 53	P/8	(Carter 190) used w/719S, SA, 720S & SA carb.....	1	7001346	-----
1951-52	P/6		1	7001391	-----
1953-54	P/6	(Carter 231).....	1	7006044	-----
Group 3.725 CARBURETOR ASSEMBLY					
1951-52	P/6	(Rochester "BC" MX-189).....	1	7002870	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.725 REPAIR KIT, CARBURETOR					
NOTE: Repair kits listed below consist of necessary parts to completely overhaul one carburetor.					
1937	P/6	(Carter 1028)	1	7001322	-----
1937	P/8	(Carter 1027)	1	7001321	-----
1938	P/6	(Carter 1030)	1	7001324	-----
1938	P/8	(Carter 1029)	1	7001323	-----
1939	P/8	(Carter 1064)	1	7001326	-----
1939	P/6	(Carter 1063)	1	7001325	-----
1940	P/6	(Carter 1085)	1	7001328	-----
1940	28 All	(Carter 1084)	1	7001327	-----
1940	29 All	(Carter 1086C)	1	7001329	-----
1941-42	P/6	(Carter 1300)	1	7001330	-----
1941 thru 47	P/8	(Carter 1086C) used to engine 12388 on 1947	1	7001329	-----
1946 thru 50	P/6 S.T.	(Carter 1366A) 46 thru 48 use w/537S carb.; 49-50 use w/717S carb.	1	7001370	-----
1947-48	P/8 S.T.	(Carter 1369) used after 12388 engines on 1947—used with 630S, SA, SB and 653S carb. on 1948.	1	7001337	-----
1949 thru 53	P/8	(Carter 1507) used with 719-720, S and SA carb.	1	7001365	-----
1948 thru 50	P/6 H.T.	(Carter 1388A) used w/652S carb. 1948 and 718S carb. 1949-50	1	7001371	-----
1951-52	P/6		1	7001392	-----
1953-54	P/6	(Carter 1731)	1	7006045	-----
Group 3.726 GASKET, CARBURETOR TO MANIFOLD					
1933 thru 40 All exc. P/8 1940			1	500372	-----
1940	28 All		1	504279	-----
1940 thru 46 All P/8 exc. 1940 28			1	504601	-----
1941 thru 52	P/6		1	504279	-----
1947 thru 53	P/8	thin	1	509507	-----
1947 thru 53	P/8	thick	1	509506	-----
1953-54	P/6	thick	1	509506	-----
1953-54	P/6	thin	1	509507	-----
1954	P/8	thick	1	518568	-----
1954	P/8	thin	1	518569	-----
Group 3.727 CONVERSION PACKAGE, CARBURETOR					
1940 thru 47 All P/8 exc. 1940-28 thru first 12,388 engines in 1947		for installing 513122 and 514097 carburetors on these models	1	510614	-----
Group 3.729 BODY ASSY., CARBURETOR THROTTLE					
1941 thru 50	P/6 S.T.	(Carter 1-389S) used with 537S or 717S—1946 thru 50	1	7001475	-----
1947 thru 53	All P/8 S.T.	(Carter 1-551S) used w/630S, 719S & SA carb.	1	7001457	-----
1948 thru 50	P/6 H.T.	(Carter 1-560S) used with 652S or 718S carb.	1	7001462	-----
1948 thru 53	P/8 H.T.	(Carter 1-559S) used w/635S or 720S, & SA carb.	1	7001469	-----
1951-52	P/6		1	7003192	-----
1953-54	P/6	(Carter 1-1070S)	1	7005913	-----
Group 3.730 AIR HORN AND MAIN WELL SUPPORT ASSY., CARBURETOR					
1951-52	P/6		1	7003454	-----
Group 3.730 AIR HORN AND CLIMATIC CONTROL ASSY., CARBURETOR					
1940	P/6	(Carter 6-347S)	1	1875456	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 6-457S) used with 548S carb. on 1947	1	7000783	-----
1941-42	P/6	(Carter 6-398S) used with 494S carb. on 1942.	1	1875488	-----
1946 thru 50	P/6	(Carter 6-532S)	1	7000423	-----
1947-48	P/8	(Carter 6-576S) used w/630S, 630SA, 630SB and 653S carb.	1	7001477	-----
1949 thru 53	P/8	(Carter 6-674S) used w/719SA carb.	1	7002752	-----
1949 thru 53	P/8	(Carter 6-675S) used w/720S & 720SA carb.	1	7002753	-----
1953-54	P/6	(Carter 6-868S)	1	7005857	-----
1938-39	All	SCREW AND WASHER, air horn (Carter 101-151S)	2	7000794	-----
1940	All exc. 29	(Carter 101-151S)	2	7000794	-----
1941 thru 50	P/6	(Carter 101-151S)	2	7000794	-----
1940 thru 46	P/8 exc. 1940 28	(Carter 101-150S)	2	7000651	-----
1947 thru 53	P/8	(Carter 101-152S)	4	7000744	-----
1951-52	P/6	air horn to bowl	4	7002879	-----
1951-52	P/6	air horn to bowl (No. 8-32 x 1")	2	451910	-----
1953-54	P/6	(Carter 101-152S)	4	7000744	-----
1947 thru 53	P/8	bowl cover to bowl (Carter 101-160S)	6	7000745	-----
1953-54	P/6	bowl cover to bowl (Carter 101-160S)	6	7000745	-----

(3.741)
(3.741)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.731 GASKET, CARB. AIR HORN TO FLOAT BOWL COVER					
1947 thru 53	P/8	(Carter 121-80).....	1	7000688	-----
1953-54	P/6	(Carter 121-80).....	1	7000688	-----
Group 3.732 COVER, CARBURETOR DUST					
1946 thru 50	P/6	(Carter 118-28).....	1	7000427	-----
1947 thru 53	P/8	(Carter 118-39).....	1	7000685	-----
1953-54	P/6	(Carter 118-39).....	1	7000685	-----
1947-48	P/8	GASKET , cover (Carter 121-116) used with 630S carb.	1	7000756	-----
1947 thru 53	P/8	SCREW AND WASHER (Carter 101-161S).....	2	7000746	-----
Group 3.735 GASKET, CARB. THROTTLE BODY					
1941 thru 50	P/6 S.T.	(Carter 121-72) used with 537S carb.	1	1875150	-----
1947 thru 53	P/8	to bowl (Carter 121-79).....	1	7000689	-----
1951-52	P/6	to bowl.....	1	7002156	-----
1953-54	P/6	to bowl (Carter 121-79).....	1	7000689	-----
1951-52	P/6	air horn to float bowl.....	1	7003191	-----
Group 3.737 COVER, CARBURETOR FLOAT BOWL					
1939-40	All exc. 1940 29	(Carter 146-85S).....	1	7000800	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 146-58S) used with 548S carb on 1947...	1	7001417	-----
1941-42	P/6	(Carter 146-119S) used with 494S carb. on 1942...	1	7001418	-----
1946 thru 50	P/6	(Carter 146-88S).....	1	7001420	-----
1947-48	P/8	(Carter 146-169S) used with 630S carb.	1	7001449	-----
1949 thru 53	P/8	(Carter 146-184S) used with 719, 720, S & SA carb.	1	7001869	-----
1953-54	P/6	(Carter 146-218S).....	1	7005879	-----
Group 3.738 GASKET, CARB. BOWL COVER TO FLOAT BOWL					
1947 thru 53	P/8	(Carter 121-81).....	1	7000690	-----
1953-54	P/6	(Carter 121-233).....	1	7005876	-----
Group 3.740 STRAINER, CARBURETOR BOWL COVER					
1939 thru 50	All	GASKET , strainer nut (Carter 20-35).....	1	1875030	-----
1951 thru 53	P/8	(Carter 20-35).....	1	1875030	-----
1953-54	P/6	(Carter 20-35).....	1	1875030	-----
1951-52	P/6		1	7001597	-----
1951-52	P/6	NUT , strainer.....	1	7002862	-----
1939 thru 50	All	NUT AND GASKET (Carter 15-35S).....	1	1875025	-----
1951 thru 53	P/8	(Carter 15-35S).....	1	1875025	-----
1953-54	P/6	(Carter 15-35S).....	1	1875025	-----
1939 thru 53	All	SCREEN (Carter 30-14).....	1	342139	-----
Group 3.741 SCREW AND WASHER, CARB. THROTTLE BODY					
1947 thru 53	P/8	to float bowl (Carter 101-149S).....	4	7000650	-----
1951-52	P/6	to float bowl.....	1	7002877	-----
1951-52	P/6	main well support.....	1	7002879	-----
1953-54	P/6	to float bowl (Carter 101-149S).....	4	7000650	-----
		(see Group 3.730 for use).....		7000745	-----
Group 3.745 FLOAT, CARBURETOR					
1939-40	28 All	(Carter 21-70S).....	1	1875205	-----
1939 thru 42	P/6	(Carter 21-73S) used with 494S carb. on 1942....	1	1875286	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 21-64S) used with 548S carb. on 1947....	1	1875352	-----
1946 thru 50	P/6	(Carter 21-86S).....	1	7000393	-----
1947 thru 53	P/8	(Carter 21-80S).....	1	7000676	-----
1951-52	P/6		1	7002672	-----
1953-54	P/6	FLOAT AND LEVER PKG. (Carter 21-150U).....	1	7005861	-----
1953-54	P/6	LEVER , auxiliary float (Carter 22-67).....	1	7005862	-----
Group 3.747 PIN, CARBURETOR FLOAT LEVER					
1937 thru 39	All	(Carter 24-15).....	1	836689	-----
1940 thru 50	P/6	(Carter 24-15).....	1	836689	-----
1940 thru 53	All P/8 exc. 1940 28	(Carter 24-24).....	1	1875363	-----
1951-52	P/6		1	7002081	-----
1953-54	P/6	(Carter 24-29).....	1	7005863	-----

(3.730)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.750 HOUSING AND COIL ASSY., CARB. THERMOSTATIC					
1939-40	28 All	(Carter 170M-64S).....	1	1875433	-----
1940 thru 47	All P/8 exc.	(Carter 170F-16S) used with 548S carb. on 1947..	1	1427371	-----
	1940 28				
1940 thru 50	P/6	(Carter 170F-64S).....	1	1875425	-----
1947 thru 53	P/8	(Carter 170N-77S).....	1	7000611	-----
1953-54	P/6	(Carter 170N-77S).....	1	7000611	-----
1951-52	P/6	COVER AND COIL ASSY., carb. thermostatic— w/gasket.....	1	7003453	-----
1940 thru 47	All P/8 exc.	CORK DISC, insulator (Carter 179-16)	1	7001423	-----
	1940 28				
1940 thru 47	All P/8 exc.	CORK STRIP, insulator (Carter 179-12)	1	1423199	-----
	1940 28				
1937 thru 47	All	GASKET, coil housing (Carter 121-74) with single carb.	1	1875423	-----
1947 thru 53	P/8	(Carter 121-78).....	1	7000610	-----
1953-54	P/6	(Carter 121-78).....	1	7000610	-----
1951-52	P/6	choke cover.....	1	7002760	-----
1951-52	P/6	choke housing to air horn.....	1	7002841	-----
1951-52	P/6	PACKING, carb. choke suction tube	1	7002883	-----
1947 thru 53	P/8	PLATE, coil housing baffle (Carter 186-15)	1	7000609	-----
1953-54	P/6	(Carter 186-15).....	1	7000609	-----
1937 thru 39	All	RETAINER, housing (Carter 63-33) used with 548S carb.	2	1875045	-----
1940	28 All	(Carter 63-48).....	2	1875400	-----
1940 thru 47	All P/8 exc.	(Carter 63-33).....	3	1875045	-----
	1940 28				
1940 thru 50	P/6	(Carter 63-48).....	3	1875400	-----
1947 thru 53	P/8	(Carter 63-58).....	3	7000614	-----
1951 thru 54	P/6	(Carter 63-58).....	3	7000614	-----
1935 thru 46	All	SCREW, retainer (Carter 101-65) (No. 6-32x1/4")	2	131880	(8.907)
1947 thru 50	P/6	(Carter 101-65)..... (No. 6-32x1/4")	3	131880	(8.907)
1947 thru 54	P/8	(Carter 101-136)..... (No. 8-32x1/4")	3	131954	(8.907)
1951 thru 54	P/6	(Carter 101-136)..... (No. 8-32x1/4")	3	131954	(8.907)
1951-52	P/6	choke housing attaching.....	2	7004487	-----
1951-52	P/6	TUBE AND SEAL ASSY., carb. choke suction	1	7002881	-----
Group 3.751 VALVE, CARBURETOR CHOKE					
1940 thru 47	All P/8 exc.	(Carter 7-113) used with 548S carb. on 1947.....	1	1438294	-----
	1940 28				
1946 thru 50	P/6	(Carter 7-144).....	1	7000424	-----
1947-48	P/8	(Carter 7-145) used w/630S, SA, SB and 653S carb.	1	7000608	-----
1937-38	All	(Carter 39-11).....	2	342146	(3.761)
1949-50	P/8	(Carter 7-145) used with 719S carb.	1	7000608	-----
1949-50	P/8	(Carter 7-156) used with 720S carb.	1	7001863	-----
1950 thru 53	P/8	(Carter 7-166) used with 719SA carb.	1	7002746	-----
1950 thru 53	P/8	(Carter 7-167) used with 720SA carb.	1	7002747	-----
1951-52	P/6		1	7002086	-----
1939 thru 50	All	SCREW, choke valve (Carter 39-10)	2	838959	-----
1951 thru 54	P/8	(Carter 39-10).....	2	838959	-----
1951-52	P/6	(Carter 39-10)..... (No. 6-32x1/4")	1	7002305	-----
1953-54	P/6	(Carter 39-10).....	2	838959	-----
Group 3.751 HOUSING ASSY., CARB. CHOKE					
1951-52	P/6		1	7002836	-----
Group 3.752 SHAFT, LEVER AND LINK ASSY., CARBURETOR CHOKE					
1937-38	P/6	(Carter 14-205S).....	1	1875022	-----
1939	P/8	(Carter 14-240S).....	1	1875184	-----
1939 thru 50	P/6	(Carter 14-222S) used with 494S carb. on 1942....	1	1875238	-----
1940 thru 47	All P/8 exc.	(Carter 14-192S) used with 548S carb. on 1947....	1	7000786	-----
	1940 28				
1942	P/6	(Carter 14-205S) used with 521S or 545S carb.	1	1875022	-----
1947 thru 50	P/8	(Carter 14-344S) used with 630S, SA, SB, 653S, 719S and 720S carb.	1	7000604	-----
1950 thru 53	P/8	(Carter 14-401S) used with 719-720, SA carb.	1	7002749	-----
1951-52	P/6		1	7002850	-----
1953-54	P/6	(Carter 14-401S).....	1	7002749	-----
1940 thru 47	All P/8 exc.	PISTON (Carter 160-20)	1	1423194	-----
	1940 28				
1937 thru 40, 1947 thru 50	All exc. 1940 29	(Carter 160-35).....	1	1875075	-----
1941 thru 46	P/6	(Carter 160-35).....	1	1875075	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.752 SHAFT, LEVER AND LINK ASSY., CARB. CHOKE (Continued)					
1951 thru 53	P/8	(Carter 160-35).....	1	1875075	-----
1951-52	P/6		1	7002853	-----
1953-54	P/6	(Carter 160-35).....	1	1875075	-----
1946 thru 50	All	PIN , choke piston (Carter 150-62).....	1	1875069	-----
1951 thru 53	P/8	(Carter 150-62).....	1	1875069	-----
1951-52	P/6		1	7002854	-----
1953-54	P/6	(Carter 150-62).....	1	1875069	-----
1951-52	P/6	CLIP , choke rod end.....	1	7003137	-----
1951-52	P/6	LEVER AND COLLAR ASSY. , carb. choke.....	1	7002860	-----
1951-52	P/6	LEVER , carb. choke trip.....	1	7002863	-----
1951-52	P/6	ROD , carb. choke.....	1	7002880	-----
1951 thru 52	P/6	SCREW , carb. choke trip lever. (Sp. Hd. No. 6-32x $\frac{1}{16}$ ").....	1	1875051	-----
1951 thru 52	P/6	WASHER , trip lever spacing.....	1	1875354	-----
Group 3.753 LEVER, CARBURETOR CHOKE					
1947 thru 53	P/8	(Carter 14-296S) with screw.....	1	7000641	-----
1953-54	P/6	(Carter 14-454S).....	1	7005860	-----
Group 3.758 VALVE, CARBURETOR THROTTLE					
1940	28 All	(Carter 2-99).....	1	1875230	-----
1940 thru 53	All P/8 exc. 1940 28	(Carter 2-92).....	2	1875428	-----
1941 thru 50	P/6	(Carter 2-99) used with 494S on 1942.....	1	1875230	-----
1953-54	P/6	(Carter 2-92).....	2	1875428	-----
Group 3.759 SHAFT AND LEVER, CARBURETOR THROTTLE					
1940	28 All	(Carter 3-370S).....	1	1875440	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 3-375S) used with 548S carb. on 1947.....	1	7000780	-----
1941 thru 50	P/6	(Carter 3-370S) used with 494S carb. on 1942.....	1	1875440	-----
1942	P/6	(Carter 3-439S) used with 521S or 545S carb. on 1942.....	1	1875562	-----
1947-48	P/8	(Carter 3-568S) used with 630S carb.....	1	7000672	-----
1947 thru 53	P/8	(Carter 3-598S) used with 630S, 630SA, 630SB and 719S carb.....	1	7001458	-----
1948 thru 50	P/6 H.T.	(Carter 3-546S) used with 652S or 718S carb.....	1	7001463	-----
1948 thru 53	P/8 H.T.	(Carter 3-605S) used with 653S or 720S & SA carb.....	1	7001470	-----
1953-54	P/6	(Carter 3-842S).....	1	7005856	-----
1947 thru 53	P/8	RING , carb. throttle shaft retaining (Carter 63-118) used with 630SA, 630SB, 653S, 719, 720, S and SA carb.....	1	7001461	-----
Group 3.761 SCREW, CARBURETOR THROTTLE VALVE AND LEVER					
1937 thru 50	All	valve attaching single carburetor (Carter 39-11).....	2	342146	-----
1940 thru 53	All P/8 exc. 1940 28	valve attaching (Carter 101-73).....	4	7000645	-----
1953	P/6	(Carter 101-73).....	4	7000645	-----
1947 thru 54	P/8	lever adjusting (Carter 101-121).....	1	839062	-----
1953-54	P/6	lever adjusting.....	1	839062	-----
1947-48	P/8	centering (Carter 101-130) used with 630S carb.....	1	7000675	-----
Group 3.762 ARM-ROD-SPRING, CARBURETOR THROTTLE					
1939-40	All exc. 1940 29	(Carter 114-42S).....	1	1875222	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 114-39S) used with 548S carb. on 1947.....	1	7000797	-----
1941-42	P/6	(Carter 114-42S) used with 494S carb. on 1942.....	1	1875222	-----
1946 thru 50	P/6	(Carter 114-42S) used w/537S or 717S carb.....	1	1875222	-----
1947-48	P/8	(Carter 114-45) used w/630S carb.....	1	7000687	-----
1949 thru 53	P/8	(Carter 114-45) used w/719S and 719SA carb.....	1	7000687	-----
1953-54	P/6	(Carter 114-45).....	1	7000687	-----
1938	All	ROD , connector (Carter 115-43).....	1	1875097	-----
1939-40	All exc. 1940 29	(Carter 115-31).....	1	1875203	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 115-47) used with 548S carb. on 1947.....	1	7000798	-----
1941 thru 48	P/6	(Carter 115-41) used with 494S carb. on 1942.....	1	1875203	-----
1942	P/6	(Carter 115-43) used with 521S or 545S carb.....	1	1875097	-----
1947 thru 53	P/8	(Carter 115-130) used w/719, 720 S and SA carb.....	1	7002125	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 3.762 ARM-ROD-SPRING, CARBURETOR THROTTLE (Continued)						
1949-50	P/6	ROD , connector (Carter 115-122) used with 717S or 718S carb.	1	7001855	-----	
1953-54	P/6	(Carter 115-206)	1	7005874	-----	
1947-48	P/8	RETAINER , throttle rod anti-rattle spring (Carter 63-93) used w/630S or 653S carb.	1	7000760	-----	
1948	P/6	(Carter 63-93) used w/652S carb.	1	7000760	-----	
1949 thru 54	All	(Carter 63-93) used w/719, 720 S and SA carb.	1	7000760	-----	
1949-50, 1953-54	P/6	throttle connector rod (Carter 172-22)	1	7002140	-----	
1949 thru 53	P/8	throttle connector rod (Carter 172-22)	1	7002140	-----	
1939 thru 54	All	RETAINER SPRING , throttle connector rod (Carter 150A-10)	AR	836159	-----	(3.841)
1947 thru 53	P/8	SCREW , shaft arm (Carter 101-74) used w/630S, 719S or 720 carb.	1	1875292	-----	
1953-54	P/6	(Carter 101-74)	1	1875292	-----	
1937 thru 48	All	SPRING , throttle connector rod anti-rattle (Carter 61-128)	1	839539	-----	(3.841)
1949-50	P/8	(Carter 61-128)	1	839539	-----	(3.841)
1947 thru 53	All	WASHER , throttle shaft arm (Carter 136-38) used with 630S, 719S or 719SA carb.	1	7000754	-----	
1953-54	P/6	(Carter 136-38)	1	7000754	-----	
Group 3.766 CAM-LEVER, CARBURETOR FAST IDLE						
1937 thru 40	All exc. 1940 29	CAM (Carter 181-115S)	1	1875554	-----	
1940-41	All P/8 exc. 1940 28	(Carter 181-33S)	1	7001424	-----	
1941 thru 49	P/6	(Carter 181-115S)	1	1875554	-----	
1942 thru 47	P/8	(Carter 181-107S) used with 548S carb. on 1947	1	7001425	-----	
1947 thru 53	P/8	(Carter 181-134S)	1	7000664	-----	
1949-50	P/6	(Carter 181-155S) used with 717S or 718S carb.	1	7001859	-----	
1951-52	P/6		1	7002876	-----	
1953-54	P/6	(Carter 181-134S)	1	7000664	-----	
1947 thru 53	P/8	LEVER , cam trip (Carter 14-355)	1	7000692	-----	
1940 thru 47	All P/8 exc. 1940 28	(Carter 14-219) used with 548S carb. on 1947	1	7000621	-----	
1953-54	P/6	(Carter 14-355)	1	7000692	-----	
1940 thru 53	All P/8 exc. 1940 28	SCREW , adjusting (Carter 101-84)	1	7000646	-----	
1953-54	P/6	(Carter 101-84)	1	7000646	-----	
Group 3.767 ARM-SPRING-SCREW, CARBURETOR FAST IDLE						
1940 thru 47	All exc. 1940 28	ARM (Carter 53A-127S)	1	7000633	-----	
1948 thru 53	All P/8 H.T.	ARM & SCREW ASS'Y. , (Carter 53A-287S) used w/653S, 720S and SA carb.	1	7001471	-----	
1937 thru 50	All	SCREW , cam attaching (Carter 101-81) single carb.	1	1875053	-----	
1940 thru 47	All	(Carter 101-70)	1	1875343	-----	
1947 thru 53	P/8	(Carter 101-140)	1	7000748	-----	
1951-52	P/6		1	7003561	-----	
1953-54	P/6	(Carter 101-140)	1	7000748	-----	
1940-41	All P/8 exc. 1940 28	SPRING , arm (Carter 61-142)	1	7000718	-----	
1942 thru 47	P/8	(Carter 61-265)	1	7000792	-----	
1947 thru 53	P/8	(Carter 61-266)	1	7000668	-----	
1953-54	P/6	(Carter 61-266)	1	7000668	-----	
Group 3.768 LINK-ROD-SPRING, CARBURETOR FAST IDLE CONNECTOR						
1940 thru 47	All P/8 exc. 1940 28	LINK , connector (Carter 117-102) used with 548S carb. on 1947	1	7000799	-----	
1947 thru 53	P/8	ROD , connector (Carter 115-70)	1	7000741	-----	
1953-54	P/6	(Carter 115-205)	1	7005873	-----	
1939 thru 54	P/8	RETAINER SPRING , fast idle connector rod (Carter 150A-10)	AR	836159	-----	(3.841)
1940-41	All P/8 exc. 1940 28	SPRING , connector link (Carter 61-123)	1	1875301	-----	
1942 thru 46	P/8	(Carter 61-264)	1	7001435	-----	
Group 3.774 NOZZLE, CARBURETOR						
1940 thru 47	All P/8 exc. 1940 28	(Carter 12-265) used with 548S carb. on 1947	1	7000785	-----	
1946 thru 50	P/6	(Carter 12-286)	1	7000397	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.792 JET AND GASKET, CARBURETOR METERING ROD					
1940	28 All	(Carter 120-133S).....	1	1875422	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 120-103S) used with 548S carb. on 1947..	2	7000662	-----
1940 thru 50	P/6	(Carter 120-133S used with 494S carb. on 1942..	1	1875422	-----
1947 thru 53	P/8	(Carter 120-65S) used with 630S carb.....	2	1875369	-----
1953-54	P/6	(Carter 120-158).....	2	1338015	-----
1951-52	P/6	JET , carb. main metering—standard.....	1	7002958	-----
1951-52	P/6	2 step lean.....	1	7002956	-----
Group 3.794 SUPPORT ASSY., POWER VALVE					
1951-52	P/6	-----	1	7002843	-----
Group 3.798 JET, CARBURETOR LOW SPEED					
1939	P/6	(Carter 11-161S).....	1	1875270	-----
1939	P/8	(Carter 11-162S).....	1	1875180	-----
1940 thru 42	P/6	(Carter 11-162S) used with 494S carb. on 1942..	1	1875180	-----
1946 thru 50	P/6	(Carter 11-168S).....	1	7000389	-----
1947 thru 53	P/8	(Carter 11-183S).....	1	7001433	-----
1953-54	P/6	(Carter 11-191S).....	1	7005858	-----
Group 3.806 ROD, CARBURETOR METERING					
1940 thru 47	All P/8 exc. 1940 28	std. (Carter 75-443) used with 548S carb. on 1947	1	7001400	-----
1941-42	P/6	std. (Carter 75-472) used with 494S carb. on 1942	1	1875495	-----
1946 thru 50	P/6	std. (Carter 75-528).....	1	7000398	-----
1947-48	P/8	std. (Carter 75-594) used with 630S carb.....	2	7000740	-----
1949 thru 53	P/8	std. (Carter 75-664) used with 719, 720S and SA carb.....	2	7001867	-----
1953-54	P/6	std. (Carter 75-910).....	2	7005914	-----
1939	P/8	1 step lean (Carter 75-366).....	1	7001403	-----
1939	P/6	1 step lean (Carter 75-368).....	1	7001401	-----
1940	P/6	1 step lean (Carter 75-427).....	1	7001405	-----
1940	28 All	1 step lean (Carter 75-425).....	1	7001407	-----
1940 thru 47	All P/8 exc. 1940 28	1 step lean (Carter 75-444).....	2	7001409	-----
1941-42	P/6	1 step lean (Carter 75-521) used with 494S carb. on 1942.....	1	7001411	-----
1942	P/6	1 step lean (Carter 75-555) used with 521S or 545S carb.....	1	7001415	-----
1946 thru 50	P/6	1 step lean (Carter 75-582).....	1	7001413	-----
1947-48	P/8	1 step lean (Carter 75-604) used with 630S carb.	2	7001436	-----
1949 thru 53	P/8	1 step lean (Carter 75-683) used with 719, 720S and SA carb.....	2	7002574	-----
1953-54	P/6	1 step lean (Carter 75-945).....	2	7006205	-----
1939	P/6	2 steps lean (Carter 75-369).....	1	7001402	-----
1940	P/6	2 steps lean (Carter 75-428).....	1	7001406	-----
1940 thru 47	All P/8 exc. 1940 28	2 steps lean (Carter 75-445) used with 548S carb. on 1947.....	1	7001410	-----
1941-42	P/6	2 steps lean (Carter 75-522) used with 494S carb. on 1942.....	1	7001412	-----
1942	P/6	2 steps lean (Carter 75-556) used with 521S or 545S carb.....	1	7001416	-----
1946 thru 50	P/6	2 steps lean (Carter 75-583).....	1	7001414	-----
1947-48	P/8	2 steps lean (Carter 75-605) used with 630S carb.	2	7001437	-----
1949 thru 53	P/8	2 steps lean (Carter 75-684) used with 719S, 720S and 720SA carb.....	2	7002575	-----
1953-54	P/6	2 steps lean (Carter 75-946).....	2	7006206	-----
Group 3.807 ARM, CARBURETOR METERING ROD					
1940 thru 47	All P/8 exc. 1940 28	(Carter 111-17).....	1	7000796	-----
Group 3.810 SPRING, CARBURETOR METERING ROD					
1938	All	(Carter 61-75).....	1	837149	-----
1939	All	(Carter 61-160).....	1	1875248	-----
1940	28 All	(Carter 61-160).....	1	1875248	-----
1940 thru 42	P/6	(Carter 61-160) used with 494S carb. on 1942..	1	1875248	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 61-120).....	1	1875323	-----
1942 thru 50	P/6	(Carter 61-75) used with 521S or 545S carb. on 1942	1	837149	-----
1947 thru 53	P/8	(Carter 61-234).....	1	7000663	-----
1953-54	P/6	(Carter 61-234).....	1	7000663	-----
1939 thru 54	P/6	RETAINER SPRING , metering rod pin.....	AR	836159	-----

(3.841)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.811 DISC, CARBURETOR METERING ROD					
1947 thru 53	P/8	(Carter 129-22).....	2	7000686	-----
Group 3.814 NEEDLE AND SEAT, CARBURETOR INTAKE					
1937 thru 39	All	(Carter 25-42S).....	1	363573	-----
1940	28 All	(Carter 25-42S).....	1	363573	-----
1940 thru 42	P/6	(Carter 25-42S) used with 494S carb.....	1	363573	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 25-74S) used with 548S carb. on 1947.....	1	7000787	-----
1942 thru 50	P/6	(Carter 25-83S) used with 521S or 545S carb. on 1942.....	1	7000788	-----
1947 thru 53	P/8	(Carter 25-105S).....	1	7001473	-----
1951-52	P/6	w/gasket.....	1	7002885	-----
1953-54	P/6	(Carter 25-236).....	1	7005864	-----
1940 thru 47	All P/8 exc. 1940 28	CLIP , needle pull (Carter 61-159) used with 548S carb. on 1947.....	1	7000637	-----
1947 thru 53	P/8	(Carter 61-257).....	1	7000624	-----
1951-52	P/6	carb. float valve pull.....	1	7002849	-----
Group 3.821 RIVET PLUG, CARBURETOR IDLE PORT					
1947 thru 50	All	(Carter 11B-108).....	2	1875015	-----
1951 thru 53	P/8	(Carter 11B-108).....	2	1875015	-----
1953-54	P/6	(Carter 11B-108).....	2	1875015	-----
Group 3.822 SCREW, CARBURETOR IDLE ADJUSTING					
1937 thru 50	P/6	(Carter 30A-39).....	1	1875035	-----
1937 thru 40	P/8 exc. 1940 29	(Carter 30A-39).....	1	1875035	-----
1940 thru 53	P/8	(Carter 30A-41) w/dual carb.....	1	1875368	-----
1951-52	P/6		1	7002875	-----
1953-54	P/6	(Carter 30A-41).....	2	1875368	-----
Group 3.823 SPRING, CARBURETOR IDLE ADJUSTING SCREW					
1937 thru 50	All	(Carter 61-57).....	1-2	1875042	-----
1951 thru 53	P/8	(Carter 61-57).....	AR	1875042	-----
1951-52	P/6		1	7003190	-----
1953-54	P/6	(Carter 61-57).....	2	1875042	-----
Group 3.825 BALL—GUIDE—SPRING, CARB. PUMP DISCHARGE					
1951-52	P/6	BALL	1	7002117	-----
1951-52	P/6	GUIDE , spring.....	1	7002119	-----
1951-52	P/6	SPRING , check valve.....	1	7002118	-----
Group 3.826 BALL, CARB. PUMP CHECK					
1951-52	P/6		1	7002120	-----
Group 3.832 NEEDLE-PLUG, CARBURETOR PUMP DISCHARGE CHECK					
1947 thru 53	P/8	NEEDLE (Carter 17-66).....	1	7000700	-----
1947-48	P/8	PLUG (Carter 122-81) used with 630S carb.....	1	7001474	-----
1948	P/8 H.T.	(Carter 122-81) used with 653S carb.....	1	7001474	-----
1949 thru 53	P/8	(Carter 122-91) used with 719, 720S & SA carb.....	1	7001868	-----
1953-54	P/6	(Carter 122-96).....	1	7005877	-----
Group 3.838 PLUNGER AND ROD, CARBURETOR PUMP					
1939	All	(Carter 64-58S).....	1	7000428	-----
1940	28 All	(Carter 64-70S).....	1	1875460	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 64-47S) used with 548S carb. on 1947.....	1	1428361	-----
1940 thru 42	P/6	(Carter 64-70S) used with 494S carb. on 1942.....	1	1875460	-----
1946 thru 50	P/6	(Carter 64-58S).....	1	7000428	-----
1947-48	P/8	(Carter 64-113S) used with 630S, SA and SB carb.....	1	7000769	-----
1949 thru 53	P/8	(Carter 64-124S) used with 719, 720S and SA carb.....	1	7001865	-----
1951-52	P/6	w/spring.....	1	7002867	-----
1953-54	P/6	(Carter 64-151S).....	1	7005870	-----
1947 thru 53	P/8	GUIDE , plunger (Carter 196-15).....	1	7000691	-----
1953-54	P/6	(Carter 196-18).....	1	7005880	-----
1947 thru 53	P/8	SCREW , pump retainer (Carter 101-67).....	1	7000749	-----
1953-54	P/6	(Carter 101-67).....	1	7000749	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.841 RETAINER—SPRING—STRAINER, CARBURETOR PUMP					
1947 thru 53	P/8	PLUG , pump discharge check (Carter 122-85S).....	1	7000767	-----
1953-54	P/6	pump passage (Carter 11B-279S).....	1	7005859	-----
1947 thru 53	P/8	RETAINER , pump spring (Carter 63-92).....	1	7000640	-----
		See Group 3.762—3.768—3.810—3.843 for use.....		836159	-----
1940 thru 47	All P/8 exc. 1940 28	RETAINER SPRING , operating lever (Carter 150A-14).....	1	1875293	-----
1937 thru 39	All	SPRING , pump (Carter 61-63).....	1	836682	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 61-171) used with 548S carb. on 1947.....	1	1875351	-----
1941 thru 50	P/6	(Carter 61-245) used with 494S carb. on 1942.....	1	1875482	-----
1947 thru 53	P/8	(Carter 61-365).....	1	7000768	-----
1947 thru 53	P/8	(Carter 61-329).....	1	7001434	-----
1953-54	P/6	(Carter 61-389).....	1	7005868	-----
1951-52	P/6	pump return.....	1	7002101	-----
1947 thru 50	P/8	pump plunger (61-338).....	1	7000638	-----
		See Group 3.762 for use.....		839539	-----
1939	All	STRAINER , pump (Carter 30-35).....	1	1875253	-----
1940 thru 47	All P/8 exc. 1940 28	(Carter 30-34) used with 548S carb. on 1947.....	1	1875394	-----
1946 thru 50	P/6	(Carter 30-35).....	1	1875253	-----
1947 thru 53	P/8	(Carter 30-42).....	1	7000752	-----
1951-52	P/6	SCREEN , pump inlet.....	1	7002866	-----
Group 3.842 LEVER AND COUNTERSHAFT, CARBURETOR PUMP OPERATING					
1940 thru 47	All P/8 exc. 1940 28	(Carter 53A-129S) used with 548S carb. on 1947..	1	7000791	-----
1946 thru 50	P/6	(Carter 53A-166S).....	1	1875190	-----
1947 thru 53	P/8	(Carter 53A-284S).....	1	7000652	-----
1953-54	P/6	(Carter 53A-363S).....	1	7005865	-----
1940 thru 47	All P/8 exc. 1940 28	RETAINER SPRING , operating lever (Carter 150A-14).....	1	1875293	-----
Group 3.843 LINK, CARBURETOR PUMP CONNECTOR					
1937-38	All	(Carter 117-28).....	1	1875060	-----
1939	All	(Carter 117-58).....	1	1875224	-----
1940	All exc. 29	(Carter 117-58).....	1	1875224	-----
1940	29 All	(Carter 117-28).....	1	1875060	-----
1941 thru 50	P/6	(Carter 117-58) used with 494S carb. on 1942.....	1	1875224	-----
1941 thru 53	P/8	(Carter 117-28) used with 521S or 545S carb. on 1942 and 630S carb. on 1947 thru 50.....	1	1875060	-----
1951-52	P/6		1	7002878	-----
1953-54	P/6	(Carter 117-159).....	1	7005875	-----
1939 thru 54	All	RETAINER SPRING , pump connector link (Carter 150A-10).....	AR	836159	-----
1953-54	P/6	WASHER , pump connector link (Carter 136-173).....	2	7005878	-----
Group 3.844 JET, CARBURETOR PUMP					
1940	29 All	(Carter 48-63).....	1	1427376	-----
1941-42	P/6	(Carter 48-99) used with 494S carb. on 1942.....	1	1875494	-----
1941 thru 47	P/8	(Carter 48-63) used with 548S carb. on 1947.....	1	1427376	-----
1942 thru 50	P/6	(Carter 48-72) used with 521S or 545S carb. on 1942.....	1	1875243	-----
1947 thru 53	P/8	(Carter 48-143S).....	1	7000647	-----
1947 thru 53	P/8	PLUG ASSY. , pump relief valve (Carter 122-75S).....	1	7000658	-----
1947 thru 53	P/8	SCREW AND WASHER , pump jet housing (Carter 101-155S).....	2	7000747	-----
1953-54	P/6	(Carter 101-155S).....	2	7000747	-----
Group 3.845 ARM AND COLLAR, CARBURETOR PUMP					
1940 thru 47	All P/8 exc. 1940-28	(Carter 53A-249S) used with 548S carb. on 1947...	1	7000790	-----
1947 thru 53	P/8	(Carter 111-45S).....	1	7000655	-----
1953-54	P/6	(Carter 111-62S).....	1	7005872	-----
1940	28 All	SPRING , pump operating lever (Carter 61-211).....	1	1875418	-----
1940	29 All	(Carter 61-169).....	1	1428353	-----
1940 thru 42	P/6	(Carter 61-211).....	1	1875418	-----
1941 thru 47	P/8	(Carter 61-169) used with 548S carb. on 1947.....	1	1428353	-----
1953-54	P/6	(Carter 61-494).....	1	7005869	-----

(3.841)

(3.841)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 3.852 CAP—PLUG—SPRING, CARBURETOR ANTI-PERCOLATOR					
1939	All	CAP AND ROCKER ARM (Carter 184-18S).....	1	1875234	-----
1940	All exc. 29	(Carter 184-18S).....	1	1875234	-----
1942 thru 50	P/6	(Carter 184-18S) used with 494S carb. on 1942....	1	1875234	-----
1940 thru 47	All P/8 exc.	PLUG ASSEMBLY , anti-percolator valve (Carter 49A-18S) used with 548S carb. on 1947.....	2	7000630	-----
1939	All	SPRING , rocker arm (Carter 61-188).....	1	1875251	-----
1940	28 All	(Carter 61-188).....	1	1875251	-----
1940 thru 50	P/6	(Carter 61-188) used with 494S carb. on 1942....	1	1875251	-----
Group 3.858 PISTON ASSEMBLY, CARBURETOR VAC					
1942	P/6	(Carter 160-43S) used with 521S or 545S carb.	1	1875148	-----
1946	P/6	PISTON AND PIN (Carter 160-67S).....	1	1875448	-----
1947 thru 50	All	-----	1	1875448	-----
1951 thru 53	P/8	-----	1	1875448	-----
1953-54	P/6	(Carter 160-67S).....	1	1875448	-----
1951-52	P/6	PISTON , carb. power valve actuating.....	1	7002929	-----
1947 thru 53	P/8	LINK , piston (Carter 117-83).....	1	7000660	-----
1953-54	P/6	(Carter 117-83).....	1	7000660	-----
Group 3.859 SPRING, CARBURETOR VACUUM PISTON					
1942 thru 50	P/6	(Carter 61-178) used with 521S carb. on 1942....	1	1875556	-----
1947 thru 53	P/8	(Carter 61-259).....	1	7000751	-----
1953-54	P/6	(Carter 61-377).....	1	7005866	-----
1951-52	P/6	SPRING , carb. power valve actuating piston.....	1	7002896	-----
1946 thru 50	P/6	LINK AND SPRING (Carter 117-665).....	1	1875200	-----
Group 3.862 BALL, CARBURETOR INTAKE CHECK					
1939 thru 48	All	steel (Carter 116-13).....	2	1875237	-----
1949-50	P/6	steel (Carter 116-13).....	2	1875237	-----
Group 3.900 FUEL PUMP PACKAGE					
1937-38	All	(A.C. 430).....	1	1523430	-----
1939 thru 48	All P/6 and 1939-40 28	(A.C. 496).....	1	1523496	-----
1939 thru 48	All P/6 and 1939-40 28	PUMP ASSY., PKG. , fuel and vacuum (A.C. 515).....	1	1523515	-----
1940	29 All	(A.C. 516).....	1	1523516	-----
1941 thru 50	P/8	(type 539).....	1	1523539	-----
1949-50	P/6	(type 539).....	1	1523539	-----
1951 thru 54	P/8	(type 9640).....	1	5592184	-----
1951-52	P/6	(type 9640).....	1	5592184	-----
1953-54	P/6	(type 9630).....	1	5592657	-----
Group 3.901 REPAIR KIT, FUEL AND VACUUM PUMP					
1939 thru 51	All	w/type 539 pump.....	1	1539000	-----
1941 thru 52	All	w/type 9640 pump.....	1	5592725	-----
1953-54	All	-----	1	5592725	-----
Group 3.903 BOWL, FUEL PUMP					
1941 thru 52	All	w/type 9640 pump.....	1	5590159	-----
1953-54	All	-----	1	5590159	-----
Group 3.904 GASKET, FUEL PUMP BOWL					
1937 thru 51	All	w/type 539 pump.....	1	5590040	-----
1941 thru 52	All	w/type 9640 pump.....	1	5590039	-----
1953-54	All	-----	1	5590039	-----
Group 3.906 BAIL ASSY., FUEL PUMP BOWL					
1941 thru 52	All	w/type 9640 pump.....	1	5590153	-----
1953-54	All	-----	1	5590153	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 3.908 CONNECTIONS, FUEL PUMP LINE						
NOTE: See Group 3.201 for fuel pump to carburetor line.						
1935 thru 38	All	elbow, pump inlet to hose.....($\frac{5}{16}$ "	1	114920	-----	(8.963)
1939 thru 50	All	elbow, pump inlet to hose (45°).....($\frac{5}{16}$ "	1	502733	-----	
1946 thru 54	All	elbow, pump to manifold (90°).....($\frac{1}{4}$ "	1	169983	-----	(8.963)
1951 thru 54	All	elbow, pump inlet to hose (45°).....($\frac{5}{16}$ "	1	116341	-----	(8.963)
1935 thru 54	All	nipple, pump outlet.....($\frac{5}{16}$ "	1	114919	-----	(8.963)
1935 thru 50	All	nut, pump inlet.....($\frac{5}{16}$ "	1	114964	-----	(8.963)
1935 thru 54	All	nut, pump outlet.....($\frac{5}{16}$ "	1	114964	-----	(8.963)
1939 thru 54	All	nut, pump to manifold.....($\frac{1}{4}$ "	2	114963	-----	(8.963)
1946 thru 54	All	connector.....($\frac{1}{4}$ "	AR	148330	-----	(8.963)
1941 thru 54	All	nut, pump to w/s wiper pipe.....	1	114963	-----	(8.963)
1937 thru 54	All	TUBING , pump to manifold.....($\frac{1}{4}$ "x25' coil)	AR	364934	-----	(8.964)
Group 3.925 DIAPHRAGM KIT, FUEL AND VACUUM PUMP						
1937 thru 51	All	(A.C. D-18).....Fuel side	1	1538510	-----	
1937 thru 51	All	(A.C. D-28).....Vacuum side	1	1538637	-----	
1941 thru 52	All	(A.C. D-120) w/type 9640 pump.....Fuel side	1	5592780	-----	
1953-54	All	Fuel side	1	5592780	-----	
1941 thru 52	All	(A.C. D-98) w/type 9640 pump.....Vacuum side	1	5592387	-----	
1953-54	All	(A.C. D-98).....Vacuum side	1	5592387	-----	
1937 thru 54	All	OIL SEAL & GASKET PKG. , fuel pump.....	1	5591805	-----	
Group 3.932 GASKET, FUEL PUMP						
1935-36	All	to block.....	1	497652	-----	
1937 thru 54	All	to block.....	1	412270	-----	
Group 3.936 BOLT, FUEL PUMP MOUNTING						
1937 thru 54	All	(Hex. $\frac{3}{8}$ "-16x1 $\frac{1}{2}$ ")	2	180126	-----	(8.900)
1940	29 All	adapter to block.....(Hex. $\frac{3}{8}$ "-16x1 $\frac{3}{4}$ ")	1	180128	-----	(8.900)
1940	29 All	adapter to block.....(Hex. $\frac{3}{8}$ "-16x3")	AR	180138	-----	(8.900)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.003 TRANSMISSION ASSEMBLY					
1940 thru 48	All L.H.D., S.T.	use 1314655 main drive gear Group 4.351 with this trans. for 1940 thru 42	1	1332890	-----
1949 thru 54	All L.H.D., S.T.	1950 speedometer driven gear—Group 4.337 must be used on 1949 jobs	1	1341223	-----
1948-49	All H.T.	TRANSMISSION PKG. , consists of trans., throttle control lever, shield, spacer and bolt	1	514073	-----
1950	P/6 H.T.	-----	1	514073	-----
1951	P/6 L.H.D., H.T.	-----	1	514341	-----
1951	P/8 L.H.D., H.T.	-----	1	514342	-----
1952	All H.T.	-----	1	516598	-----
1953	All H.T.	-----	1	517287	-----
1948-49	All H.T.	NAME PLATE , transmission	1	8609324	-----
1950-51	P/6	black	1	8609324	-----
1950-51	P/8	green	1	8611896	-----
1952 thru 54	All H.T.	green	1	8611896	-----
1948 thru 54	All H.T.	SCREW , transmission name plate (Rd. Hd. No. 2-7x $\frac{3}{16}$ ")	2	145368	(8.977)
NOTE: 1935 Type A transmission used on P/8 to Eng. 8-27162, P/6 to Eng. 6-46474 inclusive. Type B transmission used after the above engine numbers on 1935 and all subsequent models.					
NOTE: There are three types of Hydramatic Transmissions used in 1950 production. For identification purposes the P9 Transmission has a name plate attached having a black background, and is stamped P9 preceding the serial number. This transmission is also used on 1948-49 models.					
The P50-P51 Transmission has a name plate attached having a black background, and is stamped P50 or P51 preceding the serial number.					
The D50-D51 transmission has a name plate attached having a light green background, and is stamped D50 or D51 preceding the serial number.					
Group 4.005 GASKET, TRANSMISSION TO CLUTCH HOUSING					
1937-38	All	-----	1	500230	-----
1939 thru 54	All S.T.	-----	1	411714	-----
1939 thru 54	All S.T.	GASKET SET , transmission	1	1393205	-----
Group 4.006 LEVER ASSEMBLY, TRANSMISSION GEAR SHIFT					
1939 thru 52	All S.T.	painted	1	502489	-----
1950-51	2537 "SD" S.T.	chrome	1	513973	-----
1953-54	All S.T.	chrome	1	516917	(4.035)
1953-54	All S.T.	painted	1	516500	-----
NOTE: See group 4.035 for H. T. gearshift lever.					
Group 4.008 WASHER, GEAR SHIFT LEVER KNOB					
1939 thru 52	All S.T.	-----	1	502487	-----
Group 4.009 KNOB, TRANSMISSION GEAR SHIFT LEVER					
1926 thru 38	All std. shift	-----	1	374993	-----
1938	All steer. col. shift	-----	1	501283	-----
1939 thru 48	All S.T.	-----	1	507167	-----
1949 thru 52	All S.T.	black	1	512921	-----
1950	2537 "SD" S.T.	sierra rust	1	513977	-----
1953-54	2537 "SD" S.T.	palm green	1	516913	(4.035)
1953-54	2837 "SD" S.T.	black	1	515190	-----
NOTE: See group 4.035 for H. T. gearshift lever knobs.					
Group 4.015 CAP, GEAR SHIFT LEVER					
1932-1935 thru 38	All std. shift Type B	(see Note Group 4.003)	1	553577	-----
Group 4.015 COVER, GEAR SHIFT CONTROL UPPER LEVER					
1948	All H.T.	rubber	1	510974	-----
1949-50	All H.T.	gray	1	511730	-----
1949 thru 51	All H.T.	beige	1	513265	-----
1950	2537 "SD" H.T.	ivory	1	513974	-----
1951	All H.T.	gray	1	514841	-----
1951	2537 "SD" H.T.	ivory	1	516281	-----
1952	All H.T.	gray	1	516473	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.015 COVER, GEAR SHIFT CONTROL UPPER LEVER (Continued)					
1952	2537 "SD" H.T.	green.....	1	516474	-----
1953-54	All	black.....	1	515126	-----
1953	All	blue.....	1	517180	-----
1953	All	spruce green.....	1	517181	-----
1953	All	palm green.....	1	517182	-----
1954	All	blue.....	1	517970	-----
1954	All	green.....	1	517971	-----
1954	All	beige.....	1	517972	-----
1954	All	yellow.....	1	517973	-----
1954	All	coral red.....	1	517974	-----
Group 4.016 SHAFT ASSEMBLY, STEERING COLUMN SHIFT					
1939-40	25-26 All	-----	1	502500	-----
1940 thru 52	All exc.	-----	1	504052	-----
1953-54	1940-25-26 S.T.	PIN, gearshift tube yoke.....	1	515140	-----
1953-54	All	TUBE ASSY., steering column gearshift.....	1	517352	-----
1953-54	All L.H.D. S.T.	RETAINER, gearshift tube yoke pin.....	1	148146	(8.934)
1953-54	All	See Group 4.017 for use.....		3655726	-----
Group 4.017 GEARSHIFT CONTROL SHAFT PARTS					
1939 thru 52	All L.H.D. S.T.	CLIP, gearshift shaft return spring.....	1	502483	-----
1938	All steer. col. shift	PLUG, gearshift shaft end, felt..... Upper	1	501288	-----
1953-54	All S.S.	RETAINER, steering column lower seal.....	1	515129	-----
1953-54	All P.S.	-----	1	517345	-----
1953-54	All	SEAL, steering column..... Upper	2	515141	-----
1953-54	All S.S.	----- (2 1/4" O.D.) Lower	1	515128	-----
1953-54	All P.S.	----- (2 1/8" O.D.) Lower	1	517419	-----
1939	All	SPRING, gearshift shaft return.....	1	502502	-----
1940 thru 52	All L.H.D. S.T.	-----	1	504241	-----
1953-54	All H.T.	gearshift tube return.....	1	516401	-----
1953-54	All S.T.	gearshift tube return.....	1	516387	-----
Group 4.017 GEAR SHIFT CONTROL SHAFT ANTI-RATTLE PARTS					
1939 thru 52	All S.T.	CUP, gearshift shaft anti-rattle spring.....	1	502484	-----
1938	All	SPRING, steer. column shift shaft, anti-rattle, flat.....	1	501305	-----
1939 thru 42	All	anti-rattle, flat..... Lower	1	502506	-----
1939 thru 52	All	anti-rattle, coil..... Upper	1	3655726	(4.016)
1948 thru 52	All H.T.	anti-rattle—flat..... at lower bracket	1	413320	-----
1941	26-29	control rod idler lever—anti-rattle, 2-piece shift control only on L.H.D.....	1	505762	-----
Group 4.018 SUPPORT, GEAR SHIFT CONTROL					
1939 thru 48	All S.T.	----- Upper	1	502509	-----
1939	All	----- Lower	1	502511	-----
1940 thru 48	All L.H.D., S.T.	----- Lower	1	508660	-----
1949 thru 52	All S.T.	----- Upper	1	511333	-----
1949 thru 52	All L.H.D., S.T.	----- Lower	1	511334	-----
1939 thru 52	All S.T.	BEARING, gearshift upper support.....	1	502501	-----
1946 thru 52	All S.T.	BUSHING, gearshift control lower support.....	1	508661	-----
1939 thru 48	All S.T.	CAP, gearshift control lower support.....	1	507453	-----
1953-54	All H.T.	PLATE, steering column gearshift interlock.....	1	516400	-----
1953-54	All	SUPPORT, gearshift lever bearing.....	1	515131	-----
1939 thru 48	All S.T.	SUPPORT AND BEARING PKG., gearshift..... Upper	1	510328	-----
1949 thru 52	All L.H.D., S.T.	-----	1	513407	-----
1939 thru 47	All S.T.	SCREW, gearshift cap..... (Hex. 1/4"-28x1 1/4")	2	123737	(8.900)
1938 thru 40	All steer. col. shift	SCREW, gearshift control support..... Upper (Fil. Hd. 1/4"-20x7/8")	1	132268	(8.907)
1939 thru 48	All S.T.	----- Lower (Hex. 1/4"-20x1 3/4")	2	180042	(8.900)
1939 thru 52	All S.T.	----- Upper (Cl. Hd. 1/4"-28x1 1/16")	2	513234	-----
1953-54	All	gearshift lever bearing support.....	4	516235	-----
1953-54	All	WASHER, gearshift lever bearing support—special..	4	516250	-----
Group 4.018 BRACKET, GEARSHIFT CONTROL SHAFT					
1948	25 H.T.	BRACKET, lower control lever.....	1	510901	-----
1948	26 H.T.	-----	1	510904	-----
1953-54	All L.H.D., S.T.	gearshift selector lever support.....	1	516375	-----
1948	All H.T.	"U" BOLT, lower bracket.....	1	413319	-----
1949 thru 52	All	-----	1	511410	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.019		ROD ASSY., GEARSHIFT CONTROL SHAFT			
1938	All steer. col. shift	-----	1	501512	-----
1939-40	28 L.H.D.	red end.....	1	502498	-----
1939-40	26 L.H.D.	yellow end.....	1	502497	-----
1940	25 L.H.D.	green end.....	1	504131	-----
1940	29 All	blue end.....	1	504132	-----
1941 thru 48	25-27	-----	1	505803	-----
	L.H.D., S.T.	-----			
1941	26-29 L.H.D.	two rod control.....Front	1	505804	-----
1941	26-29 L.H.D.	two rod control.....Rear	1	505805	-----
1941 thru 48	26-29	with one piece control rod.....	1	506712	-----
	L.H.D., S.T.	-----			
1948	25 H.T.	-----Front	1	510929	-----
1948	25 H.T.	-----Rear	1	510916	-----
1948	26 H.T.	-----Front	1	510933	-----
1948	26 H.T.	-----Rear	1	510917	-----
1949 thru 52	All L.H.D., S.T.	-----	1	514142	-----
1949 thru 51	All H.T.	-----	1	511420	-----
1952	All H.T.	-----	1	515971	-----
1953	All H.T.	-----	1	515528	-----
1953	All L.H.D., S.T.	-----	1	517347	-----
1954	All S.T.	-----	1	518341	-----
1954	All H.T.	-----	1	518343	-----
1941	26-29 with 2-rod control on L.H.D.	BRACKET , gearshift control rod idler lever.....	1	505396	-----
1953-54	All L.H.D., S.T.	CLEVIS ASSY. , gearshift control rod.....	1	517326	-----
1939 thru 52	All S.T.	INSULATOR PACKAGE , gearshift control.....	1	510327	-----
1939 thru 52	All S.T.	INSULATOR , gearshift control rod.....	2	502488	-----
1953-54	All	gearshift control rod.....	1	515156	-----
1948 thru 54	All H.T.	NUT , gearshift control rod trunnion ret.....	2	124925	(8.916)
1953-54	All S.T.	gearshift control and selector rod trunnion ret.....	2	124925	-----
1941	26-29 with 2-rod control on L.H.D.	PIN , control rod idler lever pivot.....	1	505816	-----
1953-54	All S.T.	gearshift control rod clevis.....	1	517344	-----
1938	All steer. col. shift	PLUG , gearshift control rod end.....	2	501289	-----
1938	All steer. col. shift	SEAT , gearshift control rod ball.....	2	501300	-----
1938	All steer. col. shift	SPRING , gearshift control rod ball seat.....	2	501306	-----
1948 thru 52	All H.T.	TRUNNION , gearshift control front rod.....	1	510934	-----
1948	All H.T.	neutralizer rod to starter lever.....	1	510940	-----
1953-54	All H.T.	gearshift control rod.....	1	515155	-----
1953-54	All S.T.	gearshift selector rod.....	1	515162	-----
1939 thru 52	All S.T.	WASHER , control rod insulator fabric.....	2	502499	-----
1939 thru 54	All S.T.	control rod anti-rattle spring.....	1-2	501253	-----
1948	All H.T.	starter to gearshift neutralizer idler lever to bracket —spring.....($\frac{33}{64}$ "x $\frac{3}{4}$ "x.007")	1	413329	(8.928)
Group 4.020		CABLE ASSEMBLY, SHIFT SELECTOR CONTROL			
1938	All steer. col. shift L.H.D.	-----	1	501280	-----
1939	All L.H.D.	-----	1	502481	-----
1940	25 L.H.D.	ROD ASSEMBLY , shift selector control, green end.....	1	504133	-----
1940	26 L.H.D.	yellow end.....	1	504134	-----
1940	28 All	red end.....	1	504135	-----
1940	29 All	blue end.....	1	504136	-----
1941	25 L.H.D.	-----	1	505605	-----
1941	26-29 L.H.D.	-----	1	505606	-----
1942 thru 48	25	-----	1	507143	-----
	L.H.D., S.T.	-----			
1942 thru 48	26	-----	1	507144	-----
	L.H.D., S.T.	-----			
1949 thru 52	All L.H.D., S.T.	-----	1	511332	-----
1953	All L.H.D., S.T.	-----	1	517350	-----
1954	All S.T.	-----	1	518345	-----
1940 thru 54	All S.T.	INSULATOR , gearshift selector rod.....	1	503873	-----
1938-39	All	SPRING , selector cable anti-rattle.....	1	499997	(3.459)
Group 4.021		ROD—CABLE PARTS, GEARSHIFT SELECTOR			
1938	All steer. col. shift	PLUNGER , shift selector rod end.....	1	501291	-----
1938	All steer. col. shift	NUT , selector cable coupling.....	1	845086	-----
1938	All steer. col. shift	selector rod end plunger.....	1	413298	-----
1940 thru 52	All S.T.	COLLAR , gearshift control shaft, lower.....	1	503871	-----
1940 thru 48	All	BOLT , shaft collar.....(Hex. $\frac{3}{8}$ "-24x1 $\frac{3}{4}$ ")	1	181646	(8.900)
1940 thru 52	All S.T.	LOCKWASHER , shaft collar.....(Ext. tooth $\frac{3}{8}$ ")	1	502482	(4.046)
Group 4.022		SUPPORT ASSY., GEARSHIFT LEVER			
1953-54	All S.T.	-----	1	515142	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.025		CUP, GEARSHIFT LEVER FULCRUM SPRING			
1932, 1935 thru 38	All std. shift, Type B 1935	(see Note Group 4.003).....	2	553423	-----
1938	All steer. col. shift	PIN , gearshift lever pivot..... (7/16" O.D.)	1	3651741	-----
1939 thru 52	All S.T.	-----	2	502495	-----
Group 4.026		SPRING, GEARSHIFT LEVER			
1932, 1935 thru 38	All std. shift Type B	in fulcrum cup (see Note Group 4.003).....	2	553424	-----
1932, 1935 thru 38	All std. shift Type B	one coil tension (see Note Group 4.003).....	2	553458	-----
1932, 1935-36	All Type B	with cup at lower end of lever (see Note Group 4.003)	1	553573	-----
1937-38	All with std. shift	with cup at lower end of lever.....	1	1297402	-----
1938	All with steer. col. shift	fulcrum cup pivot pin.....	1	501302	-----
1938	All with steer. col. shift	selector control rod anti-rattle.....	1	501597	-----
1939 thru 52	All S.T.	fulcrum cup pivot pin.....	2	502505	-----
1948 thru 52	All H.T.	SPRING , gearshift control upper lever pin retainer...	1	413301	-----
1939 thru 54	All S.T.	SHIM , gearshift control lever.....	AR	501301	-----
1939 thru 52	All S.T.	WASHER , gearshift lever anti-rattle.....	1	501315	-----
Group 4.028		SPACER, GEARSHIFT LEVER FULCRUM			
1932, 1935-36	All Type B	(see Note Group 4.003).....	2	553457	-----
1937-38	All with std. shift	-----	2	1295400	-----
Group 4.035		LEVER, GEARSHIFT CONTROL UPPER			
1948 thru 51	All H.T.	-----	1	413928	-----
1952	All H.T.	-----	1	516665	-----
1953-54	All H.T.	-----	1	516917	-----
1948 thru 52	All H.T.	KNOB —black.....	1	511986	-----
1950	2537 "SD" H.T.	rust.....	1	513976	-----
1953-54	All H.T.	black.....	1	516913	-----
Group 4.036		GEARSHIFT CONTROL UPPER LEVER PARTS			
1953-54	All H.T.	PAD , gearshift lever friction.....	1	517061	-----
1948 thru 52	All H.T.	PIN , gear shift control upper lever pivot..... (5/16"x15/16")	1	141222	----- (8.939)
1953-54	All	gearshift lever fulcrum.....	1	515148	-----
1948 thru 52	All H.T.	SPRING	1	413431	-----
1953-54	All	gearshift lever anti-rattle.....	1	515147	-----
1953-54	All H.T.	gearshift lever friction pad.....	1	517062	-----
1948 thru 52	All H.T.	RETAINER , spring.....	1	413432	-----
1953-54	All	RING , gearshift lever fulcrum pin—retaining.....	1	515149	-----
1948 thru 52	All H.T.	WASHER , gearshift indicator link—spring.....	1	410218	----- (8.928)
1948 thru 52	All H.T.	gearshift control upper lever—anti-rattle.....	1	413344	----- (8.928)
Group 4.038		BRACKET, GEARSHIFT CONTROL SHAFT UPPER			
1948	All H.T.	-----	1	417548	-----
1949 thru 51	All H.T.	-----	1	511408	-----
1952	All H.T.	-----	1	516664	-----
1948	All H.T.	PLATE , upper bracket cover.....	1	417549	-----
1949 thru 52	All H.T.	-----	1	511421	-----
1948	All H.T.	BOLT , upper bracket..... (Fl. Hd. 1/4"-20x5/8")	1	132259	----- (8.907)
1953	All H.T.	SUPPORT ASSY. , gearshift lever.....	1	515516	-----
1954	All H.T.	-----	1	518275	-----
Group 4.038		COVER AND LENS, GEARSHIFT UPPER CONTROL INDICATOR			
1948 thru 51	All H.T.	-----	1	418521	-----
1952	All H.T.	-----	1	515983	-----
1948 thru 51	All H.T.	LENS , (N).....	1	415453	-----
1948 thru 51	All H.T.	(DR).....	1	418524	-----
1948 thru 51	All H.T.	(LO).....	1	415455	-----
1948 thru 51	All H.T.	(R).....	1	415456	-----
1952	All H.T.	one piece.....	1	515984	-----
1953-54	All H.T.	-----	1	515515	-----
1948 thru 51	All H.T.	RETAINER , lens.....	1	419231	-----
1952	All H.T.	-----	1	515967	-----
1953-54	All H.T.	-----	1	516919	-----
1952	All H.T.	SCREEN , lens.....	1	516191	-----
1953-54	All H.T.	-----	1	515521	-----
1948 thru 51	All H.T.	DISC , lens.....	1	418527	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.038 INDICATOR ASSEMBLY, GEARSHIFT CONTROL					
1948	All H.T.	-----	1	417584	-----
1949 thru 52	All H.T.	-----	1	511412	-----
1953-54	All H.T.	GASKET , indicator lamp housing	1	515518	-----
1953-54	All H.T.	HOUSING ASSY. , indicator lamp	1	516915	-----
1948	All H.T.	INDICATOR AND LAMP ASSEMBLY	1	511517	-----
1949 thru 52	All H.T.	-----	1	515776	-----
1948 thru 52	All H.T.	CONTACT AND WIRE ASSY. , indicator light	1	5291664	-----
1953	All H.T.	-----	1	5293783	-----
1954	All H.T.	-----	1	2960560	-----
1949 thru 52	All H.T.	FELT , indicator hold down	1	512494	-----
1948 thru 52	All H.T.	SHIELD , gearshift indicator lamp	1	514153	-----
1948 thru 52	All H.T.	SHIELD AND LAMP ASSEMBLY , gearshift indicator	1	514152	-----
Group 4.039 SHAFT AND HOUSING ASSEMBLY, GEARSHIFT CONTROL					
1948 thru 52	All H.T.	-----	1	5664347	-----
1953-54	All H.T.	TUBE ASSY. , steering column gearshift	1	517353	-----
Group 4.039 SHAFT PARTS, GEARSHIFT CONTROL LEVER					
1948	All H.T.	BLOCK , gearshift indicator link	1	418529	-----
1949 thru 52	All H.T.	-----	1	511406	-----
1948	All H.T.	BRACKET , gear shift control shaft lower	1	413430	-----
1949 thru 52	All H.T.	-----	1	511409	-----
1948 thru 52	All H.T.	SEAL , gearshift control shaft, lower	1	411325	(4.043)
1948 thru 52	All H.T.	SPRING , gearshift control shaft to lower bracket anti-rattle	1	413320	(4.017)
1948 thru 52	All H.T.	WASHER , gearshift control shaft, lower—brass	2	411649	(4.043)
Group 4.040 ROD ASSEMBLY, TRANSMISSION THROTTLE					
1948-49	P/6 H.T.	----- Front	1	510861	-----
1948-49	P/8 H.T.	----- Front	1	510862	-----
1950 thru 54	All H.T.	----- Front	1	513955	-----
1948	All H.T.	----- Rear	1	510866	-----
1949 thru 54	All H.T.	----- Rear	1	511448	-----
1949 thru 52	All H.T.	ROD , trans. neutralizer switch	1	512522	-----
1953-54	All H.T.	-----	1	515504	-----
1948-49	All H.T.	BALL JOINT , transmission throttle front rod (1/4")	1	511067	-----
1948	All H.T.	CLEVIS , rear rod (3/4")	1	116383	(8.946)
1948	All H.T.	PIN , clevis	1	510867	-----
1949 thru 54	All H.T.	TRUNNION , trans. throttle rear rod	1	512397	-----
1949 thru 54	All H.T.	WASHER , trans. neutralizer switch rod	2	510851	(3.430)
Group 4.040 ROD PARTS, GEARSHIFT CONTROL REAR					
1948	All H.T.	CLEVIS , rod	1	411368	-----
1948-49	All H.T.	NUT , gearshift control rod clevis ret.	1	124925	(8.916)
1948	All H.T.	PIN , clevis	1	408162	-----
1948 thru 54	All H.T.	WASHER , rear rod to transmission lever—spring type	2	402547	(8.928)
Group 4.040 LEVER, GEARSHIFT LOWER CONTROL RELAY					
1948	All H.T.	-----	1	510910	-----
Group 4.041 LEVER, GEARSHIFT LOWER CONTROL					
1939 thru 48	All exc. 1940 25-29 L.H.D., S.T.	-----	1	502493	-----
1940	25-29 L.H.D.	-----	1	504050	-----
1948	All H.T.	-----	1	510908	-----
1949 thru 51	All H.T.	-----	1	511416	-----
1949 thru 52	All L.H.D., S.T.	-----	1	511326	-----
1952	All H.T.	-----	1	515968	-----
1953-54	All H.T.	-----	1	517383	-----
1953-54	All L.H.D., S.T.	-----	1	516383	-----
1939-40	All L.H.D.	LEVER , gearshift control idler	1	502494	-----
1941	26-29 L.H.D.	w/2 rod control	1	502494	-----
1941	26-29 L.H.D.	at pedal plate—w/2 rod control	1	505811	-----
1941	26-29 L.H.D.	w/1 rod control	1	505760	-----
1941 thru 48	All L.H.D., S.T.	-----	1	505760	-----
1949 thru 52	All L.H.D., S.T.	-----	1	511327	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.041 LEVER, GEARSHIFT LOWER CONTROL (Continued)					
1948	All H.T.	LEVER, starter to gearshift neutralizer idler.....	1	510912	-----
1948 thru 52	All H.T.	KEY, lower lever.....	1	419675	-----
1948 thru 52	All H.T.	PLATE, bolt lock.....	1	414666	-----
1948	25 H.T.	ROD, starter to gearshift neutralizer.....	1	510920	-----
1948	26 H.T.		1	510921	-----
Group 4.042 BUSHING, GEARSHIFT CONTROL SHAFT LOWER LEVER					
1948 thru 52	All H.T.		1	411975	-----
Group 4.043 SEAL, TRANSMISSION GEARSHIFT SELECTOR CABLE					
1939	All	steering gear end.....	1	502719	-----
Group 4.043 SEAL—WASHER, GEARSHIFT CONTROL SHAFT LOWER					
1948 thru 52	All H.T.	SEAL.....	1	411325	-----
1948 thru 52	All H.T.	WASHER.....	2	411649	-----
Group 4.045 LEVER, GEARSHIFT SELECTOR CONTROL					
1940 thru 48	All L.H.D., S.T.		1	503876	-----
1949 thru 52	All L.H.D., S.T.		1	511328	-----
1953	All L.H.D., S.T.		1	516377	-----
1954	All L.H.D., S.T.		1	518413	-----
1940 thru 48	All L.H.D., S.T.	LEVER, gearshift selector idler.....	1	503877	-----
1949 thru 52	All L.H.D., S.T.		1	511329	-----
1940 thru 48	All L.H.D., S.T.	PIN, gearshift selector lever pivot.....	1	503878	-----
1949 thru 52	All L.H.D., S.T.		1	511330	-----
1953-54	All L.H.D., S.T.		1	516385	-----
1940 thru 54	All S.T.	SPRING, pivot pin retainer..... (1/4" dia. shaft)	1	148148	----- (8.934)
Group 4.046 LEVER, TRANSMISSION SHIFTER					
1938	All steer. col. shift	 Outer	1	501328	-----
	L.H.D.				
1939	All L.H.D.		1	502490	-----
1940	All L.H.D.		1	503874	-----
1941 thru 54	25 L.H.D., S.T.		1	505808	-----
1941	26-29 L.H.D.	w/2 rod control.....	1	505809	-----
1941 thru 48	26-29 L.H.D., S.T.	w/1 rod control on 1941 model.....	1	506713	-----
	L.H.D., S.T.				
1953-54	All S.T.	RETAINER, transmission shifter lever.....	1	515512	-----
1940 thru 52	All S.T.	BOLT, transmission shifter, lever to transmission..... (Hex. 3/8"-24x1 1/2")	1	503875	-----
		 (3/8"-24x3/8")	1	181629	----- (8.900)
1953-54	All S.T.	WASHER, transmission shifter lever to transmission..... (3/8" heavy)	1	502482	-----
1939 thru 52	All S.T.		1	131099	----- (8.931)
1953-54	All S.T.				
Group 4.047 SPRING, TRANSMISSION SHIFT LEVER					
1939	All L.H.D.		1	503442	-----
1940 thru 54	All S.T.		1	504224	-----
1939	All L.H.D.	EXTENSION, transmission shift lever spring.....	1	502485	-----
1940 thru 54	All L.H.D., S.T.		1	503872	-----
Group 4.048 SUPPORT, SHIFT LEVER SPRING YOKE					
1940 thru 54	All L.H.D., S.T.		1	504202	-----
1939	All L.H.D.	YOKE, selector shaft shift lever spring.....	1	502512	-----
1940 thru 54	All S.T.		1	504225	-----
Group 4.050 LEVER, TRANSMISSION SELECTOR SHAFT OUTER					
1940 thru 42	All L.H.D.		1	505806	-----
1946 thru 54	All L.H.D., S.T.		1	509097	-----
Group 4.053 LEVER, STARTER TO GEARSHIFT NEUTRALIZER					
1948	All H.T.		1	510911	-----
Group 4.054 SWITCH ASSY., TRANSMISSION NEUTRALIZER					
1949 thru 52	All H.T.	also back up lamp switch Group 2.697.....	1	1997846	-----
1953-54	All H.T.	also back up lamp switch Group 2.697.....	1	1998039	-----
1949 thru 54	All H.T.	WIRE ASSY., switch to solenoid.....	1	5289294	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.094 BAR, TRANSMISSION SHIFT					
1935 thru 38	All Type B std. shift	(see Note Group 4.003)-----	1	1297401	-----
Group 4.095 PLATE, TRANSMISSION SHIFT INTERLOCK					
1935-36	All Type B	(see Note Group 4.003)-----	1	553655	-----
1937-38	All with std. shift	-----	1	1297399	-----
Group 4.096 RETAINER, TRANSMISSION INTERLOCK PLATE					
1935 thru 38	All std. shift Type B	(see Note Group 4.003)-----	1	553654	-----
1938	All with steer. col. shift	-----	1	501321	-----
1938	All with steer. col. shift	SPRING , transmission interlock plate anti-rattle-----	1	501323	-----
Group 4.100 GASKET PKG., HYDRAMATIC TRANSMISSION					
1948 thru 50	All H.T.	-----	1	511577	-----
1951	All H.T.	-----	1	515742	-----
1952 thru 54	All H.T.	-----	1	516720	-----
Group 4.101 FLUID, HYDRAMATIC TRANS.					
1948 thru 54	All H.T.	----- (1 qt. can)	AR	557771	-----
1948 thru 54	All H.T.	----- (5 gal. drum)	AR	419282	-----
1948 thru 54	All H.T.	----- (55 gal. drum)	AR	419283	-----
Group 4.103 CASE, TRANSMISSION					
1938	All	-----	1	1305765	-----
1939	All L.H.D.	-----	1	1310010	-----
1940 thru 47	All L.H.D.	-----	1	1317853	-----
1948 thru 54	All L.H.D., S.T.	-----	1	1335514	-----
1948-49	All H.T.	-----	1	8611451	-----
1950	All H.T.	-----	1	8611854	-----
1951	All H.T.	-----	1	8613171	-----
1952	All H.T.	-----	1	8613984	-----
1953	All H.T.	-----	1	8614832	-----
1954	All H.T.	-----	1	8615429	-----
1948 thru 54	All H.T.	BOLT , transmission to flywheel housing (Hex. $\frac{1}{2}$ "-13x1 $\frac{3}{8}$ ")	4	179884	(8.900)
1948-49	All H.T.	NAME PLATE , transmission-----	1	8609324	(4.003)
1950-51	P/6	black-----	1	8609324	(4.003)
1950-51	P/8	green-----	1	8611896	(4.003)
1952 thru 54	All H.T.	green-----	1	8611896	(4.003)
1937 thru 54	All S.T.	PLUG , transmission case, filler and drain. ($\frac{1}{2}$ " sq. hd.)	2	103868	(8.971)
1948 thru 54	All H.T.	PLUG , transmission case----- (Hex. hd. $\frac{1}{8}$ ")	1	444613	(8.971)
1939 thru 54	All S.T.	selector shaft hole----- ($\frac{3}{4}$ ")	1	103892	(8.970)
1936 thru 54	All S.T.	shift shaft hole----- ($\frac{7}{8}$ ")	1-2	103893	(8.970)
Group 4.104 SCREW, TRANSMISSION COVER BREATHER					
1938 thru 54	All with steer. col. shift, S.T.	-----	1	501330	-----
1938 thru 54	All S.T.	CAP , transmission cover breather screw-----	1	498373	(4.687)
Group 4.105 COVER, TRANSMISSION CASE					
1935 thru 38	All std. shift Type B	(see Note Group 4.003)-----	1	553653	-----
1938	All steer. col. shift L.H.D.	-----	1	501318	-----
1939	L.H.D.	-----	1	1313679	-----
1940 thru 54	All S.T.	-----	1	1313679	-----
Group 4.105 COVER, TRANSMISSION CASE SIDE					
1948 thru 50	All H.T.	-----	1	8608462	-----
1951	All H.T.	-----	1	8611924	-----
1952 thru 54	All H.T.	-----	1	8614093	-----
1948 thru 54	All H.T.	BOLT w/WASHER , side cover----- ($\frac{1}{4}$ "-20x $\frac{1}{2}$ ")	12	8609489	-----
1948 thru 54	All H.T.	GASKET , screw-----	1	1307237	(1.488)
1948 thru 54	All H.T.	SCREW , with gasket-----	1	1307238	(1.483)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.106 VALVE—RETAINER—SPRING, TRANS. LINE EXHAUST					
1952	All H.T.	VALVE, 1st type..... (1 $\frac{37}{64}$ " long)	1	8614051	-----
1952	All H.T.	(2nd type)..... (1" long)	1	8614353	-----
1953-54	All H.T.	front servo line exhaust.....	1	8614794	-----
1952	All H.T.	RETAINER.....	1	8614041	-----
1953-54	All H.T.	front servo line exhaust valve spring.....	1	8614174	-----
1952	All H.T.	SPRING, 1st type..... (2 $\frac{27}{64}$ " long)	1	8614050	-----
1952 thru 54	All H.T.	(2nd type on 1952)..... (1 $\frac{49}{64}$ " long)	1	8614352	-----
Group 4.109 GASKET, TRANSMISSION CASE SIDE COVER					
1948 thru 50	All H.T.	-----	1	8608556	-----
1951	All H.T.	-----	1	8611923	-----
1952 thru 54	All H.T.	-----	1	8614176	-----
Group 4.109 GASKET, TRANSMISSION COVER					
1932, 1935 thru 38	All Type B	(see Note Group 4.003).....	1	553461	-----
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590590	-----
1939 thru 54	All S.T.	-----	1	1312441	-----
1938	All with steer. col. shift	GASKET, transmission inspection hole cover.....	1	501325	-----
Group 4.118 COVER ASSY., TORUS					
1948 thru 54	All H.T.	-----	1	8614249	-----
1948 thru 54	All H.T.	BOLT, cover to flywheel (service in complete sets)....	30	511849	-----
Group 4.119 GASKET, TORUS COVER TO FLYWHEEL					
1948 thru 54	All H.T.	-----	1	8611284	-----
Group 4.121 TORUS ASSY., FLUID COUPLING					
1948 thru 54	All H.T.	driven..... Front	1	8610183	-----
1948 thru 54	All H.T.	drive..... Rear	1	8610201	-----
1948 thru 53	All H.T.	RETAINER, driven torus check valve.....	1	8610018	-----
1948 thru 54	All H.T.	RING, driven torus retainer snap.....	1	8613260	-----
1948 thru 54	All H.T.	SPRING, driven torus check valve.....	1	8609508	-----
1948 thru 54	All H.T.	VALVE, driven torus check (use w/8613260 snap ring)	1	8613150	-----
Group 4.124 GASKET, TRANS. FRONT OIL PUMP COVER					
1948 thru 54	All H.T.	-----	1	8609437	-----
Group 4.125 SEAL ASSY., TRANS. FRONT OIL PUMP COVER					
1948 thru 54	All H.T.	-----	1	8609473	-----
Group 4.126 KEY, TRANS. FRONT OIL PUMP DRIVE GEAR					
1948 thru 54	All H.T.	-----	2	8609496	-----
Group 4.127 RING, TRANS. OIL SEAL					
1948 thru 51	All H.T.	front oil pump cover oil seal.....	2	8609472	-----
1948 thru 54	All H.T.	governor sleeve oil seal (special gap)..... (1 $\frac{3}{16}$ " x $\frac{3}{32}$ ")	4	8611053	-----
1948 thru 54	All H.T.	special gap..... (2" x $\frac{3}{32}$ ")	4	8611253	-----
1948 thru 54	All H.T.	special gap..... (2 $\frac{3}{8}$ " x $\frac{3}{32}$ ")	1	8611581	-----
1952 thru 54	All H.T.	front oil pump cover oil seal.....	1	8613202	-----
1952	All H.T.	front servo apply piston..... (1 $\frac{3}{8}$ " x $\frac{3}{32}$ ")	1	8614062	-----
1953-54	All H.T.	front servo apply piston..... (1 $\frac{1}{16}$ " x $\frac{3}{32}$ ")	1	8614122	-----
		(see Group 4.229 for use).....		8611851	-----
Group 4.128 RING, TRANS. RETAINING AND SNAP					
1948 thru 54	All H.T.	clutch drum retainer—front and rear.....	2	8609501	-----
1948 thru 54	All H.T.	driven torus retainer snap.....	1	8613260	-----
1948 thru 54	All H.T.	driving torus retainer snap.....	1	8609434	-----
1948 thru 54	All H.T.	front clutch drum locating snap.....	1	8609434	-----
1948 thru 54	All H.T.	front drive gear retainer.....	1	8609434	-----
1948 thru 54	All H.T.	front drum rear clutch hub retainer snap.....	1	8609434	-----
1948 thru 50	All H.T.	rear bearing retainer snap (horse shoe type washer)	1	8607299	-----
1950 thru 54	All H.T.	rear bearing to retainer snap.....	1	8612215	-----
1948 thru 54	All H.T.	rear clutch drum rear hub rear retainer snap.....	1	8609434	-----
1948 thru 50	All H.T.	reverse internal gear snap.....	1	8609602	-----
1951 thru 54	All H.T.	rear bearing to shaft snap.....	1	8612243	-----
1948 thru 54	All H.T.	reverse planet carrier retainer.....	1-2	8606763	-----
1948 thru 54	All H.T.	reverse unit oil pump and governor driven gear snap	1	8609422	-----
1951 thru 54	All H.T.	reverse unit piston to retainer snap.....	1	8611980	-----

(4.128)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.129 WASHERS, TRANS. THRUST						
1948 thru 54	All H.T.	front unit drive gear rear thrust—bronze.....	1	8609511	-----	
1948 thru 54	All H.T.	front unit drive gear thrust backing—steel.....	1	8609487	-----	
1948 thru 54	All H.T.	front unit drive gear front thrust—bronze.....	1	8609512	-----	
1948 thru 54	All H.T.	front clutch drum rear backing—steel.....	1	8609455	-----	
1948 thru 54	All H.T.	rear clutch hub—bronze.....	2	8609497	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.055"-.059")	1	8609191	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.062"-.067")	1	8609192	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.071"-.076")	1	8609193	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.079"-.083")	1	8609194	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.087"-.091")	1	8609195	-----	
1948 thru 54	All H.T.	main shaft selective, rear.....(.095"-.099")	1	8609196	-----	
1950 thru 54	All H.T.	main shaft selective thrust, rear.....(.103"-.107")	1	8609197	-----	
1950 thru 54	All H.T.	main shaft selective thrust, rear.....(.111"-.115")	1	8609198	-----	
1948 thru 54	All H.T.	reverse unit center gear backing—steel.....	1	8608761	-----	
1948 thru 54	All H.T.	reverse unit center gear thrust—bronze.....	1	8608658	-----	
1948 thru 54	All H.T.	front planet carrier backing—steel.....	1	8609421	-----	
1951 thru 54	All H.T.	reverse internal gear thrust—bronze.....(3¼" O.D.)	1	8613114	-----	
Group 4.131 LOCK PLATE, TRANS. CASE CENTER BEARING CAP BOLT						
1948 thru 54	All H.T.	-----	1	8609426	-----	
1948 thru 54	All H.T.	BOLT, bearing cap to case.....(Hex. ⅞"-14x2½")	2	180157	-----	(8.900)
Group 4.132 SLEEVE, TRANS. CASE OIL FILLER						
1948 thru 54	All H.T.	-----	1	8611007	-----	
Group 4.133 INDICATOR ASSY., TRANS. OIL LEVEL						
1948 thru 54	All H.T.	-----	1	8605800	-----	✓
Group 4.152 LEVER, TRANSMISSION OUTER SHIFT						
1948 thru 50	All H.T.	-----	1	8600271	-----	
1951 thru 54	All H.T.	-----	1	8613181	-----	
Group 4.158 GEAR ASSY., TRANS. FRONT DRIVE						
1948-49	All H.T.	-----	1	8607339	-----	
1950-51	All H.T.	-----	1	8611736	-----	
1952 thru 54	All H.T.	-----	1	8613184	-----	
1948 thru 54	All H.T.	WASHER, front thrust backing—steel.....	1	8609487	-----	(4.129)
1948 thru 54	All H.T.	rear thrust—bronze.....	1	8609511	-----	(4.129)
1948 thru 54	All H.T.	front thrust—bronze.....	1	8609512	-----	(4.129)
Group 4.161 CARRIER ASSY., TRANS. FRONT PLANET						
1948 thru 54	All H.T.	-----	1	8611858	-----	
1948 thru 54	All H.T.	WASHER, bronze thrust.....	1	8609511	-----	(4.129)
Group 4.162 DRUM, TRANS. FRONT CLUTCH						
1948 thru 51	All H.T.	-----	1	8611456	-----	
1952 thru 54	All H.T.	-----	1	8613976	-----	
1948 thru 54	All H.T.	WASHER, rear bronze thrust.....	1	8609511	-----	(4.129)
Group 4.163 PLATE, TRANS. CLUTCH						
1948 thru 54	All H.T.	driven-steel—front or rear.....	9-11	8603954	-----	
1948 thru 54	All H.T.	drive-steel w/facing—front or rear.....	9-11	8609115	-----	
Group 4.164 SPRING, CLUTCH RELEASE						
1948 thru 54	All H.T.	front and rear unit.....Inner	12	8609071	-----	
1948 thru 54	All H.T.	front and rear unit.....Outer	12	8609072	-----	
1948 thru 54	All H.T.	PIN, rear clutch spring guide.....	6	8609070	-----	
Group 4.166 PISTON, TRANS. CLUTCH ANNULAR						
1948-49	All H.T.	-----Front	1	8611261	-----	
1948-49	All H.T.	-----Rear	1	8611258	-----	
1950-51	P/8 H.T.	used w/D50, D51 trans. (see Note Group 4.003).....	1	8611259	-----	
1950-51	P/8 H.T.	used w/D50, D51 trans. (see Note Group 4.003).....Front	1	8611259	-----	
1950-51	P/8 H.T.	used w/D50, D51 trans. (see Note Group 4.003).....Rear	1	8611520	-----	
1950-51	P/6 H.T.	used w/P50, P51 trans. (see Note Group 4.003).....	1	8611261	-----	
		-----Front	1	8611261	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.166 PISTON, TRANS. CLUTCH ANNULAR (Continued)					
1950-51	P/6 H.T.	used w/P50, P51 trans. (see Note Group 4.003)---			
		-----Rear	1	8611258	-----
1952 thru 54	All H.T.	-----Rear	1	8613967	-----
1952 thru 54	All H.T.	-----Front	1	8613968	-----
1951 thru 53	All H.T.	-----Reverse	1	8613704	-----
1954	All H.T.	-----Reverse	1	8611934	-----
Group 4.166 EXPANDER AND SEAL PKG., CLUTCH ANNULAR PISTON					
1948 thru 51	All H.T.	see note-----Front and rear	2	8611029	-----
1952 thru 54	All H.T.	see note-----Front and rear	2	8613952	-----
1951 thru 54	All H.T.	SEAL PKG., reverse	1	8613275	-----
NOTE: Package consists of 2 seals, inner and outer expanders for 1 piston.					
Group 4.169 DRUM ASSY., TRANS. FRONT BRAKE					
1948 thru 54	All H.T.	with pins-----	1	8611446	-----
Group 4.172 SHAFT AND GEAR, TRANS. MAIN					
1948 thru 54	All H.T.	-----	1	8610712	-----
Group 4.173 TRANS. MAIN SHAFT PARTS					
1948 thru 54	All H.T.	NUT, driven torus to main shaft-----	1	8609425	-----
1948 thru 54	All H.T.	WASHER, main shaft nut lock-----	1	8613734	-----
Group 4.177 CARRIER ASSY., REAR PLANET—WITH DRIVEN SHAFT					
1948 thru 50	All H.T.	-----	1	8610716	-----
1951 thru 54	All H.T.	-----	1	8611933	-----
Group 4.179 SLEEVE ASSY., OIL DELIVERY					
1948 thru 54	All H.T.	-----	1	8611654	-----
1948 thru 54	All H.T.	RING, oil seal-----($\frac{3}{32}$ "x2")	4	8611253	----- (4.127)
Group 4.184 DRUM ASSY., TRANS. REAR CLUTCH					
1948 thru 51	All H.T.	-----	1	8611652	-----
1952 thru 54	All H.T.	-----	1	8613975	-----
Group 4.186 HUB, TRANS. REAR CLUTCH					
1948 thru 53	All H.T.	thru trans. No. P53-271454-----	1	8614243	-----
1953-54	All H.T.	after trans. No. P53-271454-----	1	8615451	-----
1953-54	All H.T.	WASHER, rear clutch hub—after trans. No. P53-271454-----	1	8615419	-----
Group 4.187 DRUM, TRANS. REAR					
1948 thru 51	All H.T.	with pin—w/three drive pins (see Note 1)-----	1	8611445	-----
1951	All H.T.	with pin—less dowel pin----- (see Note 2)	1	8613826	-----
1952 thru 54	All H.T.	w/three drive pins-----	1	8613990	-----
1948 thru 51	All H.T.	GEAR, rear internal—w/dowel pin hole (see Note 1)	1	8608759	-----
1951 thru 54	All H.T.	rear internal—less dowel pin holes----- (see Note 2)	1	8613824	-----
1948 thru 54	All H.T.	BOLT, gear to drum----- (Fl. Hd. No. 10-24x1")	2	110491	----- (8.907)
Note 1: Used on 1951 models thru trans. No. D51-121219 and P51-6939					
Note 2: Used with trans. Nos. D51-121220 & P51-6940 and up.					
Group 4.189 REVERSE UNIT PARTS, TRANS.					
1951 thru 54	All H.T.	CONE, stationary-----	1	8611937	-----
1951 thru 54	All H.T.	KEY, stationary cone-----	1	8611936	-----
1951 thru 54	All H.T.	RETAINER, reverse piston release spring--($\frac{4}{16}$ " O.D.)	1	8611985	-----
1951 thru 53	All H.T.	clutch release spring----- ($\frac{3}{8}$ " O.D.)	1	8611973	-----
1954	All H.T.	clutch release spring-----	1	8615316	-----
1951 thru 54	All H.T.	RING, snap, reverse unit piston to ret.-----	1	8611980	----- (4.128)
1951 thru 53	All H.T.	SPRING, clutch release----- ($\frac{3}{16}$ " I.D.)	1	8611972	-----
1951 thru 54	All H.T.	piston release—coil type-----	6	8611958	-----
1954	All H.T.	clutch release----- ($\frac{3}{8}$ " I.D.)	1	8615314	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.190 GEAR, REVERSE UNIT CENTER						
1948 thru 54	All H.T.	includes flange, retainer and bushings.....	1	8608765	-----	(4.129)
1948 thru 54	All H.T.	WASHER, backing—steel thrust.....	1	8608761	-----	
Group 4.192 CARRIER ASSY., TRANS. REVERSE PLANET						
1948 thru 50	All H.T.	-----	1	8608186	-----	(4.128)
1951 thru 54	All H.T.	-----	1	8611960	-----	
1948 thru 54	All H.T.	RING, retainer.....	1-2	8606763	-----	
Group 4.193 GEAR, TRANS. REVERSE INTERNAL						
1948 thru 50	All H.T.	-----	1	8608597	-----	(4.128)
1951 thru 53	All H.T.	-----	1	8611956	-----	
1954	All H.T.	-----	1	8615326	-----	
1948 thru 50	All H.T.	RING, gear retaining snap.....	1	8609602	-----	
Group 4.194 SUPPORT, TRANS. REVERSE INTERNAL GEAR						
1948-49	All H.T.	-----	1	8608745	-----	(8.900)
1950	All H.T.	-----	1	8611758	-----	
Group 4.195 PAN, TRANS. OIL						
1948 thru 54	All H.T.	-----	1	8608630	-----	(1.456)
1948 thru 54	All H.T.	GASKET, drain screw.....	1	1307237	-----	
1948 thru 54	All H.T.	SCREW, with gasket.....	1	1307238	-----	(1.453)
Group 4.196 GASKET, TRANS. OIL PAN						
1948 thru 54	All H.T.	-----	1	8608910	-----	
Group 4.200 PUMP ASSY., TRANS. REAR OIL						
1948 thru 52	All H.T.	-----	1	8611366	-----	(8.900)
1953-54	All H.T.	-----	1	8614701	-----	
1948 thru 54	All H.T.	BOLT, rear pump to case..... (Hex. $\frac{5}{16}$ "-18x $\frac{7}{8}$ ")	2	180078	-----	
Group 4.203 COVER, TRANS. REAR OIL PUMP						
1948 thru 50	All H.T.	with external tooth type pump.....	1	8609556	-----	(8.939)
1948 thru 52	All H.T.	with internal tooth type pump.....	1	8611355	-----	
1953-54	All H.T.	-----	1	8614704	-----	
1953-54	All H.T.	BOLT, rear oil pump cover.....	4	8614824	-----	
Group 4.206 GEAR PKG., TRANS. REAR OIL PUMP (With Drive Shaft)						
1948-49	All H.T.	with external tooth type pump.....	1	8610734	-----	
NOTE: Package consists of gears and shaft assy., and 2 pins.						
Group 4.210 GEAR, TRANS. OIL PUMP AND GOVERNOR DRIVE						
1948 thru 54	All H.T.	reverse unit—bronze.....	1	8609428	-----	
Group 4.211 GEAR, TRANS. OIL PUMP AND GOVERNOR DRIVEN						
1948 thru 54	All H.T.	GEAR AND PIN PKG., rear oil pump.....	1	8610744	-----	(8.939)
1948 thru 54	All H.T.	PIN..... (Str. $\frac{3}{16}$ "x $\frac{1}{8}$ ")	1	103723	-----	
Group 4.216 VALVE, TRANS. OIL PRESSURE REGULATOR						
1948 thru 51	All H.T.	-----	1	8608611	-----	(8.939)
1952 thru 54	All H.T.	-----	1	8614378	-----	
1948-49	All H.T.	GASKET, pressure regulator plug.....	1	8609515	-----	(8.939)
1950	P/8 H.T.	used with D50 trans. (see Note Group 4.003).....	1	8611827	-----	
1950	P/6 H.T.	used with P50 trans. (see Note Group 4.003).....	1	8609515	-----	(8.939)
1951 thru 54	All H.T.	-----	1	8611827	-----	
1948-49	All H.T.	PLUG ASSY., transmission pressure regulator valve.....	1	8611234	-----	(8.939)
1950	P/6 H.T.	used w/P50 trans. (see Note Group 4.003).....	1	8611811	-----	
1950	P/8 H.T.	oil pump pressure reg. used with D50 trans. (see Note Group 4.003).....	1	8611798	-----	(8.939)
1948 thru 50	All H.T.	PLUGS AND GASKET PKG., use w/8614994 pump pkg. on P/9 trans.....	1	8614982	-----	
1950	All H.T.	use w/8614994 pump pkg. on P50 trans.....	1	8614986	-----	(8.939)
1950	P/8 H.T.	use w/8614994 pump pkg. on D50 trans.....	1	8614984	-----	
1951	P/6 H.T.	consists of 1 press. reg. plug and gasket and 1 rev. booster plug.....	1	8613692	-----	(8.939)
1951	P/8 H.T.	consists of 1 each—press. reg. plug, gasket and seal—rev. booster plug—throttle valve press. plug.....	1	8613604	-----	
1952 thru 54	All H.T.	-----	1	8614133	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.216 VALVE, TRANS. OIL PRESSURE REGULATOR (Continued)					
1950	P/8 H.T.	PLUG , oil pump throttle valve pressure used with D50 trans. (see Note Group 4.003)	1	8611802	-----
1950-51	P/8 H.T.	SEAL , pressure reg. plug used with D50, D51 trans. (see Note Group 4.003)	1	8611804	-----
1952 thru 54	All H.T.	-----	1	8611804	-----
1948-49	All H.T.	SPRING , pressure regulator valve	1	8609052	-----
1950	P/6 H.T.	used with P50 trans. (see Note Group 4.003)	1	8609052	-----
1950	P/8 H.T.	used with D50 trans. (see Note Group 4.003) Front	1	8611860	-----
1951	P/6 H.T.	-----	1	8613036	-----
1951	P/8 H.T.	-----	1	8611942	-----
1952 thru 54	All H.T.	-----	1	8615263	-----
Group 4.222 PIPE, TRANS. OIL PUMP INLET (SUCTION)					
1948 thru 51	All H.T.	front pump to screen	1	8608738	-----
1952 thru 54	All H.T.	front oil pump inlet suction	1	8613234	-----
1948 thru 51	All H.T.	PLATE , inlet pipe bolt lock	2	8609531	-----
Group 4.223 GASKET, TRANS. OIL PUMP INLET PIPE					
1948 thru 51	All H.T.	front pump	1	8609490	-----
1952 thru 54	All H.T.	SEAL , front pump	1	8613199	-----
Group 4.224 SCREEN, TRANS. OIL					
1948 thru 51	All H.T.	-----	1	8608654	-----
1952 thru 54	All H.T.	-----	1	8613216	-----
Group 4.225 CYLINDER, TRANS. FRONT SERVO BAND RELEASE					
1948 thru 51	All H.T.	-----	1	8609492	-----
1952	All H.T.	-----	1	8614073	-----
1953-54	All H.T.	-----	1	8614777	-----
Group 4.226 BODY, FRONT SERVO					
1948-49	All H.T.	-----	1	8610746	-----
1950-51	All H.T.	-----	1	8611742	-----
1952	All H.T.	-----	1	8614074	-----
1953-54	All H.T.	-----	1	8614833	-----
1950 thru 54	All H.T.	BALL , frt. servo rear pump check (steel 1/2")	1	169158	(8.899)
1952	All H.T.	GASKET , front servo	1	8614377	-----
1948 thru 51, 53-54	All H.T.	PIN , dowel (1/8" x 1 1/2")	1	141109	(8.939)
1952	All H.T.	front servo sleeve locating (1/8" x 1 1/2")	1	141106	(8.939)
1948 thru 54	All H.T.	PLUG , front servo body (Hex. Hd. 1/8")	1	444613	(8.971)
1948 thru 52	All H.T.	PLUG , pipe (Slotted 1/4")	1	103884	(8.971)
1950-51	All H.T.	SEAT , front servo rear pump check valve	1	8611743	-----
1952	All H.T.	-----	1	8614125	-----
1950 thru 54	All H.T.	SPRING , front servo check valve	1	8611744	-----
Group 4.226 OIL PUMP AND COVER ASSY., TRANS. FRONT					
1948 thru 50	All H.T.	PUMP ASSY. , trans. front oil (see Group 4.216 for pressure reg. pkg. to be used with this pump)	1	8614994	-----
1951	All H.T.	-----	1	8613126	-----
1952 thru 54	All H.T.	-----	1	8613262	-----
1948 thru 51	All H.T.	BOLT , cover to pump body (1/4"-20x5/8")	3	8609532	-----
1948-49	All H.T.	cover to pump body (1/4"-20x1")	2	8609533	-----
1948 thru 50	All H.T.	cover to pump body (1/4"-20x1 3/8")	1	8609534	-----
1951	All H.T.	cover to pump body (1/4"-20x1 1/2")	1	8611821	-----
1952 thru 54	All H.T.	GUIDE , front oil pump relief valve	1	8613899	-----
1952 thru 54	All H.T.	PIN , relief valve retainer (3/32" x 1 3/16")	1	110732	(8.939)
1948 thru 51	All H.T.	RING , cover oil seal	2	8609472	(4.127)
1952 thru 54	All H.T.	-----	1	8613202	(4.127)
1948 thru 50	All H.T.	SPRING , front oil pump by-pass valve	1	8609517	-----
1951	All H.T.	-----	1	8611822	-----
1952 thru 54	All H.T.	front oil pump priming	1	8613198	-----
1952 thru 54	All H.T.	front oil pump relief valve	1	8613898	-----
1948 thru 50	All H.T.	VALVE , front oil pump by-pass	1	8609516	-----
1951	All H.T.	-----	1	8611823	-----
1952 thru 54	All H.T.	front oil pump relief	1	8613900	-----
1948 thru 54	All H.T.	WASHER , front oil pump locating	1	8609486	-----
1948 thru 51	All H.T.	cover to pump body (1/4")	3	8609514	-----
1948 thru 51	All H.T.	pump cover to body lock (1/4")	1	103319	(8.931)
1948 thru 52	All H.T.	pump cover to case (Cad. 3/16")	2	120393	(8.929)
1951	All H.T.	SCREW AND WASHER PKG. , front oil pump	1	8611878	-----
1952 thru 54	All H.T.	-----	1	8614360	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.227 VALVE, FRONT SERVO OVER RUN CONTROL						
1952	All H.T.	-----	1	8614053	-----	
1953-54	All H.T.	-----	1	8614793	-----	
1953-54	All H.T.	BODY, valve -----	1	8614884	-----	
1953-54	All H.T.	BOLT, valve body to servo -----	2	190601	-----	(8.907)
1952	All H.T.	PIN, control valve -----	1	8614186	-----	
1953-54	All H.T.	-----	1	8614136	-----	(4.265)
1952	All H.T.	SPRING, control valve -----	1	8614054	-----	
1953-54	All H.T.	-----	1	8614791	-----	
Group 4.228 PISTON, TRANS. FRONT SERVO						
1948 thru 51	All H.T.	front band release-----	1	8609458	-----	
1948 thru 51	All H.T.	front band apply-----	1	8609539	-----	
1952	All H.T.	-----	1	8614059	-----	
1953-54	All H.T.	front band release-----	1	8611849	-----	
1953-54	All H.T.	front band apply-----	1	8614851	-----	
Group 4.229 RING, TRANS. FRONT SERVO PISTON						
1948 thru 51	All H.T.	front band apply—Special gap----- $(\frac{3}{32}'' \times 1\frac{5}{16}'')$	1	8611055	-----	
1948 thru 52	All H.T.	front band release—Special gap----- $(\frac{3}{32}'' \times 1\frac{5}{16}'')$	1	8611251	-----	(4.127)
1952	All H.T.	front band apply----- $(\frac{3}{32}'' \times 1\frac{3}{8}'')$	1	8614062	-----	
1953-54	All H.T.	front band apply----- $(1\frac{1}{16}'' \times \frac{3}{32}'')$	1	8614122	-----	(4.127)
1953-54	All H.T.	front band release-----	1	8611851	-----	(4.127)
Group 4.233 SPRING, TRANS. FRONT SERVO						
1948 thru 51	All H.T.	retracting-----	1	8609449	-----	
1948 thru 51	All H.T.	booster-----	1	8609474	-----	
1952	All H.T.	release-----	1	8614412	-----	
1953-54	All H.T.	booster-----	1	8609474	-----	
1953-54	All H.T.	retracting-----	1	8609449	-----	
Group 4.234 VALVE, TRANS. FRONT UNIT SERVO DOWNSHIFT						
1948 thru 51	All H.T.	4th to 3rd-----	1	8609116	-----	
1952	All H.T.	4th to 3rd-----	1	8614126	-----	
1953-54	All H.T.	4th to 3rd-----	1	8614792	-----	
1948 thru 52	All H.T.	RETAINER, front servo 4-3 downshift valve spring -----	1	8613733	-----	
1948 thru 51	All H.T.	front servo retracting spring-----	1	8609545	-----	
1953-54	All H.T.	front servo release spring-----	1	8611848	-----	
Group 4.236 LEVER, TRANS. SERVO BAND ACTUATING						
1948 thru 54	All H.T.	-----Rear	1	8609600	-----	
Group 4.237 BEARING PKG., REAR SERVO BAND ACTUATING LEVER						
1948 thru 54	All H.T.	package contains 20 needle roller brgs.-----	1	414388	-----	
Group 4.237 PIN, TRANS. SERVO BAND ACTUATING LEVER						
1948 thru 54	All H.T.	-----	1	8613172	-----	
Group 4.239 BODY, REAR SERVO						
1948 thru 50	All H.T.	-----	1	8610748	-----	
1951	All H.T.	-----	1	8613269	-----	
1952 thru 54	All H.T.	-----	1	8613142	-----	
1952 thru 54	All H.T.	GASKET, servo body to accumulator body -----	1	8613159	-----	
Group 4.241 PISTON AND STEM ASSY., REAR SERVO						
1948 thru 54	All H.T.	accumulator-----	1	8610751	-----	
1948 thru 54	All H.T.	booster-----	1	8610752	-----	
Group 4.242 RING, TRANS. REAR SERVO PISTON						
1948 thru 54	All H.T.	accumulator—special gap----- $(\frac{3}{32}'' \times 2\frac{3}{8}'')$	1	8611581	-----	(4.127)
1948 thru 54	All H.T.	booster, small—special gap----- $(\frac{3}{32}'' \times 1\frac{11}{16}'')$	1	8611252	-----	
1948 thru 54	All H.T.	booster, large—special gap----- $(\frac{3}{32}'' \times 2\frac{1}{4}'')$	1	8611254	-----	
1948 thru 51	All H.T.	compensator—special gap----- $(\frac{3}{32}'' \times 1\frac{1}{4}'')$	1	8611054	-----	
Group 4.244 PISTON AND SPRING PKG., REAR SERVO COMPENSATOR						
1948 thru 54	All H.T.	-----	1	8613764	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.246 SPRING, TRANS. REAR SERVO					
1948 thru 54	All H.T.	accumulator piston apply.....($\frac{5}{8}$ " dia.)	1	8609061	-----
1948 thru 54	All H.T.	servo main.....($1\frac{39}{32}$ " dia.)	1	8611794	-----
1948 thru 51	All H.T.	servo inner.....($\frac{5}{8}$ " dia.)	1	8609479	-----
1948 thru 51	All H.T.	servo outer.....	1	8610339	-----
1948 thru 54	All H.T.	servo booster piston.....($1\frac{15}{16}$ " dia.)	1	8609480	-----
1952	All H.T.	rear servo compensator.....Inner	1	8614184	-----
Group 4.247 RETAINER, TRANS. REAR SERVO SPRING					
1948 thru 54	All H.T.	-----	1	8609470	-----
Group 4.248 OIL PIPES, TRANSMISSION					
1948-49	All H.T.	rear oil pump discharge.....	1	8606941	-----
1950-51	All H.T.	rear oil pump discharge.....	1	8611770	-----
1948 thru 54	All H.T.	front oil pump to front servo.....	1	8609507	-----
1948 thru 54	All H.T.	oil transfer, front to rear servo.....	1	8609459	-----
1948 thru 51	All H.T.	governor oil delivery.....	3	8609435	-----
1951 thru 54	All H.T.	reverse clutch.....	1	8611963	-----
1951	All H.T.	pressure regulator reverse.....	1	8611922	-----
1952	All H.T.	pressure regulator reverse.....	1	8614175	-----
1952 thru 54	All H.T.	governor oil delivery.....	2	8609435	-----
1952	All H.T.	governor oil delivery.....	1	8614038	-----
1952 thru 54	All H.T.	rear oil pump discharge.....	1	8614128	-----
1953-54	All H.T.	governor oil delivery.....	1	8614789	-----
1953-54	All H.T.	pressure reg. reverse.....	1	8614817	-----
1948-49	All H.T.	FITTING , rear oil pump discharge pipe to front servo.....	1	8609418	-----
1948 thru 54	All H.T.	PLUG , torus cover.....(Hex. hd. $\frac{1}{8}$ ")	1	444613	----- (8.971)
Group 4.250 ACCUMULATOR BODY, TRANS. REAR SERVO UNIT					
1948 thru 50	All H.T.	-----	1	8610749	-----
1951	All H.T.	-----	1	8613158	-----
1952	All H.T.	-----	1	8614044	-----
1953-54	All H.T.	-----	1	8614856	-----
1948 thru 51	All H.T.	CHECK VALVE PKG. , includes rivet.....	1	8610745	-----
1952	All H.T.	-----	1	8613949	-----
1953-54	All H.T.	-----	1	8614877	-----
1948 thru 52	All H.T.	PLUNGER , check valve.....	1	8609619	-----
1953-54	All H.T.	-----	1	8614859	-----
1952	All H.T.	SPRING , rear servo exhaust valve.....	1	8611715	-----
1953-54	All H.T.	-----	1	8614858	-----
1952	All H.T.	VALVE , rear servo exhaust.....	1	8611842	-----
1953-54	All H.T.	-----	1	8614886	-----
Group 4.251 BAND AND LINING, TRANS. SERVO					
1948 thru 54	All H.T.	-----Front	1	8607658	-----
1948 thru 51	All H.T.	-----Rear	1	8607477	-----
1952 thru 54	All H.T.	-----Rear	1	8613924	-----
Group 4.252 STRUT, TRANS. REAR DRUM REAR BAND					
1948 thru 51	All H.T.	-----	1	8609390	-----
1952 thru 54	All H.T.	SPRING , trans. rear band release.....	1	8613934	-----
Group 4.253 SCREW, TRANS. SERVO BAND ADJUSTING					
1948 thru 54	All H.T.	-----	2	8609584	-----
Group 4.254 PIN, TRANS. REAR DRUM REAR BAND STRUT					
1948 thru 54	All H.T.	-----	1	1299717	-----
Group 4.255 SLEEVE, TRANS. GOVERNOR OIL DELIVERY					
1948 thru 50	All H.T.	-----	1	8609436	-----
1948 thru 50	All H.T.	PLUG	1	8608657	-----
Group 4.256 GOVERNOR ASSY., TRANS.					
1948 thru 51	All H.T.	-----	1	8614425	-----
1952 thru 54	All H.T.	-----	1	8614046	-----
1948 thru 51	All H.T.	PLUNGER AND BUSHING ASSY. , G-2 governor.....	1	8610740	-----
1948 thru 54	All H.T.	RING , governor sleeve oil seal.....	4	8611053	----- (4.127)
1948 thru 51	All H.T.	STOP , governor plunger.....	2	8609441	-----
1952	All H.T.	-----	1	8609441	-----
1952	All H.T.	-----	1	8614048	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.259 FLANGE, REAR OIL PUMP GOVERNOR DRIVE						
1948 thru 54	All H.T.	FLANGE AND PIN PKG.	1	8607755	-----	
1948 thru 54	All H.T.	PIN , flange to shaft.....(Str. $\frac{1}{16}$ "x $1\frac{1}{4}$ ")	1	103726	-----	(8.939)
Group 4.265 VALVE BODY, TRANS. OIL CONTROL						
1948-49	All H.T.	Inner	1	8610750	-----	
1948-49	All H.T.	Outer	1	8611598	-----	
1950	P/6 H.T.	VALVE ASSY. , control used w/P50 trans. (see Note Group 4.003)	1	8611832	-----	
1950	P/8 H.T.	used with D50 trans. (see Note Group 4.003)	1	8611672	-----	
1951	P/6 H.T.		1	8613066	-----	
1951	P/8 H.T.		1	8611927	-----	
1952	All H.T.		1	8614129	-----	
1953	All H.T.		1	8614727	-----	
1954	All H.T.		1	8615354	-----	
1948 thru 54	All H.T.	BALL , trans. reverse unit oil pump and gov. drive gear	1	169066	-----	(8.899)
1948-49	All H.T.	manual valve detent.....($\frac{5}{16}$ ")	1	104919	-----	(8.899)
1951	All H.T.	BODY ASSY. , front servo exhaust	1	8613914	-----	
1952 thru 54	All H.T.	PIN , timing valve plug retainer	1	8614136	-----	
1948-49	All H.T.	PLATE , valve body spacer	1	8609423	-----	
1951 thru 54	All H.T.	PLUNGER , manual control valve detent	1	8611995	-----	
1948-49	All H.T.	RETAINER , manual valve detent ball	1	8611595	-----	
1951	All H.T.	manual valve detent plunger	1	8614426	-----	
1952 thru 54	All H.T.	control valve detent plunger	1	8611954	-----	
1948 thru 50	All H.T.	SPRING , manual valve detent	1	8611662	-----	
1951 thru 54	All H.T.	reverse exhaust valve	1	8611991	-----	
1951	All H.T.		1	8613839	-----	
1948 thru 50	All H.T.	VALVE , manual control	1	8609593	-----	
1951	All H.T.		1	8611974	-----	
1952 thru 54	All H.T.		1	8614164	-----	
1953-54	All H.T.	by pass	1	8614814	-----	
1948 thru 51	All H.T.	BOLT AND LOCK WASHER ASSY. , front body to inner body.....(No. 10-24x1")	3	189386	-----	(8.907)
1948 thru 51	All H.T.	front body plate to body.....(No. 10-24x $\frac{1}{16}$ ")	2-3	189384	-----	(8.907)
1948 thru 50	All H.T.	front plate to outer body.....(No. 10-24x $\frac{1}{16}$ ")	3	189384	-----	(8.907)
1948 thru 50	All H.T.	detent ball ret.....(No. 10-24x $\frac{1}{8}$ ")	1	443914	-----	(8.907)
1948 thru 54	All H.T.	detent ball ret.....(No. 10-24x $\frac{1}{8}$ ")	2	190601	-----	(8.907)
1948 thru 54	All H.T.	rear cover to inner body.....(No. 10-24x $\frac{3}{4}$ ")	3	189385	-----	(8.907)
1948 thru 51	All H.T.	outer to inner body.....(No. 10-24x $\frac{3}{4}$ ")	1	189385	-----	(8.907)
1951 thru 54	All H.T.	detent plunger ret. to body.....(No. 10-24x $\frac{3}{4}$ ")	1	189385	-----	(8.907)
1951	All H.T.	detent plunger ret. to body.....(No. 10-24x $\frac{3}{8}$ ")	1	190601	-----	(8.907)
1951	All H.T.	exh. body to outer valve body	2	189386	-----	(8.907)
1951-52	All H.T.	exh. body to outer valve body	1	190601	-----	(8.907)
1952	All H.T.	front body to inner body.....(No. 10-24x1")	1	189386	-----	(8.907)
1952 thru 54	All H.T.	timing valve body to inner body	2	189384	-----	(8.907)
1953-54	All H.T.	front to inner body.....(Fil. Hd. No. 10-24x1 $\frac{3}{8}$ ")	1	455634	-----	(8.907)
1953-54	All H.T.	front to inner body.....(Fil. Hd. No. 10-24x1 $\frac{1}{4}$ ")	2	454776	-----	(8.907)
1953-54	All H.T.	outer to inner body	2	454031	-----	(8.907)
Group 4.278 LEVER AND SHAFT, THROTTLE VALVE INSIDE						
1948 thru 54	All H.T.		1	8609591	-----	
1948 thru 54	All H.T.	PIN , manual control valve shaft...(Grooved $\frac{1}{16}$ "x $\frac{1}{2}$ ")	1	187381	-----	(8.940)
Group 4.279 LEVER ASSY., TRANS. CONTROL VALVE						
1948 thru 50	All H.T.	inside detent	1	8611266	-----	
1951	All H.T.	inside detent	1	8611999	-----	
1952 thru 54	All H.T.	inside detent	1	8614134	-----	
Group 4.282 PIN, SEAL AND WASHER PKG., INNER CONTROL LEVER						
1948 thru 54	All H.T.		1	8610742	-----	
1948 thru 54	All H.T.	SEAL AND WASHER PKG. , manual control shaft—consists of seal, inner and outer washer	1	8610731	-----	
Group 4.286 LEVER, TRANS. THROTTLE CONTROL						
1948 thru 54	All H.T.	Outer	1	8611315	-----	
Group 4.290 PISTON, TRANS. REVERSE BLOCKER						
1948 thru 50	All H.T.		1	8611768	-----	
1951 thru 54	All H.T.		1	8613177	-----	
1948 thru 51	All H.T.	BRACKET AND CRANK	1	8611760	-----	
1951 thru 54	All H.T.	PIN , reverse blocker piston stop	1	8613173	-----	
1948-49	All H.T.	SPRING , trans. reverse blocker piston retractor	1	8610309	-----	
1951 thru 54	All H.T.	reverse blocker piston	1	8613086	-----	
1948 thru 50	All H.T.	SHIM , reverse shifter bracket.....(6 max.)	AR	8610468	-----	
1948 thru 50	All H.T.	BOLT , reverse shifter brkt. to case	2	180087	-----	(8.900)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.290 BRACKET ASSY., TRANS. PARKING BRAKE					
1951	All H.T.	-----	1	8613506	-----
1952 thru 54	All H.T.	-----	1	8614077	-----
1952 thru 54	All H.T.	PIN , parking blocker piston	1	103679	-----
1951	All H.T.	PISTON , parking blocker	1	8611982	-----
1952 thru 54	All H.T.	-----	1	8614080	-----
1952 thru 54	All H.T.	RETAINER , parking blocker piston pin	1	8614082	-----
1951	All H.T.	SPRING , parking blocker piston release	1	8613811	-----
1952 thru 54	All H.T.	-----	1	8614081	-----
1951	All H.T.	STOP , parking blocker piston release spring	1	8613810	-----
Group 4.293 ROLLER, TRANS. REVERSE SHIFTER CRANK					
1948 thru 54	All H.T.	-----	1	8609594	-----
Group 4.294 ANCHOR, TRANS. REVERSE					
1948 thru 50	All H.T.	-----	1	8609761	-----
1951 thru 54	All H.T.	trans. parking brake	1	8611929	-----
1948 thru 50	All H.T.	BOLT , reverse anchor support	1	8608996	-----
1951 thru 54	All H.T.	trans. parking brake pawl support	1	8611961	-----
1948 thru 54	All H.T.	LOCK , reverse anchor support bolt	1	8609022	-----
Group 4.295 SPRING, TRANS. REVERSE ANCHOR RETRACTING					
1948 thru 50	All H.T.	-----	1	8609130	-----
1951 thru 54	All H.T.	trans. parking brake anchor return	1	8613179	-----
Group 4.301 SHAFT, TRANSMISSION SELECTOR SHIFT					
1938 All steer. col. shift L.H.D.		-----	1	501329	-----
1939 All		-----	1	1307907	-----
1940 thru 54 All S.T.		-----	1	1312989	-----
Group 4.302 LEVER, TRANSMISSION SHIFT SELECTOR INNER					
1938 All with steer. col. shift		inside transmission cover	1	500971	-----
1940 thru 54 All S.T.		shaft and lever	1	1330676	-----
1940 thru 54 All S.T.		SEAL , selector lever shaft oil, cork	1	1312580	-----
1940 thru 54 All S.T.		WASHER , selector lever shaft oil seal, plain	1	1312581	-----
1940 thru 54 All S.T.		spring type $(\frac{25}{64}"$ I.D. x $\frac{3}{4}"$ O.D.)	1	402547	(8.928)
Group 4.303 FORK, GEARSHIFT SECOND AND HIGH SHIFT					
1932, 1935 thru 38 All Type B		(see Note Group 4.003)	1	1394475	-----
1939 thru 54 All S.T.		-----	1	1307865	-----
Group 4.304 FORK, GEARSHIFT LOW AND REVERSE SHIFT					
1935 thru 38 All Type B		(see Note Group 4.003)	1	1290430	-----
1939 thru 54 All S.T.		-----	1	1307864	-----
Group 4.309 SHAFT, TRANSMISSION LOW AND REVERSE SHIFT					
1935 thru 38 All Type B		(see Note Group 4.003) $(7" \text{ long})$	1	501499	-----
1939 All		$(6\frac{27}{32}" \text{ long})$	1	1309653	-----
1940 thru 53 All S.T.		$(7\frac{3}{16}" \text{ long})$	1	1312407	-----
1932, 1935 thru 38 All Type B		SHAFT , transmission second and high shift (see Note Group 4.003) $(6\frac{11}{16}" \text{ long})$	1	501498	-----
1939 All		$(6\frac{7}{16}" \text{ long})$	1	1309654	-----
1940 thru 54 All S.T.		$(6\frac{1}{32}" \text{ long})$	1	1334187	-----
Group 4.311 SPRING, TRANSMISSION SHIFT FORK POPPET					
1931, 1932, 1935 thru 38 All exc. P/6 1931 and 1935 Type A		(see Note Group 4.003)	1	553156	-----
1933 thru 35 All Type A		(see Note Group 4.003)	1	551946	-----
1939-40 All		-----	2	1314658	-----
1941 thru 54 All S.T.		-----	2	1320299	-----
1932 thru 54 All S.T.		BALL , transmission shift shaft, steel $(\frac{3}{8}" \text{ dia.})$	2	147489	(8.899)
Group 4.312 SCREW, TRANSMISSION SHIFT FORK SET					
1935 thru 54 All exc. 1935 Type A, S.T.		headless cone point, (see Note Group 4.003)	4	1301275	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.313 SEAL, SELECTOR SHAFT					
1939 thru 54	All S.T.	transmission end.....	1	1310194	-----
Group 4.314 LEVER, TRANSMISSION SELECTOR SHAFT SHIFT					
1939 thru 54	All S.T.	second and high.....	1	1308074	-----
Group 4.315 LEVER, TRANSMISSION SELECTOR SHAFT SHIFT					
1939 thru 54	All S.T.	low and reverse.....	1	1308073	-----
Group 4.317 RETAINER, TRANSMISSION REAR BEARING					
1939	26	-----	1	1308376	-----
1939 thru 48	All exc.	-----	1	1335777	-----
	1939-26	-----			
1948-49	All H.T.	-----	1	8608768	-----
1950	All H.T.	-----	1	8611756	-----
1949 thru 54	All S.T.	-----	1	1336377	-----
1951 thru 54	All H.T.	-----	1	8611994	-----
1940 thru 54	All S.T.	BOLT , transmission rear bearing retainer.....			
		(Hex. $\frac{1}{16}$ "-14x1")	4	180145	(8.900)
		($\frac{3}{8}$ "-16x1")	5	180122	(8.900)
1948 thru 50	All H.T.	WASHER , trans. rear brg. ret. to support.....	4	1456254	-----
1948 thru 50	All H.T.	($\frac{3}{8}$ ")			
Group 4.318 GASKET, TRANSMISSION REAR BEARING RETAINER					
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590580	-----
1935 thru 37	All Type B	(see Note Group 4.003).....	1	1280171	-----
1938	All	-----	1	502239	-----
1939 thru 54	All S.T.	-----	1	1316970	-----
1948 thru 50	All H.T.	-----	1	8608488	-----
1951 thru 54	All H.T.	-----	1	8611998	-----
Group 4.335 SLEEVE, TRANSMISSION SECOND SPEED GEAR OIL					
1932, 1935 thru 38	All Type B	(see Note Group 4.003).....	1	553465	-----
1933 thru 35	All Type A	transmission rear bearing oil (see Note Group 4.003)	1	590567	(4.409)
1939	26 All	SHIELD , transmission rear bearing splash.....	1	502239	-----
1940 thru 54	All S.T.	-----	1	509500	-----
1948 thru 53	All H.T.	transmission rear bearing oil seal.....	1	8611322	-----
1939 thru 54	All S.T.	SEAL , transmission rear bearing retainer oil.....	1	502568	-----
1948 thru 50	All H.T.	trans. rev. unit rear brg. oil.....	1	1314707	-----
1951 thru 54	All H.T.	-----	1	8612229	-----
Group 4.337 GEAR AND SHAFT, SPEEDOMETER DRIVEN					
1937	All	18-6 ratio, 33-8 axle.....	1	499958	-----
1937	All	19-6 ratio, 35-8 axle.....	1	499959	-----
1937	All	20-6 ratio, 37-8 axle.....	1	499960	-----
1938	All	19-6 ratio, 35-8 axle.....	1	501097	-----
1938	All	20-6 ratio, 37-8 axle.....	1	501098	-----
Group 4.337 GEAR, SHAFT AND SLEEVE ASSY., SPEEDOMETER DRIVEN					
1939	All	15-5 ratio, 41-10 axle.....	1	502381	-----
1939	All	16-5 ratio, 43-10 axle.....	1	502382	-----
1940 thru 49	All S.T.	20-7 ratio, 39-10 axle.....	1	503932	-----
1940 thru 49	All S.T.	23-7 ratio, 41-9 axle.....	1	503935	-----
1940 thru 49	All S.T.	21-7 ratio, 41-10 axle.....	1	503933	-----
1940 thru 49	All S.T.	22-7 ratio, 43-10 axle.....	1	503934	-----
1940 thru 48	P/6 taxi	21-7 ratio, 41-10 axle, with Ohmer register.....	1	504056	-----
1948 thru 50	25 H.T.	19-7 ratio, 40-11 axle.....	1	510955	-----
1948	26 H.T.	18-7 ratio, 40-11 axle.....	1	510956	-----
1950-51	All S.T.	20-7 ratio, 39-10 axle.....	1	513802	-----
1950-51	All S.T.	21-7 ratio, 41-10 axle.....	1	513803	-----
1950-51	All S.T.	22-7 ratio, 43-10 axle.....	1	513804	-----
1950-51	All S.T.	19-7 ratio, 40-11 axle.....	1	510955	-----
1951 thru 54	All exc.	21-8 ratio, 40-11 axle.....	1	514866	-----
	export H.T.	-----			
1952 thru 54	All S.T.	20-7 ratio, 39-10 axle.....	1	516364	-----
1952 thru 54	All S.T.	21-7 ratio, 41-10 axle.....	1	516363	-----
1952 thru 54	All S.T.	22-7 ratio, 43-10 axle.....	1	516365	-----
1952 thru 54	All S.T.	19-7 ratio, 40-11 axle.....	1	516366	-----
1952 thru 54	All H.T.	18-8 ratio, 40-13 axle.....	1	515383	-----
1952 thru 54	All H.T.	18-8 ratio, 40-13 axle, o.s. gear.....	1	517321	-----
1953-54	All H.T.	20-8 ratio, 41-12 axle.....	1	517764	-----
1954	All H.T.	19-8 ratio, 42-13 axle.....	1	518433	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.339 HEAD ASSEMBLY, SPEEDOMETER (MILES)					
1942 thru 47	All	-----	1	1569593	-----
1948	All	-----	1	1569558	-----
1949-50	All	-----	1	1569877	-----
1951-52	All	-----	1	1580822	-----
1953-54	All	-----	1	1581326	-----
Group 4.342 CABLE KIT, SPEEDOMETER					
1932 thru 36	All	with tips and staking tool.....	1	846893	-----
1937 thru 54	All L.H.D.	-----	1	846890	-----
1937-38	All	CABLE AND CASING KIT, speedometer			
		(A.C. CC7).....	1	1567799	-----
1939 thru 48	All	(A.C. CC1).....	1	1567793	-----
1953-54	All H.T.	(A.C. CC1).....	1	1567793	-----
1948	All L.H.D., H.T.	CABLE ASSEMBLY	1	1567798	-----
1949 thru 52	All L.H.D., H.T.	(A.C. CC6).....	1	1569918	-----
1949 thru 54	All L.H.D., S.T.	-----	1	1580395	-----
		(A.C. CC8).....	1		
Group 4.343 GEAR, SPEEDOMETER DRIVE					
1935-36	All	13-4 or 14-4 ratio.....	1	378614	-----
1937-38	All	with all axle ratios.....	1	499957	-----
1939	All	with all axle ratios.....	1	502384	-----
1940 thru 49	All S.T.	with all axle ratios.....	1	503936	-----
1948 thru 50	All H.T.	-----	1	1315449	-----
1950 thru 54	All S.T.	-----	1	1315449	-----
Group 4.345 SPACER, SPEEDOMETER DRIVE GEAR					
1939 thru 54	All S.T.	-----	1	1308272	-----
Group 4.351 GEAR, TRANSMISSION MAIN DRIVE					
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590658	-----
1935-36	All Type B	(see Note Group 4.003).....	1	1293298	-----
1937-38	All	-----	1	1298738	-----
1939	All exc. taxi	-----	1	1308239	-----
1940 thru 42	All exc. taxi	-----	1	1314655	-----
1940 thru 42	P/6 taxi	-----	1	1332892	-----
1946 thru 54	All S.T.	-----	1	1332892	-----
Group 4.352 BEARING, TRANSMISSION MAIN SHAFT PILOT					
1932, 1935-36	All Type B	roller type (see Note Group 4.003).....	1	141848	-----
1937-38	All	BEARING PKG., main shaft pilot	1	435844	-----
1939 thru 54	All S.T.	-----	1	7450059	-----
Group 4.353 SPACER, MAIN SHAFT PILOT BEARING					
1932, 1935-36	All Type B	(see Note Group 4.003).....	1	553578	-----
1948 thru 54	All H.T.	-----	1	511102	-----
1937-38	All	RING, transmission pilot bearing snap	1	1295407	-----
1939 thru 54	All S.T.	-----	1	1298456	-----
1937-38	All	WASHER, transmission pilot bearing retainer	1	1299288	-----
1939 thru 54	All S.T.	-----	1	1299317	-----
Group 4.354 SEAL, TRANSMISSION MAIN DRIVE GEAR OIL					
1939 thru 42	P/6 taxi	-----	1	509217	-----
1946 thru 54	All S.T.	-----	1	509217	-----
Group 4.355 BEARING, TRANSMISSION FRONT					
1933 thru 35	All Type A	with cup (not sold separately) (see Note Group 4.003).....	1	590545	-----
1935 thru 54	All exc.	(see Note Group 4.003).....	1	954379	-----
	1935 Type A S.T.	-----			
Group 4.356 RETAINER, TRANSMISSION FRONT BEARING					
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590550	-----
1935-36	All Type B	(see Note Group 4.003).....	1	1293296	-----
		ring, see Group 4.361 for use.....		590548	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.358 GASKET, TRANSMISSION FRONT BEARING RETAINER						
1933 thru 35	All Type A	(see Note Group 4.003).....	4	590549	-----	
1935-36	All Type B	(see Note Group 4.003).....	1	1289458	-----	
Group 4.361 RING, TRANSMISSION FRONT BEARING SNAP						
1932	All		1	553435	-----	
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590548	-----	(4.356)
1935 thru 54	All exc.	(see Note Group 4.003).....	1	954145	-----	
1935 Type A S.T.						
1939 thru 54	All S.T.	RING PACKAGE, transmission snap	1	509517	-----	
		see Group 0.803 for use.....		1302021	-----	
Group 4.374 SLINGER, TRANSMISSION FRONT BEARING OIL						
1939 thru 42	P/6 taxi		1	1302020	-----	
1946 thru 54	All S.T.		1	1302020	-----	
Group 4.375 NUT, TRANSMISSION MAIN DRIVE GEAR LOCK						
1932, 1935-36	All Type B	(see Note Group 4.003).....	1	553502	-----	
Group 4.376 RETAINER-WASHER, TRANSMISSION FRONT BEARING						
1937 thru 54	All S.T.	RETAINER, front bearing washer	1	1321312	-----	
1937 thru 54	All S.T.	WASHER, front bearing retainer spring	1	1295397	-----	
Group 4.383 RETAINER, TRANSMISSION SYNCHRONIZER DRUM						
1932, 1935 thru 37	All Type B	third speed—small (see Note Group 4.003).....	1	1297433	-----	
1935 thru 37	All Type B	second speed—large (see Note Group 4.003).....	1	1297432	-----	
1938 thru 54	All S.T.	second and third speed.....	2	1310248	-----	
1935 thru 37	All Type B	RING, cushion spring (see Note Group 4.003)	1	1286010	-----	
		($\frac{5}{16}$ " x $3\frac{1}{4}$ " O.D.).....				
Group 4.384 DRUM, TRANSMISSION SYNCHRONIZER						
1932, 1935 thru 37	All Type B	large (see Note Group 4.003).....	1	1297852	-----	
1932, 1935 thru 37	All Type A	small third speed (see Note Group 4.003).....	1	553439	-----	
1933 thru 35	All Type A	front (see Note Group 4.003).....	1	590654	-----	
1938-39	All	second and third speed.....	2	1305659	-----	
1940 thru 54	All S.T.	second and third speed.....	2	1314659	-----	
Group 4.395 GEAR, TRANSMISSION MAIN SHAFT SECOND SPEED						
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590665	-----	
1935 thru 37	All Type B	(see Note Group 4.003).....	1	1295995	-----	
1938	All		1	1300478	-----	
1939	All		1	1307765	-----	
1940	All		1	1317585	-----	
1941 thru 54	All S.T.		1	1319471	-----	
Group 4.397 RING, MAIN SHAFT SECOND SPEED SLEEVE SNAP						
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590554	-----	
1935 thru 54	All exc.	(see Note Group 4.003).....	1	1287260	-----	
1935 Type A, S.T.						
Group 4.398 WASHER, TRANSMISSION SECOND SPEED GEAR THRUST						
1935 thru 54	All exc.	(see Note Group 4.003).....	1	1287808	-----	
1935 Type A, S.T.						
Group 4.403 SHAFT, TRANSMISSION MAIN						
1935-36	All Type B	(see Note Group 4.003).....($11\frac{1}{32}$ " overall)	1	1287295	-----	
1937-38	All	($10\frac{1}{16}$ " over-all)	1	1300025	-----	
1939	26	($23\frac{3}{8}$ " over-all)	1	1308370	-----	
1939 thru 48	All exc. 1939	($12\frac{1}{16}$ " over-all)	1	1308377	-----	
1949 thru 54	26 S.T. All S.T.		1	1333885	-----	
Group 4.404 WASHER, TRANSMISSION MAIN SHAFT TO UNIVERSAL JOINT						
1937-38	All	main shaft coupling.....	1	1298703	-----	
1949 thru 54	All S.T.	RING, trans. frt. U/J stop snap	1	1333886	-----	
1939 thru 54	All S.T.	WASHER PKG., main shaft	1	509518	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.406 WASHER, TRANSMISSION MAIN SHAFT THRUST					
1939 thru 54	All S.T.	-----	1	1308347	-----
Group 4.408 BEARING, TRANSMISSION MAIN SHAFT REAR					
1932 thru 54	All S.T.	-----	1	954387	-----
1948 thru 50	All H.T.	-----	1	903007	-----
1951 thru 54	All H.T.	-----	1	903006	-----
Group 4.409 SLEEVE, TRANSMISSION BEARING					
		see Group 4.335 for use.....		590567	-----
Group 4.412 RING, TRANSMISSION REAR BEARING SNAP					
1935 thru 54	All exc.	(see Note Group 4.003).....Front	1	1258832	-----
1935 thru 54	1935 Type A.S.T.	-----Rear	1	1308271	-----
1948 thru 50	All H.T.	retainer ring—horseshoe type.....	1	8607299	(4.128)
1950 thru 54	All H.T.	rear bearing to retainer.....	1	8612215	(4.128)
1951 thru 54	All H.T.	rear bearing to shaft.....	1	8612243	(4.128)
Group 4.413 SPRING, TRANSMISSION SYNCHRONIZER DETENT					
1935 thru 38	All Type B	(see Note Group 4.003).....	2-3	1300501	-----
Group 4.414 SLEEVE, SECOND AND HIGH SLIDING					
1935 thru 37	All Type B	(see Note Group 4.003).....	1	1295996	-----
1938	All	-----	1	1304521	-----
1939 thru 54	All S.T.	-----	1	1307805	-----
Group 4.417 GEAR, LOW AND REVERSE SLIDING					
1935 thru 38	All Type B	(see Note Group 4.003).....	1	1284124	-----
1939 thru 54	All S.T.	-----	1	1307764	-----
Group 4.421 GEAR PKG., TRANSMISSION COUNTERSHAFT					
1935 thru 38	All Type B	consists of 1—1302958 gear and 2—553433 washer (see Note Group 4.003).....	1	510847	-----
1939	All	-----	1	510848	-----
1940 thru 54	All S.T.	consists of 1—1310985 gear and 2—1309089 wshr.	1	510849	-----
Group 4.422 BUSHING, TRANSMISSION COUNTERSHAFT GEAR					
1935 thru 38	All Type B	front with spacer (see Note Group 4.003).....			-----
		-----L.H. spiral	1	1394370	-----
1935 thru 38	All Type B	rear (see Note Group 4.003).....R.H. spiral	1	553464	-----
1939	All	-----	2	1312520	-----
1940 thru 54	All S.T.	ROLLER BEARING PACKAGE , transmission counter- shaft, consists of 50 rollers.....Fr. & rr.	1	1394874	-----
Group 4.423 WASHER, COUNTER GEAR BEARING RETAINER					
1940 thru 54	All S.T.	-----Outer	2	1315274	-----
1941 thru 54	All S.T.	-----Inner	2	1319014	-----
Group 4.426 SPACER, TRANSMISSION COUNTERSHAFT GEAR					
1940	All	inside gear.....(4 ³¹ / ₃₂ " long)	1	1315287	-----
1941 thru 54	All S.T.	inside gear.....(4 ⁷ / ₈ " long)	1	1319013	-----
Group 4.428 COUNTERSHAFT, TRANSMISSION					
1932, 1935 thru 37	All Type B	(see Note Group 4.003).....(9 ¹ / ₃₂ " over-all)	1	553432	-----
1933 thru 35	All Type A	(see Note Group 4.003).....(8 ⁹ / ₁₆ " over-all)	1	590626	-----
1938	All	-----	1	1302157	-----
1939 thru 54	All S.T.	-----	1	1307848	-----
Group 4.429 LOCK, TRANSMISSION COUNTERSHAFT					
1939 thru 54	All S.T.	BALL , steel countershaft to case.....(1/4" dia.)	1	104918	(8.899)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.430 GEAR, REVERSE IDLER						
1935 thru 38	All Type B	(see Note Group 4.003).....	1	1283878	-----	
1939 thru 54	All S.T.	-----	1	1307851	-----	
Group 4.431 BUSHING, REVERSE IDLER GEAR						
1932, 1935 thru 38	All Type B	(see Note Group 4.003).....	2	553119	-----	
1939 thru 54	All S.T.	-----	2	1307898	-----	
Group 4.433 SHAFT, REVERSE IDLER GEAR						
1935 thru 38	All Type B	(see Note Group 4.003)..... (4 $\frac{15}{16}$ " over-all)	1	1284274	-----	
1939 thru 54	All S.T.	----- (4 $\frac{17}{32}$ " over-all)	1	1307847	-----	
Group 4.435 SCREW, REVERSE IDLER SHAFT LOCK						
1935 thru 38	All Type B	(see Note Group 4.003).....	1	553121	-----	
1933 thru 35	All Type A	(see Note Group 4.003).....	1	590543	-----	
1939	All L.H.D.	-----	1	1310732	-----	
1940 thru 54	All S.T.	PIN, reverse idler shaft lock	1	590832	-----	
Group 4.437 WASHER, REVERSE IDLER GEAR THRUST						
1935 thru 38	All Type B	(see Note Group 4.003)..... Rear	1	1282457	-----	
1935 thru 38	All Type B	(see Note Group 4.003)..... Front	1	1282458	-----	
1939 thru 54	All S.T.	-----	2	1307850	-----	
Group 4.442 WASHER, TRANSMISSION COUNTERSHAFT THRUST						
1932, 1935 thru 38	All Type B	(see Note Group 4.003).....	2	553433	-----	
1939	All	-----	2	1307850	-----	(4.437)
1940 thru 54	All S.T.	-----	2	1309089	-----	
Group 4.589 FLASHER, HAND BRAKE WARNING LAMP						
1952 thru 54	All	-----	1	516592	-----	
1952	All	SWITCH ASSY.	1	510963	-----	(10.275)
1953-54	All	-----	1	1998010	-----	
1953	All	HOUSING ASSY., w/lens	1	516931	-----	
1954	All	-----	1	517975	-----	
Group 4.591 LEVER—ROD ASSEMBLY, HAND BRAKE L.H.D.						
1937-38	All	-----	1	410749	-----	
1939-40	26	-----	1	504465	-----	
1941 thru 47	All	-----	1	505343	-----	
1948	All	-----	1	511033	-----	
1949 thru 51	All exc.	ROD ASSY., hand brake pull	1	516594	-----	
	2537-67	-----	1	514140	-----	
1949 thru 51	2537-67	w/chrome handle.....	1	516594	-----	
1952	All	-----	1	516996	-----	
1953-54	All	w/black handle.....	1	516193	-----	
1953	All	w/chrome handle—less cable.....	1	517961	-----	
1954	All "SD"	w/beige handle.....	1	517962	-----	
1954	All "SD"	w/red handle.....	1	517962	-----	
1954	All "SD"	w/yellow handle.....	1	517963	-----	
1953-54	All	SCREW, hand brake pull rod to inst. panel—special ...	2	516214	-----	
Group 4.595 PAWL, HAND BRAKE LEVER						
1934 thru 36	All	-----	1	496957	-----	
1938 thru 40	All exc.	for Type E lever.....	1	501420	-----	
	1940-25-29	-----	1	501727	-----	
1938-39	All L.H.D.	for Type F lever.....	1	504544	-----	
1940 thru 48	All	for Types G, I and K levers.....	1	506605	-----	
1941 thru 47	All	for Type L lever.....	2	3687878	-----	
1949 thru 52	All	pull rod—w/Type "A" rod.....	2	516197	-----	
1952	All L.H.D.	pull rod—w/Type "C" rod.....	1	516196	-----	
1953-54	All L.H.D.	pull rod—w/Type "D" rod.....	2	516197	-----	
1953-54	All L.H.D.	pull rod—w/Type "E" rod.....	1	504545	-----	
1940 thru 48	All	SLEEVE, brake lever pawl, for Type G and I lever ...	1		-----	
Group 4.596 RIVET, HAND BRAKE LEVER PAWL						
1940	All	for Type H and I levers..... (Rd. Hd. $\frac{5}{16}$ " x $\frac{5}{8}$ ")	1	104096	-----	(8.967)
1941 thru 47	All	for Type L lever.....	1	506608	-----	
1952	All L.H.D.	for Type "C" rod.....	2	516237	-----	
1953-54	All L.H.D.	for Type "E" rod.....	2	516237	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.597					
SPRING, HAND BRAKE LEVER PAWL					
1941 thru 47	All	for Type L lever.....	1	506734	-----
1949 thru 52	All	pull rod pawl—w/Type "A" rod.....	2	3687883	-----
1952 thru 54	All L.H.D.	pull rod pawl—w/Type "C" and "E" rod.....	2	516226	-----
1953-54	All	pull rod pawl—w/Type "D" rod.....	1	516228	-----
1936	All	SPRING, hand brake cable return	1	498950	-----
1937-38	All		1	500021	-----
1939-40	25-26 All		1	502738	-----
1940 thru 54	All exc. 1940		1	504661	-----
1949 thru 52	All L.H.D.	SPRING, hand brake pull rod handle return—			
		w/Type "A" rod.....	1	512556	-----
1949 thru 52	All L.H.D.	w/Type "B" and "C" rod.....	1	516597	-----
1953-54	All	w/Type "D" rod.....	1	516200	-----
1953-54	All	w/Type "E" rod.....	1	516199	-----
Group 4.603					
SECTOR, HAND BRAKE LEVER					
1937 thru 40	All exc.	for Type A lever on 1937, for Type E lever on 1938			
	1940 25-29	thru 40.....	1	500956	-----
1940	25-29 All	for Type G lever.....	1	504543	-----
1940	26 All	for Type I lever.....	1	504541	-----
1941 thru 48	All L.H.D.	for Type K lever.....	1	505345	-----
1941 thru 47	All L.H.D.	for Type L lever.....	1	506606	-----
1949 thru 51	All exc. 2537-	BRACKET ASSEMBLY, hand brake pull rod			
	67 L.H.D.	(Type B) painted.....	1	515945	-----
1949 thru 51	2537 & conv. All	(Type B).....	1	514141	-----
Group 4.608					
RIVET, HAND BRAKE LEVER SECTOR					
1938-39	All	lever to sector, for Type D lever.....	1	409198	----- (4.596)
1940	All	lever to sector, for type H and J levers.....			
		(Rd. Hd. $\frac{5}{16} \times \frac{5}{8}$).....	1	104096	----- (8.967)
1940 thru 48	All	lever to sector, for Type G, I and K levers.....			
		(Rd. Hd. $\frac{5}{8} \times \frac{1}{2}$).....	1	104109	----- (8.967)
1941 thru 47	All	lever to sector, for Type L lever.....	1	506607	-----
Group 4.625					
PEDAL, BRAKE (L.H.D.)					
1939-40	All exc. 1940 29		1	502131	-----
1941	25		1	505308	-----
1942 thru 48	26		1	507534	-----
1942 thru 48	25		1	507533	-----
1949 thru 53	All S.B.		1	507533	-----
1953-54	All P.B.		1	518315	-----
1954	All S.B.		1	518684	-----
1937-38	All	SHAFT, brake pedal	1	499868	----- (0.833)
1939 thru 54	All L.H.D.-S.B.		1	505310	----- (0.833)
1939 thru 42	All	PIN, brake pedal shaft (Grooved $\frac{1}{8} \times 1 \frac{1}{2}$)	1	142358	----- (8.940)
1940 thru 54	All exc.	RETAINER, brake pedal—			
	1940 25-26 S.B.	spring type..... ($\frac{3}{4}$ " dia. shaft)	1	142590	----- (8.934)
Group 4.626					
BUSHING, BRAKE PEDAL					
1937 thru 40	All		1	1266804	-----
Group 4.630					
PAD, BRAKE AND CLUTCH PEDAL RUBBER					
1935 thru 52	All		2	511028	-----
1953-54	All S.B.		2	494832	-----
1953-54	All P.B.		1	518318	-----
Group 4.634					
CLIP—BRACKET—BUSHING—WASHER, BRAKE PEDAL PIVOT					
1953-54	All P.B.	clip, pivot brkt. to strg. col.....	1	518324	-----
1953-54	All P.B.	BRACKET AND SHAFT	1	518319	-----
1953-54	All P.B.	BUSHING	1	518322	-----
1953-54	All P.B.	WASHER, pedal retaining	1	518323	-----
Group 4.639					
SPRING, BRAKE PEDAL RETURN					
1935-36	All		1	497526	-----
1939-40	All exc.		1	500021	----- (4.597)
	1940-25				
1941	All L.H.D.		1	500021	----- (4.597)
1942 thru 54	All S.B.		1	500021	----- (4.597)
1953-54	All P.B.	anti-rattle.....	1	518510	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.649 REPAIR KIT, BRAKE MASTER CYLINDER					
NOTE: The kit consists of valve, spring, cup, piston, boot, ring, washers and gaskets.					
1935	All	-----	1	5450414	-----
1936 thru 54	All	-----	1	5453950	-----
Group 4.650 CYLINDER ASSEMBLY, BRAKE MASTER					
1935-36	All L.H.D.	-----	1	5450377	-----
1937 thru 54	All S.B.	-----	1	5450208	-----
1938 thru 54	All S.B.	BODY , brake master cylinder.....	1	5450162	-----
Group 4.651 CAP ASSY., MASTER CYLINDER FILLER					
1935 thru 54	All S.B.	-----	1	086958	-----
1935 thru 54	All S.B.	GASKET , master cylinder filler cap.....	1	080445	-----
		see Group 14.482 for use.....		043234	-----
Group 4.652 NUT, MASTER CYLINDER HEAD					
1938 thru 54	All S.B.	with valve washer.....	1	5450615	-----
1938 thru 54	All S.B.	GASKET , master cylinder head nut.....	1	5450212	-----
Group 4.654 CUP, MASTER CYLINDER PISTON					
1935 thru 54	All S.B.	primary.....	1	5450617	-----
1935 thru 54	All S.B.	secondary.....	1	231432	-----
Group 4.655 SPRING, MASTER CYLINDER PISTON					
1935 thru 54	All	-----	1	5451121	-----
Group 4.656 RING, MASTER CYLINDER PISTON LOCK					
1935 thru 54	All S.B.	-----	1	231435	-----
1938 thru 54	All	PLATE , master cylinder push rod stop.....	1	1074927	-----
Group 4.657 VALVE ASSEMBLY, MASTER CYLINDER CHECK					
1935 thru 54	All S.B.	-----	1	5453711	-----
1935 thru 37	All	WASHER , master cylinder valve seat, flanged rim.....	1	231454	-----
1935 thru 54	All S.B.	1935 thru 37 where washer fits on flanged head nut.....	1	5450150	-----
Group 4.658 ROD, MASTER CYLINDER PUSH					
1936 thru 54	All S.B.	use 1—1074927 when using on 1936 & 37 models.....	1	5450077	-----
1936 thru 54	All	NUT , master cyl. push rod..... ($\frac{3}{8}$ "-24)	1	124925	-----
Group 4.659 BOOT, MASTER CYLINDER END					
1936 thru 54	All S.B.	-----	1	5450551	-----
Group 4.661 BOLT-CONNECTOR, MASTER CYLINDER PIPE CONNECTOR					
1935 thru 48	All	BOLT , connector.....	1	5300863	-----
1949 thru 54	All	-----	1	512270	-----
1935 thru 48	All	ADAPTER , master cylinder outlet connector.....	1	497751	-----
1935 thru 41	All exc.	CONNECTOR , master cylinder outlet.....	1	497753	-----
	1940 29	-----			
1940, 1942 thru 48	All exc.	-----	1	476745	-----
	1940 25-26	-----			
1949 thru 53	All L.H.D.	-----	1	512570	-----
1954	All L.H.D.	-----	1	518393	-----
1954	All L.H.D.	CONNECTOR BLOCK AND BRACKET , brake pipe.....	1	518406	-----
1935 thru 54	All	GASKET , master cylinder pipe connector..... Large	1	799390	-----
1935 thru 54	All	Small	1	799303	-----
Group 4.662 CLEVIS, MASTER CYLINDER CONNECTING ROD					
1939-40	25-26 All	----- ($\frac{3}{8}$ "-24)	1	104038	-----
1940-41	All exc. 1940	pedal to push rod.....	1	412268	-----
	25-26	-----			
1942 thru 54	All S.B.	pedal to push rod.....	1	507535	-----
1935 thru 39	All	PIN , master cylinder conn. rod clevis..... ($\frac{1}{16}$ "x1 $\frac{15}{16}$ ")	1	103497	-----
1940 thru 54	All	($\frac{3}{8}$ "x1 $\frac{3}{4}$ ")	1	138084	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.663 COVER—GASKET, MASTER CYLINDER					
Group 4.664 WASHER					
		see Group 2.333 for use.....		365685	-----
Group 4.665 CYLINDER ASSEMBLY, WHEEL BRAKE					
1937 thru 41	All	Front 1" bore R.H.	1	5450406	-----
1937 thru 41	All	Front 1" bore L.H.	1	5450407	-----
1942 thru 54	All	Front 1 1/16" bore R.H.	1	5450662	-----
1942 thru 54	All	Front 1 1/16" bore L.H.	1	5450663	-----
1935 thru 48	All	Rear 1 5/16" bore R.H.	1	5450400	-----
1935 thru 48	All	Rear 1 5/16" bore L.H.	1	5450401	-----
1949 thru 54	All	Rear 7/8" bore R.H.	1	5450994	-----
1949 thru 54	All	Rear 7/8" bore L.H.	1	5450995	-----
Group 4.666 VALVE, WHEEL CYLINDER BLEEDER					
1935 thru 54	All		4	1074893	-----
1935 thru 53	All	SCREW , wheel cylinder valve bleeder (No. 10-32x1/4")	4	132892	----- (8.906)
1954	All		4	5454315	-----
Group 4.667 CUP, WHEEL CYLINDER RUBBER					
1935-36	P/8, P/6 "D"	Front (1" dia.)	4	231333	-----
P/6 1935 mstr. to ser. 6AB8255					
1935-36	P/6 1935 after ser. 6AB8255, P/6 1936 mstr.	Front (1 5/16" dia.)	4	1409133	-----
1935 thru 48	All	Rear (1 5/16" dia.)	4	1409133	-----
1937 thru 41	All	Front (1" dia.)	4	231333	-----
1942 thru 54	All	Front (1 1/16" dia.)	4	1409123	-----
1949 thru 54	All	Rear (7/8" dia.)	4	5453701	-----
Group 4.667 REPAIR KIT, WHEEL CYLINDER					
1935-36	P/6 1935 mstr. to ser. 6AB8256, all knee action	Front	2	5450425	-----
1937 thru 41	All	Front	2	5450425	-----
1942 thru 54	All	Front	2	5451074	-----
1935 thru 48	All	Rear	2	5450424	-----
1949 thru 54	All	Rear	2	5453710	-----
NOTE: The above repair kits consist of 2 cups and 2 boots.					
Group 4.668 PISTON, WHEEL CYLINDER					
1936 thru 41	All	Front (1" dia.)	4	231334	-----
1942 thru 54	All	Front (1 1/16" dia.)	4	1409125	-----
1935 thru 48	All	Rear (1 5/16" dia.)	4	1409124	-----
1949 thru 54	All	Rear (7/8" dia.)	4	5453700	-----
Group 4.669 SPRING, WHEEL CYLINDER PISTON					
1935 thru 41	All	Front or rear	2-4	1074914	-----
1942 thru 54	All	Front	2	1074946	-----
1942 thru 48	All	Rear	2	1074914	-----
1949 thru 54	All	Rear	2	5453702	-----
Group 4.670 BOOT, WHEEL CYLINDER					
1935 thru 41	All	Front	4	231335	-----
1935 thru 54	All	Rear	4	231335	-----
1942 thru 54	All	Front	4	5450031	-----
Group 4.671 WASHER, FRONT BRAKE PIPE TO CONNECTOR					
1935 thru 54	All	pipe connector and front hose, small.....	2-5	231343	-----
Group 4.675 LINK, WHEEL CYLINDER CONNECTING					
1935 thru 54	All		8	509233	-----
Group 4.680 HOSE, BRAKE					
1935-36	All	Front and rear	3	476719	-----
1937-38	All	Front	2	500124	-----
1939 thru 48	All	Front	2	503925	-----
1949 thru 52	All	Front	2	511638	-----
1937 thru 54	All	Rear	1	476719	-----
1953-54	All	Front	2	515314	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.681					
		BRACKET, BRAKE HOSE OR PIPE			
1940 thru 48	25-All	rear hose to frame.....	1	504088	-----
1940 thru 48	All 26-29	-----	1	504089	-----
	exc. 1940 26				
1949 thru 54	All	rear hose to frame.....	1	511636	-----
1949 thru 52	All	front hose to frame.....	2	511647	-----
1953-54	All	front hose to frame.....	2	515371	-----
1935 thru 54	All	YOKE, brake hose to frame retainer.....	3	709818	-----
Group 4.683					
		FLUID, HYDRAULIC BRAKE			
1935 thru 54	All	pint (super 9).....	AR	5450287	-----
1935 thru 54	All	quart (super 9).....	AR	5450285	-----
1935 thru 54	All	gallon (super 9).....	AR	5450286	-----
1935 thru 54	All	5 gallons (super 9).....	AR	5450288	-----
1935 thru 54	All	30 gal. drum (super 9).....	AR	5450920	-----
1935 thru 54	All	pint (super 11).....	AR	5453723	-----
1935 thru 54	All	quart (super 11).....	AR	5453724	-----
1935 thru 54	All	gallon (super 11).....	AR	5451232	-----
1935 thru 54	All	5 gallons (super 11).....	AR	5451233	-----
1935 thru 54	All	FLUID, brake flushing—quart (Declene).....	AR	5450412	-----
1935 thru 54	All	LUBRICANT, brake, Delco (1 pound can).....	AR	5450032	-----
Group 4.685					
		PIPE, MASTER CYLINDER TO FRONT BRAKE			
1939-40	All L.H.D. exc.	to front pipe tee.....	1	504270	-----
	1939 25, 1940 29				
1941 thru 48	25 L.H.D.	to front pipe tee.....	1	505454	-----
1941 thru 48	All L.H.D. exc.	to front pipe tee.....	1	505455	-----
	25-29				
1954	All S.B.	master cylinder to connector block.....	1	518338	-----
1939 thru 48	All L.H.D.	PIPE, front brake.....	R.H.	502655	-----
1939 thru 48	All L.H.D.	-----	L.H.	502657	-----
1949 thru 52	All L.H.D.	-----	R.H.	512077	-----
1949 thru 52	All L.H.D.	-----	L.H.	512078	-----
1953	All L.H.D.	-----	R.H.	515619	-----
1953	All L.H.D.	-----	L.H.	515620	-----
1954	All	connector block to front brake.....	R.H.	518332	-----
1954	All	connector block to front brake.....	L.H.	518333	-----
1939-40	26 L.H.D.	PIPE, master cylinder to rear brake.....	1	502669	-----
1941	25 L.H.D.	-----	1	505463	-----
1941	26-29 L.H.D.	-----	1	506012	-----
1942 thru 48	25 L.H.D.	-----	1	507493	-----
1942 thru 48	26 L.H.D.	-----	1	507494	-----
1949 thru 52	All L.H.D.	-----	1	512085	-----
1953	All L.H.D.	-----	1	515373	-----
1954	28 All	connector block to rear brake pipe.....	1	517567	-----
1954	25 All L.H.D.	connector block to rear brake pipe.....	1	518336	-----
1939-40	All	connector to wheel cyl.....	L.H.	502661	-----
1941 thru 48	All	connector to wheel cyl.....	R.H.	505430	-----
1941 thru 48	All	connector to wheel cyl.....	L.H.	505431	-----
1949 thru 54	All	connector to wheel cyl.....	R.H.	512081	-----
1949 thru 54	All	connector to wheel cyl.....	L.H.	512082	-----
1935 thru 54	All	CLIP, master cylinder to brake pipe and frame, snap spring.....	AR	148129	----- (8.950)
1935 thru 54	All	NUT, front and rear brake pipe..... (1/4")	AR	137397	----- (8.963)
Group 4.686					
		ADAPTER, WHEEL CYLINDER PIPE CONNECTOR			
1937 thru 48	All	brake hose to axle.....	Rear	1	709819
1949 thru 54	All	brake hose to axle.....	Rear	1	512564
1937 thru 48	All	brake pipe.....	Front	1	503225
Group 4.687					
		SCREW, HOSE CONNECTOR BREATHER			
1937 thru 54	All	-----	1	231915	-----
		see Group 4.104 and 5.387 for use.....		498373	-----
Group 4.700					
		LEVER ASSY., HAND BRAKE DASH			
1953-54	All	-----	1	516217	-----
1953-54	All L.H.D.	BRACKET, hand brake dash lever.....	1	516223	-----
1953-54	All	CABLE ASSY., hand brake dash lever—			
		w/Type "D" rod.....	1	516215	-----
1953-54	All	GROMMET, hand brake pull rod cable—at dash.....	1	4597177	-----
1953-54	All	PIN, hand brake dash lever to bracket clevis.....	1	516209	-----
1953-54	All	hand brake dash lever sheave to lever clevis.....	1	516205	-----
1953-54	All	RING, hand brake cable to pull rod retainer—			
		w/Type "D" rod.....	1	516198	-----
1953-54	All	SHEAVE ASSY., hand brake dash lever.....	1	516220	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.764 LEVER, HAND BRAKE INTERMEDIATE						
1937-38	All L.H.D.	-----	1	500019	-----	
1940 thru 52	All exc. 1940	-----	1	505490	-----	
	25-26	-----				
1953-54	All	-----	1	515369	-----	
Group 4.765 EQUALIZER, HAND BRAKE						
1937-38	All	ROD , hand brake cable adjusting.....	1	500020	-----	
1939 thru 54	All	CLEVIS , hand brake rear cable.....	1	502707	-----	
1939 thru 54	All	PIN , hand brake rear cable clevis.....	1	502725	-----	
1940 thru 48	All	PIN , cable to lever.....	1	504411	-----	
1949 thru 54	All	-----	1	502725	-----	
1941 thru 48	25 All	HOOK , hand brake intermediate lever support.....	1	505434	-----	
1941 thru 48	26-29 All	-----	1	505361	-----	
1949 thru 54	All	-----	1	511657	-----	
Group 4.779 CABLE ASSEMBLY, BRAKE						
1937-38	All	hand brake front.....	1	500018	-----	
1940	26 L.H.D.	-----	1	504442	-----	
1940	29 All	-----	1	504444	-----	
1941 thru 48	25 All	-----	1	506440	-----	
1941 thru 48	26-29 All	-----	1	505767	-----	
1949 thru 52	All	-----	1	513644	-----	
1953-54	All	-----	1	516210	-----	
1940	29 All	CABLE ASSY. , cross lever to rear brake.....	1	504105	-----	
1941 thru 48	25 All	-----	1	505428	-----	
1941 thru 48	26-29 All	-----	1	505429	-----	
1949	All	-----	1	512040	-----	
1950 thru 52	All	-----	1	513643	-----	
1953-54	25 All	-----	1	515372	-----	
1954	28 All	-----	1	517566	-----	
Group 4.781 CLEVIS, HAND BRAKE ROD OR CABLE						
1935 thru 48	All	cable adjusting.....	4	116535	-----	(8.946)
1941 thru 54	All	cable to intermediate lever.....	1	178287	-----	(8.946)
Group 4.784 FELT, HAND BRAKE CABLE ANCHOR						
1934 thru 54	All	-----	2	496342	-----	
Group 4.785 CLAMP, HAND BRAKE CABLE						
1937 thru 48	All	cable to frame bracket.....	2	502806	-----	
Group 4.785 ANCHOR, BRAKE CABLE TO FRAME						
1939-40	All exc.	hand brake.....	Front	1	502739	-----
1940	25 L.H.D.	hand brake.....	Front	1	502740	-----
1941 thru 54	All L.H.D.	hand brake.....	Rear	1	502739	-----
1953-54	All L.H.D.	hand brake.....	Front	1	516211	-----
1953-54	All	RETAINER , hand brake cable to frame				
		front anchor.....	1	516213	-----	
1939-40	26 All	ANCHOR , rear brake cable to frame.....	L.H.	1	502704	-----
1940	25 All	-----	L.H.	1	504204	-----
1940	29 All	-----	R.H.	1	504083	-----
1940	29 All	-----	L.H.	1	504084	-----
1941 thru 48	26-29 All	-----	R.H.	1	504083	-----
1941 thru 48	26-29 All	-----	L.H.	1	504084	-----
1941 thru 48	25 All	-----	R.H.	1	505426	-----
1941 thru 48	25 All	-----	L.H.	1	505427	-----
1949 thru 52	All	-----	R.H.	1	511634	-----
1949 thru 52	All	-----	L.H.	1	511635	-----
1949 thru 54	All	YOKE , rear brake cable to brkt.....	2	709818	-----	(4.681)
Group 4.786 ANCHOR, BRAKE CABLE TO SUPPORT						
1936 thru 40	All exc. 1940	-----	2	499055	-----	
1940	29 All	-----	R.H.	1	504086	-----
1940	29 All	-----	L.H.	1	504087	-----
1941 thru 52	All	-----	R.H.	1	504086	-----
1941 thru 52	All	-----	L.H.	1	504087	-----
1953-54	All	hand brake rear cable to rear brake.....	R.H.	1	516419	-----
1953-54	All	-----	L.H.	1	516420	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 4.823 PIN, BRAKE CLEVIS						
1939 thru 48	All	hand brake cable.....($\frac{5}{16}$ " x $\frac{1}{2}$ ")	2	116445	-----	(8.942)
Group 4.898 BRACKET—PLATE, VACUUM CYLINDER MOUNTING						
1953-54	All P.B.	BRACKET.....	1	517750	-----	
1953-54	All P.B.	PLATE.....	1	518294	-----	
Group 4.901 CYLINDER ASSY., VACUUM POWER BRAKE						
1953-54	All P.B.		1	517751	-----	
Group 4.902 TANK, VACUUM RESERVE						
1953-54	All P.B.		1	518314	-----	
Group 4.904 GASKET—PLATE, VACUUM POWER BRAKE CYLINDER						
Group 4.910 GASKET—SEAL, VACUUM CYLINDER TO HYDRAULIC CYLINDER						
Group 4.913 AIR CLEANER PARTS, VACUUM POWER BRAKE CYLINDER						
Group 4.915 PLUNGER, VACUUM POWER BRAKE HYDRAULIC CYLINDER						
Group 4.916 CUP, VACUUM POWER BRAKE HYDRAULIC CYLINDER						
Group 4.917 RETAINER—RING—WASHER, VACUUM POWER BRAKE CYLINDER						
Group 4.922 PISTON, POWER BRAKE VACUUM CYLINDER						
Group 4.924 COVER—RETAINER—SPRING, VACUUM POWER BRAKE CYLINDER						

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 4.926 PIN, VACUUM CYLINDER PUSH ROD					
1953-54	All P.B.	-----	1	517752	-----
Group 4.930 FITTING—PIPE, VACUUM POWER BRAKE					
1953-54	All P/6-P.B.	manifold to check valve—front.....(3 $\frac{7}{8}$ " long)	1	518399	-----
1953-54	All P/8-P.B.	manifold to check valve—front.....(6" long)	1	518398	-----
1953-54	All P.B.	reserve tank to check valve tee.....(13 $\frac{1}{2}$ " long)	1	518395	-----
1953-54	All P.B.	vacuum cyl. to connector block.....(11" long)	1	518394	-----
1953-54	All P.B.	manifold to check valve—rear.....(2" long)	1	518402	-----
1953-54	All P.B.	vacuum cyl. to check valve.....(28" long)	1	518403	-----
Group 4.931 CLAMP—HOSE, VACUUM POWER BRAKE					
1953-54	All P.B.	CLAMP(1 $\frac{1}{16}$ ")	AR	111603	----- (1.166)
1953-54	All P.B.	(9 $\frac{9}{16}$ ")	AR	187011	-----
1953-54	All P.B.	HOSE , manifold to check valve pipe.....	1	518405	-----
1953-54	All P.B.	reserve tank to check valve pipe.....(7 $\frac{1}{2}$ " long)	1	518509	-----
Group 4.944 GASKET, VACUUM POWER BRAKE CHECK VALVE					
Group 4.955 VALVE ASSY., VACUUM POWER BRAKE CHECK					
1953-54	All P.B.	-----	1	518401	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.001 SUPPORT ASSEMBLY, FRONT BRAKE					
1939 thru 41	All	-----	2	502329	-----
1942 thru 48	All	----- R.H.	1	509213	-----
1942 thru 48	All	----- L.H.	1	509214	-----
1949 thru 54	All	----- R.H.	1	513035	-----
1949 thru 54	All	----- L.H.	1	513036	-----
1939 thru 41	All	SUPPORT ASSEMBLY, rear brake ----- R.H.	1	509278	-----
1939 thru 41	All	----- L.H.	1	509279	-----
1949 thru 54	All	----- R.H.	1	509278	-----
1949 thru 54	All	----- L.H.	1	509279	-----
1942 thru 48	All	----- R.H.	1	509215	-----
1942 thru 48	All	----- L.H.	1	509216	-----
Group 5.002 BOLT, FRONT BRAKE SUPPORT TO KNUCKLE					
1937 thru 54	All	wheel stop-----	2	502322	-----
1939 thru 54	All	----- (Hex. $\frac{1}{16}$ "-20x2 $\frac{3}{4}$ ")	6	502321	-----
1939 thru 48	All	NUT, support to knuckle bolt ----- (Hex. $\frac{1}{16}$ "-20)	4	120370	(8.915)
1937 thru 54	All	SPACER, front brake support to knuckle -----	4	556941	-----
Group 5.017 SHOE AND LINING PACKAGE, BRAKE (For Two Wheels)					
NOTE: Consists of 2 primary and 2 secondary shoe and lining assemblies.					
1936 thru 38	All	----- Front or rear	2	509133	-----
1939 thru 41	All	----- Front or rear	2	514475	-----
1942 thru 48	All	----- Front	1	516552	-----
1942 thru 54	All	----- Rear	1	514475	-----
1949 thru 54	All	----- Front	1	514472	-----
1941	All	.030 O.S.----- Front or rear	1	516535	-----
1942 thru 48	All	.030 O.S.----- Front	1	516557	-----
1942 thru 54	All	.030 O.S.----- Rear	1	516535	-----
1949 thru 54	All	.030 O.S.----- Front	1	516530	-----
Group 5.018 BRAKE LINING PACKAGE, HALF SET (For Two Wheels)					
1935	All	----- Front or rear	2	504182	-----
1936 thru 38	All	----- Front or rear	2	509130	-----
1939 thru 41	All	----- Front or rear	2	516543	-----
1942 thru 54	All	----- Rear	1	516543	-----
1942 thru 48	All	----- Front	1	516562	-----
1949 thru 54	All	----- Front	1	516540	-----
1941	All	.030 O.S.----- Front or rear	1	516549	-----
1942 thru 48	All	.030 O.S.----- Front	1	516565	-----
1942 thru 54	All	.030 O.S.----- Rear	1	516549	-----
1949 thru 54	All	.030 O.S.----- Front	1	516546	-----
Group 5.019 RIVET, BRAKE SHOE LINING					
1934 thru 48	All	-----	80	413901	-----
Group 5.022 GASKET, REAR BRAKE TO AXLE HOUSING					
1937 thru 54	All	-----	2	231888	-----
Group 5.024 BOLT, REAR BRAKE PLATE TO AXLE HOUSING					
1937 thru 54	All	----- (Spec. $\frac{3}{8}$ "-24x1")	8	414999	-----
Group 5.026 SPRING, BRAKE SHOE					
1934 thru 54	All	adjusting screw-----	4	493987	-----
1935 thru 38	All	anchor pin to shoe-----	8	497834	-----
1935-36	All	secondary—maroon-----	4	497833	-----
1937-38, 1942 thru 48	All	secondary—red-----	4	1415663	-----
1939 thru 54	All	shoe to anchor—green----- Front	4	508126	-----
1939 thru 51	All	shoe to anchor—green----- Rear	4	508126	-----
1951 thru 54	All	shoe to anchor—gray----- Rear	4	3694822	-----
Group 5.041 PIN, BRAKE SHOE HOLD-DOWN SPRING					
1935 thru 41	All	----- Front	4	5300962	-----
1942 thru 48	All	----- Front	4	412685	-----
1949 thru 54	All	----- Front	4	512132	-----
1935 thru 54	All	----- Rear	4	5300962	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 5.042 CUP, BRAKE SHOE HOLD-DOWN SPRING						
1934 thru 54	All	-----	8	493997	-----	
Group 5.043 SPRING, BRAKE SHOE HOLD-DOWN						
1934 thru 54	All	-----	8	231186	-----	
1935 thru 41	All	SPRING PACKAGE, for 1 wheel.....Front	2	510329	-----	
1935 thru 54	All	-----Rear	2	510329	-----	
1942 thru 48	All	-----Front	2	510330	-----	
1949 thru 54	All	-----Front	2	513399	-----	
Group 5.045 GUIDE, BRAKE SHOE ANCHOR PIN						
1935 thru 54	All	-----	4	497812	-----	
Group 5.050 ECCENTRIC, BRAKE SHOE						
1935 thru 38, 1942 thru 48	All	-----	4	497811	-----	
Group 5.053 SPACER, BRAKE SHOE ECCENTRIC						
1935 thru 38, 1942 thru 48	All	-----Front or rear	4	497831	-----	
Group 5.055 PIN, BRAKE SHOE ANCHOR						
1935 thru 54	All	with guide.....	4	502926	-----	
Group 5.056 WASHER, BRAKE SHOE ANCHOR PIN						
1934 thru 54	All	-----($\frac{5}{8}$ " heavy)	4	494177	-----	
Group 5.057 NUT, BRAKE SHOE ANCHOR PIN						
1935 thru 48	All	-----Front ($\frac{5}{8}$ "-18)	2	122021	-----	(8.915)
1935 thru 54	All	-----Rear ($\frac{5}{8}$ "-18)	2	122021	-----	(8.915)
1949 thru 54	All	-----Front	2	553746	-----	
Group 5.110 SCREW, BRAKE SHOE ADJUSTING						
1935 thru 54	All	-----	4	496351	-----	
Group 5.111 NUT, BRAKE SHOE ADJUSTING SCREW						
1935 thru 41	All	-----Front	2	509235	-----	
1935 thru 54	All	-----Rear	2	509235	-----	
1942 thru 54	All	-----Front	2	509208	-----	
1935 thru 41	All	SOCKET, brake shoe adjusting screw.....Front	2	509234	-----	
1935 thru 54	All	-----Rear	2	509234	-----	
1942 thru 54	All	-----Front	2	509209	-----	
Group 5.117 COVER, BRAKE ADJUSTER HOLE						
1932 thru 54	All	rubber plug.....	4	503630	-----	
Group 5.149 LEVER, HAND BRAKE ACTUATING						
1935 thru 38	All	-----Rear R.H.	1	1300430	-----	
1935 thru 38	All	-----Rear L.H.	1	1300431	-----	
1939 thru 54	All	-----Rear R.H.	1	509210	-----	
1939 thru 54	All	-----Rear L.H.	1	509211	-----	
Group 5.150 STRUT, REAR BRAKE LEVER TO SHOE						
1939 thru 54	All	-----	2	509212	-----	
Group 5.151 SPRING, REAR BRAKE ACTUATING LEVER						
1935 thru 38	All	to strut.....	2	231349	-----	
1935 thru 38	All	SPRING, rear brake lever to shoe strut.....	2	497815	-----	
1939 thru 54	All	-----	2	502327	-----	
1935 thru 38	All	WASHER, rear brake lever to shoe strut.....	2	509283	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.158 PIVOT, HAND BRAKE ACTUATING LEVER					
1935 thru 54	All	-----	2	502305	-----
1937 thru 54	All	WASHER, hand brake lever pivot spring	2	1300540	-----
Group 5.387 HOUSING ASSY., REAR AXLE					
1939	25 All	----- For bolted cover	1	501988	-----
1939-40	All exc. 1939 25	----- With welded cover	1	505032	-----
1941 thru 48	All	-----	1	505121	-----
1949	All	-----	1	511248	-----
1950 thru 54	All	-----	1	513615	-----
1937 thru 54	All	CAP, axle breather screw	1	498373	(4.687)
1937 thru 54	All	SCREW, axle breather and hose connector	1	231915	(4.687)
Group 5.394 RETAINER, REAR SPRING BUMPER					
1937 thru 53	All exc. 1940 29	-----	2	502257	-----
1940	29 All	-----	2	504221	-----
1954	All	-----	2	517532	-----
Group 5.395 BUMPER, REAR SPRING AXLE					
1939 thru 53	All	-----	2	502250	-----
1954	All	-----	2	517531	-----
1937 thru 53	All	BUMPER AND RETAINER PACKAGE, rear spring	2	510466	-----
Group 5.399 GASKET, REAR AXLE HOUSING COVER					
1937 thru 40	All	-----	1	231961	-----
Group 5.400 PLUG, REAR AXLE HOUSING FILLER					
1937 thru 49	All	-----	1	1330801	-----
1949 thru 54	All	used on cars with filler plug in diff. carrier	1	444788	-----
Group 5.401 GASKET, AXLE HOUSING FILLER PLUG					
1937 thru 49	All	----- (Rd. closed $\frac{3}{4}$ " I.D.)	1	113897	(8.955)
Group 5.420 SHAFT, REAR AXLE					
NOTE: Use 1-412111 Group 5.822 and 1-502070 Group 5.816 on 1937-38.					
1937 thru 40	All	----- (30 $\frac{1}{2}$ " over-all) R.H.	1	502063	-----
1937 thru 40	All	----- (30 $\frac{1}{2}$ " over-all) L.H.	1	502064	-----
1941 thru 48	All	----- (30 $\frac{1}{2}$ " over-all) R.H.	1	505118	-----
1941 thru 48	All	----- (30 $\frac{1}{2}$ " over-all) L.H.	1	505119	-----
1949 thru 54	All	----- (30 $\frac{1}{2}$ " over-all) R.H.	1	502063	-----
1949 thru 54	All	----- (30 $\frac{1}{2}$ " over-all) L.H.	1	502064	-----
Group 5.424 BRACKET, REAR WHEEL STATIC COLLECTOR					
1937 thru 54	All	-----	2	231895	-----
1937 thru 54	All	BRUSH, rear wheel static collector	2	1862394	-----
1937 thru 54	All	SPRING, rear wheel static collector	2	231896	-----
Group 5.447 BEARING, DIFFERENTIAL PINION FRONT					
1933 thru 36	All	-----	1	954452	-----
1937 thru 47	All	ball type	1	954780	-----
1947 thru 54	All	roller type	1	188963	-----
Group 5.452 SCREW, FRONT PINION BEARING LOCK					
1933 thru 47	All	with ball type pinion bearing	3	358073	-----
Group 5.453 SLEEVE, PINION BEARING LOCK					
1934 thru 36	All	-----	1	374633	-----
1937 thru 47	All	with ball type pinion bearing	1	499532	-----
1947 thru 54	All	SPACER, rear axle drive pinion bearing—with roller type pinion bearing	1	510424	-----
1947 thru 54	All	with roller type pinion bearing	1	510425	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes.
Group 5.460 SHIM, PINION BEARING ADJUSTING					
1937 thru 47	All	with ball type pinion bearing, front...(.012" plain)	AR	499528	-----
1937 thru 47	All	with ball type pinion bearing, front...(.015" copper)	AR	499529	-----
1937 thru 47	All	with ball type pinion bearing, front...(.018" plain)	AR	499530	-----
1939 thru 47	All	with ball type pinion bearing, front...(.014" blued)	AR	503063	-----
1947 thru 54	All	with roller type pinion bearing...(.002" plain)	AR	509263	-----
1947 thru 54	All	with roller type pinion bearing...(.003" blued)	AR	509264	-----
1947 thru 54	All	with roller type pinion bearing...(.004" copper)	AR	509265	-----
1947 thru 54	All	with roller type pinion bearing...(.005" plain)	AR	509266	-----
1947 thru 54	All	with roller type pinion bearing...(.010" plain)	AR	509267	-----
Group 5.468 SHIELD, FRONT PINION BEARING SPLASH					
1937 thru 47	All	with ball type pinion bearing.....	1	499519	-----
1947 thru 54	All	with roller type pinion bearing.....	1	506929	-----
Group 5.469 PACKING, PINION SHAFT					
1934 thru 36	All	used on axle 652951 and up on 1934.....	1	376024	-----
1937 thru 47	All	SEAL , front pinion bearing oil, with ball type pinion bearing.....	1	501839	-----
1947 thru 54	All	drive pinion oil, with roller type pinion bearing.....	1	506938	-----
Group 5.484 BEARING, DIFFERENTIAL PINION REAR					
1933 thru 35	All	used on 1935 P/8 to axle 1452022, P/6 to axle 1451985.....	1	901105	-----
1935-36	All	with 44-9 axle.....	1	379515	-----
1937 thru 47	All	ball type.....	1	107391	-----
1947 thru 54	All	roller type.....	1	188960	-----
Group 5.489 RING, DIFFERENTIAL REAR PINION BEARING LOCK					
1935 thru 47	All	except 44-9 axle on 1935-36 with N.D. bearing axle	1	377722	-----
Group 5.504 CARRIER ASSEMBLY, DIFFERENTIAL					
1939 thru 48	All	39-10 ratio.....	1	513351	-----
1939 thru 48	All	41-10 ratio.....	1	513349	-----
1939 thru 48	All	43-10 ratio.....	1	513350	-----
1939 thru 48	All	41-9 ratio.....	1	513352	-----
1948	All	40-11 ratio.....	1	513353	-----
1949 thru 54	All	41-10 ratio.....	1	513358	-----
1949 thru 54	All	40-11 ratio.....	1	513361	-----
1949 thru 54	All	39-10 ratio.....	1	513359	-----
1949 thru 54	All	43-10 ratio.....	1	513567	-----
1952 thru 54	All H.T.	40-13 ratio.....	1	516599	-----
1953-54	All H.T.	41-12 ratio.....	1	517841	-----
1954	All H.T.	42-13 ratio.....	1	518566	-----
Group 5.505 CARRIER AND CAP, DIFFERENTIAL					
1939 thru 47	All	with ball type pinion bearing.....	1	501825	-----
1947 thru 54	All	use w/513671 pkg. Group 5.506 on 1947-48.....	1	515458	-----
1947	All	PLUG , oil hole—with roller type pinion bearing.....($\frac{27}{64}$ " dia.)	1	506926	-----
1947 thru 54	All	($\frac{31}{64}$ " dia.)	1	510712	-----
Group 5.506 BOLT, DIFFERENTIAL CARRIER TO HOUSING					
1937 thru 48	All	(Hex. $\frac{3}{8}$ "-24x $\frac{7}{8}$ ")	10	181636	----- (8.900)
1949 thru 54	All	(Hex. $\frac{1}{16}$ "-20x1")	10	512389	-----
1939 thru 48	All	BOLT AND WASHER PKG. , carrier to housing (see note).....	1	513671	-----
1937 thru 54	All	BOLT , differential bearing cap.....	4	499515	----- (0.056)
NOTE: This package consists of 10 special bolts and lock washers to be used when 515458 carrier and cap is installed on 1947-48 models.					
Group 5.508 GASKET, DIFFERENTIAL CARRIER TO HOUSING					
1937 thru 48	All		1	501958	-----
1949 thru 54	All		1	512390	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.510 CASE, DIFFERENTIAL					
1937-38	All	-----	1	499508	-----
1939 thru 54	All	exc. 40-13, 41-12 and 42-13 ratio.....	1	501828	-----
1952 thru 54	All	use w/40-13, 41-12 and 42-13 ratio.....	1	503479	-----
Group 5.517 SHAFT, DIFFERENTIAL PINION					
1937-38	All	-----	1	499509	-----
1939 thru 54	All	-----	1	501833	-----
Group 5.518 SCREW, DIFFERENTIAL PINION SHAFT LOCK					
1933 thru 54	All	-----	1	472546	-----
Group 5.527 GEAR PACKAGE, DIFFERENTIAL					
1937 thru 54	All	consists of 2 side gears and 2 pinion gears.....	1	509520	-----
Group 5.529 RING GEAR AND PINION, DIFFERENTIAL					
NOTE: Use 125630 bearing when replacing 1935-36 gear and pinion. When changing gear ratio see Group 4.337 for proper speedometer gear.					
1935-36	All	RING GEAR AND PINION SET, 37-9 plain ratio			
		(see note).....	1	602476	-----
1937-38	All	35-8 ratio, Std.....	1	492198	-----
1939 thru 47	All	39-10 ratio, with ball type pinion bearing.....	1	513459	-----
1939 thru 47	All	41-10 ratio, with ball type pinion bearing.....	1	513458	-----
1939 thru 47	All	43-10 ratio, with ball type pinion bearing.....	1	513457	-----
1939 thru 47	All	41-9 ratio, with ball type pinion bearing.....	1	513456	-----
1947 thru 54	All	39-10 ratio, with roller type pinion bearing.....	1	516699	-----
1947 thru 54	All	41-10 ratio, with roller type pinion bearing.....	1	513462	-----
1947 thru 54	All	43-10 ratio, with roller type pinion bearing.....	1	513461	-----
1947 thru 49	All	41-9 ratio, with roller type pinion bearing.....	1	513460	-----
1948 thru 54	All	40-11 ratio.....	1	516700	-----
1952 thru 54	All H.T.	40-13 ratio.....	1	516701	-----
1953-54	All H.T.	41-12 ratio.....	1	517842	-----
1954	All H.T.	42-13 ratio.....	1	518565	-----
1939 thru 54	All	LUBRICANT, rear axle gear..... (2 qt. can)	AR	513379	-----
Group 5.531 BOLT, RING GEAR TO CASE					
1937 thru 52	All	exc. 40-13 ratio axle.....	12	514242	-----
1952	All	w/40-13 ratio axle.....	12	514243	-----
1953-54	All	exc. 40-13, 41-12 and 42-13 ratio axle.....	12	517082	-----
1953-54	All	w/40-13, 41-12 and 42-13 ratio axle.....	12	517083	-----
Group 5.536 BEARING, DIFFERENTIAL SIDE					
1933 thru 36	All	-----	2	902100	-----
1937 thru 54	All	-----	2	179243	-----
Group 5.537 NUT, DIFFERENTIAL SIDE BEARING ADJUSTING					
1939 thru 54	All	-----	2	515535	-----
Group 5.539 LOCK, DIFFERENTIAL SIDE BEARING ADJUSTING NUT					
1939 thru 54	All	-----	2	501806	-----
1933 thru 54	All	BOLT, adjusting nut lock..... (Hex. $\frac{5}{16}$ "-18x $\frac{5}{8}$ ")	2	180075	----- (8.900)
Group 5.542 WASHER, DIFFERENTIAL PINION THRUST					
1937 thru 54	All	-----	2	500517	-----
Group 5.543 WASHER, DIFFERENTIAL SIDE GEAR THRUST					
1937 thru 54	All	-----	2	513713	-----
Group 5.544 SHAFT, PROPELLER					
1937-38	All	Rear (40 $\frac{3}{8}$ " C to C of holes).....	1	500026	-----
1939	25 All	(54 $\frac{1}{8}$ " C to C of holes).....	1	502233	-----
1939	26 All	(47 $\frac{7}{8}$ " C to C of holes).....	1	502234	-----
1939	28 All	(43 $\frac{13}{16}$ " C to C of holes).....	1	502567	-----
1940	26 All	yellow color band.....	1	504630	-----
1940	28 All	red color band.....	1	504631	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.544 SHAFT, PROPELLER (Continued)					
1940	29 All	blue color band.....	1	504632	-----
1941 thru 48	25 S.T.	green color band.....	1	506065	-----
1941 thru 48	24-26 S.T.	yellow color band.....	1	506067	-----
1941 thru 48	27 S.T.	red color band.....	1	506066	-----
1941 thru 48	28-29 S.T.	blue color band.....	1	506068	-----
1948	25 H.T.	Saginaw type.....	1	510781	-----
1948	26 H.T.	Saginaw type.....	1	510782	-----
1949 thru 52	All	Saginaw type.....	1	511291	-----
1953-54	25 All	Saginaw type.....	1	515502	-----
1954	28 All	Saginaw type.....	1	517527	-----
Group 5.545 FLANGE, REAR UNIVERSAL JOINT					
1937 thru 40	All exc. 1940	-----	1	501777	-----
	2nd type				
1940 thru 47	All exc. 1940	daubed with red paint, with ball type pinion bearing	1	504740	-----
	1st type				
1947 thru 54	All	with roller type pinion bearing.....	1	506927	-----
1937-38	All	BOLT , front propeller shaft to universal joint.....	1	367266	(4.405)
1937	All	PIN , flange to propeller shaft groove.....	1	500789	-----
1937-38	All	RING , front propeller shaft snap.....	1	500798	-----
1937-38	All	WASHER , front propeller shaft to universal joint.....	1	500797	-----
Group 5.546 BOLT, PROPELLER SHAFT TO REAR COMPANION FLANGE					
1937 thru 54	All	-----	AR	505653	-----
Group 5.548 JOINT ASSEMBLY, UNIVERSAL					
1935-36	All	-----	1	600174	-----
1937-38	All	REPAIR KIT , universal joint..... Front or rear	1-2	516406	-----
1939 thru 54	All exc. 1940	----- Front	1	516405	-----
	with Mechanics type prop. shaft				
1939 thru 54	All exc. 1940	----- Rear	1	516406	-----
	with Mechanics type prop. shaft				
1940	All with Mechanics	----- Front or rear	1-2	509295	-----
Group 5.549 SPACER, REAR UNIVERSAL JOINT FLANGE					
1937 thru 47	All	with N.D. bearing axle.....	1	499551	-----
Group 5.550 PACKING, FRONT PROPELLER SHAFT					
1937-38	All	----- Felt	2	499915	-----
1937-38	All	SEAL , front propeller shaft..... Leather	1	500485	-----
Group 5.551 WASHER, FRONT PROPELLER SHAFT PACKING RETAINER					
1937-38	All	-----	1	499919	-----
Group 5.552 BUSHING, FRONT PROPELLER SHAFT					
1937-38	All	-----	1	499916	-----
Group 5.555 YOKE, FRONT UNIVERSAL JOINT					
1937-38	All	flange type.....	1	499922	-----
1939 thru 51	All	YOKE PACKAGE , front universal joint, with bearings, cork washers and attaching parts.....	1	506414	-----
1952 thru 54	All	front universal joint.....	1	516601	-----
1937-38	All	COUPLING AND GEAR , front propeller shaft splined	1	500027	-----
Group 5.556 SHIELD, TRANS. REAR BEARING SPLASH					
1939	26	-----	1	502239	(4.335)
1939 thru 54	All exc. 1939-26	-----	1	509500	(4.335)
Group 5.557 PLUG, FRONT UNIVERSAL JOINT DUST					
1939-40	All	----- (Cup type)	1	502237	-----
1941 thru 54	All	with Saginaw yoke..... (Cup type)	1	502237	-----
1941 thru 48	All	with mechanics yoke..... (Cup type)	1	506538	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.560 WASHER, UNIVERSAL JOINT					
1937 thru 51	All	cork.....	8	406813	-----
1952 thru 54	All	cork.....	8	5663699	-----
1937 thru 54	All	SHIELD , universal joint journal dust.....	8	406805	-----
1937-38	All	GASKET , front propeller shaft housing.....	1	499920	-----
Group 5.566 BEARING, UNIVERSAL JOINT					
1937 thru 51	All	round.....	AR	514270	-----
1952 thru 54	All	round.....	6	5664303	-----
1937 thru 51	All	trunnion, flanged type.....	Rear 8	406829	-----
1940	All	trunnion, with mechanic's joint.....	Front 2-4	406829	-----
1952 thru 54	All	flanged type.....	Rear 2	5663696	-----
Group 5.569 PLATE, UNIVERSAL JOINT FLANGE BOLT LOCK					
1937 thru 54	All	with Saginaw yoke.....	2-4	406822	-----
Group 5.578 JOURNAL ASSY., UNIVERSAL JOINT					
1937 thru 51	All	-----	2	406803	-----
1952-54	All	-----	2	5663692	-----
Group 5.586 PLATE, UNIVERSAL JOINT ROUND BEARING RETAINER					
1937 thru 54	All	Saginaw.....	AR	514393	-----
1937 thru 54	All	BOLT , universal joint round bearing lock.....	AR	406808	-----
1937 thru 54	All	LOCK , universal joint round bearing bolt, with Saginaw yoke.....	AR	1418080	-----
1941 thru 54	All	RING , universal joint bearing retainer, with mechanics' joint.....	6	506034	-----
Group 5.595 NUT, UNIVERSAL JOINT FLANGE TO PINION					
1937 thru 47	All	with ball type pinion bearing.....	1	499562	-----
1947 thru 54	All	with roller type pinion bearing—use with 513716.....	1	513715	-----
1947 thru 54	All	WASHER , drive pinion nut—use with 513715.....	1	513716	-----
Group 5.803 WHEEL, STEEL (PRIMED)					
1935-36	All	-----	5	499257	-----
1937	All	-----	5	500045	-----
1938	All	-----	5	501276	-----
1939 thru 48	All	-----	5	508847	-----
1949 thru 54	2561-62-71	-----	5	514007	-----
1949 thru 54	& All w/6 ply tires	-----	5	511927	-----
1949 thru 54	All exc. 2562-71	-----	5	511927	-----
1949 thru 54	& w/6 ply tires	-----	5	511927	-----
Group 5.809 DRUM, REAR WHEEL BRAKE					
1936	All	-----	2	498922	-----
1937-38	All	-----	2	499775	-----
1939 thru 54	All	use in sets only—optional with 409176, Kelsey-Hayes.....	2	505300	-----
1939 thru 54	All	use in sets only—optional with 505300, Motor Wheel.....	2	409176	-----
Group 5.810 SPRING PKG., BRAKE DRUM SILENCER					
1950 thru 54	All	consists of 6 retainers & 2 springs—for 2 wheels....	2	514278	-----
Group 5.811 GASKET, REAR BRAKE DRUM TO AXLE SHAFT					
1937 thru 54	All	----- (1/2" thick)	AR	499930	-----
Group 5.812 BOLT, WHEEL TO HUB					
1937 thru 54	All	R.H. thread.....	Rear 5	499542	-----
1937 thru 54	All	L.H. thread.....	Rear 5	499543	-----
1934 thru 54	All	BOLT , brake drum to axle shaft.....	4	501503	-----
1937 thru 54	All	WASHER , rear brake drum bolt..... (3/8" light)	4	110730	-----
Group 5.813 NUT, WHEEL HUB BOLT					
1937 thru 52	All	R.H. thread.....	10	405984	-----
1937 thru 54	All	L.H. thread.....	10	499550	-----
1953-54	All	R.H. thread.....	10	516637	-----

(8.931)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 5.815 DEFLECTOR, AXLE HOUSING OIL					
1937 thru 54	All		2	499928	-----
1937 thru 54	All	DRAIN, rear brake oil.....	2	499929	-----
Group 5.816 RETAINER, REAR WHEEL BEARING					
1937-38	All	inner bearing to shaft.....	2	499545	-----
1937 thru 54	All	outer bearing to housing.....	2	499932	-----
1939 thru 54	All	inner bearing to shaft.....	2	502070	-----
Group 5.819 GASKET, BRAKE DRUM OIL DEFLECTOR					
1937 thru 54	All	Rear	2	499933	-----
Group 5.822 SEAL, REAR WHEEL BEARING OIL					
1933 thru 36	All		2	592441	-----
1937-38	All	leather.....	2	232000	-----
1939 thru 54	All	leather.....	2	412111	-----
Group 5.842 WRENCH, WHEEL					
1937 thru 54	All	and jack handle.....	1	504564	-----
Group 5.855 BEARING ASSEMBLY, REAR WHEEL					
1937 thru 54	All		2	954172	-----
Group 5.858 CAP, WHEEL HUB OUTER					
1938	All		4	501269	-----
1939	All		4	502121	-----
1940	All		4	503581	-----
1941-42	All		4	916486	-----
1946	All		4	508607	-----
1947-48	All		4	509418	-----
1949-50 All std. & 2561-62 "D"			4	511541	-----
1951 thru 54 All std. & 2562 "D"			4	514588	-----
1953	All	CAP, simulated wire wheel hub.....	4	517702	-----
1954	All		4	517897	-----
1935	P/8, P/6 "D"	CAP, wheel hub inner.....Front	2	378117	-----
1937 thru 54	All	Front	2	499204	-----
1941 thru 48	2507-19-69, 2609 All	CAP, spare wheel hub.....	1	506080	-----
1953-54	All	COVER, simulated wire wheel.....	4	517701	-----
Group 5.858 DISC ASSY., WHEEL					
1949-50	All "D" exc. 2561-62-71	metal.....	4	512583	-----
1951	All "D" exc. 2562-71	metal.....	4	514789	-----
1952	All "D" exc. 2562-71	metal.....	4	516496	-----
1953	All "D" exc. 2562	metal.....	4	516696	-----
1954	All "D" exc. 2562	metal.....	4	517869	-----
Group 5.864 CLIP, WHEEL HUB CAP RETAINING					
1938	All		25	501273	-----
1939 thru 53	All		12	502122	-----
1954	All		15	564692	-----
Group 5.871 WHEEL DISC PARTS					
1948	All exc. sta. wag.	DISC, metal.....	5	510690	-----
1949 thru 54	All	PLUG, wheel—use w/chrome wheel disc.....	20	514896	-----
Group 5.875 EXTENSION, TIRE VALVE					
1949-50	All	with chrome wheel disc.....	5	513410	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.018 BOLT, STEERING KNUCKLE SUPPORT CLAMP						
1937 thru 54	All	-----	2	504348	-----	
Group 6.020 KNUCKLE, STEERING						
1937 thru 39	All	less nut.....	2	505009	-----	
1940 thru 54	All	less nut.....	2	503576	-----	
Group 6.021 BUSHING, STEERING KNUCKLE KING PIN						
1930 thru 32	All exc. P/6	-----	4	231905	-----	
1937 thru 39	All	-----	4	231905	-----	
1940 thru 52	All	-----	4	505330	-----	
1953-54	All	-----	4	503575	-----	
1934 thru 36	All exc. P/6 mstr.	BUSHING, backing plate hub.....	2	600864	-----	
Group 6.022 NUT, STEERING KNUCKLE						
1935 thru 54	All	-----	2	378137	-----	
Group 6.023 SUPPORT, STEERING KNUCKLE						
1937-38	All	-----R.H.	1	231848	-----	
1937-38	All	-----L.H.	1	231849	-----	
1939 thru 48	All	-----R.H.	1	419668	-----	
1939 thru 48	All	-----L.H.	1	419669	-----	
1949 thru 52	All	-----R.H.	1	511604	-----	
1949 thru 52	All	-----L.H.	1	511605	-----	
1953-54	All	-----R.H.	1	515210	-----	
1953-54	All	-----L.H.	1	515211	-----	
Group 6.024 BUSHING, STEERING KNUCKLE SUPPORT LOWER						
1937-38	All	-----	2	231983	-----	
1939 thru 54	All	-----	2	411147	-----	
Group 6.037 DEFLECTOR, FRONT WHEEL BEARING OIL						
1940 thru 54	All	front brake drum oil.....	2	504336	-----	
1937 thru 54	All	DRAIN, front brake oil.....	2	499879	-----	
Group 6.103 ARM, STEERING KNUCKLE						
1937-38	All	-----R.H.	1	231836	-----	
1937-38	All	-----L.H.	1	231837	-----	
1939 thru 48	All	-----R.H.	1	502022	-----	
1939 thru 48	All	-----L.H.	1	502023	-----	
1949 thru 52	All	-----R.H.	1	511338	-----	
1949 thru 52	All	-----L.H.	1	511339	-----	
1953-54	All	-----R.H.	1	515197	-----	
1953-54	All	-----L.H.	1	515198	-----	
Group 6.106 BOLT						
		See Group 7.418 for use.....		1266787	-----	
Group 6.111 COVER, TIE ROD DUST						
1939 thru 54	All	tie rod to steer. conn. rod.....	2	265765	-----	(6.886)
1937 thru 54	All	SEAL, tie rod ball dust cover.....	2	505007	-----	
Group 6.112 SPRING, TIE ROD DUST COVER						
1939 thru 54	All	-----	2	264949	-----	(6.888)
Group 6.166 SEAL, LOWER CONTROL ARM INNER BUSHING						
1938 thru 48	All	-----	4	411146	-----	
1949	All	steering knuckle support lower arm shaft.....	4	511452	-----	(6.178)
1937 thru 54	All	SEAL, knuckle support lower bushing.....	4	411382	-----	
Group 6.168 ARM, STEERING KNUCKLE SUPPORT LOWER						
1937-38	All	also use 231997 Group 6.169 on 1937...L.F. & R.R.	2	231995	-----	
1937-38	All	also use 231997 Group 6.169 on 1937...R.F. & L.R.	2	231994	-----	
1939 thru 48	All	-----R.H.	1	410944	-----	
1939 thru 48	All	-----L.H.	1	410945	-----	
1949 thru 52	All	-----R.H.	1	511601	-----	
1949 thru 52	All	-----L.H.	1	511602	-----	
1953-54	All	-----R.H.	1	515205	-----	
1953-54	All	-----L.H.	1	515206	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.168 ARM AND BUSHING PACKAGE, FRONT SUSPENSION						
1937-38	All	with seals, bushings and pin..... R.H.	1	503468	-----	
1937-38	All	with seals, bushings and pin..... L.H.	1	503469	-----	
1937-38	All	ADAPTER, control arm hydraulic reservoir cup.....	4	410757	-----	(8.984)
1937-38	All	CUP AND ADAPTER PKG., hydraulic reservoir grease.....	1	410756	-----	(8.984)
Group 6.169 BUSHING, LOWER CONTROL ARM INNER SHAFT						
1937-38	All	on 1937 with replaceable bushing.....	4	231997	-----	
1939 thru 54	All	-----	4	502721	-----	
Group 6.170 SHAFT PACKAGE, LOWER CONTROL ARM						
1939 thru 54	All	shaft with 2 bushings and 2 seals.....	2	511702	-----	
1949 thru 54	All	SEAL, steering knuckle support lwr. arm shaft bushing.....	4	511452	-----	(6.178)
Group 6.172 BOLT, LOWER CONTROL ARM SHAFT TO FRAME						
1937	All	-----	8	231515	-----	
1938 thru 54	All	-----	8	1298795	-----	
Group 6.174 PIN, LOWER CONTROL ARM PIVOT						
1937-38	All	-----	2	1328605	-----	
1939 thru 54	All	-----	2	412107	-----	
1937-38	All	NUT, lower control arm pivot pin.....	2	1325556	-----	
1939 thru 54	All	-----	2	412108	-----	
1939 thru 54	All	WASHER, lower control arm pivot lock.....	4	412170	-----	
Group 6.174 PIN PACKAGE, LOWER CONTROL ARM PIVOT						
1937-38	All	with pin, bushing, nut, washers and seals.....	2	1394944	-----	
1939 thru 54	All	with pin, bushing, nut, washers and seals.....	2	414226	-----	
Group 6.176 BUMPER, STEERING KNUCKLE SUPPORT ARM UPPER						
1937 thru 52	All	-----	2	3687670	-----	
1953-54	All	-----	2	516431	-----	
Group 6.177 BRACKET, FRONT WHEEL BUMPER STOP FRAME						
1939-40, 1949	25-26	----- R.H. or L.H.	2	501943	-----	
1940 thru 48	All	----- R.H.	1	501943	-----	
1940 thru 48	All exc. 1940	----- L.H.	1	504687	-----	
1950 thru 52	25-26	-----	2	513581	-----	
1953-54	All	----- R.H.	1	515067	-----	
1953-54	All	----- L.H.	1	515068	-----	
Group 6.178 PIN PKG., STEERING KNUCKLE SUPPORT UPPER PIVOT						
1937 thru 48	All	includes 2 bushings, 2 seals and 1 pin.....	2	506512	-----	
1949 thru 52	All	includes pin, bushing, seal, washer, nut.....	2	513376	-----	
1953-54	All	-----	2	517401	-----	
1937 thru 48	All	BOLT, upper control arm clamp..... (Hex. 3/8"-24x2")	2	181648	-----	(8.900)
1937 thru 48	All	SEAL, knuckle support upper bushing.....	4	411817	-----	
1949 thru 52	All	upper pivot pin.....	4	511452	-----	
1953-54	All	-----	4	515951	-----	
Group 6.178 ARM ASSY., STEERING KNUCKLE SUPPORT UPPER						
1949 thru 52	All	-----	2	511598	-----	
1953-54	All	-----	2	515200	-----	
1949 thru 52	All	BOLT, upper arm shaft.....	4	511454	-----	
1953-54	All	-----	4	515196	-----	
1949 thru 52	All	BUSHING, upper eccentric.....	2	511450	-----	
1953-54	All	-----	2	515194	-----	
1949 thru 52	All	BUSHING ASSY., upper arm shaft.....	4	511451	-----	
1953-54	All	-----	4	1456582	-----	
1949 thru 54	All	PIN, upper control arm pivot.....	2	412107	-----	(6.174)
1949 thru 54	All	NUT, upper cont. arm pivot pin.....	2	412108	-----	(6.174)
1949 thru 52	All	SEAL, upper arm shaft bushing.....	4	411146	-----	(6.166)
1953-54	All	-----	4	515951	-----	
1949 thru 52	All	SHAFT, strg., knuckle supt. upper arm.....	2	511453	-----	
1953-54	All	-----	2	515195	-----	
1949 thru 52	All	SHAFT PKG., steering knuckle support upper arm..	2	513375	-----	
1953-54	All	-----	2	517402	-----	
1950 thru 54	All	WASHER, upper control arm.....	4	412170	-----	(6.174)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
ARM ASSEMBLY, INTERMEDIATE STEERING					
1937-38	Group 6.179 All L.H.D.	-----	1	1298664	-----
WASHER, INTERMEDIATE STEERING ARM					
1937-38	All	-----Upper	1	1300178	-----
1937	All	-----Lower	1	1300203	-----
1938	All	-----Lower	1	1300922	-----
BUSHING, INTERMEDIATE STEERING ARM					
1937	All L.H.D.	-----	1	231941	-----
1937-38	All	SLEEVE, intermediate steering arm bushing.....	1	1394339	-----
BRACKET, INTERMEDIATE STEERING ARM FRAME					
1937-38	Group 6.186 All	-----	1	499703	-----
BOLT, INTERMEDIATE STEERING ARM PIVOT					
1937-38	Group 6.187 All	-----	1	1298766	-----
LOCK, INTERMEDIATE STEERING ARM PIVOT BOLT					
1937-38	Group 6.188 All	-----	1	499714	-----
PIN, STEERING KNUCKLE KING					
1937 thru 54	Group 6.203 All	-----	2	503577	-----
REPAIR KIT, KING PIN					
1937 thru 39	Group 6.203 All	consists of pins, bushings, bearings, plugs and lock pins.....	1	405085	-----
1940 thru 54	All	consists of pins, bushings, bearings, plugs and lock pins.....	1	504058	-----
BEARING, KING PIN THRUST					
1937 thru 54	Group 6.210 All	-----	2	230679	-----
SHIM, KING PIN THRUST BEARING					
1935 thru 54	Group 6.214 All exc. 1935-36 mstr.	.005" thick.....	AR	373481	-----
PIN, KING PIN LOCK					
1937 thru 54	Group 6.216 All	----- (1 $\frac{5}{8}$ " long)	2	514168	-----
PLUG, KING PIN BEARING EXPANSION					
1934 thru 36	Group 6.223 All exc. P/6 mstr.	-----	4	378143	-----
1937 thru 39	All	-----	4	562237	-----
1940 thru 54	All	-----	4	504688	-----
1934 thru 36	All exc. P/6 mstr.	RING, king pin bearing plug lock.....	4	378138	-----
ROD, TIE					
1937-38	Group 6.230 All	----- (20 $\frac{3}{8}$ " overall)	2	231549	-----
1939 thru 48	All	with ball..... (13 $\frac{1}{4}$ " overall)	2	264939	-----
1949 thru 52	All	ROD AND BALL ASSY., steering knuckle tie.....	2	5660367	-----
1953-54	All L.H.D.	----- R.H.	1	5663362	-----
1953-54	All	----- L.H.	1	5663358	-----
SLEEVE, TIE ROD ADJUSTER					
1939 thru 52	Group 6.232 All	----- (4 $\frac{1}{2}$ " overall)	2	264924	-----
1953-54	All	-----	2	5661925	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.233 END, TIE ROD						
1933 thru 36	All	groove on bottom.....(4 $\frac{1}{16}$ " overall) R.H.	1	374226	-----	
1933 thru 36	All	groove on bottom.....(4 $\frac{1}{16}$ " overall) L.H.	1	374227	-----	
1937-38	All	(4 $\frac{1}{8}$ " overall) R.H.	2	231948	-----	
1937-38	All	(4 $\frac{1}{8}$ " overall) L.H.	2	231949	-----	
1939 thru 52	All	(3 $\frac{1}{8}$ " overall) R.H.	1	266658	-----	
1939 thru 52	All	(3 $\frac{1}{8}$ " overall) L.H.	1	266657	-----	
1953-54	All	(3 $\frac{1}{8}$ " overall) R.H.	1	266657	-----	
1953-54	All	(3 $\frac{1}{8}$ " overall) L.H.	1	266658	-----	
Group 6.234 CLAMP, TIE ROD END						
1937 thru 52	All	-----	4	268237	-----	
1953-54	All	-----	4	5661926	-----	
Group 6.235 BOLT, TIE ROD						
1937 thru 48	All	end clamp.....(Hex. $\frac{5}{16}$ "-24x1 $\frac{1}{4}$ ")	4	181610	-----	(8.900)
1949 thru 54	All	tie rod clamp.....(Hex. $\frac{3}{8}$ "-24x1 $\frac{1}{2}$ ")	4	181643	-----	(8.900)
1937 thru 48	All	NUT, tie rod clamp bolt.....($\frac{5}{16}$ "-24)	4	125224	-----	(8.917)
1949 thru 54	All	tie rod clamp bolt.....($\frac{3}{8}$ "-24)	4	125233	-----	(8.917)
Group 6.241 SEAT, TIE ROD BALL						
1933 thru 38	All	-----	4	595586	-----	(6.874)
1939 thru 54	All	-----	4	264946	-----	(6.874)
Group 6.243 PLUG, TIE ROD END						
1933 thru 36	All	-----	2	335977	-----	(6.881)
Group 6.306 HUB AND DRUM, FRONT WHEEL BRAKE						
1937-38	All	with bearing cup.....R.H.	1	499771	-----	
1937-38	All	with bearing cup.....L.H.	1	499772	-----	
1939 thru 41	All	with bearing cup.....R.H.	1	505297	-----	
1939 thru 41	All	with bearing cup.....L.H.	1	505298	-----	
1942 thru 48	All	with bearing cup.....Kelsey-Hayes R.H.	1	507370	-----	
1942 thru 48	All	with bearing cup.....Kelsey-Hayes L.H.	1	507371	-----	
1942 thru 48	All	with bearing cup.....Motor-Wheel R.H.	1	509220	-----	
1949 thru 54	All	with bearing cup (see note).....Kelsey-Hayes R.H.	1	512141	-----	
1949 thru 54	All	with bearing cup (see note).....Kelsey-Hayes L.H.	1	512142	-----	
1949 thru 54	All	with bearing cup (see note).....Motor-Wheel R.H.	1	512143	-----	
1949 thru 54	All	with bearing cup (see note).....Motor-Wheel L.H.	1	512144	-----	
NOTE: Parts 512141, 512142 and 512143, 512144 are to be used in sets only. Each pair of hub and drum assemblies is optional with the other pair.						
Group 6.311 BEARING PACKAGE, FRONT WHEEL INNER						
1933 thru 39	All	consists of one each, cone, cup and balls.....	2	909002	-----	
1940 thru 54	All	consists of one each, cone, cup and balls.....	2	909052	-----	
Group 6.313 BEARING PACKAGE, FRONT WHEEL OUTER						
1933 thru 54	All	consists of one each, cone, cup and balls.....	2	909001	-----	
Group 6.314 CONE, FRONT WHEEL BEARING INNER						
1933 thru 39	All	-----	2	909502	-----	
1940 thru 54	All	-----	2	909552	-----	
Group 6.315 CONE, FRONT WHEEL BEARING OUTER						
1933 thru 54	All	-----	2	909501	-----	
Group 6.316 CUP, FRONT WHEEL BEARING INNER						
1933 thru 54	All	-----	2	909602	-----	
Group 6.317 CUP, FRONT WHEEL BEARING OUTER						
1933 thru 54	All	-----	2	909601	-----	
Group 6.318 BALLS AND SEPARATOR, FRONT WHEEL BEARING—INNER						
1933 thru 54	All	-----	2	909702	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.319 BALLS AND SEPARATOR, FRONT WHEEL BEARING—OUTER					
1933 thru 54	All	-----	2	909701	-----
Group 6.321 WASHER, STEERING KNUCKLE SPINDLE					
1933 thru 54	All	-----	2	3663991	-----
Group 6.326 SEAL ASSEMBLY, FRONT WHEEL HUB OIL					
1937 thru 39	All	-----	2	500257	-----
1940 thru 54	All	-----	2	504332	-----
1934 thru 36	All knee action	----- Inner	2	376033	-----
1934 thru 36	All knee action	----- Outer	2	376309	-----
Group 6.331 COLLECTOR, FRONT WHEEL STATIC					
1934 thru 54	All	-----	2	494786	-----
Group 6.335 BOLT, FRONT WHEEL HUB					
NOTE: See Group 5.813 for Hub Bolt Nut.					
1936	All	----- R.H.	6	498908	-----
1936	All	----- L.H.	6	498909	-----
1937 thru 54	All	----- R.H.	5	506051	-----
1937 thru 54	All	----- L.H.	5	506052	-----
Group 6.367 WEIGHT, WHEEL BALANCE					
1946 thru 54	All	1/2 oz.-----	AR	1318737	-----
1946 thru 54	All	1 oz.-----	AR	1318738	-----
1946 thru 54	All	1 1/2 oz.-----	AR	1318739	-----
1946 thru 54	All	2 oz.-----	AR	1318740	-----
1946 thru 54	All	2 1/2 oz.-----	AR	1318741	-----
1946 thru 54	All	3 oz.-----	AR	1318742	-----
1946 thru 54	All	3 1/2 oz.-----	AR	1330487	-----
1946 thru 54	All	4 oz.-----	AR	1330488	-----
1946 thru 54	All	5 oz.-----	AR	1330489	-----
1946 thru 54	All	6 oz.-----	AR	1330490	-----
Group 6.386 FLUID, SHOCK ABSORBER					
1934 thru 36	All	1 gal. can—for use in frt. suspension-----	AR	600658	-----
1934 thru 36	All	1 quart can—for use in frt. suspension-----	AR	603489	-----
Group 6.400 SEAL, FRONT WHEEL SUPPORT SHAFT					
1934 thru 36	All exc. P/6 Mstr.	----- Outer	2	592431	-----
Group 6.405 PACKING, FRONT WHEEL SUPPORT ARM					
1935-36	All exc. P/6 mstr.	----- Inner	2	378610	-----
Group 6.509 BOLT, STEERING GEAR					
1937 thru 48	All	gear to frame----- (Hex. 7/16"-14x3 1/2")	3	180162	----- (8.900)
1949 thru 54	All	gear to frame----- (7/16"-14x3 1/2" Cad.)	1	180162	----- (8.900)
1949 thru 54	All	gear to frame----- (7/16"-14x3" Cad.)	2	180160	----- (8.900)
Group 6.512 COVER, STEERING WHEEL HUB					
1949 thru 52	All "D"	----- Upper	1	512098	-----
1949 thru 52	All "D"	except w/direction signal-----	1	511735	-----
1953-54	All "D"	RING, steering wheel hub filler-----	1	515309	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.513 WHEEL, STEERING (DE LUXE)					
1942 thru 47	"D"	-----	1	511196	-----
1948	"D"	-----	1	511198	-----
1949-50	"D"	black	1	511645	-----
1950	2537 "SD"	rust color	1	513972	-----
1951	"D"	black	1	514645	-----
1951	2537 "SD"	blue	1	514337	-----
1952	2537 "SD"	green	1	516479	-----
1952	"D"	black	1	516478	-----
1953-54	"D"	black	1	515308	-----
1953	2537 "SD"	green	1	517176	-----
1954	"D"	blue	1	517755	-----
1954	"D"	green	1	517756	-----
1954	"SD"	coral red	1	518272	-----
1954	"SD"	beige	1	518273	-----
1954	"SD"	yellow	1	518274	-----
Group 6.513 WHEEL AND TRIM RING, STEERING (STANDARD)					
1939 thru 47	All	on 1939 thru 41 use 1-544408 pkg.	1	507490	-----
1948	All	-----	1	510641	-----
1949-50	All exc. 2561-62-67	-----	1	511643	-----
1949 thru 51	2561-62-67	-----	1	513264	-----
1951	All exc. 2562-67	-----	1	514839	-----
1952	All exc. 2562	-----	1	516486	-----
1952	2562	-----	1	516487	-----
1953	All exc. 2562-71	-----	1	515421	-----
1953	2562-71	-----	1	517178	-----
1954	2511-69	-----	1	517998	-----
1954	2562 All	-----	1	517999	-----
Group 6.514 RING, STEERING WHEEL TRIM					
1942 thru 52	All	standard wheel	1	507572	-----
Group 6.515 NUT, STEERING WHEEL					
1933 thru 38	All	-----	1	257720	-----
1939 thru 54	All	NUT, wheel to shaft (1/2"-20)	1	124934	(8.916)
1939 thru 54	All	spring lock (1/2"-20)	1	107825	(8.921)
1939 thru 54	All	WASHER, steering wheel to shaft	1	5665807	-----
		see Group 9.647 for use	1	597300	-----
Group 6.518 JACKET, STEERING COLUMN L.H.D.					
1937	All	cut off 3 3/4" from lower end on P/6	1	263573	-----
1939	All	-----	1	265083	-----
1940	25-26	-----	1	265870	-----
1940	29	-----	1	265864	-----
1941 thru 48	25 S.T.	-----	1	266992	-----
1941 thru 48	26-29 S.T.	-----	1	266916	-----
1948	25 H.T.	brown	1	5660053	-----
1948	26 H.T.	brown	1	5660071	-----
1949	All S.T.	-----	1	5660578	-----
1949	All H.T.	-----	1	5660574	-----
1950	All S.T.	-----	1	5661591	-----
1950	All H.T.	-----	1	5661605	-----
1951	All S.T.	-----	1	5662455	-----
1952	All S.T.	-----	1	5664227	-----
1951-52	All H.T.	-----	1	5664224	-----
1953	All S.S.	-----	1	5663317	-----
1954	All S.S.	-----	1	5666949	-----
1953	All P.S.	COVER ASSY., valve-w/steering column jacket	1	5680036	-----
1954	All P.S.	w/steering column jacket	1	5681348	-----
Group 6.519 ADAPTER, STEERING GEAR HOUSING UPPER BEARING					
1949 thru 52	All	-----	1	5660576	-----
1939 thru 54	All S.S.	PLUG, steering gear oil filler (1/2" sq. hd.)	1	103868	(8.971)
1941-42	26-29 All	(1 1/4" I.D.)	1	187540	(8.956)
Group 6.521 BEARING, STEERING SHAFT UPPER					
1934 thru 38	All	-----	1	262159	-----
1939 thru 52	All	-----	1	264887	-----
1953-54	All S.S.	-----	1	515163	-----
1953-54	All P.S.	-----	1	5680050	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.524 SHAFT AND WORM, STEERING GEAR					
1935-36	All L.H.D.	-----	1	262608	-----
1937-38	P/8 L.H.D.	also use 2-262200 brg. and 2-263917 race	1	265581	-----
1939-40	25-26	-----	1	269891	-----
1940	29 All	-----	1	265867	-----
1941 thru 48	26-29 All	-----	1	269889	-----
1941 thru 48	25 All	-----	1	269891	-----
1949	All L.H.D.	-----	1	5660505	-----
1950 thru 52	All L.H.D.	-----	1	5661594	-----
1953-54	All L.H.D., S.S.	-----	1	5665720	-----
1953	All P.S.	w/balls and nut	1	5680045	-----
1954	All P.S.	w/balls and nut	1	5680486	-----
Group 6.526 SPRING, STEERING SHAFT UPPER BEARING					
1939 thru 52	All	-----	1	264832	-----
1953-54	All S.S.	-----	1	5660476	-----
1934 thru 38	All	SEAT, steering shaft upper bearing spring	1	262468	-----
1939 thru 54	All S.S.	-----	1	264831	-----
Group 6.527 RACE, STEERING GEAR WORM THRUST BEARING					
1937	All	-----	2	263297	-----
1938	P/6 All, P/8 L.H.D. to Ser. 8DA11789	-----	2	263297	-----
1938	See note	-----	2	263917	-----
1939 thru 54	All S.S.	-----	2	263917	-----
NOTE: Use after Serial 8DA11787 L.H.D., after 6DA50622 L.H.D., after C6DA7423, after C8DA2322, after L6DA8431 standard shift, after L6DA8538 steering column shift, after L8DA3593 except Nos. 3612-14-16-17-18-23-30-50-51-52-67.					
Group 6.530 BEARING, STEERING GEAR THRUST					
1934 thru 37	All	-----	2	261866	-----
1938	P/6, P/8 L.H.D. to Ser. 8DA11789	-----	2	261866	-----
1938	see note	-----	2	262200	-----
1939 thru 54	All S.S.	-----	2	262200	-----
1953-54	All P.S.	-----	2	5663818	-----
NOTE: Use after Serial 8DA11787 L.H.D., after 6DA50622 L.H.D., after C6DA7423, after C8DA2322, after L6DA8431 standard shift, after L6DA8538 steering column shift, after L8DA3593 except Nos. 3612-14-16-17-18-23-30-50-51-52-67.					
Group 6.531 NUT—WASHER, STEERING GEAR WORM BEARING ADJUSTING					
1953-54	All P.S.	NUT	1	5664762	-----
Group 6.532 SCREW, STEERING GEAR WORM THRUST					
1937 thru 54	All S.S.	-----	1	263302	-----
1937 thru 54	All S.S.	NUT, steering gear worm thrust screw	1	263300	-----
1937 thru 54	All S.S.	WASHER, steering gear worm thrust screw	1	263304	-----
Group 6.550 VALVE ASSY., STEERING GEAR HYDRAULIC					
1953-54	All P.S.	-----	1	5680076	-----
1953-54	All P.S.	BOLT, elbow to valve	2	5664907	-----
1953-54	All P.S.	ELBOW (90°)	2	5664906	-----
1953-54	All P.S.	SEAL, elbow to valve	4	5665574	-----
1953-54	All P.S.	UNION (return port 3/8")	1	5664020	-----
1953-54	All P.S.	(pressure port 1/4")	1	5665614	-----
Group 6.551 PLUNGER, STEERING GEAR VALVE CENTERING					
1953-54	All P.S.	-----	10	5663828	-----
Group 6.552 SPRING, STEERING GEAR VALVE CENTERING					
1953-54	All P.S.	-----	5	5665555	-----
Group 6.553 CHECK VALVE, STEERING GEAR HYDRAULIC VALVE					
1953-54	All P.S.	with ball	1	5663874	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.554 COVER, STEERING GEAR VALVE						
1953-54	All P.S.	w/steering column jacket.....	1	5680036	-----	(6.518)
1954	All P.S.	w/steering column jacket.....	1	5681348	-----	(6.518)
Group 6.555 SEAL, STEERING GEAR VALVE COVER OIL						
1953-54	All P.S.	-----	1	5663837	-----	
Group 6.556 SEAL, STEERING GEAR VALVE HOUSING						
1953-54	All P.S.	"O" ring type..... (I.D. 2 $\frac{13}{16}$ ")	2	5665836	-----	
		see Group 6.584 for use.....		5661386	-----	
Group 6.576 CYLINDER, STEERING GEAR POWER						
1953-54	All P.S.	-----	1	5663958	-----	
1953-54	All P.S.	BOLT , elbow to cylinder.....	2	5664907	-----	(6.679)
1953-54	All P.S.	ELBOW (90°)	2	5664906	-----	(6.679)
1953-54	All P.S.	SEAL , elbow to cylinder.....	4	5665574	-----	(6.674)
Group 6.577 GASKET, STEERING GEAR POWER CYLINDER						
1953-54	All P.S.	-----	1	5663876	-----	
Group 6.578 PISTON, STEERING GEAR POWER CYLINDER						
1953-54	All P.S.	-----	1	5664557	-----	
Group 6.579 RING, STEERING GEAR POWER CYLINDER PISTON						
1953-54	All P.S.	-----	2	5663824	-----	
Group 6.580 ROD, STEERING GEAR POWER CYLINDER PISTON						
1953-54	All P.S.	-----	1	5663845	-----	
Group 6.581 NUT-WASHER, STEERING GEAR POWER CYLINDER ROD						
1953-54	All P.S.	NUT , lock.....	1	5680151	-----	
1953-54	All P.S.	WASHER , thrust.....	2	5663819	-----	
Group 6.584 ADAPTER, STEERING GEAR POWER CYLINDER						
1953-54	All P.S.	with seals.....	1	5664495	-----	
1953-54	All P.S.	SEAL , "O" ring type..... (I.D. 2 $\frac{3}{4}$ ")	2	5661386	-----	(6.556)
1953-54	All P.S.	"O" ring type..... (O.D. 1 $\frac{1}{8}$ ")	1	5661523	-----	
1953-54	All P.S.	piston rod.....	1	5664016	-----	
Group 6.586 RACK, STEERING GEAR POWER CYLINDER						
1953-54	All P.S.	-----	1	5663849	-----	
Group 6.587 PIN, STEERING GEAR POWER CYLINDER RACK						
1953-54	All P.S.	-----	1	5663850	-----	
Group 6.590 GUIDE, STEERING GEAR POWER RACK						
1953-54	All P.S.	-----	1	5663869	-----	
Group 6.591 SHIM, STEERING GEAR POWER RACK COVER						
1953-54	All P.S.	.003" thick.....	AR	5663880	-----	
1953-54	All P.S.	.005" thick.....	AR	5663881	-----	
Group 6.592 COVER, STEERING GEAR POWER RACK GUIDE						
1953-54	All P.S.	-----	1	5663868	-----	
Group 6.605 PUMP ASSY., STEERING GEAR OIL						
1953-54	All P.S.	rotor type.....	1	5680082	-----	
1954	All P.S.	vane type.....	1	5680750	-----	
Group 6.606 BRACKET, STEERING GEAR OIL PUMP						
1953-54	P/6-P.S.	w/rotor type pump.....	1	517336	-----	
1953-54	P/8-P.S.	w/rotor type pump.....	1	517335	-----	
1954	P/6-P.S.	w/vane type pump.....	1	517874	-----	
1954	P/8-P.S.	w/vane type pump.....	1	517875	-----	
1953-54	All P.S.	BOLT , oil pump to bracket.....	2	180124	-----	(8.900)
1953-54	All P.S.	SCREW , bracket to cyl. head.....	3	517356	-----	
1953-54	All P.S.	WASHER , oil pump to bracket.....	1	502306	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.608 BODY, STEERING GEAR OIL PUMP					
1953-54	All P.S.	w/bushing and rotor—w/rotor type pump.....	1	5680228	-----
1954	All P.S.	w/vane type pump.....	1	5665669	-----
1953-54	All P.S.	BOLT , elbow to oil pump body—w/rotor type pump.....	1	5680155	-----
1954	All P.S.	DOWEL PIN , rotor ring—w/vane type pump.....	2	5680269	-----
1953-54	All P.S.	ELBOW , to oil pump body—90°—w/rotor type pump.....	1	5680154	-----
1953-54	All P.S.	SEAL , elbow to oil pump body—"O" ring type—w/rotor type pump..... (I.D. 3/4")	2	5680177	-----
Group 6.609 COVER, STEERING GEAR OIL PUMP BODY					
1953-54	All P.S.	w/rotor type pump.....	1	5680225	-----
1954	All P.S.	w/vane type pump.....	1	5665650	-----
1953-54	All P.S.	BUSHING , valve cap—w/rotor type pump.....	1	5680255	-----
1953-54	All P.S.	GASKET , body to cover—w/rotor type pump.....	1	5680256	-----
1954	All P.S.	reservoir to pump body—w/vane type pump.....	1	5664569	-----
1954	All P.S.	reservoir to pump cover—w/vane type pump.....	1	5664575	-----
1953-54	All P.S.	SEAL , reservoir to body—"O" ring type—w/rotor type pump..... (I.D. 5/16")	2	5680176	-----
1953-54	All P.S.	reservoir to body—"O" ring type—w/rotor type pump..... (I.D. 3/4")	2	5680177	----- (6.608)
1953-54	All P.S.	elbow to pump cover—"O" ring type—w/rotor type pump.....	2	5665574	----- (6.674)
1953-54	All P.S.	cover to body—"O" ring type—w/rotor type pump.....	1	5664015	----- (6.674)
1953-54	All P.S.	bushing to cover—"O" ring type—w/rotor type pump..... (I.D. 13/16")	1	5680260	-----
1954	All P.S.	pressure port union—w/vane type pump.....	1	5664015	----- (6.674)
1953-54	All P.S.	BOLT , to oil pump cover—w/rotor type pump.....	1	5664907	----- (6.679)
1953-54	All P.S.	ELBOW , to oil pump cover—w/rotor type pump.....	1	5664906	----- (6.679)
1954	All P.S.	UNION , return port—w/vane type pump.....	1	5665572	----- (6.673)
1954	All P.S.	pressure port—w/vane type pump.....	1	5664020	----- (6.673)
Group 6.610 ROTOR, STEERING GEAR OIL PUMP					
1953-54	All P.S.	w/rotor type pump.....	1	5681081	-----
1954	All P.S.	w/vane type pump.....	1	5664585	-----
1954	All P.S.	VANE KIT , oil pump rotor—w/vane type pump.....	1	5664610	-----
Group 6.611 RING—SEAL, STEERING GEAR OIL PUMP ROTOR					
1954	All P.S.	w/vane type pump.....	1	5665438	-----
1954	All P.S.	SEAL —w/vane type pump..... (2 5/8" O.D.)	2	5664578	-----
Group 6.612 PLATE—SPRING, STEERING GEAR OIL PUMP					
1954	All P.S.	pressure—w/vane type pump.....	1	5665760	-----
1954	All P.S.	SPRING , flow control valve—w/vane type pump.....	1	5665652	-----
Group 6.614 SHAFT, STEERING GEAR OIL PUMP DRIVE					
1953	All P.S.	w/rotor type pump..... (w/5/16" tapped hole)	1	5680243	-----
1953-54	All P.S.	w/rotor type pump..... (w/3/8" tapped hole)	1	5681027	-----
1954	All P.S.	w/vane type pump.....	1	5665657	-----
1953-54	All P.S.	PIN , rotor drive—w/rotor type pump.....	1	5680258	-----
1953-54	All P.S.	REPAIR KIT , shaft and pulley—w/rotor type pump.....	1	517896	-----
Group 6.615 BEARING, STEERING GEAR OIL PUMP SHAFT					
1953-54	All P.S.	w/rotor type pump.....	1	954609	-----
1954	All P.S.	w/vane type pump..... Inner	1	903201	-----
1954	All P.S.	w/vane type pump..... Outer	1	954211	-----
Group 6.616 RING, STEERING GEAR OIL PUMP BEARING RETAINER					
1953-54	All P.S.	snap ring—w/rotor type pump.....	1	5680259	-----
1954	All P.S.	outer bearing—w/vane type pump.....	1	5665651	-----
Group 6.617 SEAL, STEERING GEAR OIL PUMP SHAFT					
1953-54	All P.S.	w/rotor type pump.....	1	5680261	-----
1954	All P.S.	w/vane type pump.....	1	5665833	-----
Group 6.622 VALVE ASSY., STEERING GEAR OIL PUMP RELIEF					
1953-54	All P.S.	also flow control—w/rotor type pump.....	1	5680249	-----
1953-54	All P.S.	PLATE , valve orifice—w/rotor type pump.....	1	5680079	-----
1953-54	All P.S.	RING , relief and flow control valve retaining—w/rotor type pump.....	1	5680250	-----
1953-54	All P.S.	SPRING , relief and flow control valve—w/rotor type pump..... (2 1/8" long)	1	5680262	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.624 VALVE ASSY., STEERING GEAR OIL PUMP FLOW CONTROL					
1954	All P.S.	w/vane type pump.....	1	5665656	-----
Group 6.635 RESERVOIR, STEERING GEAR OIL PUMP					
1953-54	All P.S.	w/rotor type pump.....	1	5680238	-----
1954	All P.S.	w/vane type pump.....	1	5680746	-----
1953-54	All P.S.	BODY AND GUIDE ASSY. , reservoir inlet orifice—w/rotor type pump.....	1	5680367	-----
1954	All P.S.	BOLT , reservoir cover—w/vane type pump.....	1	186284	-----
1953-54	All P.S.	COVER , reservoir—w/rotor type pump.....	1	5680234	-----
1954	All P.S.	w/vane type pump.....	1	5680157	-----
1953-54	All P.S.	ELEMENT , steering gear oil pump filter—w/rotor type pump.....	1	5664466	-----
1953-54	All P.S.	GASKET , reservoir cover—w/rotor type pump.....	1	5680237	-----
1954	All P.S.	reservoir cover—w/vane type pump.....	1	5664930	-----
1954	All P.S.	reservoir cover bolt—w/vane type pump.....	1	5664570	-----
1954	All P.S.	GUIDE , reservoir cover bolt—w/vane type pump.....	1	5664577	-----
1953-54	All P.S.	RING ASSY. , reservoir clamping—w/rotor type pump.....	1	5680229	-----
1954	All P.S.	SCREW AND WASHER , reservoir to pump body—w/vane type pump.....	1	5680865	-----
1953-54	All P.S.	VALVE AND HANDLE ASSY. , relief—w/rotor type pump.....	1	5680244	-----
1954	All P.S.	WASHER , reservoir cover bolt—w/vane type pump.....	1	5664573	-----
Group 6.655 PULLEY, STEERING GEAR OIL PUMP					
1953-54	All P.S.	w/rotor type pump.....(3 $\frac{3}{16}$ " O.D.)	1	517337	-----
1954	All P.S.	w/vane type pump.....	1	517895	-----
1953-54	All P.S.	idler.....	1	517340	-----
1953-54	All P.S.	KEY , pulley to shaft—w/rotor type pump.....	1	5680083	-----
1954	All P.S.	w/vane type pump.....	1	124543	-----
1953-54	All P.S.	WASHER , pulley to pump—w/rotor type pump.....	1	517338	-----
1953-54	All P.S.		1	563979	-----
Group 6.660 BELT, STEERING GEAR OIL PUMP					
1953-54	All P.S.	w/rotor type pump.....	1	517323	-----
1954	All P.S.	w/vane type pump.....	1	517873	-----
Group 6.670 HOSE, STEERING GEAR OIL PRESSURE					
1953-54	All P.S.	w/rotor type pump.....	1	5680042	-----
1954	All P.S.	w/vane type pump.....	1	5681042	-----
Group 6.671 HOSE, STEERING GEAR OIL RETURN					
1953-54	All P.S.	w/rotor type pump.....	1	5680043	-----
1954	All P.S.	w/vane type pump.....	1	5681035	-----
Group 6.671 CLIP, STEERING GEAR OIL HOSE					
1953-54	All P.S.		1	517645	-----
Group 6.673 UNION, STEERING GEAR OIL HOSE TO VALVE					
1953-54	All P.S.	pressure port.....($\frac{1}{4}$ ")	1	5665614	-----
1953-54	All P.S.	return port—w/rotor type pump.....($\frac{3}{8}$ ")	1	5664020	-----
1954	All P.S.	return port—w/vane type pump.....	1	5665572	-----
Group 6.674 SEAL, STEERING GEAR ELBOW TO VALVE HOUSING					
1953-54	All P.S.		4	5665574	-----
1953-54	All P.S.	return line to valve housing.....	1	5664015	-----
1953-54	All P.S.	pressure line to valve housing.....(I.D. $1\frac{15}{32}$ ")	1	5664142	-----
Group 6.677 PIPE, STEERING GEAR VALVE OIL					
1953-54	All P.S.	valve to rod end of cylinder.....	1	5663908	-----
Group 6.678 PIPE, STEERING GEAR VALVE OIL					
1953-54	All P.S.	valve to head end of cylinder.....	1	5663907	-----
Group 6.679 ELBOW, STEERING GEAR OIL PIPE					
1953-54	All P.S.	universal fitting, 90°.....	4	5664906	-----
1953-54	All P.S.	BOLT , universal fitting elbow.....	4	5664907	-----

(8.900)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.681 PIPE, STEERING GEAR VALVE BLEED LINE						
1953-54	All P.S.	-----	1	5663906	-----	(8.963)
1953-54	All P.S.	ELBOW.....90° (3/16")	2	137420	-----	
Group 6.750 BRACKET, STEERING COLUMN						
1939	All exc. 25	-----	1	502718	-----	
1940	25-26 All	-----	1	503885	-----	
1940	29 All	-----	1	503900	-----	
1941	29 All	-----	1	505365	-----	
1942 thru 48	25 All exc. 2507	-----	1	508037	-----	
1942 thru 48	2507 All	-----	1	508038	-----	
1942 thru 48	26 All	-----	1	508039	-----	
1949	All	-----Upper	1	511890	-----	
1949 thru 52	All	-----Lower	1	512473	-----	
1950 thru 52	All	-----Upper	1	513796	-----	
1953-54	All	-----Upper	1	516821	-----	
1953-54	All	-----Lower	1	516822	-----	
1942 thru 48	All	PLATE, steering column bracket tapping	1	508014	-----	
1949	All L.H.D.	steering column finish—w/dir. signal	1	512435	-----	
1949	All L.H.D.	without dir. signal	1	511892	-----	
1949	All	without heater	1	511893	-----	
1950 thru 52	All L.H.D.	with dir. signal	1	513759	-----	
1950 thru 52	All	without dir. signal	1	515782	-----	
1950 thru 52	All	without heater	1	513755	-----	
Group 6.751 BOLT, STEERING COLUMN BRACKET						
1938-39	All	steering column shift	1	154102	-----	(8.900)
1940 thru 48	All	----- (Hex. 3/8"-16x1")	1	180122	-----	
1953-54	All	screw..... (5/16"-18x2 1/2")	2	515637	-----	
Group 6.758 PAD, STEERING COLUMN BRACKET						
1942 thru 48	All	-----	1	508015	-----	
1938 thru 41	All	WASHER, steering column bracket, rubber	2	501461	-----	
1949 thru 52	All	to instrument panel	4	511891	-----	
Group 6.785 HOUSING, PITMAN SHAFT L.H.D.						
1935-36	All	-----	1	262598	-----	
Group 6.786 BUSHING, PITMAN SHAFT						
1937 thru 54	All S.S.	-----	1	5662798	-----	
1953-54	All P.S.	-----	1	266316	-----	
Group 6.803 HOUSING, STEERING COLUMN L.H.D.						
1937-38	P/6	-----	1	263430	-----	
1937 thru 48	All exc.	-----	1	263417	-----	
1949 thru 52	P/6 1937-38	-----	1	5660512	-----	
1953-54	All	-----	1	5665659	-----	
1953-54	All S.S.	-----	1	5680034	-----	
1953-54	All P.S.	-----	1	5680034	-----	
Group 6.806 SEAL ASSY., STEERING GEAR WORM						
1953-54	All P.S.	-----	1	5663834	-----	
1953-54	All P.S.	BEARING, upper worm-needle type	1	453896	-----	
1953-54	All P.S.	VENT ASSY., steering gear housing	1	5681084	-----	
Group 6.807 PLATE, STEERING GEAR HOUSING SIDE						
1937-38	All L.H.D.	with bushing	1	263462	-----	
1939 thru 54	All S.S.	with bushing	1	263462	-----	
1953-54	All P.S.	COVER ASSY., housing side	1	5663821	-----	
Group 6.809 GASKET, STEERING GEAR HOUSING SIDE PLATE						
1937 thru 54	All S.S.	-----	1	263419	-----	
1953-54	All P.S.	-----	1	5663817	-----	
Group 6.822 SCREW, STEERING GEAR SECTOR ADJUSTING						
1934 thru 54	All S.S.	pitman shaft or roller adj. (1 1/16" Dia.)	1	262566	-----	
1953-54	All P.S.	lash adjuster	1	266678	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.823 NUT, PITMAN SHAFT ADJUSTING SCREW					
1934 thru 54	All S.S.	locking.....($\frac{11}{16}$ "-18)	1	262567	-----
Group 6.824 COVER ASSY., STEERING GEAR HOUSING END					
1937 thru 48	All	-----	1	263274	-----
1949 thru 54	All L.H.D., S.S.	-----	1	5660825	-----
1953-54	All P.S.	-----	1	5663919	-----
Group 6.825 GASKET, STEERING GEAR HOUSING END PLATE					
1937 thru 54	All S.S.	-----	1	263299	-----
1953-54	All P.S.	-----	1	5663903	-----
1937 thru 47	All	PACKING , steering gear housing end plate.....	2	263309	-----
1948 thru 54	All S.S.	-----	1	263309	-----
Group 6.826 BEARING, STEERING GEAR HOUSING END COVER					
1953-54	All P.S.	-----	1	453897	-----
Group 6.828 SHIM PKG., STEERING GEAR LASH ADJUSTER					
1953-54	All P.S.	-----	1	605142	-----
Group 6.830 SLEEVE, STEERING GEAR LASH ADJUSTER					
1937 thru 54	All S.S.	-----	1	263303	-----
Group 6.841 NUT, STEERING GEAR WORM BALL					
1953	All P.S.	-----	1	5661083	-----
1954	All P.S.	-----	1	5680784	-----
Group 6.842 GUIDE, STEERING GEAR WORM BALL RETURN					
1953	All P.S.	-----	4	267502	-----
1954	All P.S.	-----	4	5680786	-----
Group 6.843 CLAMP, STEERING GEAR WORM BALL RETURN GUIDE					
1953	All P.S.	-----	1	5661082	-----
1954	All P.S.	-----	1	5680785	-----
1953-54	All P.S.	BOLT AND WASHER($\frac{1}{4}$ "-28x $\frac{5}{16}$ ")	1	187375	----- (8.907)
Group 6.844 BALL, STEERING GEAR WORM					
1953-54	All P.S.	-----	60	266800	-----
Group 6.850 SHAFT, STEERING GEAR PITMAN					
1935-36	All L.H.D.	ROLLER AND SHAFT , steering gear.....	1	262602	-----
1937 thru 54	All S.S.	KIT , pitman shaft (see note).....	1	510895	-----
1953-54	All P.S.	-----	1	5664522	-----
NOTE: Kit consists of 1 each—Roller and shaft, bushing, seal, nut, gasket, thrust washer and lock washer.					
Group 6.855 PACKING, STEERING GEAR ROLLER SHAFT					
1934 thru 36	All	at roller shaft.....	1	262155	-----
1953-54	All P.S.	at pitman shaft.....	1	270289	-----
1937 thru 54	All S.S.	SEAL , steering gear roller shaft grease.....	1	263463	-----
1937 thru 54	All S.S.	WASHER , pitman shaft thrust.....	1	263306	-----
Group 6.856 RETAINER, PITMAN SHAFT PACKING					
1953-54	All P.S.	-----	1	262156	-----
Group 6.859 ARM, STEERING GEAR PITMAN					
1937-38	P/6 L.H.D.	-----	1	264396	-----
1937-38	P/8 L.H.D.	-----	1	264393	-----
1939	All L.H.D.	-----	1	265908	-----
1940	25-26 L.H.D.	-----	1	265908	-----
1940	29 L.H.D.	-----	1	265094	-----
1941 thru 48	All	-----	1	265094	-----
1949 thru 52	All L.H.D.	-----	1	5661574	-----
1953-54	All L.H.D., S.S.	-----	1	5663354	-----
1953-54	All P.S.	-----	1	5665955	-----
Group 6.861 NUT, STEERING GEAR PITMAN ARM					
1933 thru 54	All S.S.	-----($\frac{3}{4}$ "-16)	1	254291	-----
1953-54	All P.S.	-----	1	258779	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 6.870 ROD ASSEMBLY, STEERING CONNECTING L.H.D.					
1937-38	All	(15 $\frac{1}{4}$ " over-all)	1	264494	-----
1939 thru 48	All	(25" over-all)	1	265207	-----
1953-54	All L.H.D.		1	5663364	-----
1949 thru 52	All	ROD AND SPACERS PKG.(28 $\frac{1}{2}$ " over-all)	1	513485	-----
1939 thru 52	All	ROD LINK PKG.	1	557397	-----
Group 6.874 SEAT, STEERING CONNECTING ROD BALL					
1933 thru 38	All		4	595586	-----
1939 thru 54	All	at idler lever.....	4	264946	-----
Group 6.876 SPRING, STEERING CONNECTING ROD					
1933 thru 52	All	both ends.....	2	335976	-----
1937-38	All	pitman arm end.....	2	263757	-----
1937-38	All	steering arm end.....	1	335976	-----
1953-54	All	pitman arm end.....	2	516963	-----
1953-54	All	idler arm end.....	1	335976	-----
Group 6.881 PLUG, STEERING CONNECTING ROD END					
1933 thru 38	All	both ends.....	2	335977	-----
1939 thru 52	All	both ends.....	2	264945	-----
1953-54	All	pitman arm end.....	1	1324652	-----
1953-54	All	idler arm end.....	1	264945	-----
Group 6.882 PLUG, STEERING CONNECTING ROD SAFETY					
1937-38	All	steering arm end.....	1	263697	-----
1937-38	All	pitman arm end.....	1	263698	-----
1939 thru 52	All	both ends.....	2	263697	-----
1953-54	All	both ends.....	2	5664237	-----
1953-54	All	idler arm end.....	1	263697	-----
Group 6.883 SPACER, STEERING CONNECTING ROD BALL SEAT					
1939 thru 48	All L.H.D.	triangle type, short.....	1	264925	-----
1939 thru 48	All L.H.D.	triangle type, long.....	1	264926	-----
1949 thru 52	All L.H.D.	pitman arm end.....	1	5660144	-----
1949 thru 52	All L.H.D.	idler arm end.....	1	5660145	-----
1953-54	All	idler arm end.....	1	516960	-----
1953-54	All L.H.D.	pitman arm end.....	1	516961	-----
1939 thru 54	All	COVER, steering connecting rod ball seat spacer.....	2	265516	-----
Group 6.885 WASHER, STEERING CONNECTING ROD SPACING					
1939 thru 54	All	inner.....	2	264988	-----
1953-54	All	outer.....	1	264988	-----
Group 6.886 COVER, STEERING CONNECTING ROD DUST					
1937-38	All		2	408771	-----
1939 thru 52	All		2	265765	-----
1953-54	All	pitman arm end.....	1	5663589	-----
1953-54	All	idler arm end.....	1	265765	-----
Group 6.888 SPRING, STEERING CONNECTING ROD DUST COVER					
1937-38	All		2	1257614	-----
1939 thru 54	All	at idler lever.....	2	264949	-----
Group 6.895 ARM ASSEMBLY, STEERING CONNECTING ROD IDLER					
1939 thru 54	All		1	264953	-----
Group 6.896 SUPPORT ASSY., STEERING CONNECTING ROD IDLER LEVER					
1939 thru 52	All	with bushing.....	1	413048	-----
1953-54	All	with bushing.....	1	516710	-----
1939 thru 54	All	BOLT, idler lever to frame..... (Hex. $\frac{3}{8}$ "-24x1")	2	181637	-----
1939 thru 53	All	(Hex. $\frac{3}{8}$ "-24x1 $\frac{1}{4}$ ")	1	181639	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 6.897 BUSHING, STEERING CONNECTING ROD IDLER LEVER						
1939	All	-----	1	412509	-----	
1940 thru 54	All	-----	1	413050	-----	
Group 6.898 SEAL, IDLER LEVER BUSHING OIL						
1939 thru 54	All	-----	1	411231	-----	
1939	All	RETAINER, idler lever bushing.	1	402453	-----	(0.837)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.003 FRAME ASSEMBLY, CHASSIS (L.H.D.)					
1950	All exc. 2537-67 & taxi	-----	1	513631	-----
1950	2567 & taxi	-----	1	513632	-----
1950	2537 All	-----	1	513959	-----
1951-52	All exc. 2537-67 & taxi	-----	1	514693	-----
1951-52	2567 & taxi	-----	1	514694	-----
1951-52	2537 All	-----	1	514696	-----
1953	All exc. 2537-67 & taxi	-----	1	515064	-----
1953	2567 & taxi	-----	1	515335	-----
1953	2537 All	-----	1	515336	-----
1954	2511-62-69 All	-----	1	517978	-----
1954	2537 All	-----	1	517980	-----
1954	2567 & Taxi	-----	1	517979	-----
1954	2837 All	-----	1	517547	-----
1954	2867 All	-----	1	517545	-----
1954	2869 All	-----	1	517543	-----
1941 thru 48	26-29 exc. sta. wag.	FRAME PKG. , consists of frame, bolt and washer (use w/511535 for H.T. and 511537 for S.T.—Group 7.011	1	510999	-----
1941 thru 48	26 sta. wag.	use w/511535 for H.T. and 511537 for S.T.—Group 7.011	1	511000	-----
1951 thru 48	2567 & taxi	use w/511534 for H.T. and 511536 for S.T.—Group 7.011	1	510998	-----
1941 thru 48	25 exc. 2567 & taxi	use w/511534 for H.T. and 511536 for S.T.—Group 7.011	1	510997	-----
1949	All exc. 2561-67 & taxi	use w/513209 pkg. for H.T. & 513199 pkg. for S.T.	1	511321	-----
1949	2561-67 & taxi	use w/513209 pkg. for H.T. and 513199 pkg. for S.T.	1	511589	-----
Group 7.010 CROSS MEMBER, FRONT FRAME					
1940	29 All	-----	1	504657	-----
1941 thru 48	All	-----	1	506207	-----
1949 thru 52	All	(see note)	1	512198	-----
1953-54	All	-----	1	517167	-----
NOTE: See Group 7.061 for radiator and engine support cross member.					
Group 7.011 CROSS MEMBER, FRONT CENTER					
1937-38	All	CROSS MEMBER , engine rear support	1	500229	-----
1939	25 All	-----	1	501933	-----
1940	25 All	-----	1	503896	-----
1940	29 All	-----	1	503626	-----
1941 thru 48	All L.H.D. S.T.	BOLT (Hex. Hd. $\frac{5}{16}$ "-24NF3x $\frac{3}{4}$ ")	6	444684	-----
1941 thru 48	All L.H.D. S.T.	NUT (Spec. Hex. $\frac{5}{16}$ "-24)	6	511539	-----
1941 thru 48	25 S.T.	CROSS MEMBER PKG. , engine rear support	1	511536	-----
1941 thru 48	26-29 L.H.D. S.T.	-----	1	511537	-----
1948	25 L.H.D., H.T.	-----	1	511534	-----
1948	26 L.H.D., H.T.	-----	1	511535	-----
1949 thru 54	All H.T.	-----	1	513209	-----
1949 thru 54	All S.T.	-----	1	513199	-----
NOTE: Cross member package includes—1 cross member, 6 bolts, 6 nuts and 6 washers.					
Group 7.013 CROSS MEMBER, REAR CENTER					
1940	25	rear shock support	1	503897	-----
1949-50	All	rear shock absorber frame	1	512199	-----
1951 thru 54	All	rear shock absorber frame	1	514713	-----
Group 7.014 CROSS MEMBER, REAR					
1941 thru 48	25 All	fuel tank front	1	505248	-----
1941 thru 48	25 All	fuel tank rear	1	505249	-----
1941 thru 48	26-29	fuel tank front	1	505171	-----
1941 thru 48	26-29	fuel tank rear	1	505172	-----
1941 thru 48	exc. sta. wag.	-----	-----	-----	-----
1941 thru 48	26 sta. wag.	fuel tank rear	1	506222	-----
1949 thru 52	All	-----	1	511221	-----
1953	All	-----	1	515076	-----
1954	All	-----	1	517992	-----
Group 7.016 SUPPORT, RUNNING BOARD					
1937-38	All	Front	2	499851	-----
1937-38	All	Rear	2	499852	-----
1939	25 All	Front	1	501962	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.016 SUPPORT, RUNNING BOARD (Continued)					
1939	25 All	Rear	2	501963	-----
1939	26 All	with running boards.....Front	1	501964	-----
1939	26 All	with running boards.....Rear	2	501965	-----
1940	25	Front or rear	4	504055	-----
1940	26 All	Front	2	503852	-----
1940	26 All	Rear	2	503807	-----
Group 7.056 BRACKET, MASTER CYLINDER FRAME					
1937-38	All L.H.D.		1	501057	-----
Group 7.061 BRACKET, RADIATOR SUPPORT FRAME					
1941 thru 48	All	Front	1	505159	-----
1949 thru 54	All	Front	1	511209	-----
1949 thru 52	All	CROSS MEMBER, rad. and engine supt. frameFront	1	511213	-----
1953-54	All	Front	1	515079	-----
Group 7.104 BUSHING, SPRING					
		see Group 7.413 and 7.504 for use.....		379647	-----
Group 7.112 BRACKET, REAR SPRING FRONT					
1939	25 All	R.H.	1	501937	-----
1939-40	26 exc. 2667 & taxi		2	501936	-----
1939-40	2667 & taxi		2	502370	-----
1940	25 All	R.H.	1	503887	-----
1940	25 All	L.H.	1	503888	-----
1940	29 All		2	503615	-----
1941-42	25 exc. 2567 & taxi	L.H.	1	505231	-----
1941-42	2567 & taxi	R.H.	1	507709	-----
1941-42	2567 & taxi	L.H.	1	507710	-----
1941 thru 48	26-29 All	508550 bolt—Group 7.529 must be used with this bracket.....	2	509051	-----
1941 thru 48	exc. sta. wag.		2	509052	-----
1941 thru 48	Sta. wag.		1	509047	-----
1941 thru 48	25 All exc. 2567 & taxi	R.H.	1	509048	-----
1946 thru 48	25 All exc. 2567 & taxi	L.H.	1	509049	-----
1946 thru 48	2567 & taxi	R.H.	1	509050	-----
1946 thru 48	2567 & taxi	L.H.	1	511203	-----
1949	All exc. 2567 & taxi	R.H.	1	511204	-----
1949	All exc. 2567 & taxi	L.H.	1	511581	-----
1949	2567 & taxi	R.H.	1	511582	-----
1949	2567 & taxi	L.H.	1	513634	-----
1950	All exc. 2567 & taxi	R.H.	1	513635	-----
1950	All exc. 2567 & taxi	L.H.	1	513636	-----
1950	2567 & taxi	R.H.	1	513637	-----
1950	2567 & taxi	L.H.	1	514704	-----
1951-52	All exc. 2567 & taxi	R.H.	1	514705	-----
1951-52	All exc. 2567 & taxi	L.H.	1	514706	-----
1951-52	2567 & taxi	R.H.	1	514707	-----
1951-52	2567 & taxi	L.H.	1	515069	-----
1953-54	All exc. 2567 & taxi	R.H.	1	515070	-----
1953-54	All exc. 2567 & taxi	L.H.	1	515341	-----
1953-54	2567 & taxi	R.H.	1	515342	-----
1953-54	2567 & taxi	L.H.	1		-----
Group 7.118 BRACKET, REAR SPRING REAR					
1939-40	25-26 All		2	501799	-----
1940	29 All	R.H.	1	503616	-----
1940	29 All	L.H.	1	503617	-----
1941 thru 48	25 All	R.H.	1	505232	-----
1941 thru 48	25 All	L.H.	1	505233	-----
1941 thru 48	26-29 All	R.H.	1	510462	-----
1941 thru 48	26-29 All	L.H.	1	510463	-----
1949-50	All	R.H.	1	511263	-----
1949-50	All	L.H.	1	511264	-----
1951-52	All		2	514708	-----
1953-54	All		2	515071	-----
1954	28 All	R.H.	1	517553	-----
1954	28 All	L.H.	1	517554	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 7.225 BAR, FUEL TANK SADDLE FRAME						
1941 thru 48	25 All	-----	2	505224	-----	
1941 thru 48	26-29 All	-----	2	505151	-----	
	exc. sta. wag.					
Group 7.227 BRACKET, ENGINE SUPPORT REAR						
1937-38	All	----- R.H.	1	500226	-----	
1937-38	All	----- L.H.	1	500227	-----	
Group 7.237 BRACKET, CLUTCH AND BRAKE PEDAL SHAFT L.H.D.						
1939-40	26	-----	1	502286	-----	
1940	25	-----	1	503886	-----	
1940	29 All	-----	1	503613	-----	
1941 thru 48	28	-----	1	505237	-----	
1941 thru 48	26-29 All exc.	-----	1	505158	-----	
	sta. wag.					
1941 thru 48	Sta. wag.	-----	1	506677	-----	
1949 thru 54	All	-----	1	511207	-----	
Group 7.238 NUT, FRONT STABILIZER						
1937 thru 54	All	spring lock type----- (5/16"-24)	2	107822	-----	(8.921)
Group 7.240 LINK PACKAGE, FRONT STABILIZER						
1937 thru 52	All	includes bolt, nut, washer, spacer, 4 bushings and cup-----	2	500906	-----	
1953-54	All	-----	2	517319	-----	
1937 thru 52	All	SPACER , front stabilizer link-----	2	410738	-----	
1953-54	All	-----	2	515218	-----	
Group 7.241 SHAFT, FRONT STABILIZER						
1937-38	All	-----	1	500148	-----	
1939-40	All exc. 29	-----	1	504161	-----	
1940	29 All	-----	1	504162	-----	
1941 thru 48	All	-----	1	505661	-----	
1949 thru 52	All	-----	1	511548	-----	
1953-54	All	-----	1	515217	-----	
Group 7.242 BRACKET, FRONT STABILIZER FRAME						
1939-40	All	-----	2	504266	-----	
1941 thru 54	All	-----	2	502138	-----	
Group 7.243 BUSHING, FRONT STABILIZER BAR INSULATOR						
1937-38	All	-----	2	500314	-----	
1939 thru 48	All	-----	2	502722	-----	
1949 thru 54	All	to frame-----	2	511538	-----	
Group 7.244 BUSHING, FRONT STABILIZER LINK						
1937 thru 54	All	-----	8	5325788	-----	
1937-38	All	RETAINER , with nut, stabilizer link grommet lower--	2	5313826	-----	
Group 7.245 RETAINER, FRONT STABILIZER LINK BOLT GROMMET						
1937 thru 54	All	-----	8	043468	-----	
Group 7.248 BOLT						
		See Group 7.395 for use-----		1284634	-----	
		See Group 7.395 for use-----		1290140	-----	
Group 7.249 NUT, FRONT SHOCK ABSORBER TO FRAME BOLT						
		See Group 7.395 for use-----		1297755	-----	
Group 7.314 BRACKET, REAR SHOCK ABSORBER FRAME						
1941 thru 48	26-29	-----	2	505157	-----	
	exc. export					
1941 thru 48	25	-----	2	505236	-----	
1949-50	All	-----	2	511210	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.330 BRACKET, BODY TO FRAME FRONT					
1940	29 All	Front and intermediate	4	503689	-----
1941	26-29 All	Front and intermediate	4	503689	-----
1941	25 All	Front and front center	2-4	415041	-----
1942 thru 48	25 All	Front center	2	415041	-----
1942 thru 48	25 exc. 2567 & taxi	R.H.	1	507226	-----
1942 thru 48	25 exc. 2567 & taxi	L.H.	1	507227	-----
1942 thru 52	2567 & taxi	R.H.	1	508023	-----
1949	2561	R.H.	1	508023	-----
1942 thru 48	26 All	Intermediate	2	503689	-----
1942 thru 48	26 All	R.H.	1	506922	-----
1942 thru 48	26 All	L.H.	1	507135	-----
1949 thru 53	All	Front	2	511229	-----
1949 thru 53	All	Intermediate	2-4	511230	-----
1950 thru 52	2537	R.H.	1	508023	-----
1953	2537-67 & taxi	R.H.	1	515339	-----
1953	2537-67 & taxi	L.H.	1	515340	-----
1954	All	R.H.	1	517987	-----
1954	All	L.H.	1	517988	-----
1954	All	Front intermediate	2	517989	-----
1954	All	Rear intermediate	2-4	517990	-----
Group 7.332 BRACKET, BODY FRAME					
1941 thru 48	2567 & taxi	Intermediate rear	2	505785	-----
1942 thru 48	26 All	BRACE, body front frame bracket L.H.	1	507136	-----
Group 7.334 BRACKET, BODY TO FRAME REAR					
1941 thru 48	25 All	-----	2	505229	-----
1941 thru 48	26-29 All	-----	2	505154	-----
1949 thru 52	All	-----	2	511231	-----
1953	All	-----	2	515040	-----
1954	All	-----	2	517991	-----
Group 7.345 SHOCK ABSORBER					
1937-38	All	Front R.H.	1	5316100	-----
1937-38	All	Front L.H.	1	5316101	-----
1937-38	All	Rear	2	5394045	-----
1939 thru 48	All	Rear	2	5394983	-----
1939 thru 48	All	Front R.H.	1	5352332	-----
1939 thru 48	All	Front L.H.	1	5352333	-----
1949 thru 52	All taxi and police cars	Front	2	5513562	-----
1949 thru 52	All taxi & police cars	Rear	2	5513563	-----
1949 thru 52	All exc. taxi & police cars	Front	2	5516126	-----
1949 thru 52	All exc. taxi & police cars	Rear	2	5516127	-----
1953-54	All exc. taxi & police cars	Front	2	5303492	-----
1953-54	All exc. taxi & police cars	Rear	2	5303290	-----
1953-54	All taxi & police cars	Front	2	5519438	-----
1953-54	All taxi & police cars	Rear	2	5519439	-----
Group 7.355 LINK, SHOCK ABSORBER					
1936	P/6 mstr.	for 1/16" pin Front	2	5300180	-----
1936	All	for 1/16" pin Rear	2	5300181	-----
Group 7.356 PIN, SHOCK ABSORBER					
1936	All	Front or rear (1/16") AR	AR	5300135	-----
Group 7.364 BRACKET ASSEMBLY, FRONT SHOCK ABSORBER					
1949 thru 52	All	Upper	2	511590	-----
1949 thru 52	All	Lower	2	511552	-----
1953-54	All	Upper	2	515212	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 7.371 SHIELD, REAR SHOCK ABSORBER						
1939 thru 48	All	R.H.	1	502686	-----	
1939 thru 48	All	L.H.	1	502687	-----	
1949 thru 52	All	R.H.	1	511639	-----	
1949 thru 52	All	L.H.	1	511640	-----	
Group 7.377 BUSHING, SHOCK ABSORBER						
1930 thru 36	All	Front or rear	AR	041133	-----	(7.388)
1949 thru 54	All	Front	8	5325788	-----	(7.244)
1937 thru 54	All	Rear	8	517098	-----	
1949 thru 54	All	RETAINER , frt. shock abs. bushing.....Front	8	043468	-----	(7.245)
All	All	FLUID , shock absorber.....1 gal.	AR	600658	-----	(6.386)
All	All	1 qt.	AR	603489	-----	(6.386)
Group 7.395 BOLT, SHOCK ABSORBER MOUNTING						
1937	All	to cross member—front, with shims.....	2	1298766	-----	(6.187)
1937-38	All	to frame—rear, upper and lower.....	4	500288	-----	
1938 thru 48	All	to frame—long, front.....	2-4	1290140	-----	(7.248)
1939 thru 48	All	to frame and axle, rear.....	2-4	502685	-----	
1939 thru 48	All	to frame, front.....($\frac{1}{2}$ "-20x2 $\frac{1}{2}$ ")	4	1284634	-----	(7.248)
1949 thru 52	All	to upper bracket.....	4	511437	-----	
1949 thru 54	All	to frame, rear.....($\frac{1}{16}$ "-20x2")	2	124133	-----	(8.900)
1949 thru 54	All	to axle, rear.....	2	502685	-----	
1937 thru 48	All	NUT , front shock absorber to frame bolt.....(Hex. $\frac{1}{2}$ "-20)	8	1297755	-----	(7.249)
1940 thru 48	All	rear shock absorber to frame bolt.....			-----	
		(Hex. locking $\frac{1}{2}$ "-20)	AR	126016	-----	(8.917)
1946 thru 54	All	rear shock absorber to axle bolt.....(Hex. locking $\frac{1}{2}$ "-20)	AR	126016	-----	(8.917)
1949 thru 54	All	(Hex. locking $\frac{1}{16}$ "-20)	2	126022	-----	(8.917)
Group 7.397 WASHER, REAR SHOCK ABSORBER BOLT						
1937 thru 54	All	($2\frac{1}{32}$ " I.D.x1 $\frac{1}{4}$ " O.D.) Inner	AR	513978	-----	
1937 thru 48	All	($1\frac{17}{32}$ " I.D.x1 $\frac{1}{4}$ " O.D.) Outer	4	500456	-----	
1953-54	All	($\frac{9}{16}$ " I.D.x1 $\frac{1}{4}$ " O.D.) Outer	2	446230	-----	
1939-40	25	SPACER , rear shock absorber to frame.....	2	502809	-----	
1949 thru 54	All		2	502809	-----	
Group 7.412 SPRING ASSEMBLY, FRONT						
NOTE: Springs are coil unless otherwise specified.						
1935-36	All mstr. and 1935 taxi	less cover—leaf spring.....	2	508961	-----	
1937-38	P/8 exc. with side carrier		2	500356	-----	
1937-38	P/8 with side carrier		2	1422058	-----	
1937-38	P/6		2	409160	-----	
1939	25 exc. taxi		2	502840	-----	
1939	26 exc. taxi		2	502842	-----	
1939-40	Taxi		2	502842	-----	
1939-40	26 taxi and All 28		2	502841	-----	
1940	25 exc. taxi		2	504503	-----	
1940	26 exc. taxi		2	509037	-----	
1940-41	28-29 exc. 1940 28	daubed w/red paint.....	2	509040	-----	
1941	24 sta. wag.	daubed w/red paint.....	2	509040	-----	
1941	25 exc. taxi		2	509037	-----	
1941 thru 48	26 taxi	daubed w/red paint.....	2	509040	-----	
1941	24-26-27 exc. sta. wag.		2	509039	-----	
1941 thru 48	25 taxi		2	509039	-----	
1941 thru 52	All heavy duty		2	506481	-----	
1942 thru 47	2567		2	509038	-----	
1942 thru 48	2527 S.T.		2	509038	-----	
1942 thru 48	26-27 exc. 2767, taxi & sta. wag.		2	509039	-----	
1942 thru 48	26-28 sta. wag. S.T.	daubed w/green paint.....	2	508116	-----	
1942 thru 48	28 exc. sta. wag. S.T.	daubed w/red paint.....	2	509040	-----	
1942 thru 48	2507-11-19-27B		2	509037	-----	
1948	25 H.T.		2	509039	-----	
1948	P/6-2567 S.T.		2	509039	-----	
1948	P/6-2567 H.T.	daubed w/red paint.....	2	509040	-----	
1948	P/8-2767 S.T.	daubed w/red paint.....	2	509040	-----	
1948	26-27 exc. taxi and sta. wag. H.T.	daubed w/red paint.....	2	509040	-----	
1948	26-28 sta. wag. H.T.	daubed w/grey and yellow paint.....	2	511138	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.412		SPRING ASSEMBLY, FRONT (Continued)			
1948	P/8 H.T. exc. sta. wag.	daubed w/grey paint.....	2	511135	-----
1949	P/8 S.T. 2507-08-11-27-27B-69 All	daubed w/grey paint.....	2	511135	-----
1949	P/8 H.T. 2507-08-11-27-27B-69 All	daubed w/green and brown paint.....	2	512927	-----
1949	P/6 S.T. 2507-08-11-27-27B-69 All	daubed w/red paint.....	2	509040	-----
1949	P/6 H.T. 2507-08-11-27-27B-69 All	daubed w/grey paint.....	2	511135	-----
1949	P/8 S.T. 2561-62-71 All	daubed w/grey and yellow paint.....	2	511138	-----
1949	P/8 H.T. 2561-62-71 All	daubed w/red and yellow paint.....	2	511755	-----
1949	P/6 S.T. 2561-62-71 All	daubed w/green paint.....	2	508116	-----
1949	P/6 H.T. 2561-62-71 All	daubed w/grey and yellow paint.....	2	511138	-----
1949 thru 52	P/8 S.T. 2567	daubed w/green and brown paint.....	2	512927	-----
1949 thru 52	P/8 H.T. 2567	daubed w/blue and yellow paint.....	2	512928	-----
1949 thru 52	P/6 S.T. 2567	daubed w/grey paint.....	2	511135	-----
1949 thru 52	P/6 H.T. 2567	daubed w/green and brown paint.....	2	512927	-----
1949 thru 52	P/8 S.T. & H.T. taxi & police cars	daubed w/blue and yellow paint.....	2	512928	-----
1949 thru 52	P/6 S.T. & H.T. taxi & police cars	daubed w/red and yellow paint.....	2	511755	-----
1950	P/8 S.T. 2507-08-11-27-27B-69 All	daubed w/grey paint.....	2	511135	-----
1950	P/8 H.T. 2507-08-11-27-27B-69 All	daubed w/green and brown paint.....	2	512927	-----
1950	P/6 S.T. 2507-08-11-27-27B-69 All	daubed w/red paint.....	2	509040	-----
1950	P/6 H.T. 2507-08-11-27-27B-69 All	daubed w/grey paint.....	2	511135	-----
1950 thru 52	P/8 S.T. 2562-71 All	daubed w/grey and yellow paint.....	2	511138	-----
1950 thru 52	P/8 H.T. 2562-71 All	daubed w/red and yellow paint.....	2	511755	-----
1950 thru 52	P/6 S.T. 2562-71 All	daubed w/green paint.....	2	508116	-----
1950 thru 52	P/6 H.T. 2562-71 All	daubed w/grey and yellow paint.....	2	511138	-----
1951	P/8 S.T. 2507-11-27-27B-37-69 All	daubed w/grey paint.....	2	511135	-----
1951	P/8 H.T. 2507-11-27-27B-37-69 All	daubed w/green and brown paint.....	2	512927	-----
1951	P/6 S.T. 2507-11-27-27B-37-69 All	daubed w/red paint.....	2	509040	-----
1951	P/6 H.T. 2507-11-27-27B-37-69 All	daubed w/grey paint.....	2	511135	-----
1952	P/8 S.T. 2511-37-69 All	daubed w/grey paint.....	2	511135	-----
1952	P/8 H.T. 2511-37-69 All	daubed w/green and brown paint.....	2	512927	-----
1952	P/6 S.T. 2511-37-69 All	daubed w/red paint.....	2	509040	-----
1952	P/6 H.T. 2511-37-69 All	daubed w/grey paint.....	2	511135	-----
1953-54	P/6 S.T. 2511-37-69 All	daubed w/red paint.....	2	516432	-----
1953-54	P/8 S.T. 2511-37-69-2837-69 All	daubed w/grey paint.....	2	516433	-----
1953-54	P/6 H.T. 2511-37-69 taxi & police cars All	daubed w/grey paint.....	2	516433	-----
1953-54	P/8 H.T. 2511-37-69-2837-69 All	daubed w/green and brown paint.....	2	516434	-----
1953-54	P/6 H.T. 2562-67-71 All	daubed w/green and brown paint.....	2	516434	-----
1953-54	P/6 S.T. 2562-67-71 taxi & police cars All	daubed w/grey paint.....	2	516433	-----
1953-54	P/8 S.T. 2562-67-71-2867 taxi & police cars All	daubed w/green and brown paint.....	2	516434	-----
1953-54	P/8 H.T. 2567-2867	daubed w/grey and yellow paint.....	2	516435	-----
1953-54	All heavy duty	daubed w/red and blue paint.....	2	516730	-----
Group 7.413		BUSHING, FRONT SPRING			
1931 thru 33	All	-----Front	AR	3690790	(7.504)
1933	All	-----Rear	2	379647	(7.104)
1935-36	P/6 mstr.	-----Front	2	379647	(7.104)
Group 7.417		U-BOLT, FRONT SPRING			
1935-36	P/6 mstr.	bolt type.....	4	601231	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 7.418 SEAT, FRONT SPRING						
1937-38	All	R.H.	1	231838	-----	
1937-38	All	L.H.	1	231839	-----	
1937-38	All	BOLT , front spring seat.....Inner	4	231740	-----	
1937-38	All	Outer	4	1266787	-----	(6.106)
Group 7.421 BRACKET, FRONT SPRING BUMPER						
1937-38	All	Lower	2	231842	-----	
Group 7.422 BUMPER, STEERING KNUCKLE SUPPORT ARM LOWER						
1937-38	All	at lower control arm.....	2	500429	-----	
1939 thru 54	All	at lower control arm.....	2	516442	-----	
1938	P/6 mstr.	BUSHING , front spring seat insulator.....	2	399303	-----	(7.547)
Group 7.427 PIN, SPRING SHACKLE						
1933 thru 36	All	standard.....Front or rear	4	495031	-----	
1937 thru 49	All	standard.....Rear	4	499538	-----	
1937 thru 49	All	.005" oversize.....Rear	4	500466	-----	
Group 7.428 BOLT, FRONT SPRING SHACKLE						
1931 thru 33	All	Rear	4	3685989	-----	(7.529)
1935-36	P/6 mstr.	Rear	4	3685989	-----	(7.529)
Group 7.436 SHACKLE, FRONT SPRING						
1933	All		4	495034	-----	
1935-36	P/6 mstr.		4	495034	-----	
Group 7.443 WASHER, SPRING SHACKLE PIN OR BOLT						
1933 thru 49	All	cork, rear spring rear shackle pins.....	8	593705	-----	
1939 thru 49	All	cork, rear spring front bolt.....	4	502442	-----	
Group 7.495 COVER PACKAGE, SPRING (METAL)						
1941 thru 50	All exc.	for one rear spring.....	2	507776	-----	
	heavy duty					
1951 thru 54	25 All exc.	for one rear spring.....	2	514327	-----	
	heavy duty					
1954	28 All		2	518415	-----	
Group 7.502 LINER, REAR SPRING LEAF (WOOD)						
1942 thru 50	All	(51½" long)	2	507728	-----	
1951 thru 54	25 All	(56¼" long)	AR	514845	-----	
1954	28 All	(56⅝" long)	2	517576	-----	
Group 7.503 SPRING ASSEMBLY, REAR						
NOTE: Identifying color appears on spring eye.						
1935-36	All		2	497729	-----	
1937-38	2601-09-11-19	less cover.....	2	508944	-----	
1937-38	2627-27B-67		2	500441	-----	
1939	2511-19-2611-19-27-27B	less cover.....	2	508947	-----	
1939	2527-27B		2	502903	-----	
1939-40	26-29 heavy duty		2	508949	-----	
1939-40	Sta. wag.	less cover.....	2	508951	-----	
1940	2527-27B	less cover.....	2	508952	-----	
1940	2511-19	less cover.....	2	508953	-----	
1940	29-26 All	less cover.....	2	508947	-----	
1941	2927		2	507758	-----	
1941	2919		2	507759	-----	
1941 thru 48	25 All		2	507758	-----	
1941 thru 48	26 All		2	507759	-----	
1941 thru 49	Taxi		2	507768	-----	
1941 thru 48	Sta. wag.		2	507760	-----	
1941 thru 48	Heavy duty		2	506091	-----	
1949	All exc. 2561-62-71,	white.....	2	512401	-----	
	taxi, & police cars					
1949	All police cars	green and red.....	2	513400	-----	
1949	All heavy duty		2	506091	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 7.503 SPRING ASSEMBLY, FRONT (Continued)						
1949	2561-62-71 All	-----	2	513303	-----	
1950	2507-11-27-27B-37-67-69 All	white-----	2	513624	-----	
1950	All taxi & police cars	green and red-----	2	513625	-----	
1950	2562-71 All	red and aluminum-----	2	513626	-----	
1951-52	2507-11-27-27B-37-67-69 All	yellow-----	2	514419	-----	
1951-52	All taxi & police cars	green and red-----	2	514312	-----	
1951-52	2562-71 All	red and aluminum-----	2	514313	-----	
1953-54	2511-67-69 All	-----	2	517004	-----	
1953-54	2537 All	yellow-----	2	517006	-----	
1953-54	2562-71 All	white-----	2	517008	-----	
1953-54	All taxi & police cars	red-----	2	517007	-----	
1954	2837 All	light blue-----	2	517579	-----	
1954	2867-69 All	purple-----	2	517580	-----	
Group 7.504 BUSHING, REAR SPRING						
1931 thru 38	All	-----Front	2	3690790	-----	
1935-36	P/6	-----Rear	2	379647	-----	(7.104)
1937 thru 49	All	-----Rear	4	499533	-----	
1939 thru 49	All	-----Front	2	499533	-----	
1950 thru 54	All	-----Rear	4	513639	-----	
1950 thru 54	All	-----Front	2	513638	-----	
1937 thru 54	All	BUSHING PACKAGE-----Rear	2	514049	-----	
Group 7.506 BOLT, REAR SPRING CENTER						
1935 thru 54	All	-----($\frac{5}{16}$ "-24x $\frac{3}{4}$ ")	2	1288224	-----	
Group 7.516 CLIP, REAR SPRING						
1937 thru 54	All	-----	4	500897	-----	
1933 thru 54	All	NUT, spring clip, thick-----($\frac{1}{2}$ "-20)	8	125653	-----	(8.915)
Group 7.518 PLATE, REAR SPRING CLIP						
1937-38	All	-----R.H.	1	500309	-----	
1939 thru 48	All exc. 1939 25	with direct action type shock-----R.H.	1	502255	-----	
1939 thru 48	All exc. 1939 25	with direct action type shock-----L.H.	1	502256	-----	
1949	All	-----R.H.	1	511641	-----	
1949	All	-----L.H.	1	511642	-----	
1950 thru 54	All	-----R.H.	1	513641	-----	
1950 thru 54	All	-----L.H.	1	513642	-----	
Group 7.523 SHACKLE, REAR SPRING						
1935 thru 40	All	long-----Outer R.H.	1	500304	-----	
1935 thru 40	All	short-----Inner	2	495035	-----	
1937 thru 40	All	long-----Outer L.H.	1	500305	-----	
1941 thru 54	All	-----Inner and outer	4	495035	-----	
Group 7.524 BUSHING, REAR SPRING BRACKET						
1937 thru 49	All	-----	4	499533	-----	(7.504)
Group 7.529 BOLT, REAR SPRING SHACKLE						
1931 thru 38	All	-----Front ($3\frac{5}{8}$ " long)	2	3685989	-----	
1937 thru 54	All	thru rear shackle----- (Carr. $\frac{3}{8}$ "-16x $3\frac{3}{4}$ ")	2	126720	-----	(8.903)
1939 thru 49	All	-----Front	2	508550	-----	
1950 thru 54	All	-----Front	2	3685989	-----	
1950 thru 54	All	NUT, rear spring front shackle bolt----- (Lock $\frac{1}{2}$ "-13)	2	120378	-----	(8.915)
1940 thru 49	All	WASHER, rear spring front bolt----- (Int. tooth $1\frac{1}{16}$ ")	2	141707	-----	(8.932)
Group 7.545 PAD, REAR SPRING SEAT INSULATOR						
1937 thru 49	All	-----	4	510277	-----	
Group 7.547 BUSHING, SPRING INSULATOR PAD						
1930 thru 49	All	-----Front or rear	2	399303	-----	
1939 thru 47	All	INSULATOR, spring seat pad bushing-----	4	502249	-----	
Group 7.552 RETAINER, REAR SPRING SEAT INSULATOR PAD						
1937-38	All	-----	4	399302	-----	
1939 thru 49	All	-----	4	510291	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.629 CLAMP, SPARE WHEEL					
1939	2527-27B	-----	1	594335	-----
1939-40	2511-19 and taxi	with rear tire carrier.....	1	597408	-----
1940	2527	with rear tire carrier.....	1	594335	-----
1941 thru 48	Sta. wag.	-----	1	594335	-----
1941 thru 48	2527-27B-67,	-----	1	1293432	-----
	2607, 2927 All	-----			
1941 thru 48	2507-11-19,	-----	1	1441246	-----
	2609, 2919 All	-----			
1942 thru 48	Taxi	-----	1	1441246	-----
1949 thru 54	All exc. 2561-62-71	-----	1	511658	-----
1949 thru 54	2561-62-71 All	-----	1	512416	-----
Group 7.632 BOLT, SPARE TIRE CLAMP					
1938	All exc. sta. wag.	with rear tire carrier..... (Spec. Hex. $\frac{9}{16}$ "-12x3 $\frac{1}{4}$ ")	1	408481	-----
1939-40	2527-27B	----- (Spec. Hex. $\frac{7}{16}$ "-20x1 $\frac{3}{4}$ ")	1	502681	-----
1941	2627-2927	-----	1	408481	-----
1941 thru 48	All exc. 2507	----- (Spec. Hex. $\frac{9}{16}$ "-12x2 $\frac{3}{4}$ ")	1	506462	-----
1941 thru 48	Sta. wag.	----- (Spec. Hex. $\frac{7}{16}$ "-20x1 $\frac{3}{4}$ ")	1	502681	-----
1947-48	2607 All	----- (Spec. Hex. $\frac{9}{16}$ "-12x2 $\frac{3}{4}$ ")	1	506462	-----
1949 thru 54	2561-62-71 All	----- (Spec. Hex. $\frac{9}{16}$ "-12x6 $\frac{3}{4}$ ")	1	512417	-----
1941 thru 48	2511-19-69 All	STUD, spare wheel clamp retaining.....	1	506458	-----
1941 thru 48	2609, 2919 All	-----	1	506071	-----
1942 thru 48	2507 All	-----	1	506071	-----
1949 thru 52	2511-27-27B-69 All	-----	1	511659	-----
1949-50	2507-08 All	-----	1	513903	-----
1951	2507 All	-----	1	513903	-----
1953-54	All exc. 2562-71	-----	1	517055	-----
Group 7.633 NUT, SPARE WHEEL CLAMP BOLT					
1937-38	2627B and side wheel jobs	-----	1	500164	-----
1939	2611-19	-----	1	500164	-----
1940	25-26	with side wheel carrier.....	1	500164	-----
1941 thru 48	2507-11-19-2609-2919 All	wing type.....	1	506581	-----
1949 thru 54	All exc. 2561-62-71	-----	1	511592	-----
Group 7.679 CASE, SPARE WHEEL LOCK					
1935 thru 40	All	-----	1-2	379477	-----
Group 7.680 CYLINDER, TIRE CARRIER LOCK					
1935 thru 40	All	uncoded less keys.....	AR	601271	-----
1934 thru 40	All	PLUNGER, lock case.....	1	496557	-----
1934 thru 40	All	SPRING, plunger.....	1	496558	-----
Group 7.792 PAD					
		see Group 7.865 for use.....		411799	-----
Group 7.796 SUPPORT, FRONT LICENSE PLATE					
1935 thru 39	All	-----	1	502341	-----
1940	All	-----	1	597893	-----
1934 thru 39	All	BAR, front license support, upper.....	1	496147	-----
Group 7.797 CUSHION, FRONT LICENSE PLATE					
1941-42	All	rubber..... ($\frac{1}{2}$ ")	1	506597	-----
1941 thru 48	All	SPACER, front license plate.....	2	505823	-----
Group 7.798 BRACKET, FRONT LICENSE SUPPORT					
1939	All	-----	1	502312	-----
1949 thru 53	All	-----	1	511925	-----
1954	All	-----	1	517849	-----
1940	All	CLAMP, front license bracket to bumper.....	1	408860	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.828 GUARD ASSEMBLY, BUMPER					
1938	P/8	single.....	4	501187	-----
1938	P/6	single.....	4	501188	-----
1939	All	single.....	4	502027	-----
1940	All	 Front R.H.	1	504140	-----
1940	All	 Front L.H.	1	504141	-----
1940	Exc. sta. wag.	 Rear	2-4	503578	-----
1941	All	std. equipment..... Front R.H.	1	505527	-----
1941	All	std. equipment..... Front L.H.	1	505528	-----
1941	All	std. equipment..... Rear R.H.	1	505583	-----
1941	All	std. equipment..... Rear L.H.	1	505584	-----
1942	All	std. equipment..... Front R.H.	1	507403	-----
1942	All	std. equipment..... Front L.H.	1	507404	-----
1942	All	std. equipment..... Rear R.H.	1	507405	-----
1942	All	std. equipment..... Rear L.H.	1	507406	-----
1946 thru 48	All	std. equipment..... Rear L.H.	1	508541	-----
1946 thru 48	All	std. equipment..... Rear R.H.	1	508542	-----
1946 thru 48	All	std. equipment..... Front R.H.	1	509273	-----
1946 thru 48	All	std. equipment..... Front L.H.	1	509274	-----
1949 thru 52	All	std. equipment..... Front R.H.	1	514374	-----
1949 thru 52	All	std. equipment..... Front L.H.	1	514375	-----
1949 thru 52	All exc. 2561-62-71	std. equipment..... Rear R.H.	1	514375	-----
1949 thru 52	All exc. 2561-62-71	std. equipment..... Rear L.H.	1	514374	-----
1949 thru 52	2561-62-71 All	used w/bumper wing guards..... Rear R.H.	1	514396	-----
1949 thru 52	2561-62-71 All	 Rear	2	514394	-----
1953-54	2562-71 All	std. equipment..... Rear	2	515867	-----
1953-54	All	std. equipment..... Front R.H.	1	515582	-----
1953-54	All	std. equipment..... Front L.H.	1	515583	-----
1953-54	2511-37-67-69 All	std. equipment..... Rear outer R.H.	1	515584	-----
1953-54	2511-37-67-69 All	std. equipment..... Rear outer L.H.	1	515585	-----
1953-54	All exc. 2562-71	std. equipment..... Rear center	1	515613	-----
1954	28 All	std. equipment..... Rear outer R.H.	1	517384	-----
1954	28 All	std. equipment..... Rear outer L.H.	1	517385	-----
1946 thru 48	All	BAFFLE , rear bumper guard..... Front or rear	4	508562	-----
1949-50	All		2	512901	-----
1940	All	SPACER , grille guard vertical—chrome..... Center	1	504460	-----
Group 7.828 GUARD ASSEMBLY, BUMPER ACCESSORY					
1941	All	 Front R.H., rear L.H.	2	505738	-----
1941	All	 Front L.H., rear R.H.	2	505739	-----
1942	All	 Front center R.H.	1	507407	-----
1942	All	 Front center L.H.	1	507408	-----
1942	All	 Rear center R.H.	1	507409	-----
1942	All	 Rear center L.H.	1	507410	-----
1942	All	at end..... Front R.H., rear L.H.	2	507480	-----
1942	All	at end..... Front L.H., rear R.H.	2	507479	-----
1946 thru 48	All	GUARD ASSY., WING Front R.H., rear L.H.	2	508758	-----
1946 thru 48	All	 Front L.H., rear R.H.	2	508759	-----
1949 thru 51	All	 Front R.H.	1	515955	-----
1949 thru 51	All	 Front L.H.	1	515956	-----
1949 thru 51	2561-62-71 All	 Rear R.H.	1	512347	-----
1949 thru 51	2561-62-71 All	 Rear L.H.	1	512348	-----
1949 thru 52	All exc. 2562-71	 Rear R.H.	1	515957	-----
1949 thru 52	All exc. 2562-71	 Rear L.H.	1	515958	-----
1952	All exc. 2562-71	 Front R.H.	1	515955	-----
1952	All exc. 2562-71	 Front L.H.	1	515956	-----
1953-54	All	 Front R.H.	1	515562	-----
1953-54	All	 Front L.H.	1	515563	-----
1953-54	All exc. 2562-71	 Rear R.H.	1	515551	-----
1953-54	All exc. 2562-71	 Rear L.H.	1	515552	-----
1949 thru 52	All	GUARD ASSY., MASTER Front R.H.	1	514358	-----
1949 thru 52	All	 Front L.H.	1	514359	-----
1950 thru 52	All exc. 2562-71	 Rear R.H.	1	514359	-----
1950 thru 52	All exc. 2562-71	 Rear L.H.	1	514358	-----
1953-54	All	 Front R.H.	1	515924	-----
1953-54	All	 Front L.H.	1	515925	-----
1946 thru 48	All	BOLT , bumper wing guard spacer. (Hex. $\frac{1}{16}$ "-14x2 $\frac{1}{4}$ ").....	2	180155	-----
1949 thru 52	All	wing guard to impact bar..... Front outer	2	511956	-----
1949 thru 52	All	wing guard to impact bar..... Front inner	2	511955	-----
1949 thru 52	All exc. 2561-62-71	to impact bar..... Rear outer	2	511956	-----
1949 thru 52	All exc. 2561-62-71	to impact bar..... Rear inner	2	511955	-----
1949 thru 52	2561-62-71	to impact bar.....	2	512353	-----

(8.900)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 7.828 GUARD ASSEMBLY, BUMPER ACCESSORY (Continued)						
1949 thru 54	All	master guard to brace—front or rear..... (Sp. Hd. $\frac{1}{16}$ "-14x1")	AR	499811	-----	(7.852)
1953-54	All	to impact bar..... (Hex-hd. $\frac{3}{8}$ "-24x $\frac{3}{4}$ " cad.)	8	181635	-----	(8.900)
1940	All	SPACER , at grille guard center bar—wedge type	1	504491	-----	
1941	All	grip and spring, rear bumper center guard	1	506705	-----	
1946 thru 48	All	wing guard bolt	2	509204	-----	
1946 thru 48	All	wing guard to impact bar	4	508934	-----	
1949 thru 52	All exc. 2561-62-71	wing guard to impact bar..... Rear outer	2	515973	-----	
1949 thru 52	All exc. 2561-62-71	wing guard to impact bar..... Rear inner	2	515972	-----	
1949 thru 52	All	wing guard to impact bar..... Front outer	2	515973	-----	
1949 thru 52	All	wing guard to impact bar..... Front inner	2	515972	-----	
1949 thru 51	2561-62-71 All	wing guard to impact bar..... Rear	2	512352	-----	
1942	All	WASHER , guard to rail—wedge type	8	507486	-----	
Group 7.829 BRACE, BUMPER MASTER GUARD						
1949 thru 52	All	 Front	2	512684	-----	
1950 thru 52	All exc. 2562-71	 Rear R.H.	1	514877	-----	
1950 thru 52	All exc. 2562-71	 Rear L.H.	1	514878	-----	
1953-54	All	 Front	2	515916	-----	
1949 thru 52	All	BRACKET , to frame..... Front R.H.	1	512685	-----	
1949 thru 52	All	 Front L.H.	1	512686	-----	
1953-54	All	to frame..... R.H.	1	515914	-----	
1953-54	All	to frame..... L.H.	1	515915	-----	
1940	All	CLAMP , bar to grille guard..... Front	2	504459	-----	
1941-42	All	wing guard	4	505742	-----	
1946 thru 48	All	wing guard to impact bar	4	508769	-----	
1949 thru 52	All	RETAINER , to cross bar..... Front	2	512701	-----	
Group 7.830 PLATE, FRONT BUMPER GUARD TAPPING						
1941-42	All	guard to bumper	2	505662	-----	
1946 thru 48	All		4	508549	-----	
1947-48	All	TAPPING PLATE and INSULATOR ASSY. , rear bumper guard bolt	2	510698	-----	
Group 7.831 BAR, FRONT BUMPER INTACE, CHROME						
1939	P/6		1	502032	-----	
1939	P/8		1	502950	-----	
1940	25-26 All	 Outer R.H.	1	504157	-----	
1940	All	 Outer L.H.	1	504158	-----	
1940	All	 Center	2	504154	-----	
1941	All		1	505354	-----	
1946 thru 48	All	 Outer R.H.	1	508529	-----	
1946 thru 48	All	 Outer L.H.	1	508530	-----	
1946 thru 48	All	 Center	1	508528	-----	
1949-50	All		1	511756	-----	
1951-52	All		1	514659	-----	
1953-54	All		1	515014	-----	
1946 thru 48	All	SHIM , front bumper impact bar	AR	509253	-----	
1946 thru 48	All	SPACER , front bumper bar to frame bar..... Inner	4	508532	-----	
Group 7.831 BAR, REAR BUMPER IMPACT, CHROME						
1938	P/8 exc. sta. wag.		1	501193	-----	
1939	25 exc. 2561-62		1	502039	-----	
1939	26 All		1	502040	-----	
1939	P/8		1	502948	-----	
1940	25 exc. sta. wag.		1	504066	-----	
1940	26		1	504067	-----	
1940	28		1	504068	-----	
1941	25-26		1	505374	-----	
1941	29 exc. sta. wag.		1	505375	-----	
1942	Exc. sta. wag.		1	508227	-----	
1946 thru 48	All	 Outer R.H.	1	508564	-----	
1946 thru 48	All	 Outer L.H.	1	508565	-----	
1946 thru 48	25	 Center	1	508775	-----	
1946 thru 48	26 sta. wag.	 Center	1	508983	-----	
1946 thru 48	26 exc. sta. wag.	 Center	1	508563	-----	
1949	All exc. 2561-62-71		1	511757	-----	
1949 thru 52	2561-62-71 All	 Center	1	3698600	-----	
1949 thru 51	2561-62-71 All	 Outer R.H.	1	516298	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.831 BAR, REAR BUMPER IMPACT, CHROME (Continued)					
1949 thru 51	2561-62-71 All	Outer L.H.	1	516299	-----
1950 thru 52	All exc. 2562-71	-----	1	513925	-----
1952	2562-71 All	Outer R.H.	1	3698602	-----
1952	2562-71 All	Outer L.H.	1	3698601	-----
1953-54	All exc. 2562-71	-----	1	515016	-----
1953-54	2562-71 All	Center	1	3697690	-----
1953-54	2562-71 All	Outer R.H.	1	3697344	-----
1953-54	2562-71 All	Outer L.H.	1	3697343	-----
1946 thru 48	All	SPACER, bumper bar to frame bar	2	508533	-----
Group 7.831 BAR, BUMPER (Accessory Guard)					
1942	All	grille guard, rail type	Front R.H.	1	507484
1942	All	grille guard, rail type	Front L.H.	1	507485
1942	All	grille guard, rail type	Rear R.H.	1	507411
1942	All	grille guard, rail type	Rear L.H.	1	507412
1949-50	All	master guard cross	Front	1	512683
1950 thru 52	All exc. 2562-71	master guard cross	Rear	1	514876
1952-52	All	master guard cross	Front	1	514883
1953	All	master guard cross	Front	1	515920
1954	All	master guard cross	Front	1	517680
Group 7.833 EXTENSION, REAR BUMPER APRON					
		See Group 7.871 for use		3698115	-----
Group 7.836 BAR, FRONT BUMPER TO FRAME					
1946 thru 48	All	-----	Inner	1	508535
1946 thru 48	All	-----	Outer R.H.	1	508536
1946 thru 48	All	-----	Outer L.H.	1	508537
1949-50	All	-----	Inner R.H.	1	512402
1949-50	All	-----	Inner L.H.	1	512403
1949-50	All	-----	Outer R.H.	1	512404
1949-50	All	-----	Outer L.H.	1	512405
1951-52	All	-----	Inner	1	514576
1951-52	All	-----	Outer R.H.	1	514577
1951-52	All	-----	Outer L.H.	1	514578
1953-54	All	-----	Inner	1	515018
1953-54	All	-----	Outer R.H.	1	515019
1953-54	All	-----	Outer L.H.	1	515020
1949-50	All	BAR, front bumper support	Inner center	1	511810
1953-54	All	BRACE, front bumper to frame	R.H.	1	517403
1953-54	All	-----	L.H.	1	517404
1937-38	All	BRACKET, front bumper to frame	-----	2	499807
1939	All	-----	-----	2	502028
1940	All	-----	-----	2	504152
1941	All	-----	R.H.	1	505498
1941	All	-----	L.H.	1	505499
1942	All	-----	R.H.	1	507047
1942	All	-----	L.H.	1	507048
1949-50	All	SPACER, front bumper bar to frame bar	-----	4	514018
Group 7.836 BAR, REAR BUMPER TO FRAME					
1946 thru 48	26 sta. wag.	-----	Inner	1	508989
1946 thru 48	25 All	-----	Inner	1	508777
1946 thru 48	26 exc. sta. wag.	-----	Inner	1	508567
1946 thru 48	26 exc. sta. wag.	-----	Outer R.H.	1	508568
1946 thru 48	26 exc. sta. wag.	-----	Outer L.H.	1	508569
1946 thru 48	25 All	-----	Outer R.H.	1	508778
1946 thru 48	25 All	-----	Outer L.H.	1	508779
1946 thru 48	26 sta. wag.	-----	Outer R.H.	1	508987
1946 thru 48	26 sta. wag.	-----	Outer L.H.	1	508988
1949	All exc. 2561-62-71	-----	Inner	1	511785
1949 thru 52	2561-62-71 All	-----	Center inner	1	511939
1949	All exc. 2561-62-71	-----	Outer R.H.	1	511781
1949	All exc. 2561-62-71	-----	Outer L.H.	1	511782
1949-50	2561-62-71 All	-----	Outer R.H.	1	511940
1949-50	2561-62-71 All	-----	Outer L.H.	1	511941
1950 thru 52	All exc. 2562-71	-----	R.H.	1	514714
1950 thru 52	All exc. 2562-71	-----	L.H.	1	514715
1951-52	2562-71 All	-----	Outer R.H.	1	514786
1951-52	2562-71 All	-----	Outer L.H.	1	514787

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.836		BAR, REAR BUMPER TO FRAME (Continued)			
1953-54	All exc. 2562-71	 R.H.	1	515022	-----
1953-54	All exc. 2562-71	 L.H.	1	515023	-----
1953-54	2562 All	 R.H.	1	515836	-----
1953-54	2562 All	 L.H.	1	515837	-----
1953	2571	 R.H.	1	517021	-----
1953	2571	 L.H.	1	517022	-----
1951-52	2562-71 All	BOLT , rear bumper to frame bar rear.....	2	514819	-----
1953-54	2562 All		2	514819	-----
1951-52	2562-71 All	SPACER , rear bumper frame bar.....	2	514788	-----
1953-54	2562 All		2	514788	-----
1939	25 All	BRACKET , rear bumper to frame.....	2	502033	-----
1939-40	26		2	502034	-----
1940	25 exc. sta. wag.		2	504070	-----
1940	29 All		2	504071	-----
1941	25 All	 R.H.	1	505519	-----
1941	25 All	 L.H.	1	505520	-----
1941	26 All	 R.H.	1	505482	-----
1941	26 All	 L.H.	1	505483	-----
1941	29 exc. sta. wag.	 R.H.	1	506687	-----
1941	29 exc. sta. wag.	 L.H.	1	506688	-----
1942	25 All	 R.H.	1	507058	-----
1942	25 All	 L.H.	1	507059	-----
1942	26 exc. sta. wag.	 R.H.	1	507060	-----
1942	26 exc. sta. wag.	 L.H.	1	507061	-----
Group 7.852		EMBLEM ASSEMBLY, BUMPER CENTER			
1937 thru 48	All	BOLT , impact bar to frame bar, outer front or rear..... (Spec. Hd. $\frac{1}{16}$ "-14x1")	AR	499811	-----
1946 thru 48	All	to frame..... Rear (Spec. Hd. $\frac{1}{16}$ "-14x1 $\frac{1}{2}$ ")	2	511784	-----
1946 thru 48	All	wing guard to bumper bar, standard equipment..... (Spec. Hd. $\frac{1}{16}$ "-14x $\frac{5}{8}$ ")	4	509003	-----
1941 thru 48	All	without wing guards..... (Spec. Hd. $\frac{1}{16}$ "-14x $\frac{5}{8}$ ")	AR	505666	-----
1949 thru 54	All	impact bar to frame bar..... Outer	AR	511783	-----
1949-50	All	 Inner	2	511784	-----
1941 thru 47	All	CAP , bumper guard bolt rubber.....	4	506660	-----
1940	All	CLIP , bumper center to outer bar.....	2	504153	-----
1949 thru 54	All w/out wing guards	PLUG , bumper impact bar hole..... Front or rear ($\frac{3}{8}$ " dia.)	AR	514180	-----
1949-50	All w/out wing guards	 ($\frac{5}{16}$ ")	8	513432	-----
1950 thru 54	All w/out wing guards	 ($\frac{3}{8}$ ")	AR	514181	-----
Group 7.859		BOLT, BUMPER			
1940	All	center bar center bolt..... (Spec. Hd. $\frac{1}{16}$ "-14x3 $\frac{3}{8}$ ")	1	504149	-----
1940	All	center bar to clip..... (Spec. Hd. $\frac{1}{16}$ "-14x3 $\frac{3}{8}$ ")	4	504151	-----
1946 thru 54	All	front and rear bumper to frame..... (Spec. Hd. $\frac{1}{2}$ "-20x1 $\frac{1}{16}$ ")	AR	508895	-----
1949-50	All	front bump. assy. to frame (Zinc).....	2	511830	-----
1953-54	All	front bumper to frame..... (Spec. $\frac{1}{2}$ "-20x1 $\frac{3}{4}$ ")	4	517405	-----
Group 7.860		SPACER FRONT BUMPER CENTER BAR			
1940	All	 Outer	4	504148	-----
1940	All	 Center	1	504150	-----
Group 7.865		PAD, BUMPER (RUBBER)			
1937-38	All	to fender..... Front	2	500477	-----
1939-40	All	front bumper to fender.....	2	504077	-----
1939	26	to body..... Rear	2	411799	-----
1940	25 exc. sta. wag.	rear bumper to body.....	2	504076	-----
1940	26-29	to body..... Rear	2	504077	-----
Group 7.866		STABILIZER, FRONT BUMPER			
1946 thru 48	All	 R.H.	1	510255	-----
1946 thru 48	All	 L.H.	1	510256	-----
1946	All	STABILIZER PKG.	1	510420	-----
Group 7.868		CUSHION, FRONT BUMPER APRON			
1941	All	to bumper bracket—rubber.....	2	505941	-----
1946 thru 48	All	INSULATOR , bumper center bar..... Front and rear	2	508772	-----
1946 thru 48	All	front bumper to bumper apron.....	2	510268	-----
1947-48	All	BUMPER , front bumper apron to grille—rubber.....	3	503865	-----
1947	All	RETAINER , front bumper apron to grille.....	4	494104	-----

(7.792)

(1.216)
(2.175)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 7.870		APRON, BUMPER			
1941	All	APRON, front bumper	1	505242	-----
1942-46	All	-----	1	506964	-----
1947-48	All	-----	1	510619	-----
1949	All	-----	1	511758	-----
1950	All	-----	1	513742	-----
1951-52	All	-----	1	514586	-----
1953	All	-----	1	515618	-----
1954	All	-----	1	517637	-----
1941-42	25 All	APRON, rear bumper	1	506016	-----
1941-42	2607-09 All	-----	1	506017	-----
1941	29 All	-----	1	506018	-----
1946 thru 48	2607-09 All	-----	1	508556	-----
1946 thru 48	Sta. wag.	-----	1	508963	-----
1946 thru 48	25 All	-----	1	508780	-----
1949-50	All exc. 2561-62-71	-----	1	511693	-----
1949 thru 52	2561-62 All	-----	1	512215	-----
1949 thru 52	2571	-----	1	512216	-----
1951-52	All exc. 2562-71	-----	1	514585	-----
1953-54	2511-37-67-69 All	-----	1	515686	-----
1953-54	2562 All	-----	1	515902	-----
1953	2571	-----	1	515873	-----
1954	28 All	-----	1	517613	-----
1948	All	BOLT, apron to fender	2	510450	-----
1949 thru 54	All	SCREW, front bumper apron to rad. splash apron and to fender	AR	3650059	----- (8.143)
Group 7.871		ANTI-SQUEAK, REAR BUMPER APRON EXTENSION			
1946 thru 48	25 All	-----	2	508792	-----
1946 thru 48	26 exc. sta. wag.	-----	2	508555	-----
1946 thru 48	Sta. wag.	-----	2	508967	-----
1946 thru 48	Sta. wag.	apron to fender.....	2	508962	-----
1949	All	rear bumper apron.....	1	3688664	-----
1949	2561-62 All	-----	1	3689013	-----
1941	25 All	CUSHION, rear bumper apron to frame	2	506056	-----
1941-42	All exc. 1941-25	rubber.....	2	506057	-----
1946 thru 48	25 All	EXTENSION ASSEMBLY, rear bumper apron R.H.	1	508783	-----
1946 thru 48	25 All	L.H.	1	508784	-----
1946 thru 48	2607-09 All	R.H.	1	508570	-----
1946 thru 48	2607-09 All	L.H.	1	508571	-----
1946 thru 48	Sta. wag.	R.H.	1	508975	-----
1946 thru 48	Sta. wag.	L.H.	1	508976	-----
1949 thru 52	All exc. 2561-62-71	R.H.	1	511699	-----
1949 thru 52	All exc. 2561-62-71	L.H.	1	511700	-----
1946 thru 48	25 All	FILLER, rear bumper to apron	1	508782	-----
1946 thru 48	2607-09 All	-----	1	508558	-----
1946 thru 48	Sta. wag.	-----	1	508965	-----
1949 thru 54	All exc. 2561-62-71	-----	1	512103	-----
1949 thru 52	2561-62-71 All	-----	1	3688856	-----
1946 thru 48	25 All	apron extension..... R.H.	1	508790	-----
1946 thru 48	25 All	apron extension..... L.H.	1	508791	-----
1946 thru 48	2607-09 All	apron extension..... R.H.	1	508574	-----
1946 thru 48	2607-09 All	apron extension..... L.H.	1	508575	-----
1949 thru 52	All exc. 2561-62-71	apron extension..... R.H.	1	512104	-----
1949 thru 52	All exc. 2561-62-71	apron extension..... L.H.	1	512105	-----
1953-54	All exc. 2562-71	apron end..... R.H.	1	515271	-----
1953-54	All exc. 2562-71	apron end..... L.H.	1	515272	-----
1953-54	2562-71 All	-----	1	3698115	----- (7.833)
1942	All exc. sta. wag.	SUPPORT, rear bumper apron to frame	2	507520	-----
1941 thru 54	All	SCREW, bumper apron to body			
		(Spec. Hex. No. 14x $\frac{3}{4}$ ") Rear	AR	3650059	----- (8.143)
1946 thru 48	Sta. wag.	BOLT, bumper apron to extension			
		(Truss Hd. $\frac{1}{4}$ "-20- $\frac{5}{8}$ ") Rear	4	137335	----- (8.913)
1941 thru 48	All	NUT, bumper apron to bumper spring (No. 14) Rear	9	414791	----- (8.921)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.000 PANEL, HOOD UPPER					
1939	25 All	----- R.H.	1	503255	-----
1939	25 All	----- L.H.	1	503256	-----
1939	26 All	----- R.H.	1	503257	-----
1939	26 All	----- L.H.	1	503258	-----
1940	25 All	----- R.H.	1	504431	-----
1940	25 All	----- L.H.	1	504432	-----
1940	26 All	----- R.H.	1	504433	-----
1940	26 All	----- L.H.	1	504434	-----
1940	29 All	----- R.H.	1	504435	-----
1940	29 All	----- L.H.	1	504436	-----
1941	29 All	----- R.H.	1	505106	-----
1941	29 All	----- L.H.	1	505107	-----
1941	25 All	----- R.H.	1	505210	-----
1941	25 All	----- L.H.	1	505211	-----
1941	26 All	punched for mldg.----- R.H.	1	505146	-----
1941	26 All	punched for mldg.----- L.H.	1	505147	-----
1942	25 All	punched for mldg.----- R.H.	1	506839	-----
1942	25 All	punched for mldg.----- L.H.	1	506840	-----
1942	26 All	punched for mldg.----- R.H.	1	506906	-----
1942	26 All	punched for mldg.----- L.H.	1	506907	-----
1942	25 All	----- R.H.	1	508092	-----
1942	25 All	----- L.H.	1	508093	-----
1942 thru 47	26 All	----- R.H.	1	508610	-----
1942	26 All	----- L.H.	1	508095	-----
1946-47	25 All	----- R.H.	1	508686	-----
1946-47	25 All	----- L.H.	1	508687	-----
1946-47	26 All	----- L.H.	1	508611	-----
1948	25 All	----- R.H.	1	510492	-----
1948	25 All	----- L.H.	1	510493	-----
1948	26 All	----- R.H.	1	510494	-----
1948	26 All	----- L.H.	1	510495	-----
1949-50	All	----- R.H.	1	514778	-----
1949-50	All	----- L.H.	1	514779	-----
1951-52	All	----- R.H.	1	516510	-----
1951-52	All	----- L.H.	1	516511	-----
1953	All	----- R.H.	1	514956	-----
1953	All	----- L.H.	1	514957	-----
1954	All	----- R.H.	1	517623	-----
1954	All	----- L.H.	1	517624	-----
1949 thru 52	All	BRACE ASSEMBLY, hood cross----- Front	1	513225	-----
1953-54	All	----- Front	1	515860	-----
1942 thru 48	All	SCREW, R.H. to L.H. hood panel attaching----- (Hex. No. 8-15x $\frac{3}{8}$ ")	AR	504971	(8.269)
1949 thru 54	All	----- (Hex. No. 8-15x $\frac{3}{8}$ ")	AR	443882	(8.977)
1949 thru 54	All	SCREW AND LOCKWASHER ASSY., hood cross brace----- Front	4	513565	-----
Group 8.001 PANEL, HOOD SIDE					
1939	25 All	----- R.H.	1	502973	-----
1939	25 All	----- L.H.	1	502974	-----
1939	26 All	----- R.H.	1	502975	-----
1939	26 All	----- L.H.	1	502976	-----
1940	25 All	----- R.H.	1	503912	-----
1940	25 All	----- L.H.	1	503913	-----
1940	26 All	----- R.H.	1	503914	-----
1940	26 All	----- L.H.	1	503915	-----
1940	29 All	----- R.H.	1	503916	-----
1940	29 All	----- L.H.	1	503917	-----
1940	All	side panel to fender skirt. (Sheet Metal No. 12x $\frac{3}{4}$ ")	8	179370	(8.977)
1937-38	All	NUT, hood side panel wing.----- ($\frac{1}{4}$ "-20)	6	110685	(8.920)
1940	All	side panel to fender skirt.----- (Spec. No. 12)	8	502443	(1.273)
1940	All	SCREW, hood side panel to radiator support.----- (No. 12x $\frac{3}{8}$ ")	4	179368	(8.977)
Group 8.005 LOUVRE, HOOD SIDE PANEL					
1940	All	----- R.H.	3	503719	-----
1940	All	----- L.H.	3	503720	-----
1940	All	NUT, hood louvre spring.----- ($\frac{3}{16}$ ")	24	177941	(8.921)
Group 8.007 BRACKET, HOOD PANEL					
1940	25 All	----- Side lower	2	504044	-----
1937-38	All	BOLT, hood panel and support bracket.-----	6	502223	(8.238)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 8.013 PROP ASSEMBLY, HOOD						
1937-38	All	----- R.H.	1	500380	-----	
1937-38	All	----- L.H.	1	500381	-----	
1939-40	26 All	PIN, hood prop clevis -----	2	370825	-----	(5.052)
Group 8.013 BRACKET, HOOD HINGE SPRING DASH						
1940	25 All	----- L.H.	1	503769	-----	
1941	29 All	----- R.H.	1	506174	-----	
1941	29 All	----- L.H.	1	506175	-----	
1941	26 All	----- R.H.	1	505697	-----	
1941	26 All	----- L.H.	1	505698	-----	
1942 thru 48	25 All	----- R.H.	1	507182	-----	
1942 thru 48	25 All	----- L.H.	1	507183	-----	
1942 thru 48	26 All	----- R.H.	1	507257	-----	
1942 thru 48	26 All	----- L.H.	1	507258	-----	
1949 thru 52	All	to shroud ----- R.H.	1	511632	-----	
1949 thru 52	All	to shroud ----- L.H.	1	511633	-----	
1953-54	All	to shroud ----- R.H.	1	515188	-----	
1953-54	All	to shroud ----- L.H.	1	515189	-----	
1949-50	All	GUIDE ASSY., hood rear -----	1	512737	-----	
1949-50	All	BRACKET, hood rear guide -----	1	512736	-----	
1939-40	All exc. 1940	SPRING, hood hinge -----	2	504986	-----	
1940	25 All	----- Front	2	504969	-----	
1940	29 All	----- Front	2	504975	-----	
1941	29 All	----- Front	2	506189	-----	
1941	25 All	----- Front	2	506412	-----	
1941	26 All	----- Front	2	506053	-----	
1942 thru 48	All	----- Front	2	507187	-----	
1949 thru 54	All	----- Front	2	512700	-----	
Group 8.015 HINGE ASSY., HOOD						
1939	25 All	HINGE ASSY., hood—with reinforcement -----	1	502576	-----	
1939	26 All	-----	1	502415	-----	
1940	26 All	-----	1	503810	-----	
1940	29 All	-----	1	503808	-----	
1941	29 All	-----	1	505695	-----	
1941	25 All	-----	1	505689	-----	
1941	26 All	-----	1	505694	-----	
1942 thru 48	25 All	-----	1	508693	-----	
1942 thru 48	26 All	----- Rear	1	508692	-----	
1949 thru 52	All	-----	1	511616	-----	
1953-54	All	-----	1	515602	-----	
1940	25 All	LINK, hood hinge ----- Front	2	503758	-----	
1940	26 All	----- Front	2	503822	-----	
1940	29 All	----- Front	2	503754	-----	
1940	25 All	----- Rear R.H.	1	504471	-----	
1940	25 All	----- Rear L.H.	1	504472	-----	
1940	26 All	----- Rear	2	503821	-----	
1940	29 All	----- Rear R.H.	1	503766	-----	
1940	29 All	----- Rear L.H.	1	503767	-----	
1941	26-29 All	----- Front	2	505578	-----	
1941	25 All	----- Front	2	505692	-----	
1941	26-29 All	----- Center R.H.	1	506167	-----	
1941	26-29 All	----- Center L.H.	1	506168	-----	
1941	26-29 All	----- Intermediate R.H.	1	506540	-----	
1941	26-29 All	----- Intermediate L.H.	1	506541	-----	
1941	26-29 All	----- Rear	2	505581	-----	
1941	25 All	----- Rear	2	505693	-----	
1942 thru 48	25 All	----- Front	2	507184	-----	
1942 thru 48	26 All	----- Front	2	507253	-----	
1942 thru 48	25 All	----- Rear R.H.	1	507185	-----	
1942 thru 48	25 All	----- Rear L.H.	1	507186	-----	
1942 thru 48	26 All	----- Rear R.H.	1	507254	-----	
1942 thru 48	26 All	----- Rear L.H.	1	507255	-----	
1949 thru 54	All	----- Front R.H.	1	511621	-----	
1949 thru 54	All	----- Front L.H.	1	511622	-----	
1949 thru 52	All	----- Rear R.H.	1	511623	-----	
1949 thru 52	All	----- Rear L.H.	1	511624	-----	
1953-54	All	----- Rear R.H.	1	516403	-----	
1953-54	All	----- Rear L.H.	1	516404	-----	
1942 thru 54	All	PIN, hood hinge link pivot -----	8	563569	-----	
1939	All	BOLT, hood hinge and bracket ----- (hex. No. 12x $\frac{1}{8}$ ")	6	145415	-----	(8.977)
1940	All	hood hinge to hood ----- (Spec. hd. No. 10-24x $\frac{1}{8}$ ")	2	505035	-----	
1939	All	RIVET, hood hinge -----	8	502431	-----	
1939 thru 41	All	-----	4-6	503794	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.015 HINGE ASSY., HOOD (Continued)					
1941	26-29 All	RIVET, intermediate link	4	505699	-----
1941	26-29 All	hood spring hook to link	2	506019	-----
1942 thru 48	All	hood hinge	8	507188	-----
1939	All	WASHER, hood hinge	4	500456	----- (7.397)
1940	All	 (1 1/2" I.D.x1 1/2" O.D.)	1	503795	-----
1940	All	to body	4	505000	-----
1941	All	 (1 1/2" I.D.x1 1/2" O.D.)	8-12	505943	-----
1941	All	 (1 1/2" I.D.x1 1/2" O.D.)	4	506050	-----
1949 thru 54	All	to body—rubber	4	513984	-----
Group 8.019 BRACKET, HOOD HINGE COWL					
1941	25 All	 R.H.	1	505706	-----
1941	25 All	 L.H.	1	505707	-----
1941	26-29 All	 R.H.	1	505708	-----
1941	26-29 All	 L.H.	1	505709	-----
1942 thru 48	25 All	 R.H.	1	507350	-----
1942 thru 48	25 All	 L.H.	1	507351	-----
1942 thru 48	26 All	 R.H.	1	507352	-----
1942 thru 48	26 All	 L.H.	1	507353	-----
Group 8.024 BUMPER, HOOD PANEL					
1938	All	upper panel to radiator	4	499379	----- (1.216)
1939	26 All	upper panel to cowl	2	499379	----- (1.216)
1939	25 All	upper panel to cowl	2	500222	----- (1.216)
1941	25 All	to front fender upper	2	505306	-----
1941	25 All	to front fender lower	2	506468	-----
1941 thru 52	All	to fender	AR	503865	----- (1.216)
1941 thru 48	All	to lower catch plate	2	506351	-----
1948	All	to shroud	2	419674	-----
1949 thru 52	All	to shroud	2	513388	-----
1953-54	All	to fender	12	515456	-----
1953-54	All	to shroud	2	517442	-----
1953-54	All	BRACKET, hood to shroud bumper	2	517441	-----
1949 thru 54	All	CAP, hood adjustable bumper	Front 2	511961	-----
1949 thru 54	All	NUT, hood adjustable bumper, spring type	Front 2	511947	-----
1949 thru 53	All	SCREW, hood adjustable bumper	(5/16"-18x1 1/4") 2	160722	-----
1953-54	All	 (5/16"-18x1 1/2")	2	160731	-----
		See Group 10.587 for use		3664645	-----
Group 8.030 ORNAMENT, HOOD TOP (ILLUMINATED)					
1949	All	less insert	1	512714	-----
1950	All	with insert	1	513870	-----
1951	All	with insert	1	514871	-----
1952	All	with insert	1	515576	-----
1953	All	with insert	1	516830	-----
1954	All	with insert	1	517629	-----
1953	All	CLIP, hood top ornament wing ret.	1	4152044	-----
1949	All	INSERT, ornament	1	512713	-----
1950	All		1	513871	-----
1951	All		1	514869	-----
1952	All	face	1	515577	-----
1952	All	 Upper	1	515578	-----
1953	All	face	1	516725	-----
1954	All	face	1	517673	-----
1949 thru 54	All	SHROUD, hood top ornament bulb	1	513496	-----
1953	All	WING, hood top ornament	R.H. 1	516989	-----
1953	All		L.H. 1	516990	-----
1949	All	WIRE & SOCKET ASSY.	1	5289584	-----
1950 thru 52	All		1	5290783	-----
1953-54	All	on body	(16" long) 1	5298539	-----
1953	All	on hood	(86" long) 1	5298735	-----
1954	All	on hood	(86 1/2" long) 1	5299808	-----
Group 8.030 ORNAMENT, HOOD TOP					
1938	P/6	lock type	1	501199	-----
1939	P/8	lock type	1	502785	-----
1939	P/6	lock type	1	502553	-----
1940	P/6	lock type	1	503976	-----
1940	P/8 exc. 29	lock type	1	504232	-----
1940	29	lock type	Front 1	504163	-----
1940	29	lock type	Rear 1	504164	-----
1941	P/8	lock type	1	505449	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.030 ORNAMENT, HOOD TOP (Continued)					
1941	P/6	-----	1	505435	-----
1942	All	-----	1	507432	-----
1946	25 All	-----	1	508668	-----
1946	26 All	-----	1	508614	-----
1947	All	-----	1	509591	-----
1948	All	-----	1	510563	-----
1949	All	exc. illuminated ornament	1	511506	-----
1950	All	exc. illuminated ornament	1	513747	-----
1951	All	exc. illuminated ornament—chrome	1	516415	-----
1952	All	exc. illuminated ornament	1	515594	-----
1953	All	exc. illuminated ornament	1	516780	-----
1954	All	exc. illuminated ornament	1	517658	-----
1948	All	EMBLEM, hood front	1	510562	-----
1949	All	-----	1	511667	-----
1950	All	-----	1	513676	-----
1940	P/8	INSERT, hood ornament	1	504245	-----
1942	All	----- Plastic	1	507305	-----
1946	26 All	----- Plastic	1	508616	-----
1948	All	----- Plastic	1	510564	-----
1951	All	exc. illuminated ornament—plastic	1	507305	-----
1941	P/8	INSERT PACK., consists of insert and screws	1	506766	-----
1942-46	All exc. 1946 25	----- Rear	1	507614	-----
1941 thru 46	P/8	SCREW, ornament to base (No. 6-32x $\frac{3}{4}$ ")	3	100908	(8.907)
1951	All	ornament to base—used w/plastic insert	3	100908	(8.907)
1948	All	SCREW AND WASHER ASSY., hood insert	2	512021	-----
1951	All	SPACER, hood top ornament to hood	1	515985	-----
Group 8.032 BRACKET, HOOD LOCK ORNAMENT					
1939	All	-----	1	502551	-----
1940	25-26 All	-----	1	503752	-----
1940	29 All	-----	1	503734	-----
1939-40	All	PIN, hood lock clevis	1	502542	-----
1939-40	All	SPRING, hood lock ornament	1	502539	-----
Group 8.034 REINFORCEMENT, HOOD LOCK PILOT					
1939	All	-----	1	502552	-----
1940	All	-----	1	503755	-----
Group 8.035 PILOT, HOOD LOCK					
1939-40	All	-----	1	502540	-----
1941 thru 48	All	hood catch plate	1	506571	-----
1949 thru 52	All	BRACKET ASSEMBLY, hood catch pilot to hood	1	511916	-----
1953-54	All	pilot to upper baffle	1	515333	-----
1939-40	All	SPRING, hood lock pilot	1	502543	-----
1941 thru 52	All	-----	1	506572	-----
1939-40	All	RETAINER, hood lock pilot spring	1	502546	-----
1941 thru 52	All	-----	1	3685641	(8.085)
Group 8.036 CATCH, HOOD LOCK SAFETY					
1939-40	All	-----	1	502545	-----
1941	All	-----	1	506574	-----
1942	All	-----	1	507866	-----
1946-47	All	HOOK, hood catch upper plate safety	1	508873	-----
1948	All	HOOK ASSY.	1	510572	-----
1949 thru 52	All	-----	1	511767	-----
1939-40	All exc. 1940 25	EYE BOLT, hood lock	2	502538	-----
1940	25 All	-----	2	503753	-----
1949 thru 52	All	PLATE, hood safety hook striker	1	512537	-----
1941-42	All	RIVET, hood catch hook	1	506575	-----
1946 thru 48	All	-----	1	508875	-----
1939-40	All	ROLLER, hood lock	1	502541	-----
1939-40	All	ROD, hood lock roller	1	502544	-----
1939-40	All	SPRING, hood lock rod	1	502548	-----
1939-40	All	----- R.H.	1	502549	-----
1941-42	All	SPRING, hood safety catch	1	506576	-----
1946 thru 48	All	-----	1	508876	-----
Group 8.038 GUIDE, HOOD LOCK PILOT					
1939	All	-----	1	502547	-----
1940	All	-----	1	503756	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.039 PLATE, HOOD SIDE PANEL NAME					
1941	P/6	Pontiac.....	2	505644	-----
1941	P/8	Pontiac.....	2	505645	-----
1941	P/8	Eight.....	2	505646	-----
1942	P/8	Pontiac Eight..... R.H.	1	507522	-----
1942	P/8	Pontiac Eight..... L.H.	1	507523	-----
1946	P/8	Pontiac Eight..... R.H.	1	508621	-----
1946	P/8	Pontiac Eight..... L.H.	1	508622	-----
1946	P/6	Pontiac..... R.H.	1	508625	-----
1946	P/6	Pontiac..... L.H.	1	508626	-----
1947	All	ORNAMENT, hood side..... R.H.	1	509530	-----
1947	All	 L.H.	1	509531	-----
1948	P/6		2	510559	-----
1948	P/8		2	510560	-----
1941	All	NUT, side panel name plate spring.....	6-12	505654	-----
1942	P/8		4	507528	-----
1948	All	WASHER, hood side ornament to hood.....	4	511948	-----
Group 8.040 SPEED NUT					
		See Group 2.680, 2.724 and 8.147 for use.....		3695282	-----
Group 8.049 GRILLE ASSY., HOOD CENTER					
1939	25 All		1	502075	-----
1939	26 All		1	502076	-----
1940	25 All		1	503579	-----
1940	26 All		1	503580	-----
1940	29 All		1	503594	-----
1941	25 All		1	505756	-----
1941	26 All		1	505757	-----
1941	29 All		1	505758	-----
1942 thru 47	25 All		1	506849	-----
1942 thru 47	26 All		1	506850	-----
1948	25 All		1	511738	-----
1948	26 All		1	511737	-----
1949	All		1	511493	-----
1950	All		1	513768	-----
1951	All		1	514428	-----
1952	All		1	516480	-----
1953	All		1	516775	-----
1954	All		1	517599	-----
1942 thru 47	All	PLATE, hood center grille finish.....	1	507087	-----
1953-54	All	WASHER, hood center grille sealing.....	10	516932	----- (10.203)
Group 8.050 ATTACHING PARTS, HOOD GRILLE					
1940	All	PAD, hood grille, at center grille retainer..... Rubber	3	503833	-----
1939-40	All	RETAINER, hood center grille.....	8	502635	-----
1937-38	All	BOLT, hood grille, at center grille anchor plate.....	2	502223	----- (8.238)
1941 thru 54	All	hood center grille..... (Carr. No. 10-24x $\frac{3}{8}$ ")	16	126193	----- (8.903)
1948	All	hood center grille retainer Nos. 1 and 3..... (No. 10-24x $\frac{1}{8}$ ")	4	510598	-----
Group 8.054 MOLDING, HOOD TOP PANEL SIDE					
1938	P/6	 R.H.	1	501053	-----
1938	P/6	MOLDING, hood panel..... Side	2	501132	-----
1939	All	 Side	8	502399	-----
1939	26 All	 Upper R.H.	1	502524	-----
1939	26 All	 Upper L.H.	1	502525	-----
1940	25-26	square end on 26..... L.H.	1	504667	-----
1940	26 All	tapered end..... R.H.	1	503712	-----
1940	26 All	tapered end..... L.H.	1	503713	-----
1940	29 All	 L.H.	1	503736	-----
1941	P/6 29	 R.H.	1	505371	-----
1941	P/6 29	 L.H.	1	505372	-----
1941	25 All		2	506609	-----
1941	26 All	 R.H.	1	505369	-----
1941	26 All	 L.H.	1	505370	-----
1941	P/8 25		2	506610	-----
1941	P/8 26	 R.H.	1	505649	-----
1941	P/8 26	 L.H.	1	505650	-----
1941	P/8 29 All	 R.H.	1	505651	-----
1941	P/8 29 All	 L.H.	1	505652	-----
1942	P/6 All	 R.H.	1	507037	-----
1942	P/6 All	 L.H.	1	507038	-----
1942	P/8 All	 R.H.	1	507524	-----
1942	P/8 All	 L.H.	1	507525	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 8.054 MOLDING, HOOD TOP PANEL SIDE (Continued)						
1939-40	All exc. 1939-25	BOLT , hood upper panel molding				
		(Spec. No. 10-24x $\frac{3}{8}$ ")	4	502760	-----	
1941	25 All	(Spec. No. 10-24x $\frac{3}{8}$ ")	2	505448	-----	(8.231)
1941	25 All	(Spec. No. 10-24x $\frac{3}{8}$ ")	6	506247	-----	(8.177)
1942	All		16	507053	-----	
1939	26 All	FASTENER , hood upper panel molding	20	502761	-----	
1939	All	side molding	32	502764	-----	
1940	All	hood upper panel molding	18	504330	-----	
1941	25 All	hood panel molding	8	506629	-----	
Group 8.056 BOLT						
		See Group 12.118 for use		1300735	-----	
Group 8.075 CONTROL ASSEMBLY, HOOD CATCH						
1941	All		1	505582	-----	
1942 thru 48	All		1	510785	-----	
1949-50	All L.H.D.		1	512205	-----	
1951	All L.H.D.		1	514571	-----	
1952	All L.H.D.		1	516507	-----	
Group 8.076 GROMMET, HOOD CATCH CONTROL CABLE THRU RADIATOR						
1948	All	Upper baffle	1	511181	-----	
Group 8.077 TRUNNION, HOOD CATCH CONTROL						
1941, 1948 thru 52	All		1	375437	-----	(3.483)
1942 thru 47	All		1	507865	-----	
1941 thru 48	All	CLIP , hood control cable, to fender L.H.	2	506179	-----	
1949 thru 52	All	hood catch cable to fender skirt	4	4572939	-----	(11.582)
1941 thru 52	All	at loom	1	505986	-----	
1941 thru 47	All	to lower catch plate	1	413993	-----	
1948 thru 50	All	control cable to lower plate	1	3658861	-----	
1951-52	All	control cable to lower plate	1	511984	-----	
Group 8.080 PLATE ASSEMBLY, HOOD CATCH LOWER						
1941	All		1	505526	-----	
1942 thru 47	All		1	508867	-----	
1948	All	for baffle see Group 1.285	1	3664616	-----	
1949-50	All	for baffle see Group 1.285	1	511905	-----	
1951-52	All	for baffle see Group 1.285	1	514563	-----	
1941	25 All	BRACE , hood catch upper plate to hood	1	506313	-----	
1941	26-29 All		1	506314	-----	
1942 thru 48	25 All		1	507119	-----	
1942 thru 48	26 All		1	507120	-----	
1941	See note	BRACE , lower plate to radiator, two piece R.H.	1	505829	-----	
1941	See note	L.H.	1	506361	-----	
1941	See note	one piece	1	506588	-----	
1942 thru 47	All	BRACE , lower plate to radiator support	1	506960	-----	
1948	All		1	510575	-----	
1949 thru 52	All		1	511879	-----	
1953	All	BRACE , upper baffle to radiator support	1	515247	-----	
1954	All		1	517743	-----	
NOTE: Part Nos. 505829 and 506361 used on 1941 thru Serial Nos. 8JA 2324, 8JB 4859, 8JC 3072, 6JA 3816, 6JB 7596 and 6JC 3289. Part No. 506588 used on 1941 after the above serial numbers.						
Group 8.081 SPRING, HOOD CATCH LOCK PLATE						
1948	All		1	3658835	-----	
Group 8.082 BOLT, HOOD CATCH LOCK						
1941	All		1	506567	-----	
1942 thru 47	All		1	507858	-----	
Group 8.083 PLATE ASSEMBLY, HOOD CATCH UPPER						
1941	All		1	505525	-----	
1942 thru 47	All		1	508871	-----	
1948	All		1	510573	-----	
1946 thru 48	All	BRACKET , safety hook	1	508872	-----	
1953	All	LATCH AND SAFETY HOOK ASSY. , hood	1	515334	-----	
1954	All		1	517758	-----	
1941	All	LEVER , hood catch lock	1	506563	-----	
1941	All	RIVET , hood lock Lever to bolt	1	506568	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.084 SPRING, HOOD CATCH LEVER					
1941 thru 47	All	At lower lock lever	1	506566	-----
1942 thru 47	All	Lock bolt auxiliary	1	508128	-----
1951-52	All	SPRING, hood latch (Coil $\frac{1}{16}$ " x $2\frac{3}{16}$ ")	1	514568	-----
Group 8.085 RETAINER, HOOD CATCH LOCK PLATE					
1948	All		1	3658875	-----
1949 thru 52	All	BOLT, hood catch pilot	1	2227394	-----
1953-54	All		1	516343	-----
		See Group 8.035 for use		3685641	-----
Group 8.112 APRON, ENGINE SIDE					
1939-40	25-26 L.H.D.	L.H.	1	502752	-----
1940	29 All	L.H.	1	504211	-----
1941 thru 48	P/6 L.H.D.	R.H.	1	505458	-----
1941 thru 48	P/8 L.H.D.	R.H.	1	505905	-----
1941 thru 48	All L.H.D.	L.H.	1	506737	-----
1949 thru 52	All	R.H.	1	511654	-----
1949 thru 52	All L.H.D.	L.H.	1	511655	-----
1953	All S.S.	L.H.	1	516311	-----
1953-54	All P.S.	L.H.	1	517398	-----
1953-54	All H.T.	R.H.	1	517929	-----
1950 thru 52	All	R.H.	1	513784	-----
1939 thru 54	All	DOOR ASSY., front fender access		177999	-----
		SCREW, engine apron to frame (No. 14x $\frac{1}{2}$ ")	4-8		(8.977)
Group 8.120 BRACKET, ENGINE SIDE PAN					
1939-40	All exc. 29 L.H.D.	Rear R.H.	1	502757	-----
Group 8.125 APRON, RADIATOR SPLASH					
1937-38	All		1	499541	-----
1939	All		1	502190	-----
1940	All exc. 29		1	503679	-----
1940	29 All		1	503905	-----
1941 thru 48	All	front cross member to radiator R.H.	1	507884	-----
1941 thru 48	All	front cross member to radiator L.H.	1	507885	-----
1942 thru 47	All	to radiator support	1	506968	-----
1948	All	to radiator support	1	510502	-----
1949 thru 52	All	to radiator cross member	1	511866	-----
1949 thru 52	All	to radiator support	1	511846	-----
1953-54	All	to radiator cross member	1	517010	-----
1953-54	All	to support and baffles	1	515031	-----
Group 8.130 FENDER, FRONT (PRIME)					
NOTE: Fenders are less skirt unless otherwise specified.					
1937-38	P/8	includes skirt, without well R.H.	1	500275	-----
1937	P/8	includes skirt, without well L.H.	1	500276	-----
1938	P/8	includes skirt, without well L.H.	1	501263	-----
1938	P/6	includes skirt, without well L.H.	1	501264	-----
1939	25 All	includes skirt, without well R.H.	1	502604	-----
1939	25 All	includes skirt, without well L.H.	1	502605	-----
1939	26 All	includes skirt, without well R.H.	1	502648	-----
1939	26 All	includes skirt, without well L.H.	1	502649	-----
1940	26 All		1	503662	-----
1940	26 All		1	503663	-----
1940	29 All		1	503698	-----
1940	29 All		1	503699	-----
1941	29 All		1	505214	-----
1941	29 All		1	505215	-----
1941	25 All		1	505260	-----
1941	26 All		1	505218	-----
1941	26 All		1	505219	-----
1942 thru 47	25 All		1	507206	-----
1942 thru 47	25 All		1	507207	-----
1942 thru 47	26 All		1	507847	-----
1942 thru 47	26 All		1	507848	-----
1948	25 All		1	510468	-----
1948	25 All		1	510469	-----
1948	26 All		1	510470	-----
1948	26 All		1	510471	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.130 FENDER, FRONT (PRIME) (Continued)					
1949-50	All	----- R.H.	1	515838	-----
1949-50	All	----- L.H.	1	515839	-----
1951-52	All	----- R.H.	1	515723	-----
1951-52	All	----- L.H.	1	515724	-----
1953	All std. exc. 2571	----- R.H.	1	514952	-----
1953	All std. exc. 2571	----- L.H.	1	514953	-----
1953	All "D" & 2571	----- R.H.	1	515408	-----
1953	All "D" & 2571	----- L.H.	1	515409	-----
1954	All std.	----- R.H.	1	517646	-----
1954	All std.	----- L.H.	1	517647	-----
1954	All "D"	----- R.H.	1	517648	-----
1954	All "D"	----- L.H.	1	517649	-----
Group 8.131 CAP ASSEMBLY, FRONT DOOR FENDER					
1942 thru 47	25 All	----- R.H.	1	506952	-----
1942 thru 47	25 All	----- L.H.	1	506953	-----
1942 thru 47	26 All	----- R.H.	1	507836	-----
1942 thru 47	26 All	----- L.H.	1	507837	-----
1948	25 All	----- R.H.	1	510622	-----
1948	25 All	----- L.H.	1	510623	-----
1948	26 All	----- R.H.	1	510624	-----
1948	26 All	----- L.H.	1	510625	-----
Group 8.132 MOLDING, FRONT DOOR FENDER CAP					
1942-46	26 All	----- R.H.	3	507105	-----
1942-46	26 All	----- L.H.	3	507106	-----
1948	All "D"	----- R.H.	1	510606	-----
1948	All "D"	----- L.H.	1	510607	-----
1941 thru 46	All exc. 25	BOLT , cap molding.....(Spec. No. 10-24x $\frac{1}{2}$ ")	AR	505401	----- (8.148)
Group 8.133 SUPPORT, FRONT DOOR FENDER CAP					
1942 thru 48	25 All	----- Front	2	507692	-----
1942 thru 48	26 exc. sta. wag.	----- Front	2	507701	-----
1946 thru 48	Sta. wag.	----- Front	2	512824	-----
1946 thru 48	Sta. wag.	----- Rear	2	512825	-----
1942 thru 48	25 All	ANTI-SQUEAK , front door fender cap.....	2	507820	-----
1942 thru 48	26 All	-----	2	507895	-----
1948	All "D"	BOLT ASSY. , fender cap mldg. to cap front.....	6	511058	----- (8.148)
1948	All "D"	----- Intermediate	4	511706	-----
1948	All "D"	----- Rear	4	511705	-----
1946 thru 48	All	BUMPER , front door fender cap to fender.....	Rubber 6	509288	-----
1942 thru 48	All exc. sta. wag.	CLAMP , fender cap to door.....	Rear 2	418160	-----
1942 thru 48	All exc. sta. wag.	CLIP , front door fender cap.....	8	507042	-----
1942 thru 48	Sta. wag.	-----	8	507679	-----
1949	2561 All	CLIP , quarter outer panel lower molding..... R.H.	1	417972	-----
1949	2561 All	----- L.H.	1	417973	-----
1942 thru 48	All	NUT , fender cap to support..... Clip type	4	414791	----- (8.921)
1942 thru 48	All	SCREW , fender cap to clip....(Spec. hex. No. 14x $\frac{3}{4}$ ")	7	3650059	----- (8.143)
1948	All exc. sta. wag.	SPACER , fender cap to door rear clamp.....	2	417976	-----
Group 8.136 WASHER, FENDER TO BODY					
1933 thru 48	All	----- front ($\frac{3}{8}$ " I.D. x $1\frac{1}{4}$ " O.D.)	AR	481663	----- (8.206)
1941	29 All	----- Lower	2	041289	-----
1953-54	All	rubber-sealing.....($1\frac{1}{2}$ " O.D. x $\frac{5}{16}$ " I.D.)	2	513984	----- (8.015)
Group 8.136 SHIM, FRONT FENDER TO SHROUD					
1949 thru 54	All	----- ($\frac{1}{8}$ ") upper	AR	511788	-----
1949 thru 54	All	----- ($\frac{1}{16}$ ") upper	AR	511787	-----
1949 thru 54	All	----- ($\frac{1}{32}$ ") upper	AR	511786	-----
1949 thru 54	All	----- ($\frac{1}{8}$ ") lower	AR	511791	-----
1949 thru 54	All	----- ($\frac{1}{16}$ ") lower	AR	511790	-----
1949 thru 54	All	----- ($\frac{1}{32}$ ") lower	AR	511789	-----
Group 8.139 RETAINER, FRONT FENDER SUPPORT BOLT					
1941	All	front fender to body bolt.....	8	1315931	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.141 SUPPORT, FRONT FENDER OUTER					
1937-38	All	 R.H.	1	500178	-----
1937-38	All	 L.H.	1	500179	-----
1939	All		2	502159	-----
1940	25-26 All		2	503725	-----
1940	29 All	 R.H.	1	503749	-----
1942 thru 48	All	BRACKET , front fender to radiator..... R.H.	1	506973	-----
1942 thru 48	All	 L.H.	1	506974	-----
Group 8.143 SCREW, FRONT FENDER					
1935-36	All	to shell and apron..... (Hex. spec. $\frac{1}{4}$ -20x $\frac{15}{16}$ ")	6	496120	----- (1.269)
1942 thru 48	All	front fender to extension..... (Hex. No. 14x $\frac{3}{4}$ ")	6	3650059	-----
Group 8.147 MOLDING, FRONT FENDER SIDE					
1941	26-29 All	 Upper R.H.	1	505408	-----
1941	26-29 All	 Upper L.H.	1	505409	-----
1941	26-29 All	 Center R.H.	1	505410	-----
1941	26-29 All	 Center L.H.	1	505411	-----
1941	26-29 All	 Lower R.H.	1	505412	-----
1941	26-29 All	 Lower L.H.	1	505413	-----
1941	29 All	 18 $\frac{7}{8}$ " long at running board	2	505667	-----
1942-46	26, "D" only on 1942	 R.H.	3	507097	-----
1942-46	26, "D" only on 1942	 L.H.	3	507098	-----
1948	All "D"	 R.H.	1	510604	-----
1948	All "D"	 L.H.	1	510605	-----
1949-50	All "D" & 2571		2	511648	-----
1951	All "D" & 2571	1st type w/die cast ornament..... R.H.	1	514657	-----
1951	All "D" & 2571	1st type w/die cast ornament..... L.H.	1	514658	-----
1951	All "D" & 2571	2nd type w/embossed ornament..... R.H.	1	515820	-----
1951	All "D" & 2571	2nd type w/embossed ornament..... L.H.	1	515821	-----
1952	All "D" & 2571	 R.H.	1	516446	-----
1952	All "D" & 2571	 L.H.	1	516447	-----
1953	All "D" & 2571	 R.H.	1	515055	-----
1953	All "D" & 2571	 L.H.	1	515056	-----
1954	All "D"	 R.H.	1	517540	-----
1954	All "D"	 L.H.	1	517541	-----
1942 thru 48	All	MOLDING , front fender top.....	2	507121	-----
1942-46	26, "D" only on 1942	EMBLEM , front fender side..... R.H.	1	507578	-----
1942-46	26, "D" only on 1942	 L.H.	1	507579	-----
1942 thru 48	All	ORNAMENT , fender headlamp upper.....	2	507110	-----
1949-50	P/6 exc. "D" & 2571	front fender.....	2	510559	----- (8.039)
1949-50	P/8 exc. "D" & 2571	front fender.....	2	510560	----- (8.039)
1949-50	P/6 "D" & 2571	front fender.....	2	511649	-----
1949-50	P/8 "D" & 2571	front fender.....	2	511650	-----
1951	All "D" & 2571	front fender molding.....	6	514602	-----
1953	All exc. "D" & 2571	PLATE , front fender name..... R.H.	1	515805	----- (12.112)
1953	All exc. "D" & 2571	 L.H.	1	515806	----- (12.112)
1954	All exc. "D"	 R.H.	1	517614	-----
1954	All exc. "D"	 L.H.	1	517615	-----
1942 thru 47	All	NUT , headlamp mldg. to fender.....	2	3695282	----- (8.040)
1949-50	All "D" & 2571	front fender ornament to fender.....	4	511324	-----
1953	All exc. "D"	front fender name plate to fender.....	6	511750	----- (12.182)
1954	All exc. "D"	front fender name plate to fender.....	8	446059	----- (8.148)
1949	All "D" & 2571	WASHER , cup, as fender ornament to fender.....	4	511518	-----
Group 8.148 BOLT, FENDER MOLDING					
1941 thru 46	All exc. 1941	 (Spec. No. 10-24x $\frac{1}{2}$ ")	AR	505401	-----
1942 thru 48	All	for front top molding..... (Spec. No. 6-32x $\frac{3}{8}$ ")	AR	507149	-----
1948	All "D"	BOLT ASSY. , side molding to fender.....	6	511058	-----
1949-50	All "D" & 2571	 Front	6	511651	-----
1951	All "D" & 2571	 Center and rear	2	514640	-----
1951	All "D" & 2571	 Front R.H.	4	514642	-----
1952	All "D" & 2571	BOLT ASSY. , side molding to fender..... Front R.H.	1	516455	-----
1952	All "D" & 2571	 Front L.H.	1	516456	-----
1952	All "D" & 2571	 Center	2	516454	-----
1952	All "D" & 2571	 Rear upper	2	516452	-----
1952	All "D" & 2571	 Rear lower	2	516453	-----
1949 thru 54	All "D"	NUT , front fender molding to fender..... (No. 10-24)	AR	446059	-----
1941 thru 46	All exc. 2567	CLIP , fender side molding.....	AR	4114230	----- (10.708)
1942 thru 48	All	RETAINER , top molding sealing washer.....	AR	508045	-----
1953	All "D" & 2571	RETAINER ASSY. , front fender molding.....	12	515059	-----
1953	All "D" & 2571	front fender molding..... Rear	2	515061	-----
1954	All "D"		10	517418	-----
1942 thru 48	All	WASHER , top molding sealing.....	AR	508044	-----
1949	"D"	front fender ornament sealing.....	4	510437	-----
1949-50	All	front fender ornament to fender—rubber.....	4	511948	----- (8.039)
1949-50	All "D" & 2571	ornament to fender sealing—rubber.....	4	514448	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.150 BRACKET, FRONT FENDER COWL					
1942 thru 48	25 All	-----	2	507215	-----
1942 thru 48	26 All	-----	2	507421	-----
Group 8.153 SKIRT, FRONT FENDER					
1939	25 All	----- R.H.	1	502572	-----
1939	25 All	----- L.H.	1	502573	-----
1939	26 All	----- R.H.	1	502574	-----
1939	26 All	----- L.H.	1	502575	-----
1940	25 L.H.D.	----- R.H.	1	503964	-----
1940	25 All	----- L.H.	1	503965	-----
1940	26 L.H.D.	----- R.H.	1	504020	-----
1940	29 All	----- R.H.	1	503955	-----
1940	29 All	----- L.H.	1	503956	-----
1941	26-29 L.H.D.	----- R.H.	1	505637	-----
1941	26-29 All	----- L.H.	1	505638	-----
1941	25 All	----- R.H.	1	505772	-----
1941	25 All	----- L.H.	1	505773	-----
1942 thru 48	25 L.H.D.	----- R.H.	1	506882	-----
1942 thru 48	25 All	----- L.H.	1	506883	-----
1942 thru 48	26 L.H.D.	----- R.H.	1	507151	-----
1942 thru 48	26	----- L.H.	1	507152	-----
1949 thru 52	All	----- R.H.	1	513786	-----
1949 thru 52	All	----- L.H.	1	511851	-----
1953-54	All	----- R.H.	1	515826	-----
1953-54	All	----- L.H.	1	515827	-----
Group 8.154 ANTI-SQUEAK, FRONT FENDER					
1939-40	All	to body-----	2	601726	----- (8.205)
1941 thru 48	All	FELT , front fender skirt----- Lower	2	505570	-----
1946 thru 48	All	cushion, skirt to battery support----- AR	AR	506597	----- (7.797)
1941	All	-----	2	505567	----- (2.337)
1941 thru 48	All exc. 1941-25	skirt to fender----- Upper	2	505566	-----
1949 thru 54	All	skirt to frame-----	2	511860	-----
1942 thru 48	25 All	SEAL , baffle to cowl----- Upper	2	507219	-----
1942 thru 48	26 All	baffle to cowl----- Upper	2	507422	-----
1942 thru 48	All	baffle to cowl----- Lower	2	507221	-----
1949 thru 52	All	baffle to fender-----	2	511861	-----
1953-54	All	baffle to fender-----	2	515215	-----
1942 thru 48	All	WASHER , front fender baffle-----	AR	507220	----- (Spec. Flat $\frac{5}{16}$ " I.D.x1" O.D.)
Group 8.155 BRACE, FRONT FENDER					
1940	25 All	to frame----- R.H.	1	504253	-----
1940	25 All	to frame----- L.H.	1	504254	-----
1940	26 All	to frame-----	2	504255	-----
1940	29 All	to frame----- R.H.	1	504257	-----
1940	29 All	to frame----- L.H.	1	504258	-----
1941	26 All	to frame----- R.H.	1	505560	-----
1941	26 All	to frame----- L.H.	1	505561	-----
1941	29 All	to frame----- R.H.	1	505562	-----
1941	29 All	to frame----- L.H.	1	505563	-----
1942 thru 48	25 All	to frame----- R.H.	1	506910	-----
1942 thru 48	25 All	to frame----- L.H.	1	506911	-----
1942 thru 48	26 All	to frame----- R.H.	1	507158	-----
1942 thru 48	26 All	to frame----- L.H.	1	507159	-----
1942 thru 48	25 All	skirt to baffle----- R.H.	1	506895	-----
1942 thru 48	25 All	skirt to baffle----- L.H.	1	506896	-----
1942 thru 48	26 All	skirt to baffle----- R.H.	1	507956	-----
1942 thru 48	26 All	skirt to baffle----- L.H.	1	507957	-----
1949 thru 54	All	skirt baffle to fender-----	2	511739	-----
1949 thru 52	All	BAFFLE ASSEMBLY , fender to shroud----- R.H.	1	511883	-----
1949 thru 52	All	----- L.H.	1	511884	-----
1953-54	All	----- R.H.	1	516183	-----
1953-54	All	----- L.H.	1	516184	-----
1941	26-29 All	BRACKET , front fender skirt baffle to fender-----	2	505572	-----
1949 thru 54	All	NUT , to baffle spring-----	2	512568	-----
1942 thru 48	25 All	RETAINER , front fender cowl baffle seal-----	1	507360	-----
1942 thru 48	25 All	----- Upper R.H.	1	507361	-----
1942 thru 48	26 All	----- Upper L.H.	1	507424	-----
1942 thru 48	26 All	----- Upper R.H.	1	507425	-----
1942 thru 48	26 All	----- Upper L.H.	1	507425	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.156 CUSHION, FRONT FENDER SUPPORT					
1941 thru 48	All	SPACER, radiator support to frame used with 506588, Group 8.080.....Steel	1	506594	-----
1949 thru 54	All	-----	1	513165	-----
Group 8.157 PLATE, RADIATOR SUPPORT CUSHION					
1933 thru 54	All	-----	2	495418	-----
1934 thru 54	All	SHIM, radiator support cushion.....	AR	499723	-----
Group 8.162 SHIELD, FRONT FENDER STONE					
1940	25-26 All	rubber.....R.H.	1	504375	-----
1940	25-26 All	rubber.....L.H.	1	504376	-----
1940	25-26 All	RETAINER, front fender stone shield.....	2	504377	-----
Group 8.175 SHIELD, REAR FENDER					
1942-46	26 Chieftain only on 1942	-----R.H.	1	507540	-----
1942 thru 47	25 All	-----R.H.	1	507538	-----
1942 thru 47	25 All	-----L.H.	1	507539	-----
1942 thru 47	26 All	-----R.H.	1	507849	-----
1942 thru 47	26 All	-----L.H.	1	507850	-----
1948	25 All	-----R.H.	1	510662	-----
1948	25 All	-----L.H.	1	510663	-----
1948	26 All	-----R.H.	1	510666	-----
1948	26 All	-----L.H.	1	510667	-----
1949 thru 52	All	-----	2	513992	-----
1953-54	All	-----	2	515221	-----
Group 8.176 MOLDING, REAR FENDER SHIELD (CHROME)					
1941	25 All	-----R.H.	1	506169	-----
1941	25 All	-----L.H.	1	506170	-----
1941	26 All	-----Lower R.H.	1	505792	-----
1941	26 All	-----Lower L.H.	1	505793	-----
1941	29 All	-----Lower R.H.	1	505794	-----
1941	29 All	-----Lower L.H.	1	505795	-----
1942-46	26 All	-----Lower	2	507558	-----
1942-46	26 All	-----Upper	2	507559	-----
1942-46	26 All	-----Center	2	507560	-----
1953-54	All "D"	-----	2	516705	-----
Group 8.177 SEAL, REAR FENDER SHIELD RUBBER					
1939-40	All exc. 1940-25	edging type.....R.H.	1	1315552	-----
1939-40	All exc. 1940-25	edging type.....L.H.	1	1315553	-----
1941	All	-----R.H.	1	506129	-----
1941	All	-----L.H.	1	506130	-----
1942 thru 48	All	-----	2	510408	-----
1949 thru 54	All	-----	2	513993	-----
1941	29 All	BOLT, fender shield molding (Spec. No. 10-24x $\frac{3}{16}$ ")	10	506247	-----
1941	25-26 All	----- (Spec. No. 10-24x $\frac{1}{2}$ ")	10	505462	-----
1953-54	All "D"	fender shield molding.....	8	516706	-----
1942 thru 48	All	SCREW, fender shield seal.....	4	507584	-----
1949 thru 54	All	bracket to fender..... (Rd. Hd. No. 10-24x $\frac{1}{2}$ ")	8	446813	-----
1949 thru 54	All	NUT, bracket to fender..... (Spring Type No. 10-24)	4	513418	-----
Group 8.179 BRACKET, REAR FENDER SHIELD FENDER					
1949 thru 52	All	-----Front R.H.	1	513413	-----
1949 thru 52	All	-----Front L.H.	1	513414	-----
1949 thru 52	All	-----Rear R.H.	1	513415	-----
1949 thru 52	All	-----Rear L.H.	1	513416	-----
1953-54	All	-----Front R.H.	1	515572	-----
1953-54	All	-----Front L.H.	1	515573	-----
1953-54	All	-----Rear R.H.	1	515570	-----
1953-54	All	-----Rear L.H.	1	515571	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.203 FENDER, REAR (PRIME)					
1937-38	All	 R.H.	1	500491	-----
1937-38	All exc. sta. wag.	 L.H.	1	500481	-----
1939	25 All	without tail lamp holes..... R.H.	1	501908	-----
1939	25 All	with tail lamp holes..... L.H.	1	501907	-----
1940	25 All	 R.H.	1	604628	-----
1940	25 All	 L.H.	1	604627	-----
1940	29 All	 L.H.	1	1394998	-----
1941	25 All	 R.H.	1	506344	-----
1941	25 All	 L.H.	1	506345	-----
1941	29 All	 R.H.	1	505057	-----
1941	29 All	 L.H.	1	505058	-----
1942 thru 47	25 All	 R.H.	1	506825	-----
1942 thru 47	25 All	 L.H.	1	506826	-----
1942 thru 47	26 All	 R.H.	1	507840	-----
1942 thru 47	26 All	 L.H.	1	507841	-----
1948	25 All	 R.H.	1	510630	-----
1948	25 All	 L.H.	1	510631	-----
1948	2607-09 All	 R.H.	1	510634	-----
1948	2607-09 All	 L.H.	1	510635	-----
1948	26 sta. wag.	 R.H.	1	510636	-----
1948	26 sta. wag.	 L.H.	1	510637	-----

NOTE: See Group 12.940 for 1949 and subsequent models.

Group 8.204 MOLDING-GUARD, REAR FENDER (CHROME)					
MOLDING					
1941	26-29 All	 Upper R.H.	1	505402	-----
1941	26-29 All	 Upper L.H.	1	505403	-----
1941	26-29 All	 Center R.H.	1	505404	-----
1941	26-29 All	 Center L.H.	1	505405	-----
1941	26-29 All	 Lower R.H.	1	505406	-----
1941	26-29 All	 Lower L.H.	1	505407	-----
1942-46	26 All	 Front upper R.H.	1	507018	-----
1942-46	26 All	 Front upper L.H.	1	507019	-----
1942-46	26 All	 Front center R.H.	1	507020	-----
1942-46	26 All	 Front center L.H.	1	507021	-----
1942-46	26 All	 Front lower R.H.	1	507022	-----
1942-46	26 All	 Front lower L.H.	1	507023	-----
1942-46	26 All	 Rear upper R.H.	1	507024	-----
1942-46	26 All	 Rear upper L.H.	1	507025	-----
1942-46	26 All	 Rear center R.H.	1	507026	-----
1942-46	26 All	 Rear center L.H.	1	507027	-----
1942	26 All	 Rear lower R.H.	1	507028	-----
1942	26 All	 Rear lower L.H.	1	507029	-----
1946	2607-09 All	 Rear lower R.H.	1	508553	-----
1946	2607-09 All	 Rear lower L.H.	1	508554	-----
1946	sta. wag.	 Rear lower R.H.	1	508972	-----
1946	sta. wag.	 Rear lower L.H.	1	508973	-----
1941 thru 46	All	CLIP , rear fender molding.....	18	4114230	(10.708)

NOTE: See Group 12.116 for 1949 and subsequent models.

Group 8.205 ANTI-SQUEAK, REAR FENDER					
1938 thru 48	All	fender to body, 100 ft. roll, front or rear.....	AR	601726	-----
Group 8.206 WASHER, FENDER TO BODY AND FRAME SCREW					
1933 thru 48	All	 (Flat $\frac{3}{8}$ " I.D.x1 $\frac{1}{4}$ " O.D.)	AR	481663	-----
1940 thru 48	25 All	BOLT , rear fender to body.....	6	3651216	-----
1940 thru 48	All	 (Hex. $\frac{5}{16}$ "-18x $\frac{3}{4}$ ")	AR	180077	(8.900)
1942 thru 48	All	NUT , rear fender to body.....	AR	414791	(8.921)
		 (For No. 14-10 metal screw)			

Group 8.208 DOOR, FUEL TANK REAR FENDER					
1940	29 All		1	1307620	-----
1941 thru 48	25 All		1	505332	-----
1941 thru 48	All exc. 25		1	505113	-----
1940 thru 48	All exc.	SCREW , fuel tank fender door.....			
	1940 25-26	 (Sheet Metal No. 8x $\frac{5}{16}$ ")	3	148379	(8.977)

NOTE: See Group 12.944 for 1949 and subsequent models.

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 8.209 SPRING, FUEL TANK REAR FENDER DOOR						
1940 thru 48	All exc.	----- R.H.	1	1304620	-----	
1940 thru 48	1940 25-26	----- L.H.	1	1304621	-----	
1941 thru 54	All	BARREL AND CAP, fuel tank door lock -----	1	1316127	-----	
NOTE: See Group 12.944 for 1949 and subsequent models.						
Group 8.210 BUMPER, FUEL TANK REAR FENDER DOOR						
1940	29 All	-----	2	3693292	-----	(10.263)
1941 thru 48	All	rubber-----	2	417320	-----	
NOTE: See Group 12.944 for 1949 and subsequent models.						
Group 8.211 CYLINDER, FUEL TANK FENDER DOOR LOCK						
1941 thru 54	All	-----	1	1316128	-----	
1941 thru 48	All	BOLT, fuel tank door lock -----	1	1316350	-----	
1949 thru 52	All	-----	1	556980	-----	
1953-54	All	-----	1	515599	-----	
Group 8.212 BRACE, REAR FENDER						
1939	25 All	-----	2	502565	-----	
1940	25 All	-----	2	503928	-----	
Group 8.214 SHIELD, REAR FENDER STONE						
1939-40	26 All	less running boards----- R.H.	1	502804	-----	
1939-40	26 All	less running boards----- L.H.	1	502805	-----	
1940	29 All	15 $\frac{3}{4}$ " long x Approx. 7"----- L.H.	1	1314347	-----	
1940	29 All	14 $\frac{3}{16}$ " long x Approx. 13 $\frac{1}{16}$ "----- R.H.	1	1315538	-----	
1940	29 All	14 $\frac{3}{16}$ " long x Approx. 13 $\frac{1}{16}$ "----- L.H.	1	1315539	-----	
1941	25 All	----- R.H.	1	505479	-----	
1941	25 All	----- L.H.	1	505480	-----	
1941	26 All	----- R.H.	1	505394	-----	
1941	26 All	----- L.H.	1	505395	-----	
1941	2919-27 All	----- R.H.	1	505362	-----	
1941	2919-27 All	----- L.H.	1	505363	-----	
1941	29 sta. wag.	----- R.H.	1	506515	-----	
1941	29 sta. wag.	----- L.H.	1	506516	-----	
1942 thru 47	25 All	----- R.H.	1	506902	-----	
1942 thru 47	25 All	----- L.H.	1	506903	-----	
1942 thru 47	26 All	----- R.H.	1	506904	-----	
1942 thru 47	26 All	----- L.H.	1	506905	-----	
1948	25 exc. "D"	----- R.H.	1	510737	-----	
1948	25 exc. "D"	----- L.H.	1	510738	-----	
1948	26 exc. "D"	----- R.H.	1	510739	-----	
1948	26 exc. "D"	----- L.H.	1	510740	-----	
1948	25 "D"	chrome----- R.H.	1	510591	-----	
1948	25 "D"	chrome----- L.H.	1	510592	-----	
1948	26 "D"	chrome----- R.H.	1	510593	-----	
1948	26 "D"	chrome----- L.H.	1	510594	-----	
DEFLECTOR, See Group 8.217 for use				1314826	-----	
DEFLECTOR, See Group 8.217 for use				1313463	-----	
NOTE: See Groups 12.114 and 12.116 for 1949 and subsequent models.						
Group 8.217 DEFLECTOR, REAR FENDER GRAVEL (METAL)						
1940	29 All	----- R.H.	1	1314826	-----	(8.214)
1940	29 All	----- L.H.	1	1313463	-----	(8.214)
1941	2919-27	----- L.H.	1	505187	-----	
1941	25 All	----- R.H.	1	505537	-----	
1941	25 All	----- L.H.	1	505540	-----	
1941 thru 48	26-29 exc.	----- R.H.	1	505183	-----	
	sta. wag.					
1941 thru 48	2607-09 All	----- L.H.	1	506863	-----	
1942 thru 48	25 All	----- R.H.	1	506857	-----	
1942 thru 48	25 All	----- L.H.	1	506856	-----	
1942 thru 48	26 sta. wag.	----- R.H.	1	507824	-----	
1942 thru 48	26 sta. wag.	----- L.H.	1	507826	-----	
1949 thru 51	All exc.	----- R.H.	1	4562406	-----	
	2561-62-71					
1949 thru 51	All exc.	----- L.H.	1	4562407	-----	
	2561-62-71					
1949 thru 52	2561-62-71 All	----- R.H.	1	4562743	-----	
1949 thru 52	2561-62-71 All	----- L.H.	1	4562744	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.217 DEFLECTOR, REAR FENDER GRAVEL (METAL) (Continued)					
1952	2511-37-67-69 All	----- R.H.	1	4562406	-----
1952	2511-37-67-69 All	----- L.H.	1	4562407	-----
1953-54	All exc. 2562-71	----- L.H.	1	4596471	-----
1953-54	2562-71 All	----- L.H.	1	4602211	-----
1937-38	All	PLATE ASSY., gravel deflector. R.H.	1	499559	-----
1937-38	All	----- L.H.	1	499560	-----
1939-40	26 All	----- L.H.	1	502181	-----
1942 thru 48	25 All	SEAL, rear fender gravel deflector. Inner upper L.H.	1	506862	-----
1942 thru 48	25 All	Inner lower L.H.	1	506861	-----
1942 thru 48	25 All	Outer L.H.	1	506860	-----
1942 thru 48	2607-09 All	Inner upper L.H.	1	506866	-----
1942 thru 48	2607-09 All	Inner lower L.H.	1	506865	-----
1942 thru 48	2607-09 All	Outer L.H.	1	506864	-----
1942 thru 48	26 sta. wag.	Inner upper L.H.	1	507829	-----
1942 thru 48	26 sta. wag.	Inner lower L.H.	1	507830	-----
1942 thru 48	26 sta. wag.	Outer L.H.	1	508230	-----
Group 8.228 APRON, BODY SPLASH					
NOTE: For Body Rocker Panels see Group 12.934.					
1939	26 All	without running boards R.H.	1	502229	-----
1939	26 All	without running boards L.H.	1	502230	-----
1940	26 All	without running boards R.H.	1	503555	-----
1940	26 All	without running boards L.H.	1	503556	-----
1942 thru 48	25 All	EXTENSION, body rocker panel R.H.	1	507197	-----
1942 thru 48	25 All	----- L.H.	1	507198	-----
1942 thru 48	26 All	----- R.H.	1	507374	-----
1942 thru 48	26 All	----- L.H.	1	507375	-----
1941 thru 48	All	SCREW, plate to extension. (Flat Hd. No. 8x $\frac{1}{2}$ ")	AR	511820	-----
Group 8.229 MAT, BODY ROCKER PANEL EXTENSION					
1942	25 All	----- R.H.	1	507396	-----
1942	25 All	----- L.H.	1	507397	-----
1942	26 All	----- R.H.	1	507398	-----
1942	26 All	----- L.H.	1	507399	-----
1946 thru 48	25 All	PLATE, body rocker panel ext. Aluminum R.H.	1	507562	-----
1946 thru 48	25 All	Aluminum L.H.	1	507563	-----
1946 thru 48	26 All	Aluminum R.H.	1	507564	-----
1946 thru 48	26 All	Aluminum L.H.	1	507565	-----
1942 thru 48	All	SEAL, body rocker panel extension	2	507199	-----
1942 thru 48	All	SCREW, rocker panel mat to extension			
		(Bind. Hd. No. 8-15x $\frac{1}{2}$ ")	12	141502	----- (8.977)
Group 8.230 BRACE, SPLASH APRON TO FRAME					
1939	26 All	without running boards Front R.H.	1	502225	-----
1939	26 All	without running boards Front L.H.	1	502226	-----
Group 8.231 MOLDING, BODY ROCKER PANEL					
1939	26 All	without running boards	2	502221	-----
1940	26 All	without running boards R.H.	1	503582	-----
1940	26 All	without running boards L.H.	1	503583	-----
1940	29 All	without running boards	2	503918	-----
1941	29 All	-----	2	505452	-----
1941	25 All	-----	2	505505	-----
1941	26 All	-----	2	505461	-----
1942 thru 48	25 All	----- R.H.	1	508796	-----
1942 thru 48	25 All	----- L.H.	1	508797	-----
1942 thru 48	26 All	----- R.H.	1	508798	-----
1942 thru 48	26 All	----- L.H.	1	508799	-----
1949 thru 52	All	----- R.H.	1	511524	-----
1949 thru 52	All	----- L.H.	1	511525	-----
1942 thru 48	25 All	MOLDING, front fender and rocker panel ext. R.H.	1	508800	-----
1942 thru 48	25 All	----- L.H.	1	508801	-----
1942 thru 48	26 All	----- R.H.	1	508802	-----
1942 thru 48	26 All	----- L.H.	1	508803	-----
1940	26-29	BOLT, body splash apron mldg. (Spec. $\frac{1}{4}$ "-20x $\frac{5}{8}$ ")	4	504368	----- (8.309)
1941	29 All	BOLT, rocker panel molding to fender			
		(Spec. No. 10-24x $\frac{3}{4}$ ")	6	505448	-----
		(Spec. No. 10-24x $\frac{1}{2}$ ")	16	505462	-----
1941	25-26 All	(Spec. No. 10-24x $\frac{1}{2}$ ")	AR	507437	-----
1942 thru 48	All	-----	4	3688946	----- (8.309)
1949 thru 52	All	NUT, rocker panel extension mldg. bolt. (No. 10-24)	AR	446059	-----
1947-48	All	-----			

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 8.231 MOLDING, BODY ROCKER PANEL (Continued)						
1939	26 All	CLIP, rocker panel molding.....	22	502224	-----	
1940	26-29 All	-----	18	504102	-----	
1941	29 All	-----	18	506150	-----	
1941	25-26 All	-----	22	506151	-----	
1942 thru 48	All	-----	AR	508114	-----	
1949 thru 52	All	-----	14	3690097	-----	(8.309)
Group 8.299 BOARD ASSEMBLY, RUNNING						
1939	25 All	----- R.H.	1	502118	-----	
1939	25 All	----- L.H.	1	502119	-----	
1939	26 All	----- R.H.	1	502089	-----	
1939	26 All	----- L.H.	1	502090	-----	
1940	25 All	----- R.H.	1	503677	-----	
1940	25 All	----- L.H.	1	503678	-----	
1940	26 All	----- R.H.	1	503567	-----	
1940	26 All	----- L.H.	1	503568	-----	
1940	29 All	----- R.H.	1	504350	-----	
1940	29 All	----- L.H.	1	504351	-----	
1941	29 All	----- R.H.	1	505663	-----	
1941	29 All	----- L.H.	1	505664	-----	
NOTE: See Group 7.016 for running board supports.						
Group 8.304 MOLDING, RUNNING BOARD						
1940	25 All	----- R.H.	1	503706	-----	
1940	25 All	----- L.H.	1	503707	-----	
1940	26 All	----- R.H.	1	503708	-----	
1940	26 All	----- L.H.	1	503709	-----	
1940	29 All	-----	2	504366	-----	
1941	29 All	-----	2	505665	-----	
Group 8.309 RETAINER, RUNNING BOARD MOLDING						
1940	All	BOLT, running board molding..... (Spec. 1/4-20x5/8")	4	504368	-----	
1941	29 All	to fender..... (Spec. No. 10-24x3/4")	6	505448	-----	(8.231)
1940	All	CLIP, running board molding.....	22	504955	-----	
		See Group 8.231 for use.....		3690097	-----	
		See Group 8.231 for use.....		3688946	-----	
Group 8.798 WINDSHIELD WASHER UNIT AND PARTS						
1940 thru 48	All exc. 2567-2667	CONTROL ASSY., w/s washer.....	1	603010	-----	
1951-52	All	HEAD ASSY., w/s washer lower cylinder—used with 2nd type on 1951.....	1	1459039	-----	
1941 thru 50	All exc. 2567	JAR, w/s washer.....	1	604088	-----	
1949 thru 50	2567	-----	1	513017	-----	
1951	All	1st type..... inside dia. of opening 2 13/16"	1	604088	-----	
1951 thru 54	All	2nd type on 1951..... inside dia. of opening 4 3/4"	1	3692419	-----	
1940 thru 48	All exc. 2567-2667	NOZZLE, w/s washer spray.....	2	3699138	-----	
1949 thru 54	All	ROD ASSY, w/s washer control valve push.....	2	3699025	-----	
1953-54	All	-----	1	4605136	-----	
Group 8.820 JACK,						
1946 thru 48	All	-----	1	512012	-----	
1949 thru 52	All exc. 2561-62-71	-----	1	514363	-----	
1949 thru 54	2561-62-71 All	heavy duty.....	1	512012	-----	
1953-54	All exc. 2562-71	-----	1	517073	-----	
1946 thru 49	All	REPAIR KIT, safety jack—use w/jacks having 1/2" dia. screw.....	1	516416	-----	
1950 thru 54	All	use w/jacks having 5/8" dia. screw.....	1	516417	-----	
Group 8.821 KIT, TOOL						
1941 thru 54	All	-----	1	506249	-----	
1950 thru 54	All exc. 2562-71	RETAINER ASSY., tool—holds tools to floor pan.....	1	514055	-----	
Group 8.823 HANDLE, WHEEL JACK						
1937 thru 54	All	and wheel wrench.....	1	504564	-----	(5.842)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.845 HEATER PARTS					
1942 thru 48	All	CASE ASSY., U/S heater..... Lower	1	507276	-----
1942 thru 48	All	U/S heater..... Upper	1	507275	-----
1949 thru 54	All	U/S heater.....	1	3121004	-----
1949 thru 54	All exc. 2571	DUCT ASSEMBLY, U/S heater crossover.....	1	512386	-----
Group 8.846 HOSE AND HOSE PARTS, HEATER					
All	All	HOSE, 100 ft. roll..... $1\frac{1}{2}$ " dia.	AR	506531	-----
1938-39, 1948	All	BRACKET, heater hose support—dash heater.....	2	3109234	-----
1940, 1942 thru 47	All	hose to cyl. head—dash heater.....	AR	3113741	-----
1940 thru 47	All	hose to cyl. head—U/S heater.....	1	3114200	-----
1940 thru 47	All	hose to clutch housing—U/S heater.....	1	3113743	-----
1940 thru 47	P/6	hose support w/radio—U/S heater.....	1	504826	-----
1941 thru 47	All	hose to cyl. head—U/S heater.....	1	3113741	-----
1948	All	hose to water pump—U/S and dash heater.....	1	510770	-----
1949 thru 54	All	heater water tube to frame—U/S heater.....	1	512274	-----
All	All	CLAMP, heater hose—U/S and dash heater..... ($1\frac{1}{8}$ " for $\frac{5}{8}$ " I.D. hose)	AR	1335545	----- (8.948)
1949 thru 52	All	heater water tube to dash—U/S heater.....	1	512871	-----
1940 thru 47	All	CLIP, heater hose—double—U/S heater.....	2	504830	-----
1948	All	double—U/S heater.....	1	510769	-----
1948	All	single—U/S heater.....	3	510765	-----
1950 thru 52	All exc. 2567	single—dash heater.....	1	510765	-----
1939	P/6	GROMMET, heater pipe dash, flat type—dash heater..... Upper or lower	1-2	503425	-----
1942 thru 48	All	LOOM, heater.....	2	3116570	-----
1940 thru 47	All	dash hose cover—U/S heater.....	1	3113230	-----
1949 thru 52	All	TUBE, car heater to radiator fitting water—U/S heater..... Front	1	512594	-----
1949 thru 52	All	U/S heater..... Rear	1	512595	-----
1949 thru 52	All	defroster to heater water—U/S heater.....	1	512596	-----
1953-54	All	heater to radiator fitting water—U/S heater..... Front	1	517414	-----
1953-54	All	U/S heater..... Rear	1	515557	-----
1953-54	All	defroster to heater water—U/S heater.....	1	517415	-----
Group 8.852 SWITCH, HEATER CONTROL					
1933 thru 41	All	dash heater.....	1	3115112	-----
1939	P/8	dash heater.....	1	3112801	-----
1940	All	dash heater.....	1	3113850	-----
1940	All	with defroster—U/S heater.....	1	3113952	-----
1941	All	with defroster—U/S heater.....	1	3115055	-----
1942 thru 48	All	with defroster—dash heater.....	1	3115977	-----
1949 thru 52	All	heater blower motor—U/S heater.....	1	515740	-----
1950	All	dash heater.....	1	514096	-----
1951	All	dash heater.....	1	514333	-----
1952	All	dash heater.....	1	516475	-----
1953-54	All	heater blower motor—U/S heater.....	1	1998021	-----
1941	All	BLOCK, fuse—U/S heater.....	1	1998760	-----
1942 thru 48	All	U/S heater.....	1	507467	-----
1942 thru 48	All	dash heater.....	1	1998760	-----
1942 thru 48	All	CONNECTOR, 2 wire at blower motor—U/S heater.....	1	3114169	----- (2.649)
1940	All	FUSE, 6 amp.—dash heater.....	1	147683	----- (8.965)
1940	All	10 amp.—U/S heater switch.....	1	117142	----- (8.965)
1941 thru 48	All	9 amp.—dash heater.....	1	147684	----- (8.965)
1940	All	KNOB, switch—dash heater.....	1	3115980	----- (9.779)
1941	All	U/S heater.....	1	3115156	-----
1942 thru 48	All	dash heater.....	1	3115978	-----
1949 thru 52	All	NUT, heater blower motor switch—U/S heater.....	1	512446	-----
1942 thru 48	All	WASHER, control rod felt—U/S heater.....	6	505630	----- (9.649)
1941 thru 48	All	WIRE, to switch—dash heater.....	1	3114299	----- (9.792)
1942 thru 48	All	fuse block to blower motor switch—U/S heater.....	1	3116727	-----
1942 thru 48	All	switch to motor—U/S heater.....	1	3116729	-----
1950	All	motor to switch & fuse block—dash heater.....	1	5291061	-----
1951-52	All	motor to switch & fuse block—dash heater.....	1	5291070	-----
Group 8.854 CORE ASSY., HEATER					
1942 thru 50	All	U/S heater.....	1	3122289	-----
1942 thru 48	All	dash heater.....	1	3114980	-----
1950	All	dash heater.....	1	3122121	-----
1951 thru 54	All	U/S heater.....	1	3126209	-----
1951-52	All	dash heater.....	1	3127817	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.855 MOTOR ASSEMBLY, HEATER					
1940-41	All	U/S heater.....	1	5047478	-----
1940 thru 48	All	dash heater.....	1	5047473	-----
1942 thru 52	All	U/S heater.....	1	5047664	-----
1950 thru 52	All	dash heater.....	1	5047684	-----
1953-54	All	U/S heater.....	1	5047663	-----
Group 8.856 SPACER, HEATER MOTOR					
1942 thru 54	All	sealing type—U/S heater.....	1	3113284	-----
Group 8.857 BLOWER ASSEMBLY, HEATER					
1942 thru 48	All	U/S heater and w/s defroster.....	1	507268	-----
1949 thru 52	All	U/S heater.....	1	511895	-----
1953-54	All	U/S heater.....	1	515273	-----
1942 thru 48	All	CASE ASSY. , motor—U/S heater.....	1	507269	-----
1942 thru 48	All	U/S heater.....	1	507272	-----
1949 thru 52	All	U/S heater.....	1	511896	-----
1949 thru 54	All	U/S heater.....	1	511898	-----
1953-54	All	U/S heater.....	1	516975	-----
1942 thru 54	All	IMPELLER , heater blower—U/S heater.....	1	3116365	-----
1942 thru 54	All	SCREW , heater case to core—U/S heater.....	5	3120880	-----
1942 thru 54	All	impeller to motor—U/S heater.....	1	140880	----- (8.975)
Group 8.866 PANEL ASSEMBLY, HEATER CONTROL					
1942 thru 48	All	less transfer, U/S heater.....	1	510706	-----
1949 thru 54	All	ELBOW , defroster water hose to cyl. head.....	1	512530	-----
1953-54	All	HOUSING ASSY. , heater control dial.....	1	1550199	-----
1942 thru 48	All	KNOB , heater and defroster switch—U/S heater.....	3	507314	-----
1949 thru 52	All	defroster air and temp. control—U/S heater.....	2	515721	-----
1953-54	All	defroster air and temp. control—U/S heater.....	2	516914	-----
1953-54	All	LEVER ASSY. , temperature control—U/S heater.....	1	516892	-----
1949	All	PLATE ASSY. , steering col. and htr. control—U/S heater.....	1	512653	-----
1950	All	U/S heater.....	1	513765	-----
1951-52	All	U/S heater.....	1	515737	-----
1949 thru 52	All	RETAINER ASSY. , control panel lamp—U/S heater.....	1	513128	-----
1942 thru 48	All	REFLECTOR , heater control panel—U/S heater.....	1	507777	-----
1942 thru 48	All	SCREW , knob—U/S heater.....	2	140870	----- (8.975)
1951-52	All	defroster air & temp. control knob—U/S heater (No. 10-32x $\frac{1}{4}$ ").....	2	140918	-----
1953-54	All	defroster air & temp. control knob—U/S heater (No. 8-32x $\frac{5}{16}$ ").....	2	453069	----- (8.975)
1949-50	All	SHAFT ASSY. , temperature control—U/S heater.....	1	513653	-----
1951-52	All	U/S heater.....	1	514437	-----
1942 thru 52	All	SOCKET AND WIRE , heater control panel lamp—U/S heater.....	1	1886497	-----
1942 thru 48	All	SWITCH , control panel lamp—U/S heater.....	1	515740	----- (8.852)
1942 thru 48	All	TRANSFER , control panel—U/S heater.....	1	510705	-----
1942 thru 48	All	WASHER , knob screw felt—U/S heater.....	6	505630	----- (9.649)
1942 thru 48	All	WIRE , light switch to control panel—U/S heater.....	1	3116728	-----
Group 8.866 VALVE, HEATER SHUTOFF					
1933 thru 41	All	without dash control—dash heater.....	1	3113844	-----
1940-41	All	with dash control, hose connector at back—U/S heater.....	1	3113914	-----
1942 thru 48	All	with dash control—dash heater.....	1	3113844	-----
1950 thru 52	All	dash heater.....	1	3113034	-----
1942 thru 48	All	CABLE , shut off valve—U/S heater.....	1	509271	-----
1942 thru 48	All	CAM , defroster air valve—U/S heater.....	1	507333	-----
1940	All	CONTROL ASSY. , heater valve—U/S heater.....	1	3113988	-----
1941	All	U/S heater.....	1	3115466	-----
1942, 1947-48	All	ELBOW , heater hose to head—U/S heater.....	1	510361	-----
1946 thru 48	All	NIPPLE , defroster hose to head, straight—U/S heater.....	1	509044	-----
1948	All	water shut off valve—dash heater.....	1	3121447	-----
1950 thru 52	All	water shut off valve—dash heater.....	1	3121447	-----
1949-50	All	RETAINER , spring, def. air control shaft to defroster and knob—U/S heater.....	2	512519	-----
1949-50	All	temperature control shaft to knob—U/S heater.....	1	512519	-----
1949 thru 52	All	temp. cont. shaft to cont. valve—spring type—U/S heater.....	1	148147	----- (8.934)
1953-54	All	ROD , temperature control—U/S heater.....	1	515300	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 8.866		VALVE, HEATER SHUTOFF (Continued)			
1949 thru 54	All	SEAL , defroster air hole dash—U/S heater.....	1	510186	-----
1949 thru 52	All	defroster valve hole dash—U/S heater.....	1	510187	-----
1953-54	All	defroster valve hole dash—U/S heater.....	1	515437	-----
1940	All	SEAT AND SPACER PKG. , heater valve.....			
		(use w/3113914 valve)—dash heater.....	1	544387	-----
1949 thru 52	All	SLEEVE , defroster air and temp. cont. knob—U/S heater.....	2	510191	-----
1953-54	All	SUPPORT ASSY. , control lever pivot—U/S heater..	1	515301	-----

NOTE: Windshield Defroster parts listed in Group 9.779.

Group 8.890		SWITCH ASSY., UNDERHOOD AND TROUBLE LIGHT			
1942 thru 47	All		1	509104	-----
1948 thru 52	All		1	513970	-----
1953-54	All		1	515470	-----
1942 thru 48	All	FUSE , underhood light—5 amp.....	1	126049	-----
1942	All	NUT , underhood light switch mounting... (Hex. $\frac{3}{8}$ "-32)	1	508301	-----
1948 thru 52	All		1	509294	-----
1953-54	All		1	515471	-----
1950 thru 52	All	PLATE , striker.....	1	513969	-----
1953-54	All		1	515482	-----
1949	All	STOP , switch.....	1	512339	-----
1942 thru 48	All	WIRE AND FUSE HOLDER —female.....	1	508300	-----

(10.275)

(8.965)

(2.697)

STANDARD PARTS

Parts are plain unless marked: Br.—Brass; Cad.—Cadmium; Chr.—Chrome; Nic.—Nickel; Pkzd.—Parkerized.

Group No.	Description	Part No.
-----------	-------------	----------

8.899 BALL, STEEL



$\frac{3}{16}$ " Dia.	169066
$\frac{1}{4}$ " Dia.	104918
$\frac{5}{16}$ " Dia.	104919
$\frac{3}{8}$ " Dia.	147489
$\frac{1}{2}$ " Dia.	169158
$\frac{5}{8}$ " Dia.	104923

8.900 BOLT, HEXAGON HEAD



No. 10-24x $\frac{1}{8}$ " Cad.	187572
$\frac{1}{4}$ "-20x $\frac{1}{8}$ " Cad.	180016
$\frac{1}{4}$ "-20x $\frac{3}{8}$ " Cad.	180018
$\frac{1}{4}$ "-20x $\frac{1}{2}$ " Cad.	121879
$\frac{1}{4}$ "-20x $\frac{3}{4}$ " Cad.	180020
$\frac{1}{4}$ "-20x $1\frac{1}{8}$ " Cad.	180021
$\frac{1}{4}$ "-20x $1\frac{1}{4}$ " Cad.	180022
$\frac{1}{4}$ "-20x $1\frac{1}{2}$ " Cad.	180024
$\frac{1}{4}$ "-20x $1\frac{3}{4}$ " Cad.	180034
$\frac{1}{4}$ "-20x $2\frac{1}{4}$ " Cad.	180042
$\frac{1}{4}$ "-20x $2\frac{1}{2}$ " Cad.	180044
$\frac{1}{4}$ "-20x $2\frac{3}{4}$ " Cad.	180046
$\frac{1}{4}$ "-20x $3\frac{1}{2}$ " Cad.	180048
$\frac{1}{4}$ "-20x $3\frac{3}{4}$ " Cad.	180052
$\frac{1}{4}$ "-20x $4\frac{1}{2}$ " Cad.	189293
$\frac{1}{4}$ "-28x $\frac{1}{8}$ " Cad.	181561
$\frac{1}{4}$ "-28x $\frac{3}{8}$ " Cad.	181003
$\frac{1}{4}$ "-28x $\frac{1}{2}$ " Cad.	181566
$\frac{1}{4}$ "-28x $\frac{3}{4}$ " Cad.	123456
$\frac{1}{4}$ "-28x $1\frac{1}{8}$ " Cad.	181568
$\frac{1}{4}$ "-28x $1\frac{1}{4}$ " Zinc.	123737
$\frac{1}{4}$ "-28x $1\frac{1}{2}$ " Cad.	181575
$\frac{1}{4}$ "-28x $1\frac{3}{4}$ " Zinc.	123762
$\frac{5}{16}$ "-18x $\frac{1}{8}$ " Cad.	180073
$\frac{5}{16}$ "-18x $\frac{3}{8}$ " Cad.	180075
$\frac{5}{16}$ "-18x $\frac{1}{2}$ " Cad.	180077
$\frac{5}{16}$ "-18x $\frac{3}{4}$ " Cad.	180078
$\frac{5}{16}$ "-18x $1\frac{1}{8}$ " Cad.	180079
$\frac{5}{16}$ "-18x $1\frac{1}{4}$ " Cad.	180081
$\frac{5}{16}$ "-18x $1\frac{1}{2}$ " Cad.	180083
$\frac{5}{16}$ "-18x $1\frac{3}{4}$ " Cad.	180085
$\frac{5}{16}$ "-18x $2\frac{1}{4}$ " Cad.	180087
$\frac{5}{16}$ "-18x $2\frac{1}{2}$ " Cad.	180089
$\frac{5}{16}$ "-18x $2\frac{3}{4}$ " Cad.	180091
$\frac{5}{16}$ "-18x $3\frac{1}{2}$ " Cad.	180113
$\frac{5}{16}$ "-24x $\frac{3}{8}$ " Cad.	187147
$\frac{5}{16}$ "-24x $\frac{1}{2}$ " Cad.	181587
$\frac{5}{16}$ "-24x $\frac{3}{4}$ " Cad.	181591
$\frac{5}{16}$ "-24x $1\frac{1}{8}$ " Cad.	181593
$\frac{5}{16}$ "-24x $1\frac{1}{4}$ " Cad.	181595
$\frac{5}{16}$ "-24x $1\frac{1}{2}$ " Cad.	181596
$\frac{5}{16}$ "-24x $1\frac{3}{4}$ " Cad.	181608
$\frac{5}{16}$ "-24x $2\frac{1}{4}$ " Cad.	181610
$\frac{5}{16}$ "-24x $2\frac{1}{2}$ " Cad.	181614
$\frac{5}{16}$ "-24x $2\frac{3}{4}$ " Cad.	181618
$\frac{5}{16}$ "-24x $3\frac{1}{2}$ " Cad.	181620
$\frac{5}{16}$ "-24x $3\frac{3}{4}$ " Cad.	181621
$\frac{3}{8}$ "-16x $\frac{1}{8}$ " Cad.	180116
$\frac{3}{8}$ "-16x $\frac{3}{8}$ " Cad.	180118
$\frac{3}{8}$ "-16x $\frac{1}{2}$ " Cad.	180120
$\frac{3}{8}$ "-16x $\frac{3}{4}$ " Cad.	180121
$\frac{3}{8}$ "-16x $1\frac{1}{8}$ " Cad.	180122
$\frac{3}{8}$ "-16x $1\frac{1}{4}$ " Cad.	180124
$\frac{3}{8}$ "-16x $1\frac{1}{2}$ " Cad.	180126
$\frac{3}{8}$ "-16x $1\frac{3}{4}$ " Cad.	180128
$\frac{3}{8}$ "-16x $2\frac{1}{4}$ " Cad.	180130

Group No.	Description	Part No.
-----------	-------------	----------

8.900 BOLT, HEXAGON HEAD (Cont.)

$\frac{3}{8}$ "-16x $2\frac{1}{4}$ " Cad.	180132
$\frac{3}{8}$ "-16x $2\frac{1}{2}$ " Cad.	180134
$\frac{3}{8}$ "-16x $3\frac{1}{2}$ " Cad.	180138
$\frac{3}{8}$ "-16x $3\frac{3}{4}$ " Cad.	127949
$\frac{3}{8}$ "-16x $4\frac{1}{2}$ " Plain.	186284
$\frac{3}{8}$ "-24x $\frac{5}{8}$ " Cad.	181629
$\frac{3}{8}$ "-24x $\frac{3}{4}$ " Cad.	181635
$\frac{3}{8}$ "-24x $\frac{1}{2}$ " Cad.	181636
$\frac{3}{8}$ "-24x $1\frac{1}{8}$ " Cad.	181637
$\frac{3}{8}$ "-24x $1\frac{1}{4}$ " Cad.	181639
$\frac{3}{8}$ "-24x $1\frac{1}{2}$ " Cad.	181643
$\frac{3}{8}$ "-24x $1\frac{3}{4}$ " Cad.	181646
$\frac{3}{8}$ "-24x $2\frac{1}{4}$ " Cad.	181648
$\frac{3}{8}$ "-24x $2\frac{1}{2}$ " Cad.	181650
$\frac{3}{8}$ "-24x $3\frac{1}{2}$ " Cad.	181652
$\frac{3}{8}$ "-24x $4\frac{1}{2}$ " Cad.	187044
$\frac{7}{16}$ "-14x $\frac{3}{4}$ " Zinc.	122239
$\frac{7}{16}$ "-14x $\frac{1}{2}$ " Cad.	180144
$\frac{7}{16}$ "-14x $1\frac{1}{8}$ " Cad.	180145
$\frac{7}{16}$ "-14x $1\frac{1}{4}$ " Cad.	180147
$\frac{7}{16}$ "-14x $1\frac{1}{2}$ " Cad.	180149
$\frac{7}{16}$ "-14x $1\frac{3}{4}$ " Cad.	180151
$\frac{7}{16}$ "-14x $2\frac{1}{4}$ " Cad.	180153
$\frac{7}{16}$ "-14x $2\frac{1}{2}$ " Cad.	108609
$\frac{7}{16}$ "-14x $2\frac{3}{4}$ " Zinc.	180155
$\frac{7}{16}$ "-14x $3\frac{1}{2}$ " Cad.	180157
$\frac{7}{16}$ "-14x $3\frac{3}{4}$ " Cad.	180160
$\frac{7}{16}$ "-14x $4\frac{1}{2}$ " Cad.	180162
$\frac{7}{16}$ "-20x $\frac{3}{4}$ " Cad.	181659
$\frac{7}{16}$ "-20x $\frac{1}{2}$ " Zinc.	181665
$\frac{7}{16}$ "-20x $1\frac{1}{8}$ " Cad.	181666
$\frac{7}{16}$ "-20x $1\frac{1}{4}$ " Cad.	181668
$\frac{7}{16}$ "-20x $1\frac{1}{2}$ " Cad.	181670
$\frac{7}{16}$ "-20x $1\frac{3}{4}$ " Cad.	181672
$\frac{7}{16}$ "-20x $2\frac{1}{4}$ " Cad.	124133
$\frac{7}{16}$ "-20x $2\frac{1}{2}$ " Cad.	181675
$\frac{7}{16}$ "-20x $2\frac{3}{4}$ " Cad.	181676
$\frac{7}{16}$ "-20x $3\frac{1}{2}$ " Cad.	181678
$\frac{7}{16}$ "-20x $3\frac{3}{4}$ " Cad.	181680
$\frac{7}{16}$ "-20x $4\frac{1}{2}$ " Cad.	181682
$\frac{7}{16}$ "-20x $5\frac{1}{2}$ " Cad.	187612
$\frac{1}{2}$ "-13x $\frac{1}{8}$ " Cad.	180172
$\frac{1}{2}$ "-13x $\frac{1}{4}$ " Cad.	180173
$\frac{1}{2}$ "-13x $\frac{3}{8}$ " Cad.	180175
$\frac{1}{2}$ "-13x $\frac{1}{2}$ " Cad.	180177
$\frac{1}{2}$ "-13x $\frac{3}{4}$ " Cad.	179884
$\frac{1}{2}$ "-13x $1\frac{1}{8}$ " Cad.	122439
$\frac{1}{2}$ "-13x $1\frac{1}{4}$ " Cad.	180179
$\frac{1}{2}$ "-13x $1\frac{1}{2}$ " Cad.	180181
$\frac{1}{2}$ "-20x $\frac{1}{8}$ " Cad.	181694
$\frac{1}{2}$ "-20x $\frac{1}{4}$ " Cad.	181696
$\frac{1}{2}$ "-20x $\frac{3}{8}$ " Cad.	181698
$\frac{1}{2}$ "-20x $\frac{1}{2}$ " Cad.	181700
$\frac{1}{2}$ "-20x $\frac{3}{4}$ " Cad.	181701
$\frac{1}{2}$ "-20x $1\frac{1}{8}$ " Cad.	181702
$\frac{1}{2}$ "-20x $1\frac{1}{4}$ " Cad.	181705
$\frac{1}{2}$ "-20x $1\frac{1}{2}$ " Cad.	181707
$\frac{1}{2}$ "-20x $1\frac{3}{4}$ " Cad.	181709
$\frac{1}{2}$ "-20x $2\frac{1}{4}$ " Cad.	181711
$\frac{1}{2}$ "-20x $2\frac{1}{2}$ " Cad.	181713
$\frac{9}{16}$ "-12x $1\frac{1}{4}$ " Cad.	180201
$\frac{9}{16}$ "-12x $1\frac{1}{2}$ " Cad.	180207
$\frac{9}{16}$ "-12x $1\frac{3}{4}$ " Cad.	180212
$\frac{9}{16}$ "-12x $2\frac{1}{4}$ " Cad.	180218
$\frac{9}{16}$ "-12x $2\frac{1}{2}$ " Cad.	180229
$\frac{9}{16}$ "-12x $2\frac{3}{4}$ " Cad.	180231
$\frac{9}{16}$ "-12x $3\frac{1}{2}$ " Cad.	180236
$\frac{9}{16}$ "-18x $1\frac{1}{4}$ " Cad.	181725
$\frac{9}{16}$ "-18x $1\frac{1}{2}$ " Cad.	181727
$\frac{9}{16}$ "-18x $1\frac{3}{4}$ " Cad.	181729
$\frac{9}{16}$ "-18x $2\frac{1}{4}$ " Cad.	181731
$\frac{9}{16}$ "-18x $2\frac{1}{2}$ " Cad.	181732
$\frac{9}{16}$ "-18x $2\frac{3}{4}$ " Cad.	181733

Group No.	Description	Part No.
-----------	-------------	----------

8.900 BOLT, HEXAGON HEAD (Cont.)

$\frac{3}{8}$ "-18-3" Cad.	181735
$\frac{3}{8}$ "-18-3 $\frac{1}{2}$ " Cad.	181743
$\frac{5}{8}$ "-11x $1\frac{1}{4}$ " Cad.	180255
$\frac{5}{8}$ "-11x $1\frac{1}{2}$ " Cad.	180269
$\frac{5}{8}$ "-11x $1\frac{3}{4}$ " Cad.	180272
$\frac{5}{8}$ "-11x $2\frac{1}{4}$ " Cad.	180279
$\frac{5}{8}$ "-11x $2\frac{1}{2}$ " Cad.	181822

8.902 BOLT, STEP



No. 10-24x $\frac{5}{8}$ " Cad.	128307
$\frac{1}{4}$ "-20x $1\frac{1}{8}$ " Cad.	128381
$\frac{1}{4}$ "-20x $1\frac{1}{4}$ " Cad.	128390
$\frac{1}{4}$ "-20x $1\frac{1}{2}$ " Cad.	128398
$\frac{1}{4}$ "-20x $1\frac{3}{4}$ " Cad.	128402
$\frac{1}{4}$ "-20x $2\frac{1}{4}$ " Cad.	128624
$\frac{1}{4}$ "-20x $2\frac{1}{2}$ " Cad.	128628
$\frac{1}{4}$ "-20x $2\frac{3}{4}$ " Cad.	128632
$\frac{1}{4}$ "-20x $3\frac{1}{2}$ " Cad.	128640
$\frac{5}{16}$ "-18x $\frac{7}{8}$ " Cad.	128417
$\frac{5}{16}$ "-18x $1\frac{1}{8}$ " Cad.	128421
$\frac{5}{16}$ "-18x $1\frac{1}{4}$ " Cad.	128430
$\frac{5}{16}$ "-18x $1\frac{1}{2}$ " Cad.	128439
$\frac{5}{16}$ "-18x $1\frac{3}{4}$ " Cad.	120232
$\frac{5}{16}$ "-18x $2\frac{1}{4}$ " Cad.	128661
$\frac{5}{16}$ "-18x $2\frac{1}{2}$ " Cad.	128664
$\frac{5}{16}$ "-18x $2\frac{3}{4}$ " Cad.	128667
$\frac{5}{16}$ "-18x $3\frac{1}{2}$ " Cad.	128676
$\frac{5}{16}$ "-18x $3\frac{3}{4}$ " Cad.	128685
$\frac{3}{8}$ "-16x $1\frac{1}{2}$ " Cad.	128480
$\frac{3}{8}$ "-16x $1\frac{3}{4}$ " Zinc.	128701
$\frac{1}{2}$ "-14x $3\frac{1}{4}$ " Zinc.	128759

8.903 BOLT, CARRIAGE




No. 10-24x $\frac{5}{8}$ " Cad.	126193
$\frac{1}{4}$ "-20x $\frac{1}{8}$ " Zinc.	126266
$\frac{1}{4}$ "-20x $\frac{3}{8}$ " Cad.	120518
$\frac{1}{4}$ "-20x $\frac{1}{2}$ " Cad.	126335
$\frac{1}{4}$ "-20x $\frac{3}{4}$ " Cad.	126339
$\frac{1}{4}$ "-20x $1\frac{1}{8}$ " Cad.	126344
$\frac{1}{4}$ "-20x $1\frac{1}{4}$ " Cad.	126348
$\frac{1}{4}$ "-20x $1\frac{1}{2}$ " Cad.	126609
$\frac{1}{4}$ "-20x $1\frac{3}{4}$ " Cad.	126614
$\frac{1}{4}$ "-20x $2\frac{1}{4}$ " Cad.	126638
$\frac{1}{4}$ "-20x $2\frac{1}{2}$ " Cad.	126216
$\frac{1}{4}$ "-20x $2\frac{3}{4}$ " Cad.	126358
$\frac{1}{4}$ "-20x $3\frac{1}{2}$ " Cad.	120230
$\frac{1}{4}$ "-20x $3\frac{3}{4}$ " Cad.	126373
$\frac{1}{4}$ "-20x $4\frac{1}{2}$ " Cad.	120231
$\frac{1}{4}$ "-20x $5\frac{1}{2}$ " Cad.	126380
$\frac{1}{4}$ "-20x $6\frac{1}{2}$ " Cad.	126385
$\frac{1}{4}$ "-20x $7\frac{1}{2}$ " Cad.	126652
$\frac{1}{4}$ "-20x $8\frac{1}{2}$ " Cad.	126662
$\frac{1}{4}$ "-20x $9\frac{1}{2}$ " Cad.	126987
$\frac{1}{4}$ "-20x $10\frac{1}{2}$ " Cad.	110299
$\frac{1}{4}$ "-20x $11\frac{1}{2}$ " Cad.	109392
$\frac{1}{4}$ "-20x $12\frac{1}{2}$ " Cad.	127222

STANDARD PARTS

Group No.	Description	Part No.	Group No.	Description	Part No.	Group No.	Description	Part No.
8.903 BOLT, CARRIAGE (Cont.)			8.907 BOLT, FILLISTER HEAD			8.909 BOLT, OVAL HEAD		
								
3/8"-16x1"	Cad.....	120915	No. 6-32x1/4"	Cad.....	131880	No. 6-32x 5/16"		426701
1/2"	Cad.....	126402	3/8"	Cad.....	131890	No. 8-32x 3/4" Nic.		107090
1 1/8"	Cad.....	126411	1/2"	Cad.....	131899	No. 10-24x1 1/4" Chr.		134305
1 1/4"	Cad.....	126416	3/4"	Cad.....	100908	2"	Chr.....	134317
2"	Cad.....	126419	1"	Cad.....	131919	(Oval Cross Recess Hd.)		
2 1/4"	Cad.....	126422	No. 8-32x1/4"	Cad.....	131954	5/16"-24x 7/8" Cad.		179398
2 1/2"	Cad.....	126696	3/8"	Cad.....	131963			
3"	Cad.....	126705	1/2"	Cad.....	131970			
3 1/2"	Cad.....	126715	3/4"	Cad.....	131979			
3 3/4"	Cad.....	126720	1"	Cad.....	131987			
4"	Cad.....	126725	No. 10-24x1"		110491			
1/2"-13x1 1/4" Cad.		126485	1/4"	Cad.....	132096			
1 1/2" Cad.		120917	No. 10-24x 5/16" Cad. Cr. Recess		159858			
8.906 BOLT, ROUND HEAD			No. 10-32x 5/8" Cad.		132105			
			1/2"	Cad.....	120216			
No. 6-32x1/4"	Cad.....	132688	3/4"	Cad.....	132119			
3/8"	Cad.....	132696	1"	Cad.....	131238	1/4"-20x 5/8" Chr.		137335
1/2"	Cad.....	132705	1 1/8"	Cad.....	132255			
3/4"	Cad.....	129028	1 1/4"	Cad.....	132259			
1"	Cad.....	132711	1 3/8"	Cad.....	132264			
1 1/8"	Cad.....	132715	1 1/2"	Cad.....	132268			
1 1/4"	Cad.....	132719	1 3/4"	Cad.....	132273			
No. 8-32x1/4"	Cad.....	122159	1"	Zinc.....	132273			
3/8"	Cad.....	121832	8.907 BOLT AND LOCK WASHER ASSY., FILLISTER HEAD					
1/2"	Cad.....	132760	No. 10-24x 7/16"		189384	No. 6-32 Cad.		134530
3/4"	Cad.....	132764	5/8"		190601	8-32 Cad.		120622
No. 10-24x 1/4"	Cad.....	132821	3/4"		189385	No. 10-24 Cad.		120361
3/8"	Cad.....	132830	1"		443914	10-32 Cad.		120614
1/2"	Cad.....	120221	1 1/8"		189386	12-24 Cad.		121743
No. 10-24x 1/2" St. Steel Cr. Recess	446813		1 1/4"		454031	No. 12-32 Cad.		188445
3/4"	Cad.....	120222	1 3/8"		454776	5/16"-24		124920
1"	Cad.....	120910	1 1/2"	Cad.....	455634			
1 1/8"	Cad.....	132844	1 3/4"	Cad.....	431791			
1 1/4"	Cad.....	132848	8.908 BOLT, FLAT HEAD					
1 1/2"	Cad.....	132852						
No. 10-32x 3/4"	Cad.....	132892	No. 6-32x 1/4"	Cad.....	133414	8.915 NUT, HEXAGON (Regular)		
3/8"	Cad.....	132900	3/8"	Cad.....	133423	1/4"-20 Cad.		120375
1/2"	Cad.....	132908	No. 8-32x 1/2"	Cad.....	133491	1/4"-28 Cad.		120367
3/4"	Cad.....	132915	3/4"	Cad.....	133495	5/16"-18 Cad.		120376
1"	Cad.....	132919	No. 10-24x 3/8"	Cad.....	133556	5/16"-24 Cad.		121917
1 1/8"	Cad.....	132923	1/2"	Cad.....	123854	3/8"-16 Cad.		120377
1 1/4"	Cad.....	132926	3/4"	Cad.....	133567	3/8"-24 Cad.		120369
1 1/2"	Cad.....	132930	1"	Cad.....	120620	7/8"-14 Cad.		124573
1 3/4"	Cad.....	132934	1 1/8"	Cad.....	133573	7/8"-20 Cad.		120370
2"	Cad.....	132938	1 1/4"	Cad.....	120621	1 1/8"-20 Cad. (thick)		127855
2 1/4"	Cad.....	132942	1 3/8"	Cad.....	120691	1 1/2"-13 Cad.		120378
2 1/2"	Cad.....	132947	1 1/2"	Cad.....	133583	1 1/2"-20 Cad.		120371
No. 12-24x 5/8"	Cad.....	132969	1 3/4"	Cad.....	133634	1 1/2"-20 Cad. (thick)		125653
1"	Cad.....	121742	No. 10-32x 1/2"	Cad.....	133634	9/16"-12 Cad.		124583
1 1/8"	Cad.....	132979	No. 12-24x 5/8"	Cad.....	120626	9/16"-18 Cad.		124634
1 1/4"	Cad.....	132982	1/4"-20x 1/2"	Cad.....	133767	9/16"-18 Cad. (thick)		143417
1 1/2"	Cad.....	132985	3/8"	Cad.....	120585	1 1/8"-11 Cad.		124589
1 3/4"	Cad.....	132988	1/2"	Cad.....	120697	5/8"-18 Cad.		122021
1"	Cad.....	132988	3/4"	Cad.....	120629	3/4"-16 Cad.		125949
1 1/4"-20x 3/8"	Cad.....	131375	1"	Cad.....	120657			
1 1/2"	Cad.....	120628	1 1/4"	Cad.....	133781			
1 3/4"	Cad.....	120583	1 1/2"	Cad.....	133784			
2"	Cad.....	133043	1 3/4"	Cad.....	133789			
2 1/4"	Cad.....	133046	2"	Cad.....	133793			
2 1/2"	Cad.....	133049	2 1/4"	Cad.....	133797			
3"	Cad.....	133053	2 1/2"	Cad.....	133802			
3 1/4"	Cad.....	133056	3"	Cad.....	133812			
3 1/2"	Cad.....	133058	5/16"-18x1 3/8"		113917	1/4"-20 Cad.		124818
3 3/4"	Cad.....	133063	5/8"		133822	1/4"-28 Cad.		120613
1/4"-28x 5/8"		143317				5/16"-18 Cad.		124824
5/16"-18x 1/2"	Cad.....	131394				3/8"-16 Cad.		124829
3/4"	Cad.....	133094						
1"	Cad.....	133102						
1 1/4"	Cad.....	133106						

Page 261

STANDARD PARTS

Group No.	Description	Part No.	Group No.	Description	Part No.	Group No.	Description	Part No.				
8.932 WASHER SHAKEPROOF (Cont.)			8.942 PIN, CLEVIS			8.955 GASKET, ROUND CLOSED						
No. 10 Int. Cad.	-----	121801		$\frac{1}{4}$ " x $\frac{5}{16}$ " Zinc	-----		$\frac{3}{16}$ " I.D.	-----	105450			
Ext. Zinc	-----	138479			-----			-----	114622			
Ext. Ctsk. Cad.	-----	138597			-----			-----	105453			
$\frac{1}{4}$ " Ext. Pkd.	-----	121753			-----			-----	113897			
$\frac{1}{4}$ " Int. Zinc	-----	120423			8.946 END YOKE			8.956 GROMMET, RUBBER				
$\frac{5}{16}$ " Ext. Cad.	-----	138485						$\frac{5}{16}$ " x $\frac{1}{2}$ " Cad.	-----	Type	For Hole	For I.D.
$\frac{5}{16}$ " Ext. Ctsk. Cad.	-----	134512	-----	One hole		$\frac{5}{8}$ "	$\frac{3}{8}$ "		$\frac{1}{16}$ "		-----	117961
$\frac{5}{16}$ " Int. Cad.	-----	138538	-----	One hole		$\frac{7}{8}$ "	$\frac{1}{2}$ "		$\frac{1}{16}$ "		-----	120879
$\frac{5}{8}$ " Ext. Zinc	-----	138489	-----	One hole		$\frac{1}{2}$ "	$\frac{1}{16}$ "		$\frac{1}{8}$ "		-----	187540
$\frac{5}{8}$ " Int. Cad.	-----	138542	8.948 CLAMP, HOSE			8.960 KEY, WOODRUFF						
$\frac{1}{4}$ " Int. Cad.	-----	131718	$\frac{1}{4}$ " Zinc-adj.	$\frac{1}{16}$ "-24 (1 $\frac{7}{8}$ " long)		-----			$\frac{1}{8}$ " x $\frac{1}{2}$ "		$\frac{1}{8}$ " x $\frac{5}{8}$ "	$\frac{1}{8}$ " x $\frac{3}{4}$ "
$\frac{1}{4}$ " Ext. Cad.	-----	136857			-----							
$\frac{1}{2}$ " Int. Cad.	-----	138549			-----							
$\frac{5}{16}$ " Int. Cad.	-----	138553			-----							
$\frac{5}{8}$ " Int. Cad.	-----	138557			-----							
$\frac{5}{8}$ " Ext. Cad.	-----	138502			-----							
$\frac{11}{16}$ " Int. Zinc	-----	141707	-----									
$\frac{7}{8}$ " Int. Pkd.	-----	138569	-----									
8.934 RETAINER, SPRING			8.950 CLIP, PIPE OR CABLE			8.963 CONNECTOR, THREADED SLEEVE						
	$\frac{3}{16}$ " Groove Dia.	-----		$\frac{15}{16}$ " for $\frac{5}{8}$ " I.D. Hose	-----		$\frac{1}{4}$ " Brass	$\frac{1}{4}$ " Brass	148330			
		148147			-----							
		148148			-----							
		142590			-----							
		142590			-----							
8.938 PIN, COTTER			CLIP, SNAP SPRING			ELBOW, THREADED SLEEVE						
	$\frac{1}{16}$ " x $\frac{1}{2}$ "	-----		$\frac{1}{8}$ " & $\frac{1}{4}$ " Double	-----		$\frac{1}{8}$ "	$\frac{1}{8}$ "	134251			
		103361			-----							
		103363			-----							
		103364			-----							
		107762			-----							
8.939 PIN, STRAIGHT			8.951 COCK, DRAIN			NIPPLE, THREADED SLEEVE						
	$\frac{3}{32}$ " x $\frac{1}{8}$ "	-----		$\frac{1}{4}$ " Single	-----		$\frac{1}{8}$ " Tubing	$\frac{3}{16}$ " Tubing	121534			
		103374			-----							
		103376			-----							
		103383			-----							
		103385			-----							
8.940 PIN, GROOVED			8.952 COCK, DRAIN			8.953 COCK, DRAIN						
	$\frac{1}{8}$ " x $\frac{1}{2}$ "	-----	$\frac{1}{8}$ " Pipe Thread	$\frac{1}{8}$ " Single	-----	$\frac{1}{8}$ " (90°)	$\frac{1}{4}$ " (90°)	$\frac{1}{8}$ " (45°)	114919			
		187381			-----							
		142485			-----							
		142487			-----							
		142358			-----							
8.941 PIN, GROOVED			8.954 COCK, DRAIN			8.955 COCK, DRAIN						
	$\frac{1}{8}$ " x $\frac{1}{2}$ "	-----	$\frac{1}{8}$ " Pipe Thread	$\frac{1}{8}$ " Single	-----	$\frac{1}{8}$ " (90°)	$\frac{1}{4}$ " (90°)	$\frac{1}{8}$ " (45°)	116341			
		187381			-----							
		142485			-----							
		142487			-----							
		142358			-----							

Page 263

STANDARD PARTS

Group No.	Description	Part No.	Group No.	Description	Part No.	Group No.	Description	Part No.
8.977 SCREW			8.991 STUD			8.984 FITTING, GREASE (Cont.)		
FLAT HEAD								
No. 8x $\frac{1}{2}$ " Nic. (Cr. Recess).....		169180	$\frac{5}{16}$ "-24x $\frac{1}{8}$ " Cad. or Zinc		186895	$\frac{1}{4}$ "-28 Taper Thd. (45°)		117175
No. 10x $\frac{1}{4}$ "		127835	$\frac{5}{16}$ "x1 $\frac{3}{4}$ " Zinc		117245	Adapter—Reservoir		410757
			$\frac{3}{8}$ "-16-24x $\frac{1}{8}$ "		111123	Cup		125609
			$\frac{3}{8}$ "-24x $\frac{5}{8}$ "- $\frac{3}{8}$ "-16x $\frac{3}{16}$ "		178453			
TRUSS HEAD			8.984 FITTING, GREASE			8.987 FASTENERS		
No. 12x $\frac{5}{8}$ " Cad.		179368				Rivet		431822
No. 14x $\frac{5}{8}$ " Cad.		179296	Straight Lub.					
			67 $\frac{1}{2}$ ° Elbow					
			Hinge Lid					
			$\frac{1}{4}$ "-28 Straight Taper Thd.		110347	8.988 CAP, TIRE VALVE		
			$\frac{5}{16}$ " Straight Press Type		109455	(5 per box) $\frac{5}{8}$ " long		125641
			67 $\frac{1}{2}$ ° Elbow $\frac{1}{8}$ " Pipe Thd.		109350			
			28° Elbow $\frac{5}{16}$ " Press Type		127760			

Group 8.991

BULB, LIGHT



Year	Part Name	Type Base	Candle Power	Mfrs. No.	Part No.	Changes
1951 thru 54	Ash tray and floor lamp	S.C. Bayonet	6	81	142306	-----
All thru 1947	Auxiliary Lamp	S.C. Flange	32	1323	145431	-----
1942 thru 54	Back Up Lamp	S.C. Bayonet	32	1133	142309	-----
1953-54 exc. 2562-71	Back Up Lamp	S.C. Bayonet	21	1129	103642	-----
1938 thru 54	Beam Indicator	S.C. Bayonet	1	51	115273	-----
1950 thru 54	Courtesy Lamp	D.C. Bayonet	6	82	119434	-----
1940 thru 54	Direction Signal	D.C. Bayonet	21-3	1154	145416	-----
1940 thru 54	Direction Signal Pilot Light	S.C. Bayonet	1	51	115273	-----
All thru 1940	Dome Lamp	S.C. Bayonet	6	81	142306	-----
1941 thru 48 exc. 2567	Dome Lamp	D.C. Bayonet	6	82	119434	-----
1941 thru 48 2567	Dome Lamp	S.C. Bayonet	2	55	125588	-----
1949 thru 52	Dome Lamp	D.C. Bayonet	15	88	120406	-----
1953-54 exc. 2537-67	Dome Lamp	D.C. Bayonet	15	210	453138	-----
1935 thru 54	Electric Clock	S.C. Bayonet	2	55	125588	-----
All thru 1940	Fender Lamp	S.C. Bayonet	3	63	142303	-----
1952 thru 54	Hand Brake Warning Lamp	S.C. Bayonet	2	55	125588	-----
1940 thru 54	Head Lamp, Sealed Beam Unit				193195	-----
1942 thru 48	Heater Panel	S.C. Bayonet	1	51	115273	-----
1949 thru 54	Heater Panel	S.C. Bayonet	2	55	125588	-----
1949 thru 54	Hood Ornament	S.C. Bayonet	1	51	115273	-----
1939 thru 41 and 1949 thru 54	Ignition Key Hole	S.C. Bayonet	1	51	115273	-----
1941 thru 54	Instrument Panel Compartment	S.C. Bayonet	2	55	125588	-----
1937 thru 49	Instrument Panel Cluster	S.C. Bayonet	2	55	125588	-----
1947	Instrument Lamp	S.C. Bayonet	6	81	142306	-----
1942 thru 54	Parking Lamp	S.C. Bayonet	3	63	142303	-----
1935 thru 48	Radio Lamp, Deluxe Radio	S.C. Bayonet	1	51	115273	-----
1940 thru 48	Radio Lamp, Super Deluxe	S.C. Bayonet	2	55	125588	-----
1939 thru 46	Rear Luggage Compartment Lamp	S.C. Bayonet	2	55	125588	-----
1947 thru 54	Rear Luggage Compartment Lamp	S.C. Bayonet	6	81	142306	-----
1939 thru 54 exc. 2571 & Sta. wag.	Rear License Lamp	S.C. Bayonet	3	63	142303	-----
1950 thru 54	Rear, Quarter Corner Lamp	D.C. Bayonet	6	82	119434	-----
All thru 1948	Safety Lamp	S.C. Bayonet	32	1323	145431	-----
1948 thru 54	Shift Indicator H. T.	S.C. Bayonet	1	51	115273	-----
All thru 1938	Stop Lamp	S.C. Bayonet	15	87	119294	-----
1949 2561-62-71	Stop Lamp	S.C. Bayonet	21	1129	103642	-----
1950 thru 52 2562	Stop Lamp	S.C. Bayonet	21	1129	103642	-----
1935 thru 38	Tail Lamp	S.C. Bayonet	3	63	142303	-----
1937 thru 52	Tail Lamp	S.C. Bayonet	3	63	142303	-----
2571 & Sta. wag.						-----
1939 thru 52 exc. 2571 & Sta. wag.	Tail Lamp	D.C. Bayonet	21-3	1154	145416	-----
1953-54 All	Tail Lamp	D.C. Bayonet	21-3	1154	145416	-----
1942 thru 47	Under Hood Lamp	S.C. Bayonet	6	81	142306	-----
1948-49	Under Hood Lamp	D.C. Bayonet	6	82	119434	-----
1950 thru 52	Under Hood Lamp	D.C. Bayonet	15	88	120406	-----
1953-54 All	Under Hood Lamp	S.C. Bayonet	15	87	119294	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 9.011 WASHER, BODY BOLT						
All	All	For 1/16" bolt	AR	1285607	-----	(0.738)
All	All	NUT, body bolt	AR	120371	-----	(8.915)
All	All	self locking	AR	126006	-----	(8.917)
1950 thru 54	All	PLUG, body bolt hole	2	432449	-----	
Group 9.023 SHIM, BODY TO FRAME						
1933-34, 1939	All exc. 1939-26	steel	AR	366981	-----	
1940 thru 54	All	CUSHION, body bolt	AR	504374	-----	
1942 thru 48	2567	SHIM, No. 1 bolt std.	2	507894	-----	
1949 thru 53	2537-67 All	No. 1 bolt	2	511865	-----	
1949 thru 54	All	steel (.060 thick)	AR	513290	-----	
Group 9.030 KIT, UNIVERSAL CLIP AND TEE BOLT						
NOTE: For attaching moldings to body and fenders.						
All	All	zip clip kit	AR	561644	-----	
Group 9.038 PLATE, STEERING COLUMN AND PEDAL						
1939-40	All exc.	-----	1	502265	-----	
1941 thru 48	1940-25-29 L.H.D.	-----	1	505392	-----	
1941 thru 48	All exc. 2507	Upper	1	505383	-----	
1941 thru 48	25 L.H.D.	Lower	1	505393	-----	
1941 thru 48	26-29 L.H.D.	Upper	1	506691	-----	
1941 thru 48	26-29 L.H.D.	with one piece control rod	1	507112	-----	
1942 thru 48	2507 All L.H.D.	Upper	1	511565	-----	
1949	All L.H.D.	Upper	1	511566	-----	
1949 thru 52	All L.H.D.	Lower	1	513806	-----	
1950 thru 52	All L.H.D.	Upper	1	517086	-----	
1953-54	All L.H.D.-S.B.	Lower	1	517081	-----	
1953-54	All L.H.D.-S.B.	Upper	1	505381	-----	
1941 thru 48	All exc. 2507	PLATE, steering column and pedal, felt retainer	1	505382	-----	
1941 thru 48	L.H.D.	-----	1	507111	-----	
1942 thru 48	26-29 L.H.D.	-----	1	505380	-----	
1941 thru 48	2507 All L.H.D.	-----	1	511563	-----	
1949	All L.H.D.	-----	1	511564	-----	
1949 thru 52	All L.H.D.	felt retainer filler	1	513805	-----	
1950 thru 52	All L.H.D.	-----	1	510961	-----	
1948 thru 51	All L.H.D., H.T.	PLATE, clutch pedal floor holecover	1	517090	-----	
1953-54	All H.T.	SEAL, clutch pedal floor hole	1		-----	
Group 9.039 FELT, STEERING COLUMN AND PEDAL PLATE						
1939-40	26 L.H.D.	Upper	1	502281	-----	
1941 thru 48	All exc. 2507	Upper	1	506322	-----	
1941 thru 48	L.H.D.	-----	1	506326	-----	
1941 thru 48	All exc. 2507	Lower	1	506324	-----	
1941 thru 48	L.H.D.	Upper	1	506328	-----	
1941 thru 48	26-29 L.H.D.	Lower	1	507113	-----	
1942 thru 48	2507 All L.H.D.	Lower	1	507114	-----	
1942 thru 48	2507 All L.H.D.	Upper	1	511570	-----	
1949	All L.H.D.	Upper	1	511571	-----	
1949	All L.H.D.	Lower	1	513798	-----	
1950 thru 52	All L.H.D.	Upper	1	513799	-----	
1950 thru 52	All L.H.D.	Lower	1	518326	-----	
1953-54	All P.B.	RETAINER, clutch pedal seal	1	518327	-----	
1953-54	All P.B.	steering column seal	1	517089	-----	
1953-54	All S.T.	SEAL, clutch pedal	1	517089	-----	
1953-54	All S.B.	brake pedal	1		-----	
Group 9.045 COLLAR, STEERING COLUMN TOE BOARD (RUBBER)						
1939-40	All	-----	1	502563	-----	
1941 thru 47	26-29 All	GROMMET, steering column and toe board	1	505858	-----	
1941 thru 47	All exc. 2507	-----	1	507891	-----	
1942 thru 48	2507 All	-----	1	510744	-----	
1948	All exc. 2507	-----	1	510922	-----	
1948	26 All	-----	1	510724	-----	
1949 thru 52	All L.H.D.	-----	1	511472	-----	
1953-54	All L.H.D.	black	1	515043	-----	
1954	All L.H.D.	beige	1	518384	-----	
1954	All L.H.D.	red	1	518385	-----	
1954	All L.H.D.	yellow	1	518386	-----	
1953-54	All L.H.D.	SEAL, steering column	1	517088	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.046 SCREW, STEERING COLUMN AND PEDAL PLATE RETAINER					
1940 thru 48	All	(Truss Hd. No. 14x $\frac{5}{8}$ ")	AR	179296	----- (8.977)
Group 9.106 COVER ASSY., TRANSMISSION FLOOR HOLE					
1948	25 L.H.D., H.T.		1	510900	-----
1948	26 L.H.D., H.T.		1	510958	-----
1948	All H.T.	inspection hole.....	1	513996	-----
1948	All H.T.	servo band adjusting.....	1	510897	-----
1949 thru 54	All H.T.	servo band adjusting.....	1	511999	-----
1949 thru 54	All	inspection hole.....	1	513996	-----
1950 thru 54	All	pressure regulator.....	1	513744	-----
Group 9.127 ANTI-SQUEAK, COWL LEDGE					
1941 thru 48	25 All		1	4125516	-----
1942 thru 48	26 All		1	4125517	-----
1946 thru 48	Sta. wag.		1	4125517	-----
1949 thru 52	All		2	4562181	-----
1953-54	All		1	4595571	-----
1950 thru 52	All	BAFFLE , hood to shroud water—rubber.....	1	514121	-----
Group 9.128 RETAINER, SHROUD HOOD LEDGE LACING					
1946 thru 48	All		2	4148933	-----
1949 thru 54	All	CLIP , shroud hood ledge lacing.....	6	374488	-----
Group 9.131 BRACE, DASH TO INSTRUMENT PANEL					
1948	2567		1	510670	-----
1949 thru 52	2567	R.H.	1	512769	-----
1949 thru 52	2567	L.H.	1	512757	-----
1953-54	2567	R.H.	1	515111	-----
1953-54	2567	L.H.	1	515112	-----
Group 9.620 PACKING, ANTENNA ROD					
1941	All		2	1442266	-----
Group 9.628 RING, ANTENNA ROD PACKING					
1941	All	Upper	1	506139	-----
Group 9.635 INSULATOR, ANTENNA ROD TOP					
1941	All	Hard rubber	1	506136	-----
Group 9.647 ANTENNA, PARTS, RADIO					
1949 thru 52	All	ADAPTER , antenna to fender—manual operated antenna.....	1	515717	-----
1952	All	antenna switch to inst. panel—w/motor operated antenna.....	1	516427	-----
1952	All	antenna to fender—w/motor operated antenna.....	1	516421	-----
1953-54	All	antenna to fender—w/motor operated antenna.....	1	516591	-----
1953-54	All	antenna to fender—w/manual operated antenna.....	1	516936	-----
1953-54	All	antenna switch to inst. panel—w/motor operated antenna.....	1	516954	-----
1946-47	All w/Ward	BAR , antenna to fender bracket to spacer.....	1	509145	-----
1948	All w/Radiart	BODY AND TUBE ASSY. , antenna support.....	1	511073	-----
1949 thru 52	All	die cast type—manual operated antenna.....	1	512237	-----
1953-54	All	antenna support—w/manual operated antenna.....	1	515537	-----
1942 thru 48	25 w/Radiart	BRACE , to fender.....	1	507608	-----
1946-47	All w/Ward		1	509146	-----
1942 thru 47	All exc. w/Ward	BRACKET , antenna to lower brace.....	1	507591	-----
1946-47	All w/Ward		1	509142	-----
1949 thru 52	All	support tube to fender—manual operated antenna.....	1	512240	-----
1952	All	support tube to fender—w/motor operated antenna.....	1	516426	-----
1952	All	antenna support—w/motor operated antenna.....	1	516423	-----
1953-54	All	support tube to fender—w/manual operated antenna.....	1	515540	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.647		ANTENNA PARTS, RADIO (Continued)			
1953-54	All	support tube to fender—w/motor operated antenna	1	516906	
1953-54	All	antenna support—w/motor operated antenna	1	516903	
1941 thru 48	All	CONTACT , antenna ground—hood	1	506379	
1941 thru 48	All	fender	1	506380	
1949-50	All	hood	1	512244	
1949-50	All	fender	1	512245	
1952 thru 54	All	antenna lead-in mast—w/motor operated antenna	1	517059	
1952 thru 54	All	FUSE , 30 amp. w/motor operated antenna (1 1/8" long)	1	120114	(8.965)
1941 thru 52	All	GROMMET , antenna lead-in	1	4115225	
1953-54	All		1	4603180	
1946-47	All w/Ward	HOUSING ASSY. , antenna mast support	1	510972	
1941	All exc. Vacuum L.H.D.	INSULATOR , antenna mast mounting	1	505723	
1942 thru 48	All w/Radiart	to fender	1	507981	
1942 thru 48	All w/Ward	to fender	1	507930	
1953-54	All	antenna tube nipple—w/motor operated antenna	1	517171	
1941	All exc. Vacuum	LEAD IN ASSEMBLY , mast antenna—consists of 506633 lead in and 506634 eye bolt	1	506036	
1941	All Vacuum		1	506047	
1942 thru 47	All w/Radiart		1	509272	
1946-47	All w/Ward		1	509149	
1947-48	All w/Radiart	w/detachable mast type	1	510584	
1949 thru 52	All	antenna to radio	1	512241	
1953-54	All	antenna to radio	1	515541	
1946-47	All w/Ward	MAST ASSEMBLY , antenna	1	509136	
1946-47	All w/Ward	less housing	1	510968	
1947 thru 54	All	w/manual operated antenna (length 63")	1	515735	
1948 thru 54	All	w/manual operated antenna (length 93")	1	515736	
1952 thru 54	All	w/motor operated antenna	1	516641	
1952	All	MOTOR AND DRIVE UNIT ASSY. , w/motor operated antenna	1	516645	
1953-54	All	w/motor operated antenna	1	517315	
1942 thru 48	All w/Radiart	NUT , mast mounting	1	507982	
1942 thru 47	All w/Ward	antenna to fender mounting	1	507931	
1946-47	All w/Ward	mounting bracket to antenna	1	509143	
1947-48	All w/Radiart	w/detachable mast antenna	1	510746	
1949 thru 54	All	to fender	1	554422	
1949 thru 54	All	mast to support	1	554371	
1952	All	antenna mounting—w/motor operated antenna	1	516424	
1952	All	switch to inst. panel—w/motor operated antenna	1	516430	
1952 thru 54	All	support bracket mounting—w/motor operated antenna	1	516646	
1953-54	All	antenna mounting—w/motor operated antenna	1	517192	
1953-54	All	switch to inst. panel—w/motor operated antenna	1	516958	
1942 thru 48	All w/Radiart	PAD , to fender insulator	1	507983	
1942 thru 47	All w/Ward		1	507932	
1949 thru 52	All	to fender adapter—manual operated antenna	1	512242	
1952	All	to fender adapter—w/motor operated antenna	1	516428	
1953-54	All	antenna to fender—w/motor operated antenna	1	517172	
1941	All Vacuum	ROD ASSEMBLY , antenna	1	506736	
1942 thru 54	All	SEAL , antenna mounting nut—manual operated antenna	1	507984	
1953-54	All	fender adapter—w/manual operated antenna (9/16" O.D.)	1	515543	
1953-54	All	fender adapter—w/manual operated antenna (1" O.D.)	1	515542	
1942 thru 54	All	SCREW , tube and bracket support—manual operated antenna	3	142806	
1950 thru 54	All	SLEEVE , antenna non-glare—w/manual operated antenna	1	514102	
1952 thru 54	All	w/motor operated antenna	1	517017	
1942 thru 47	All w/Radiart	SPACER , antenna to fender	1	507915	
1946-47	All w/Ward		1	509144	
1947-48	All w/Radiart	w/detachable type antenna	1	511197	
1949 thru 54	All	antenna to fender—manual operated antenna	1	512243	
1953-54	All	antenna tube to fender—w/motor operated antenna	1	517173	
1946-47	All w/Ward	STUD , antenna mast contact	1	510969	
1952	All	SWITCH , antenna—w/motor operated antenna	1	516429	
1953-54	All	antenna—w/motor operated antenna	1	516959	
1952 thru 54	All	TIP , antenna mast—w/motor operated antenna	1	516643	
1952	All	TUBE ASSY. , antenna nylon housing—w/motor operated antenna	1	516644	
1952	All	antenna body—w/bushing and insulator—w/motor operated antenna	1	516640	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.647 ANTENNA PARTS, RADIO (Continued)					
1953-54	All	antenna nylon housing—w/motor operated, antenna	1	516905	-----
1953-54	All	antenna body—w/bushing and insulator—w/motor operated antenna	1	516904	-----
1940-41	All Vacuum	VALVE ASSEMBLY , antenna control	1	504762	-----
1942	All Vacuum		1	507650	-----
1940	All Vacuum	WASHER , antenna mtg.	1	1429832	-----
1941-42	All	antenna control valve—mounting	1	1429830	-----
1941-42	All	spacing	1	597300	-----
1942 thru 47	All w/Ward	contact stud to housing	1	511032	-----
1942 thru 48	All w/Radiart	to fender spacer rubber	1	508160	-----
1946-47	All w/Ward	antenna mast contact stud (flat)	1	510970	-----
1946-47	All w/Ward	antenna mast contact stud (lock)	1	510971	-----
1952 thru 54	All	WIRE ASSY. , switch to antenna—w/motor operated antenna	1	5296415	-----
NOTE: The Ward Antenna may be identified by the red plastic ball on the top. The Radiart Antenna may be identified by the steel ball on the top.					
Group 9.649 KNOB, RADIO					
1940	All	tuning and volume control	2	7238288	-----
1941	All	tuning and volume control	2	505627	-----
1942 thru 48	All	tuning and volume control	2	507505	-----
1949-50	All	tuning and volume control	2	511834	-----
1951	All	tuning and volume control—chrome	2	514608	-----
1951-52	All	tuning and volume control—black	2	515718	-----
1941	All	tone control	1	505626	-----
1942 thru 48	All	tone control	1	507511	-----
1949 thru 52	All	tone control—black	1	511833	-----
1951	All	tone control—chrome	1	514784	-----
1953-54	All	tuning and volume control	2	516948	-----
1953-54	All	tone control	1	516946	-----
1949 thru 52	All	KNOB ASSY. , rear speaker control	1	514265	-----
1953-54	All	rear speaker control	1	515125	-----
1941	All	COLLAR , knob spacer deluxe radio	1	505625	-----
1942 thru 48	All	DUMMY KNOB SPACER —back of tuning control knob	1	507510	-----
1949 thru 52	All	back of tuning control knob—black	1	511831	-----
1953-54	All	back of tuning control knob	1	516945	-----
1949 thru 52	All	PLATE , rear speaker control	1	515854	-----
1940	All	PUSH BUTTON , radio tuner—deluxe radio	5	7238917	-----
1941	All	master radio	5	505766	-----
1941	All	deluxe radio	5	7241219	-----
1942	All	master radio	5	1215931	-----
1942 thru 48	All	chrome trim—deluxe radio	5	7242136	-----
1942 thru 48	All	super deluxe radio	6	1215813	-----
1946 thru 48	All	master radio	5	1216587	-----
1949-50	All		5	1218885	-----
1940	All	SCREW , knob to shaft (No. 8-32x $\frac{3}{16}$ "	2	128036	-----
1941 thru 52	All	(No. 8-32x $\frac{1}{16}$ "	AR	187437	-----
1953-54	All	(No. 8-32x $\frac{5}{16}$ "	2	217217	-----
1942 thru 48	All	TAB PACKAGE , radio station letter—super deluxe radio	1	7257478	-----
1941 thru 48	All	WASHER , knob spacer collar spring	1	7238755	-----
1941 thru 54	All	radio tone control knob—felt	1	505630	-----
1949 thru 52	All	dummy knob anti-rattle	1	513486	-----
1953-54	All	dummy knob spring	1	7238755	-----
NOTE: See Group 10.256 for Radio Controls Finish Plate.					
Group 9.650 STATIC COLLECTOR PARTS					
1937 thru 54	All	BRACKET , rear wheel static collector	2	231895	-----
1937 thru 54	All	BRUSH , rear wheel static collector	2	1862394	-----
1934 thru 54	All	COLLECTOR , front wheel static	2	494786	-----
1935 thru 48	All	INSULATOR , radio distributor suppressor	1	509129	-----
1940 thru 48	All	SHIELD , heater hose radio ground—U/S heater	2	504836	-----
1937 thru 54	All	SPRING , rear wheel static collector	2	231896	-----
1937 thru 54	All	STRAP , cylinder head ground	1	5298902	-----
1941 thru 47	All	SUPPORT , radio dash to instrument panel	1	4115965	-----
1935 thru 47	All	SUPPRESSOR , radio distributor	1	1207821	-----
Group 9.654 SWITCH ASSEMBLY, RADIO					
1949 thru 52	All	CABLE AND CONTROL ASSY. , radio rear speaker	1	514255	-----
1953-54	All		1	7260922	-----
1932 thru 37	All	FUSE , radio—15 amp (1 $\frac{1}{4}$ " long)	AR	120151	-----
1938-39	All	14 amp (1 $\frac{1}{16}$ " long)	AR	147685	-----
1940 thru 47	All	9 amp—master 5 tube radio (1 $\frac{1}{8}$ " long)	AR	147684	-----

(6.515)

(8.975)
(8.975)
(8.975)(5.424)
(5.424)
(6.331)(5.424)
(12.794)(8.965)
(8.965)
(8.965)

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes	
Group 9.654 SWITCH ASSEMBLY, RADIO (Continued)						
1940 thru 54	All	14 amp—deluxe radio.....(1 $\frac{1}{16}$ " long)	AR	147685	-----	(8.965)
1940 thru 48	All	20 amp—deluxe and super deluxe radio.....(1 $\frac{1}{4}$ " long)	1	106653	-----	(8.965)
1947	All	14 amp—master 6 tube radio.....(1 $\frac{1}{16}$ " long)	AR	147685	-----	(8.965)
1940 thru 47	All L.H.D.	HOLDER , radio "A" lead and female fuse master radio	1	504617	-----	
1940 thru 47	All	super deluxe radio.....	1	504842	-----	
1941 thru 48	All L.H.D.	radio "A" lead fuse—deluxe radio.....	1	5273906	-----	
1947	All L.H.D.	master 6 tube radio.....	1	511057	-----	
1948	All L.H.D.	super deluxe radio.....	1	7257464	-----	
1948	All L.H.D.	radio "A" lead fuse—standard radio.....	1	511056	-----	
1938 thru 48	All	TUBE , radio fuse insulating.....(1 $\frac{15}{16}$ " long)	1	501270	-----	
Group 9.655 GRILLE, INSTRUMENT PANEL RADIO SPEAKER						
1940	All	-----R.H.	1	504028	-----	
1940	All	-----L.H.	1	504029	-----	
1940	All	-----Center	1	504027	-----	
1941-42	All	-----Outer	1	505441	-----	
1946 thru 48	All	-----	1	508580	-----	
1949-50	All	-----	1	511573	-----	
1951-52	All	-----Outer	1	515786	-----	
1951-52	All	-----Inner	1	515785	-----	
1953-54	All	-----Inner	1	516812	-----	
1953-54	All	-----Center	1	516813	-----	
1953-54	All	-----Outer	1	516814	-----	
1947-48	P/8	NAME PLATE , radio speaker grille.....	1	509625	-----	
1953-54	All	RETAINER , radio speaker grille.....	1	514938	-----	
Group 9.656 ANTI-SQUEAK, RADIO GRILLE						
1949 thru 52	All	GASKET , radio speaker grille.....	1	511576	-----	
1953-54	All	grille screen to outer grille.....	1	517444	-----	
1946 thru 48	All	INSULATOR , radio speaker grille screen.....	1	508582	-----	
1949-50	All	-----	1	511574	-----	
1941 thru 48	All	NUT , spring type.....Grille to panel	1	187490	-----	
1953-54	All	WASHER , grille screen to inner grille.....	3	517445	-----	
Group 9.658 SCREEN, RADIO SPEAKER GRILLE						
1946 thru 52	All exc. 1947-48 P/8	-----	1	508581	-----	
1947-48	P/8	-----	1	509626	-----	
1949-50	All	-----	1	511575	-----	
1951	All	-----	1	514581	-----	
1952	All	-----	1	516492	-----	
1953-54	All	-----	1	514937	-----	
Group 9.663 CONDENSER, RADIO						
1935-36	All	ammeter.....	1	1849161	-----	
1941 thru 48	All	ammeter.....	1	1910147	-----	
1940 thru 54	All	generator—w/clamp (.5 mfd.).....	1	1917580	-----	
1949 thru 52	All	generator regulator—less clamp (.5 mfd.).....	1	1913140	-----	
1953-54	All	generator regulator—w/clamp (.5 mfd.).....	1	1921835	-----	
1949 thru 52	All	CLAMP , generator regulator.....	1	1911137	-----	
Group 9.667 BOLT-NUT, RADIO RECEIVER TO INSTRUMENT PANEL						
1941 thru 54	All	BOLT , receiver unit to brace.....	1	505629	-----	
1940 thru 54	All	NUT , receiver unit to panel.....	2	7235968	-----	
Group 9.709 LIGHTER ASSEMBLY, CIGAR						
1941	All	-----	1	505669	-----	
1942 thru 48	All	-----	1	507400	-----	
1949-50	All	-----	1	511823	-----	
1951-52	All	-----	1	515712	-----	
1953-54	All	-----	1	516950	-----	
1940	25 L.H.D.	BRACKET , cigar lighter.....	1	504473	-----	(2.189)
1940	26-29 L.H.D.	-----	1	504268	-----	(2.189)
1941 thru 48	All L.H.D.	-----	1	505860	-----	(2.189)
1938 thru 54	All	HEATING ELEMENT , with plug.....	1	609829	-----	
1940 thru 48	All	INSULATOR , cigar lighter.....	1	503486	-----	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.709 LIGHTER ASSEMBLY, CIGAR (Continued)					
1941	All	KNOB , cigar lighter.....	1	505672	-----
1942 thru 48	All	-----	1	507402	-----
1949-50	All	-----	1	511827	-----
1951-52	All	-----	1	515715	-----
1953-54	All	-----	1	516953	-----
1942 thru 48	All	KNOB-PLUG and ELEMENT , cigar lighter.....	1	507401	-----
1949-50	All	-----	1	511825	-----
1951	All	w/chrome knob.....	1	514612	-----
1951-52	All	w/black plastic knob.....	1	515713	-----
1953-54	All	-----	1	516952	-----
Group 9.712 FUSE, CIGAR LIGHTER					
1940	All	-----	1	504562	-----
1941 thru 54	All	-----	1	1314453	-----
Group 9.718					
NOTE: For windshield wiper pipes see Group 8.964 copper tubing.					
Group 9.743 INSTRUMENT PANEL PARTS					
1942-46	All	CASE , includes bezel, dial and glass..... (Miles)	1	1566504	-----
1947	All	includes bezel, dial and glass..... (Miles)	1	1568670	-----
1948	All	includes bezel, dial and glass..... (Miles)	1	1569567	-----
1953-54	All	instrument panel cluster (battery and fuel).....	1	1501356	-----
1953-54	All	instrument panel cluster (oil and water).....	1	1507706	-----
1949-50	All	BODY ASSY. , instrument cluster.....	1	1569911	-----
1951	All	-----	1	1580821	-----
1952	All	-----	1	1581956	-----
1953-54	All	-----	1	1582147	-----
1951-52	All	FACE , instrument cluster (oil and water).....	1	1580817	-----
1951-52	All	(battery and fuel).....	1	1580818	-----
1953-54	All	instrument panel cluster..... (Miles)	1	1581321	-----
1949-50	All	PLATE , instrument cluster back (oil and water).....	1	1507349	-----
1949-50	All	(battery and fuel).....	1	1501155	-----
1951-52	All	(battery and fuel).....	1	1501285	-----
1951-52	All	(oil and water).....	1	1512286	-----
1949-50	All	RING , speedometer head plastic figure..... (Miles)	1	1569876	-----
1951-52	All	----- (Miles)	1	1580814	-----
1949-50	All	RETAINER AND BEZEL ASSEMBLY , instrument panel cluster (oil and water).....	1	1507352	-----
1949-50	All	(battery and fuel).....	1	1501161	-----
1949-50	All	(speedometer figure ring).....	1	1569875	-----
1951-52	All	RETAINER , instrument panel face (oil and water).....	1	1580819	-----
1951-52	All	(battery and fuel).....	1	1580820	-----
1951-52	All	(speedometer figure ring).....	1	1580816	-----
1953-54	All	instrument panel face.....	1	1581320	-----
1953-54	All	SCREW , instrument cluster to brace.....	2	516922	-----
Group 9.764 CLIP, SPEEDOMETER CABLE					
1939-40	All	to dash.....	2	502523	-----
Group 9.772 CLOCK PARTS, ELECTRIC					
1942 thru 48	All	BEZEL	1	507833	-----
1949-50	All	-----	1	512511	-----
1951-52	All	-----	1	515710	-----
1953-54	All	-----	1	517382	-----
1940	All	CRYSTAL	1	1565355	-----
1941	All	-----	1	1566081	-----
1942 thru 48	All	-----	1	1566496	-----
1949-50	All	-----	1	512512	-----
1951-52	All	CRYSTAL PKG. , clock—consists of crystal, reflector and instruction sheet.....	1	514287	-----
1953-54	All	-----	1	517390	-----
1949-50	All	GASKET	1	512513	-----
1937	All	FUSE , 2 amp. used w/983525 clock.....	1	148086	-----
1951	All	SCREW , set, clock to grille.....	2	514599	(8.965)
1951 thru 54	All	clock to grille..... (No. 10-24x $\frac{3}{8}$ ")	2	140908	(8.975)
1939	All	WIRE ASSEMBLY	1	503325	-----
1941	All	-----	1	505603	-----
1942 thru 48	All L.H.D.	-----	1	507209	-----
1949-50	All	-----	1	5289477	-----
1951-52	All	-----	1	5291069	-----
1953-54	All	-----	1	5292830	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.773					
1949 thru 52	All exc. 2561-62	SAFETY LIGHT PARTS			
1949 thru 52	2561-62 All	ARM AND PINION PACKAGE	1	5942695	
1953-54	All exc. 2562		1	5939173	
1953-54	2562 All		1	5943972	
1949 thru 52	All		1	5943976	
1953-54	All	BASE AND SWITCH KNOB ASSEMBLY	1	5941050	
1949 thru 52	All		1	5943852	
1953-54	All		1	5937965	
1949 thru 53	All	BEARING, handle	1	5940980	
1949 thru 52	All	BRACKET, outside mounting R.H.	1	5940979	
1949 thru 52	All	outside mounting L.H.	1	5940786	
1953-54	All exc. 2562	outside mounting R.H.	1	5940785	
1953-54	All exc. 2562	outside mounting L.H.	1	5943825	
1953-54	2562 All	outside mounting L.H.	1	5940960	
1949 thru 52	All	BRACKET AND NUT ASSY., inside mounting R.H.	1	5940959	
1949 thru 52	All	inside mounting L.H.	1	5943820	
1953-54	All exc. 2562	inside mounting R.H.	1	5943819	
1953-54	All exc. 2562	inside mounting L.H.	1	5943821	
1953-54	2562 All	inside mounting L.H.	1	601545	
1935 thru 42	All	CAP, bulb	1	3699178	
1939 thru 42	All	switch	1	3114169	(2.649)
1941 thru 48	All	CONNECTOR, wire	1	5941202	
1949 thru 54	All	DOOR ASSEMBLY, chrome	1	147685	(8.965)
1941 thru 48	All	FUSE, 14 amp (1 1/16" long)	1	106653	(8.965)
1949 thru 54	All	20 amp (1 1/4" long)	1	604835	
1935 thru 48	All	GASKET, lens	1	510458	
1948 thru 54	All L.H.D.	GROMMET, wire thru instrument panel	1	5938359	
1949 thru 54	All	HANDLE	1	601555	
1935 thru 47	All	LENS	1	5938675	
1949	All	MIRROR ASSEMBLY	1	5941195	
1950 thru 54	All		1	5936462	
1949 thru 54	All	PINION AND BEARING ASSEMBLY, handle end	1	5938954	
1949 thru 52	All	PINION AND BEARING PACKAGE, lamp end	1	5940643	
1953-54	All	lamp end	1	604833	
1941 thru 47	All	REFLECTOR—rim fastens at top	1	604834	
1941 thru 48	All	RIM—fastens at top	1	5937929	
1949 thru 54	All	SCREW, handle	1	445542	
1949	All	mirror attaching	1	450628	
1950 thru 54	All	mirror attaching	1	5936796	
		See Group 9.774 for use		444279	
1948	All	SEALED BEAM UNIT R.H. or L.H.	1	451651	
1949 thru 54	All		1	5936458	
1949 thru 54	All	SPRING, base and switch knob contact	3	238288	(9.774)
1949 thru 54	All	lens retaining unit	1	5938145	
1949 thru 54	All	STIFFENER, mirror	1	602272	
1939 thru 48	All	SWITCH	1	5938700	
1949 thru 54	All	WASHER, mirror—spring type	1	510456	
1941 thru 48	All	WIRE ASSEMBLY, connector to fuse holder L.H.	1	510457	
1941 thru 48	All	fuse holder to lighting switch L.H.	1		
Group 9.774					
1948	All	FOG LIGHT PARTS			
1941	All	BODY ASSEMBLY	2	5937627	
1946	All	BRACKET	1-2	5931995	
1946	All		R.H.	5936206	
1947	All		L.H.	5936205	
1947	All	BRACKET, mounting	R.H.	5936858	
1948	All		L.H.	5936857	
1948	All		R.H.	5937428	
1949	All		L.H.	5937427	
1950	All		2	5938529	
1951-52	All		2	5939451	
1953	All		2	514751	
1954	All		2	5940750	
1954	All		R.H.	5945038	
1946 thru 52	All		L.H.	5945037	
1953-54	All	CONNECTOR, with dual fog lamp	AR	1872486	(2.649)
All	All	(3 wire type)	1	3698457	
1942-46	All	CAP, lamp bulb—with 145431 bulb, Group 8.991	AR	920325	
1947	All	DOOR ASSEMBLY	1-2	5934459	
1948	All	with dual fog lamps	2	5936674	
1949 thru 54	All	with dual fog lamps	2	5937619	
1949 thru 52	All	with dual fog lamps	2	5941416	
1953-54	All	ESCUTCHEON, fog light switch mounting	1	512660	
1948	All	fog light switch mounting	1	516920	
1949-50	All	INSERT, mounting bracket to No. 4 grille bar spacer	2	5937604	
1951	All	KNOB ASSEMBLY, fog light switch	1	512659	
1951-52	All	chrome	1	514543	
1953-54	All	black	1	515722	
			1	516966	

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.774 FOG LIGHT PARTS (Continued)					
1946-47	All	LAMP ASSEMBLY	2	926852	-----
1948	All	-----	2	926859	-----
1949 thru 52	All	-----	2	926924	-----
1953-54	All	-----	2	926078	-----
1937-38	All	LENS , w/985174 guide lamp..... (6 $\frac{11}{16}$ " O.D.)	1-2	921415	-----
1942 thru 47	All	-----	1-2	5933400	-----
1949 thru 53	All	NUT , fog light switch mounting.....	1	512658	-----
1942 thru 47	All	REFLECTOR , with gasket.....	1-2	5933397	-----
1937-38	All	RIM (for 985174 lamp).....	1	409185	-----
1942	All	SCREW , auxiliary lamp door..... (Fill. Hd. No. 8-32x $\frac{1}{2}$ ")	1-2	924622	(2.729)
1946 thru 54	All	----- (Fill. Hd. No. 6-18x $\frac{1}{8}$ ")	AR	5936796	(9.773)
1953-54	All	fog lamp switch knob.....	1	128036	(8.975)
1948	All	SEALED BEAM UNIT —with dual lights... (4 $\frac{5}{8}$ " dia.)	2	451653	-----
1949 thru 52	All	----- (5" dia.)	2	451652	-----
1953-54	All	----- (5" dia.)	2	453910	-----
1948	All	SPACER , mounting bracket bolt.....	2	5937602	-----
1949 thru 52	All	-----	1	512661	-----
1953-54	All	switch mounting.....	1	515348	-----
1946	All	SUPPORT , bracket.....	2	5936204	-----
1949	All	-----	2	5938530	-----
1950	All	-----	2	5939472	-----
1951-52	All	-----	2	514752	-----
1940 thru 47	All	SWITCH	1	5932084	-----
1948	All	-----	1	510814	-----
1949 thru 52	All	use with factory installed fog lights.....	1	512657	-----
1949 thru 52	All	use with field installed fog lights.....	1	512929	-----
1953-54	All	-----	1	515349	-----
1947	All	TAPPING PLATE , fog light mounting bracket with dual fog lights.....	2	5936856	-----
1948	All	----- To No. 4 grille bar	2	5938189	-----
1946 thru 52	All	WASHER , fog light to bracket..... (Flat for $\frac{3}{8}$ " bolt)	2	923663	-----
1953-54	All	----- (Flat for $\frac{3}{8}$ " bolt)	2	120388	(8.929)
		See Group 9.773 for use.....		238288	-----
Group 9.775 GROMMET, RUBBER					
Type		For Hole	Inside Dia.	For Groove	
Two Holes		1 $\frac{5}{16}$ " x $\frac{3}{4}$ "	2 at $\frac{1}{4}$ "	$\frac{1}{16}$ "	493908
One Hole		$\frac{1}{2}$ "	$\frac{3}{8}$ "	$\frac{1}{16}$ "	216551
1933	All L.H.D.	see Group 1.743 and Group 10.152 for use.....			493908
1933-34	All	w/s cleaner line thru dash.....	1	216551	-----
1935-36	P/6	choke-throttle contact thru dash.....	1	216551	-----
1939-40	All	choke-throttle contact thru dash.....	1	216551	-----
1940 thru 47	All	horn wire thru steering column hsg.....	1	216551	-----
1948	All	fuel gauge wire thru rear compartment.....	1	216551	-----
1953-54	All	horn and ignition wire thru dash.....	1	510582	-----
		thermo gauge pipe thru dash.....	1	515384	-----
Group 9.779 DEFROSTER ASSEMBLY, HOT WATER HEATER WINDSHIELD					
1941	All	less tubes and inlet—U/S heater.....	1	3114757	-----
1942 thru 47	All	less tubes and fittings—U/S heater.....	1	507303	-----
1953-54	All	with U/S heater.....	1	3128087	-----
1949 thru 52	All	DEFROSTER PKG. , consists of defroster and shaft end.....	1	514453	-----
1941 thru 48	All	ADAPTER , w/s defroster—dash heater.....	1	3120791	-----
1940 thru 47	All	BLOWER AND MOTOR , w/s defroster—U/S heater.....	1	3120792	-----
1942 thru 48	All	CLAMP , defroster inlet elbow support—U/S heater.....	1	507958	-----
1942 thru 48	All	COLLAR , defroster air inlet tube—U/S heater.....	1	507463	-----
1942 thru 48	All	CORE ASSEMBLY , defroster—U/S heater.....	1	3116289	-----
1949 thru 52	All	U/S heater.....	1	3126137	-----
1953-54	All	U/S heater.....	1	3128258	-----
1942 thru 48	All	ELBOW , defroster air inlet.....	1	507464	-----
1949 thru 52	All	ELBOW AND SUPPORT ASSY. , air outlet—U/S heater.....	1	512276	-----
1953-54	All	U/S heater.....	1	515277	-----
1940 thru 48	All	GROMMET , defroster pipe thru dash—U/S and dash heater.....	2	503425	(8.846)
1950 thru 52	All	heater pipe thru dash—dash heater.....	2	503425	(8.846)
1937	All	HOSE , defroster (for 983524)—dash heater... (29" long)	AR	3109171	-----
1940 thru 48	All	U/S and dash heater..... (1 $\frac{1}{2}$ " x 21 $\frac{1}{2}$ ")	1	3113681	-----
1942 thru 48	All	defroster pipe connector air, rubber—U/S heater.....	2	509176	-----
1949 thru 54	All	defroster air inlet—U/S heater..... (8 $\frac{1}{4}$ " long)	1	512285	-----
1949 thru 52	All	defroster nozzle air—U/S heater (33" long)..... R.H.	1	512286	-----
1949 thru 52	All	defroster nozzle air—U/S heater..... L.H.	1	514165	-----
1950 thru 52	All	defroster air—dash heater..... R.H.	1	514094	-----
1950 thru 52	All	defroster air—dash heater..... L.H.	1	514095	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.779 DEFROSTER ASSEMBLY, HOT WATER HEATER WINDSHIELD (Continued)					
1953-54	All	defroster nozzle air—U/S heater..... R.H.	1	515447	-----
1953-54	All	defroster nozzle air—U/S heater..... L.H.	1	515448	-----
1938 thru 41	All exc. 39-40 25	INLET , defroster deflector—dash heater..... L.H.	1	3112048	-----
1939-40	25 All	dash heater.....	2	3109067	-----
1942 thru 48	All	dash heater..... R.H.	1	3116231	-----
1942 thru 48	All	dash heater..... L.H.	1	3116232	-----
1940 thru 48	All	KNOB , defroster switch—dash heater.....	1	3115980	-----
1953-54	All	LEVER ASSY. , defroster air control—U/S heater.....	1	516887	-----
1940-41	All	MOTOR ASSEMBLY , defroster.....	1	5047531	-----
1942 thru 48	All	dash heater.....	1	5047531	-----
1949 thru 52	All	NOZZLE ASSEMBLY , defroster air hose.....	2	512288	-----
1953-54	All	defroster air hose—U/S heater..... R.H.	1	515184	-----
1953-54	All	defroster air hose—U/S heater..... L.H.	1	515185	-----
1942 thru 48	All	RETAINER , defroster elbow seal at fender skirt—U/S heater.....	1	507474	-----
1942 thru 48	All	defroster inlet collar to dash—U/S heater.....	1	507471	-----
1953-54	All	ROD , defroster air control—U/S heater.....	1	515298	-----
1942 thru 48	All	SEAL , defroster elbow, at fender skirt—U/S heater.....	1	507475	-----
1949-50	All	SHAFT ASSEMBLY , defroster, air control—U/S heater.....	1	513652	-----
1951-52	All	U/S heater.....	1	514432	-----
1949 thru 52	All	SHAFT AND LINK ASSEMBLY , defroster air valve (thru defroster unit) U/S heater.....	1	3122391	-----
1949 thru 54	All	SPRING , defroster air valve—U/S heater.....	1	3124496	-----
1949-50	All	defroster air valve shaft, anti-rattle—U/S heater.....	1	3124513	-----
1951 thru 54	All	defroster air valve shaft, anti-rattle—U/S heater.....	1	3127573	-----
1949 thru 54	All	temperature control shaft anti-rattle, U/S heater.....	1	507329	-----
1953-54	All	control lever and pivot anti-rattle—U/S heater.....	1	515296	-----
1953-54	All	STUD , control lever pivot—U/S heater.....	1	515295	-----
1937 thru 39	All	SWITCH , w/s defroster—dash heater.....	1	3115112	(8.852)
1940	All	U/S heater.....	1	3113953	-----
1941	All	dash heater.....	1	3115114	-----
1942 thru 48	All	dash heater.....	1	3115979	-----
1942 thru 48	All	heater and defroster—U/S heater.....	1	515740	(8.852)
1949 thru 54	All	TRUNNION , defroster air valve shaft outer lever—U/S heater.....	1	512452	-----
1953-54	All	air control rod—U/S heater.....	1	515331	-----
1942 thru 48	All	TUBE , defroster air inlet, steel—U/S heater.....	1	509177	-----
1942 thru 48	All	VALVE ASSEMBLY , car temperature control—U/S heater.....	1	510768	-----
1949 thru 52	All	U/S heater.....	1	514452	-----
1953-54	All	U/S heater.....	1	3128099	-----
1941 thru 48	All	WIRE , blower to switch—U/S heater..... L.H.	1	3114299	(9.792)
1941 thru 47	All	SCREW , defroster inlet—dash heater.....	4	187163	(8.977)
1948	All	(Bind. Hd. No. 6-20x $\frac{1}{4}$ ").....	4	3120880	(8.857)
1941 thru 48	All	defroster blower and adapter—U/S heater.....	8	126143	(8.977)
1951-52	All	(Bind. Hd. No. 6-18x $\frac{1}{4}$ ").....	1	140918	(8.866)
1951-52	All	air control shaft to defr.—U/S heater.....	1		
Group 9.782 ELBOW, AIR INTAKE					
1941	25 All	to dash—U/S heater.....	1	505993	-----
1941	26-29 All	to dash—U/S heater.....	1	505994	-----
1942 thru 54	All	air intake frame—U/S heater.....	1	510729	-----
1942 thru 48	All	blower to front tube.....	1	507288	-----
Group 9.784 SCREEN, AIR INLET					
1941	All	U/S heater.....	1	506022	-----
1942 thru 48	All	U/S heater.....	1	507472	-----
1942-46	All	BAFFLE , heater air intake—U/S heater.....	1	509232	-----
1941 thru 48	All	CLAMP , air inlet screen to tube—U/S heater..... (for 2 $\frac{1}{2}$ " I.D. hose)	1	3692864	(1.166)
Group 9.785 GASKET, AIR INTAKE					
1942 thru 48	All	COVER , air intake in fender skirt.....	1	507122	-----
1942 thru 48	All	in L.H. radiator baffle.....	1	507092	-----
1949 thru 54	All	in L.H. fender skirt baffle.....	1	507092	-----
1949 thru 54	All	NUT , air intake deflector to dash..... (Spring type)	6	511965	-----
1949	All	air control cable clip to dash.....	1	511965	-----
Group 9.786 HOSE, AIR INTAKE					
1949 thru 54	All	DEFLECTOR , air intake.....	2	511964	-----
1949 thru 54	All	TUBE , to dash connector..... (Rubber)	2	511966	-----

PONTIAC CHASSIS PARTS SECTION

YEAR	MODEL	PART NAME	Per Car	Part No.	Changes
Group 9.786 HOSE, AIR INTAKE (Continued)					
1940	All	U/S heater.....(39½" long)	1	3112961	-----
1941	All	elbow to tube—U/S heater....(2½" I.D. x 7½" long)	1	506009	-----
1941	25 All	elbow to defroster—U/S heater.....(2½" I.D. x 13¾" long)	1	506010	-----
1941	26-29 All	elbow to defroster—U/S heater.....(2½" I.D. x 15½" long)	1	506011	-----
1942 thru 48	All	rear intermediate—U/S heater.....(4¼" I.D. x 19" long)	1	510941	-----
1949 thru 52	All	heater rear air—U/S heater.....(4¼" I.D. x 13½" long)	1	511902	-----
1953-54	All	heater to blower—U/S heater.....	1	515423	-----
1949 thru 52	All	COVER , heater intake valve cont. rod—U/S heater.....	1	512338	-----
1949 thru 52	All	U/S heater.....Upper	1	512317	-----
1953-54	All	U/S heater.....Lower	1	515425	-----
1953-54	All	U/S heater.....Upper	1	515428	-----
1942 thru 48	All	U/S heater.....Lower	1	515428	-----
1942 thru 48	All	CLAMP , air intake-tube support—U/S heater.....	2	507461	-----
1942 thru 48	All	rear tube to body bracket—U/S heater.....	1	507462	-----
1949 thru 54	All	rear tube to body bracket—U/S heater.....	1	511901	-----
1942 thru 54	All	hose clamp type—U/S heater.....	3	513479	-----
1949 thru 54	All	FLANGE , air intake tube to air duct.....	1	512284	-----
1942 thru 48	All	SHIELD , air intake rear tube—U/S heater.....	1	507478	-----
1949 thru 52	All	car heater air hose—U/S heater.....	1	511903	-----
1953-54	All	heater air hose—U/S heater.....	1	515424	-----
1942 thru 54	All	SLEEVE , air intake elbow to heater—U/S heater.....	1	513389	-----
1941	All	TUBE , air intake (metal)—U/S heater.....	1	506006	-----
1942 thru 48	All	front (metal)—U/S heater.....	1	507289	-----
1942 thru 48	All	intermediate (metal)—U/S heater.....	1	507290	-----
1942 thru 48	All	rear (steel)—U/S heater.....	1	507831	-----
1949 thru 54	All	car heater rear air—U/S heater.....	1	511904	-----
1949 thru 52	All	heater air intake (complete)—U/S heater.....	1	512307	-----
1953-54	All	heater air intake (complete)—U/S heater.....	1	515427	-----
Group 9.787 CONTROL ASSEMBLY, AIR INLET					
1940	All	U/S heater.....	1	3113987	-----
1941	All	KNOB AND SHAFT , air inlet—U/S heater.....	1	3115051	-----
1949-50	All	includes knobs, bracket and rods.....	1	511963	-----
1951	All		1	514834	-----
1952	All		1	516499	-----
1953-54	All	R.H.	1	516923	-----
1953-54	All	L.H.	1	516924	-----
1949 thru 54	All	CLIP , control cable to body.....	2	511984	-----
1953-54	All	FERRULE , air intake control.....	2	516832	-----
Group 9.789 VALVE AND BODY ASSEMBLY, AIR VENTILATOR					
1949 thru 54	All	in right hand duct.....	1	511967	-----
1949 thru 54	All	in left hand duct.....	1	511968	-----
Group 9.792 WIRE ASSEMBLY					
		see Group 8.852 and Group 9.779 for use.....		3114299	-----
Group 9.802 DUCT ASSEMBLY, BODY AIR INTAKE					
1949 thru 54	All	R.H.	1	511722	-----
1949 thru 54	All	L.H.	1	511723	-----
1949 thru 54	All	SCREEN , body air intake.....	2	511793	-----

(8.077)